




---

# Service Manual

## S150 Skid-Steer Loader

---

S/N A8M0 60001 & Above



EQUIPPED WITH  
BOBCAT INTERLOCK  
CONTROL SYSTEM (BICS)



Printed in Europe.

**Thanks very much for your reading,  
Want to get more information,  
Please click here, Then get the complete  
manual**

**JustClickHere** 

**NOTE:**

**If there is no response to click on the link above,  
please download the PDF document first, and then  
click on it.**

**Have any questions please write to me:  
[admin@servicemanualperfect.com](mailto:admin@servicemanualperfect.com)**



# MAINTENANCE SAFETY



## WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



**Safety Alert Symbol:** This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.


### CORRECT



B-10731a

⚠ Never service the Bobcat Skid-Steer Loader without instructions.


### CORRECT



B-15590

⚠ Use the correct procedure to lift or lower operator cab.

### CORRECT



B-15591

⚠ Cleaning and maintenance are required daily.

### WRONG



B-15592

- ⚠ Have good ventilation when welding or grinding painted parts.
- ⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- ⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


### WRONG



B-15593

⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


### WRONG



B-15599

- ⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- ⚠ Never modify equipment or add attachments not approved by Bobcat Company.

### WRONG



B-15600

- ⚠ Stop, cool and clean engine of flammable materials before checking fluids.
- ⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.
- ⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- ⚠ Never fill fuel tank with engine running, while smoking or when near open flame.

### WRONG



B-15601

- ⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- ⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- ⚠ Keep rear door closed except for service. Close and latch door before operating the loader.

### WRONG



B-6589

- ⚠ Lead-acid batteries produce flammable and explosive gases.
- ⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
- ⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW08-0805



**Bobcat®**

## ALPHABETICAL INDEX

ACCESS PANEL (INSIDE).....	50-120	FUEL SYSTEM .....	10-100, 70-70
ACCESS PANEL (INSIDE) (SJC).....	50-121	FUEL TANK.....	50-80
AIR CLEANER .....	70-40		
AIR CLEANER SERVICE.....	10-80	HEATER COIL.....	80-50
ALTERNATOR.....	60-30	HEATER FAN .....	80-60
		HEATER SYSTEM .....	80-10
BACK-UP ALARM SYSTEM .....	60-210	HEATER UNIT.....	80-40
BATTERY .....	60-20	HEATER VALVE .....	80-70
BOBCAT CONTROLLER (ACS).....	60-71	HIGH FLOW VALVE .....	20-150
BOBCAT CONTROLLERS (GATEWAY AND AUXILIARY).....	60-70	HYDRAULIC CONNECTION SPECS .....	SPEC-30
BOBCAT CONTROLLER (SJC) (DRIVE).....	60-72	HYDRAULIC CONTROL VALVE (ACS) OR (SJC) ..	20-41
BOBCAT INTERLOCK CONTROL SYSTEM (BICS).....	60-100	HYDRAULIC CONTROL VALVE (STANDARD).....	20-40
BOB-TACH (HAND LEVER).....	10-140, 50-40	HYDRAULIC/HYDROSTATIC FILTERS .....	20-80
BOB-TACH (POWER) .....	10-141	HYDRAULIC FLUID RESERVOIR .....	20-90
BOB-TACH ([POWER-OPTION) .....	50-41	HYDRAULIC/HYDROSTATIC FLUID SPECIFICATIONS .....	SPEC-40
BOB-TACH (POWER) BLOCK .....	20-130	HYDRAULIC/HYDROSTATIC SYSTEM.....	10-120
BRAKE (SINGLE SPEED) .....	40-10	HYDRAULIC PUMP (STANDARD).....	20-60
BRAKE (TWO-SPEED).....	40-11	HYDRAULIC PUMP (STANDARD) (HIGH FLOW) ..	20-61
BUCKET POSITION VALVE.....	20-110	HYDRAULIC PUMP (SJC) .....	20-70
		HYDRAULIC PUMP (SJC) (HIGH FLOW) .....	20-71
CALIBRATION.....	60-160	HYDRAULIC SYSTEM INFORMATION .....	20-10
CAMSHAFT AND TIMING GEARS.....	70-100	HYDROSTATIC MOTOR .....	30-20
CASE DRAIN FILTER .....	30-80	HYDROSTATIC MOTOR (TWO SPEED) .....	30-21
CHAINCASE .....	40-30	HYDROSTATIC MOTOR CARRIER (SINGLE ANDTWO-SPEED WITH MANUAL CONTROLS) .....	30-30
CHARGE PRESSURE .....	30-40	HYDROSTATIC MOTOR CARRIER (SINGLE ANDTWO-SPEED WITH SJC CONTROLS) .....	30-31
CONTROL HANDLE/LEVER .....	50-110	HYDROSTATIC PUMP .....	30-50
CONTROL HANDLE/LEVER (ACS).....	50-111	HYDROSTATIC PUMP (SJC).....	30-51
CONTROL HANDLE/LEVER (SJC) .....	50-112	HYDROSTATIC SYSTEM INFORMATION.....	30-10
CONTROL PANEL .....	50-100		
CONTROL PANEL (SJC).....	50-101	INSTRUMENT PANELS .....	60-50
CONTROL PANEL SETUP .....	60-180		
CONTROL PEDALS (ACS).....	50-91	LIFT ARMS .....	50-50
CONTROL PEDALS AND LINKAGES .....	50-90	LIFT ARM BYPASS CONTROL VALVE .....	20-50
CONTROL SYSTEM (ACS) .....	60-130	LIFT ARM SUPPORT DEVICE .....	10-20
CONVERSIONS.....	SPEC-50	LIFTING AND BLOCKING THE LOADER .....	10-10
CRANKSHAFT AND PISTONS .....	70-90	LIGHTS .....	60-60
CYLINDER (BOB-TACH).....	20-22	LOADER SPECIFICATIONS.....	SPEC-10
CYLINDER (LIFT) .....	20-20	LOADER STORAGE & RETURN TO SERVICE ...	10-190
CYLINDER (TILT).....	20-21	LUBRICATING THE LOADER.....	10-150
CYLINDER HEAD .....	70-80	LUBRICATION SYSTEM.....	70-60
DIAGNOSTICS SERVICE CODES .....	60-90	MAIN RELIEF VALVE.....	20-30
DRIVE BELT.....	30-60	MAINTENANCE CLOCK.....	60-200
DRIVE COMPONENTS .....	40-20	MUFFLER .....	70-30
ELECTRICAL/HYD. CONTROLS.....	60-140	OIL COOLER .....	20-100
ELECTRICAL/HYD. CONTROLS (SJC).....	60-141	OPERATOR CAB .....	10-30, 50-20
ELECTRICAL SYSTEM INFORMATION .....	60-10	OPERATOR SEAT.....	50-30
ENGINE COOLING SYSTEM .....	10-90, 70-50	OPERATOR SEAT (SUSPENSION).....	50-31
ENGINE LUBRICATION SYSTEM .....	10-110		
ENGINE INFORMATION.....	70-10	PASSWORD SETUP .....	60-190
ENGINE SPEED CONTROL.....	70-20	PIVOT PINS .....	10-180
ENGINE SPEED CONTROL (SJC).....	70-21		
FINAL DRIVE TRANSMISSION (CHAINCASE) ...	10-130		
FLYWHEEL AND HOUSING.....	70-110		
FLYWHEEL RPM SENSOR .....	60-170		
FRONT AUXILIARY HYDRAULIC COUPLER BLOCK.....	20-140		

## ALPHABETICAL INDEX (CONT'D)

REAR AUXILIARY DIVERTER VALVE .....	20-120
REAR DOOR .....	50-70
REAR GRILL .....	50-60
REGULAR MAINTENANCE .....	80-20
REMOTE START TOOL KIT-MEL1563 .....	10-60
REMOTE START TOOL (SERVICE TOOL) - KIT - 6689779 .....	10-61
SEAT BAR .....	50-10
SEAT BAR SENSOR .....	60-110
SERVICE PC (LAPTOP COMPUTER) .....	60-150
SERVICE SCHEDULE.....	10-70
SPARK ARRESTOR MUFFLER .....	10-170
SPEED SENSORS (SJC).....	60-80
STARTER.....	60-40
STEERING DRIFT COMPENSATION .....	60-161
STOPPING THE ENGINE AND LEAVING THE LOADER.....	10-200
TIRE MAINTENANCE .....	10-160
TORQUE SPECIFICATIONS FOR BOLTS .....	SPEC-20
TOWING THE LOADER .....	10-50
TRACTION LOCK.....	60-120
TRANSPORTING THE LOADER ON A TRAILER ..	10-40
TROUBLESHOOTING .....	80-30
TWO-SPEED VALVE .....	30-70
WINDOW (FRONT DOOR).....	50-133
WINDOW (REAR).....	50-130
WINDOW (SIDE) .....	50-132
WINDOW (TOP) .....	50-131

## CONTENTS

FOREWORD .....	II
SAFETY INSTRUCTIONS .....	V
FIRE PREVENTION .....	VII
SERIAL NUMBER LOCATIONS .....	IX
DELIVERY REPORT .....	X
BOBCAT LOADER IDENTIFICATION .....	XI
SAFETY AND MAINTENANCE .....	10-01
HYDRAULIC SYSTEM .....	20-01
HYDROSTATIC SYSTEM .....	30-01
DRIVE SYSTEM .....	40-01
MAIN FRAME .....	50-01
ELECTRICAL SYSTEM & ANALYSIS .....	60-01
ENGINE SERVICE .....	70-01
HEATER .....	80-01
SPECIFICATIONS .....	SPEC-01

**SAFETY &  
MAINTENANCE**

**HYDRAULIC  
SYSTEM**

**HYDROSTATIC  
SYSTEM**

**DRIVE  
SYSTEM**

**MAIN FRAME**

**ELECTRICAL  
SYSTEM &  
ANALYSIS**

**ENGINE  
SERVICE**

**HVAC**

**SPECIFICATIONS**




# FOREWORD

This manual is for the Bobcat loader mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, Starting procedure, daily checks, etc.

A general inspection of the following items must be made after the loader has had service or repair:


1. Check that the ROPS/FOPS (Including side screens) is in good condition and is not modified.




2. Check that ROPS mounting hardware is tightened and is Bobcat approved.




3. The seat belt must be correctly installed, functional and in good condition.



4. The seat bar must be correctly adjusted, clean and lubricated.




5. Check lift arm support device, replace if damaged.



6. Machine signs must be legible and in the correct location.



7. Steering levers and foot pedals must return to neutral.



8. Check for correct function of the work lights




9. The parking brake must function correctly.




10. Enclosure door latches must open and close freely.




11. Bob-Tach wedges and linkages must function correctly and be in good condition.



12. Safety treads must be in good condition.




13. Check for correct function of indicator lamps (Optional on some models).



14. Check hydraulic fluid level, engine oil level and fuel supply.




15. Inspect for fuel, oil or hydraulic fluid leaks.




16. Lubricate the loader.




17. Check the condition of the battery and cables.



22. Operate the loader and check all functions.




18. Inspect the air cleaner for damage or leaks. Check the condition of the element.




23. Check for any field modification not completed.




19. Check the electrical charging system.




24. Check for correct function of the Bobcat Interlock Control System (BICS) before the machine is returned to the customer.



20. Check tires for wear and pressure.



25. Recommend to the owner that all necessary corrections be made before the machine is returned to service.



21. Inspect for loose or broken parts or connections.





**Bobcat®**

## SAFETY INSTRUCTIONS



### Safety Alert Symbol

This symbol with a warning statement means:  
"Warning, be alert! Your safety is involved!"  
Carefully read the message that follows.



## WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



## WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

## IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Skid-Steer Loader Operator Training Course is available through your local dealer or at **[www.training.bobcat.com](http://www.training.bobcat.com)** or **[www.bobcat.com](http://www.bobcat.com)**. This course is intended to provide rules and practices of correct operation of the Skid-Steer Loader. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at **[www.training.bobcat.com](http://www.training.bobcat.com)** or **[www.bobcat.com](http://www.bobcat.com)**. They provide information for safe and correct service procedures.
- The Skid-Steer Loader Safety Video is available from your Bobcat dealer or at **[www.training.bobcat.com](http://www.training.bobcat.com)** or **[www.bobcat.com](http://www.bobcat.com)**.

SI SSL-1007 SM

## SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

SI SSL-1007 SM

## FIRE PREVENTION



### Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

### Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

### Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

## Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

### Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

### Starting

Do not use ether or starting fluids on any engine that has glow plugs. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

SI SSL-1007 SM

## **FIRE PREVENTION (CONT'D)**

### **Welding And Grinding**

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

### **Fire Extinguishers**




Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

SI SSL-1007 SM

## SERIAL NUMBER LOCATIONS

Always use the serial number of the loader when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.


**Figure 1**



### Loader Serial Number

The loader serial number plate is located on the outside of the loader frame [Figure 1].

Explanation of loader Serial Number:




1. The four digit Model/Engine Combination Module number identifies the model number and engine combination.

2. The five digit Production Sequence Number identifies the order which the loader is produced.

## Engine Serial Number

**Figure 2**



The engine serial number is located on the side of the engine [Figure 2].





DELIVERY REPORT

Figure 3

The diagram shows a 'DELIVERY REPORT' form. It has a header 'DELIVERY REPORT' at the top right. The form is divided into sections: a 'WARNING' section on the left, and several text areas on the right and bottom. A small box with 'B-16315' is located at the bottom right of the form area.

The delivery report must be filled out by the dealer and signed by the owner or operator when the Bobcat loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely **[Figure 3]**.

## BOBCAT LOADER IDENTIFICATION



◆ Optional or Field Accessory (Not Standard Equipment)

\* TIRES - Tires shown may not be standard. The machine is factory equipped with standard tires. Other tires are available.

† Bucket - Several different buckets and other attachments are available for this machine.

● ROPS, FOPS - Roll Over Protective Structure, per SAE / ISO 3471, and Falling Object Protective Structure per ISO 3449, Level I. Level II is available.



**Bobcat®**