




Service Manual

S175 Skid-Steer Loader

S/N A8M460001 & Above



EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS)



Printed in Europe.

MAINTENANCE SAFETY



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT



B-10731a

⚠ Never service the Bobcat Skid-Steer Loader without instructions.

CORRECT



B-15535

⚠ Use the correct procedure to lift or lower operator cab.

CORRECT



B-15524

⚠ Cleaning and maintenance are required daily.

WRONG



B-15734

- ⚠ Have good ventilation when welding or grinding painted parts.
- ⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- ⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.

WRONG



B-15732

⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


WRONG



B-15525

- ⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- ⚠ Never modify equipment or add attachments not approved by Bobcat Company.

WRONG



B-15733

- ⚠ Stop, cool and clean engine of flammable materials before checking fluids.
- ⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.
- ⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- ⚠ Never fill fuel tank with engine running, while smoking or when near open flame.

WRONG



B-15523

- ⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- ⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- ⚠ Keep rear door closed except for service. Close and latch door before operating the loader.

WRONG



B-6589

- ⚠ Lead-acid batteries produce flammable and explosive gases.
- ⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
- ⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW07-0805

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**



Bobcat®

ALPHABETICAL INDEX

ACCESS PANEL (INSIDE).....	50-120	HEATER COIL.....	80-50
ACCESS PANEL (INSIDE) (SJC).....	50-121	HEATER FAN	80-60
AIR CLEANER	70-40	HEATER SYSTEM	80-10
AIR CLEANER SERVICE.....	10-80	HEATER UNIT.....	80-40
ALTERNATOR	60-30	HEATER VALVE	80-70
BACK-UP ALARM SYSTEM	60-210	HIGH FLOW VALVE	20-150
BATTERY	60-20	HYDRAULIC CONNECTION SPECS.	SPEC-30
BOBCAT CONTROLLER (ACS).....	60-71	HYDRAULIC CONTROL VALVE (ACS) OR (SJC) ..	20-41
BOBCAT CONTROLLERS		HYDRAULIC CONTROL VALVE (STANDARD).....	20-40
(GATEWAY AND AUXILIARY).....	60-70	HYD./HYDRO FLUID SPECIFICATIONS	SPEC-40
BOBCAT CONTROLLER (SJC) (DRIVE).....	60-72	HYDRAULIC FLUID RESERVOIR	20-90
BOBCAT INTERLOCK CONTROL		HYDRAULIC/HYDROSTATIC FILTERS	20-80
SYSTEM (BICS).....	60-100	HYDRAULIC/HYDROSTATIC SYSTEM.....	10-120
BOB-TACH (HAND LEVER).....	10-140, 50-40	HYDRAULIC PUMP (SJC)	20-70
BOB-TACH (POWER)	10-141, 50-41	HYDRAULIC PUMP (SJC) (HIGH FLOW)	20-71
BRAKE (SINGLE SPEED)	40-10	HYDRAULIC PUMP (STANDARD).....	20-60
BRAKE (TWO-SPEED).....	40-11	HYDRAULIC PUMP (STANDARD) (HIGH FLOW) ..	20-61
BUCKET POSITION VALVE.....	20-110	HYDRAULIC SYSTEM INFORMATION	20-10
CALIBRATION.....	60-160	HYDROSTATIC MOTOR	30-20
CAMSHAFT AND TIMING GEARS.....	70-100	HYDROSTATIC MOTOR CARRIER	
CASE DRAIN FILTER	30-80	(SINGLE AND TWO-SPEED WITH	
CHAINCASE	40-30	MANUAL CONTROLS)	30-30
CHARGE PRESSURE	30-40	HYDROSTATIC MOTOR CARRIER	
CONTROL HANDLE/LEVER	50-110	(SINGLE AND TWO-SPEED WITH	
CONTROL HANDLE/LEVER (ACS).....	50-111	SJC CONTROLS)	30-31
CONTROL HANDLE/LEVER (SJC).....	50-112	HYDROSTATIC MOTOR (TWO SPEED)	30-21
CONTROL PANEL	50-100	HYDROSTATIC PUMP	30-50
CONTROL PANEL SETUP	60-180	HYDROSTATIC PUMP (SJC).....	30-51
CONTROL PANEL (SJC).....	50-101	HYDROSTATIC SYSTEM INFORMATION.....	30-10
CONTROL PEDALS AND LINKAGES	50-100	INSTRUMENT PANELS	60-50
CONTROL PEDALS (ACS).....	50-91	LIFT ARM BYPASS CONTROL VALVE	20-50
CONTROL SYSTEM (ACS)	60-130	LIFT ARMS	50-50
CONVERSIONS.....	SPEC-50	LIFT ARM SUPPORT DEVICE	10-20
CRANKSHAFT AND PISTONS.....	70-90	LIFTING AND BLOCKING THE LOADER	10-10
CYLINDER (BOB-TACH).....	20-22	LIGHTS	60-60
CYLINDER HEAD	70-80	LOADER SPECIFICATIONS.....	SPEC-10
CYLINDER (LIFT)	20-20	LOADER STORAGE & RETURN TO SERVICE ...	10-190
CYLINDER (TILT).....	20-21	LUBRICATING THE LOADER.....	10-150
DIAGNOSTIC SERVICE CODES.....	60-90	LUBRICATION SYSTEM.....	70-60
DRIVE BELT.....	30-60	MAIN RELIEF VALVE.....	20-30
DRIVE COMPONENTS	40-20	MAINTENANCE CLOCK.....	60-200
ELECTRICAL/HYRAULIC CONTROLS	60-140	MUFFLER	70-30
ELECTRICAL/HYRAULIC CONTROLS (SJC).....	60-141	OIL COOLER	20-100
ELECTRICAL SYSTEM INFORMATION	60-10	OPERATOR CAB	10-30, 50-20
ENGINE COOLING SYSTEM	10-90, 70-50	OPERATOR SEAT	50-30
ENGINE INFORMATION.....	70-10	OPERATOR SEAT (SUSPENSION).....	50-31
ENGINE LUBRICATION SYSTEM.....	10-110	PASSWORD SETUP	60-190
ENGINE SPEED CONTROL.....	70-20	PIVOT PINS	10-180
ENGINE SPEED CONTROL (SJC).....	70-21	POWER BOB-TACH BLOCK.....	20-130
FINAL DRIVE TRANSMISSION (CHAINCASE) ...	10-130		
FLYWHEEL AND HOUSING	70-110		
FLYWHEEL RPM SENSOR	60-170		
FRONT AUXILIARY HYD. COUPLER BLOCK.....	20-140		
FUEL SYSTEM	10-100, 70-70		
FUEL TANK.....	50-80		

ALPHABETICAL INDEX (CONT'D)

REAR AUXILIARY DIVERTER VALVE	20-120
REAR DOOR.....	50-70
REAR GRILL	50-100
REGULAR MAINTENANCE.....	80-20
REMOTE START TOOL KIT-MEL1563	10-60
REMOTE START TOOL (SERVICE TOOL) KIT-6689779	10-61
SEAT BAR	50-10
SEAT BAR SENSOR.....	60-110
SERVICE PC (LAPTOP COMPUTER).....	60-150
SERVICE SCHEDULE	10-70
SPARK ARRESTOR MUFFLER.....	10-170
SPEED SENSORS (SJC)	60-80
STARTER	60-40
STEERING DRIFT COMPENSATION.....	60-161
STOPPING THE ENGINE AND LEAVING THE LOADER	10-200
TIRE MAINTENANCE	10-160
TORQUE SPECIFICATIONS FOR BOLTS.....	SPEC-20
TOWING THE LOADER.....	10-50
TRACTION LOCK	60-120
TRANSPORTING LOADER ON A TRAILER	10-40
TROUBLESHOOTING	80-30
TWO-SPEED VALVE.....	30-70
WINDOW (FRONT DOOR)	50-133
WINDOW (REAR)	50-130
WINDOW (SIDE).....	50-132
WINDOW (TOP).....	50-131

CONTENTS

FOREWORD	II
SAFETY INSTRUCTIONS	V
FIRE PREVENTION	VII
SERIAL NUMBER LOCATIONS	IX
DELIVERY REPORT	X
LOADER IDENTIFICATION	XI
SAFETY AND MAINTENANCE	10-01
HYDRAULIC SYSTEM	20-01
HYDROSTATIC SYSTEM	30-01
DRIVE SYSTEM	40-01
MAIN FRAME	50-01
ELECTRICAL SYSTEM & ANALYSIS	60-01
ENGINE SERVICE	70-01
HEATER	80-01
SPECIFICATIONS	SPEC-01

**SAFETY &
MAINTENANCE**

**HYDRAULIC
SYSTEM**

**HYDROSTATIC
SYSTEM**

**DRIVE
SYSTEM**

MAIN FRAME

**ELECTRICAL
SYSTEM &
ANALYSIS**

**ENGINE
SERVICE**

HVAC


SPECIFICATION

FOREWORD

This manual is for the Bobcat loader mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, Starting procedure, daily checks, etc.

A general inspection of the following items must be made after the loader has had service or repair:

1. Check lift arm support device, replace if damaged. (Stored Position)




2. Check that ROPS mounting hardware is tightened and is Bobcat approved.




3. The seat belt must be correctly installed, functional and in good condition.



4. The seat bar must be correctly adjusted, clean and lubricated.




5. Check lift arm support device; replace if damaged.



6. Machine signs must be legible and in the correct location.



7. Steering levers and foot pedals must return to neutral.



8. Check for correct function of the work lights



9. The parking brake must function correctly.



10. Enclosure door latches must open and close freely.




11. Bob-Tach wedges and linkages must function correctly and be in good condition.




12. Safety treads must be in good condition.



13. Check for correct function of indicator lamps (Optional on some models).



14. Check hydraulic fluid level, engine oil level and fuel supply.




15. Inspect for fuel, oil or hydraulic fluid leaks.




16. Lubricate the loader.



17. Check the condition of the battery and cables.



22. Operate the loader and check all functions.



18. Inspect the air cleaner for damage or leaks. Check the condition of the element.




23. Check for any field modification not completed.




19. Check the electrical charging system.



24. Check for correct function of the Bobcat Interlock Control System (BICS™) before the machine is returned to the customer.




20. Check tires for wear and pressure.



Recommend to the owner that all necessary corrections be made before the machine is returned to service.



21. Inspect for loose or broken parts or connections.





SAFETY INSTRUCTIONS



Safety Alert Symbol

This symbol with a warning statement means:
"Warning, be alert! Your safety is involved!"
Carefully read the message that follows.



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Skid-Steer Loader Operator Training Course is available through your local dealer or at **www.training.bobcat.com** or **www.bobcat.com**. This course is intended to provide rules and practices of correct operation of the Skid-Steer Loader. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at **www.training.bobcat.com** or **www.bobcat.com**. They provide information for safe and correct service procedures.
- The Skid-Steer Loader Safety Video is available from your Bobcat dealer or at **www.training.bobcat.com** or **www.bobcat.com**.

SI SSL-1007 SM

SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

SI SSL-1007 SM

FIRE PREVENTION



Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

Starting

Do not use ether or starting fluids on any engine that has glow plugs. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

Spark Arrestor Exhaust System

The spark arrestor exhaust system is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrestor exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

SI SSL-1007 SM

FIRE PREVENTION (CONT'D)


Welding And Grinding

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

Fire Extinguishers



Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.


SI SSL-1007 SM

SERIAL NUMBER LOCATIONS

Always use the serial number of the loader when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

Loader Serial Number

Figure 1



The loader serial number plate is located on the outside of the loader frame [Figure 1].


Explanation of loader Serial Number:

XXXX	XXXXX
Model 1.-Model/ Engine Combination	Model 2.-Production Sequence (Series)

1. The four digit Model/Engine Combination Module number identifies the model number and engine combination.
2. The five digit Production Sequence Number identifies the order which the loader is produced.

Engine Serial Number

Figure 2



The engine serial number is in the location shown [Figure 2].

Dealer Conv -- Not for Resale


DELIVERY REPORT

Figure 3

The diagram shows a 'DELIVERY REPORT' form. It includes a header section with fields for 'Date', 'Time', 'Location', 'Operator', and 'Dealer'. Below this is a 'WARNING' section with multiple lines of text. To the right of the 'WARNING' section is another large section with multiple lines of text. At the bottom left is a section with fields for 'Signature', 'Name', and 'Title'. At the bottom right is a small box labeled 'B-16315'.

The Delivery Report must be filled out by the dealer and signed by the owner or operator when the Bobcat loader is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely [Figure 3].

LOADER IDENTIFICATION



◆ OPTIONAL OR FIELD ACCESSORY (Not Standard Equipment)

* TIRES - The Bobcat loader is factory equipped with heavy duty flotation tires. See Specifications Section and your Bobcat dealer for available tires.

† BUCKET - Several different buckets and other attachments are available for the Bobcat loader.

● ROPS, FOPS - Roll Over Protective Structure, per SAE J1040 and ISO 3471, and Falling Object Protective Structure per SAEJ1043 and ISO 3449, Level I. Level II is available. The Bobcat loader is base-equipped with a standard operator cab as shown. Extra insulated cab is available as an option (Reduced noise level).



Bobcat®