


463



Bobcat®

Service Manual

S/N 522211001 & Above
S/N 522111001 & Above



**EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)**

IR Ingersoll Rand
Compact Vehicle Technologies
Printed in U.S.A.

MAINTENANCE SAFETY




WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.


W-2003-0903




Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




Never service the Bobcat Skid-Steer Loader without instructions.




Use the correct procedure to lift or lower operator cab.




Cleaning and maintenance are required daily.




- Have good ventilation when welding or grinding painted parts.
- Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.




Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.



- Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- Never modify equipment or add attachments not approved by Bobcat Company.



- Stop, cool and clean engine of flammable materials before checking fluids.
- Never service or adjust loader with the engine running unless instructed to do so in the manual.
- Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- Never fill fuel tank with engine running, while smoking or when near open flame.



- Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- Keep rear door closed except for service. Close and latch door before operating the loader.



- Lead-acid batteries produce flammable and explosive gases.
- Keep arcs, sparks, flames and lighted tobacco away from batteries.
- Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MAINTENANCE SAFETY



WARNING


Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.


CORRECT



B-10731a

- ⚠ Never service the Bobcat Skid-Steer Loader without instructions.


CORRECT



B-12365

- ⚠ Use the correct procedure to lift or lower operator cab.


CORRECT



B-7469

- ⚠ Cleaning and maintenance are required daily.


WRONG



B-11799

- ⚠ Have good ventilation when welding or grinding painted parts.
- ⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.
- ⚠ Avoid exhaust fume leaks which can kill without warning. Exhaust system must be tightly sealed.


WRONG



B-15231

- ⚠ Disconnecting or loosening any hydraulic tubeline, hose, fitting, component or a part failure can cause lift arms to drop. Do not go under lift arms when raised unless supported by an approved lift arm support device. Replace it if damaged.


WRONG



B-15280

- ⚠ Never work on loader with lift arms up unless lift arms are held by an approved lift arm support device. Replace if damaged.
- ⚠ Never modify equipment or add attachments not approved by Bobcat Company.


WRONG



B-6590

- ⚠ Stop, cool and clean engine of flammable materials before checking fluids.
- ⚠ Never service or adjust loader with the engine running unless instructed to do so in the manual.
- ⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- ⚠ Never fill fuel tank with engine running, while smoking or when near open flame.

WRONG



B-6580

- ⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- ⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protection approved for type of welding.
- ⚠ Keep rear door closed except for service. Close and latch door before operating the loader.

WRONG



B-6589

- ⚠ Lead-acid batteries produce flammable and explosive gases.
- ⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
- ⚠ Batteries contain acid which burns eyes or skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.



Bobcat®

ALPHABETICAL INDEX

| | | | |
|--|--------------|---------------------------------------|--------------|
| AIR CLEANER | 70-01 | HYDRAULIC FLUID SPECIFICATIONS | SPEC-01 |
| AIR CLEANER SERVICE | 10-01 | HYDRAULIC PUMP | 20-01 |
| ALTERNATOR | 60-01 | HYDRAULIC RESERVOIR | 20-01 |
| AUXILIARY CONTROL LOCKBOLT | 10-01 | HYDRAULIC SYSTEM INFORMATION | 20-01 |
| | | HYDRAULIC/HYDROSTATIC SYSTEM | 10-01 |
| BASCI TROUBLESHOOTING | 80-01 | HYDROSTATIC MOTOR | 30-01 |
| BATTERY | 60-01 | HYDROSTATIC PUMP | 30-01 |
| BICS™ SYSTEM (WITH PRESS TO OPERATE BUTTON) | 60-01 | HYDROSTATIC SYSTEM INFORMATION | 30-01 |
| BICS™ SYSTEM CONTROLLER | 60-01 | | |
| | | INSTRUMENT PANEL | 60-01 |
| BOB-TACH | 10-01, 50-01 | | |
| | | LIFT ARMS | 50-01 |
| CHAINCASE | 40-01 | LIFT ARM BY-PASS VALVE | 20-01 |
| CHARGE PRESSURE | 30-01 | LIFT ARM SUPPORT DEVICE | 10-01 |
| COMPONENTS | 80-01 | LIFTING AND BLOCKING THE LOADER | 10-01 |
| CONTROLS | 20-01 | LIGHTS | 60-01 |
| CONTROL PANEL | 30-01 | LOADER SPECIFICATIONS | SPEC-01 |
| CONVERSIONS | SPEC-01 | LUBRICATING THE BOBCAT | 10-01 |
| COOLING FAN | 70-01 | | |
| CYLINDER(S) | 20-01 | | |
| | | MAIN RELIEF VALVE | 20-01 |
| DRIVE BELT | 30-01 | MUFFLER | 70-01 |
| DRIVE COMPONENTS | 40-01 | | |
| | | OPERATOR CAB | 10-01, 50-01 |
| ELECTRICAL SYSTEM INFORMATION | 60-01 | OPERATOR SEAT | 50-01 |
| ENGINE | 70-01 | | |
| ENGINE COMPONENTS AND TESTING | 70-01 | PARKING BRAKE | 40-01 |
| ENGINE COOLING SYSTEM | 10-01 | PIVOT PINS | 10-01 |
| ENGINE LUBRICATION SYSTEM | 10-01 | | |
| ENGINE MOUNTING BRACKET | 70-01 | RADIATOR | 70-01 |
| ENGINE SPECIFICATIONS | SPEC-01 | REAR AXULIARY DIVERTER | 20-01 |
| ENGINE SPEED CONTROL | 70-01 | REAR DOOR | 50-01 |
| | | REAR WINDOW | 50-01 |
| FAN | 70-01 | RECONDITIONING THE ENGINE | 70-01 |
| FINAL DRIVE TRANSMISSION (CHAINCASE) | 10-01 | REGULAR MAINTENANCE | 80-01 |
| FLYWHEEL | 70-01 | REMOTE START SWITCH | 10-01 |
| FUEL SYSTEM | 10-01 | | |
| FUEL TANK | 50-01 | SEAT BAR RESTRAINT SYSTEM | 10-01 |
| | | SEAT BAR | 50-01 |
| HEATER UNIT | 80-01 | SEAT BAR SENSOR | 60-01 |
| HEATER COIL | 80-01 | SERVICE SCHEDULE | 10-01 |
| HEATER FAN | 80-01 | SPARK ARRESTOR MUFFLER | 10-01 |
| HEATER VALVE | 80-01 | STARTER | 60-01 |
| HYDRAULIC CONNECTION SPECS | SPEC-01 | STEERING | 30-01 |
| HYDRAULIC CONTROL VALVE | 20-01 | SYSTEM TROUBLESHOOTING CHART | 80-01 |
| HYDRAULIC FILTER | 20-01 | | |
| | | TIRE MAINTENANCE | 10-01 |
| | | TORQUE SPECIFICATIONS FOR BOLTS ... | SPEC-01 |
| | | TOWING THE LOADER | 10-01 |
| | | TRACTION LOCK | 60-01 |
| | | TRANSPORTING THE LOADER | 10-01 |
| | | TROUBLESHOOTING | 70-01 |



Bobcat®

CONTENTS

| | |
|------------------------------------|---------|
| FOREWORD..... | II |
| SAFETY INSTRUCTIONS | V |
| SERIAL NUMBER LOCATIONS | IX |
| DELIVERY REPORT..... | IX |
| BOBCAT LOADER IDENTIFICATION | X |
| SAFETY AND MAINTENANCE..... | 10-01 |
| HYDRAULIC SYSTEM | 20-01 |
| HYDROSTATIC SYSTEM..... | 30-01 |
| DRIVE SYSTEM | 40-01 |
| MAIN FRAME | 50-01 |
| ELECTRICAL SYSTEM & ANALYSIS | 60-01 |
| ENGINE SERVICE | 70-01 |
| SPECIFICATIONS | SPEC-01 |

**SAFETY AND
MAINTENANCE**

**HYDRAULIC
SYSTEM**

**HYDROSTATIC
SYSTEM**

**DRIVE
SYSTEM**

**MAIN
FRAME**

**ELECTRICAL
SYSTEM AND
ANALYSIS**

**ENGINE
SERVICE**


SPECIFICATIONS

FOREWORD

This manual is for the Bobcat loader excavator mechanic. It provides necessary servicing and adjustment procedures for the Bobcat loader and its component parts and systems. Refer to the for operating instructions, starting procedure, daily checks, etc.

A general inspection of the following items must be made after the loader has had service or repair:

1. Check that the ROPS/FOPS (Including side screens) is in good condition and is not modified.




9. The parking brake must function correctly.




2. Check that ROPS mounting hardware is tightened and is Melroe approved.




10. Enclosure door latches must open and close freely.




3. The seat belt must be correctly installed, functional and in good condition.




11. Bob-Tach wedges and linkages must function correctly and be in good condition.




4. The seat bar and pedal interlocks must be correctly adjusted, clean and lubricated.




12. Safety treads must be in good condition.



5. Check lift arm support device, replace if damaged.




13. Check for correct function of indicator lamps (Optional on some models).




6. Machine signs must be legible and in the correct location.




14. Check hydraulic fluid level, engine oil level and fuel supply.



7. Steering levers and foot pedals must return to neutral.



15. Inspect for fuel, oil or hydraulic fluid leaks.




8. Check for correct function of the work lights.




16. Lubricate the loader.




17. Check the condition of the battery and cables.



22. Operate the loader and check all functions.




18. Inspect the air cleaner for damage or leaks. Check the condition of the element.




23. Check for any field modification not completed.




19. Check the electrical charging system.




24. Check for correct function of the Bobcat Interlock Control System (BICST™) before the machine is returned to the customer.




20. Check tires for wear and pressure.



Recommend to the owner that all necessary corrections be made before the machine is returned to service.



21. Inspect for loose or broken parts or connections.



**CALIFORNIA
PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.



Bobcat®

SAFETY INSTRUCTIONS



Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903



WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Skid-Steer Loader Operator Training Course is available through your local dealer or at www.training.bobcat.com or www.bobcat.com. This course is intended to provide rules and practices of correct operation of the Skid-Steer Loader. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com. They provide information for safe and correct service procedures.
- The Skid-Steer Loader Safety Video is available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com.

SI SSL-0206 SM

SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner/operator review the recommended uses of the product when delivered. If the owner/operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Call Before You Dig

1-888-258-0808

When you call, you will be directed to a location in your state/city for information about buried lines (telephone, cable TV, water, sewer, gas, etc.)

SAFETY INSTRUCTIONS (CONT'D)

Fire Prevention

The machine and attachments have components that are at high temperature under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.


Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it will increase fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential hazard.

The spark arrestor muffler is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

- Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.
- The operator cab, engine compartment, and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazard and overheating.
- Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part.
- Check fuel and hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Tighten or replace any parts that show leakage. Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.
- Do not use ether or starting fluids on any engine which has glow plugs. These starting aids can cause explosion and injure you or bystanders.
- Always clean the machine, disconnect the battery, and disconnect the wiring from the controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding. Have good ventilation when grinding or welding painted parts. Wear a dust mask when grinding painted parts. Toxic dust or gas can be produced.
- Stop the engine and let it cool before adding fuel. **NO SMOKING!**

- Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.
- Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

Figure 1



- Know where fire extinguishers and first aid kits are located and how to use them. Fire extinguishers are available from your Bobcat dealer [Figure 1].



Bobcat®

Dear

**Thanks very much for your visiting and
patience.**

Want to get more information,

Please click here, Go back to the page.

**After your payment, you will have instant access to
your download.**

The Download Link will also be sent to your e-mail.

You will get the complete manual

Have any questions

please write to me

admin@servicemanualperfect.com