

1187/1187B FELLER BUNCHER TABLE OF CONTENTS

DIVISION/SECTION	SECTION NO.	FORM NO.
1 GENERAL		
Safety Rules, Service Manual Introduction, and		
Torque Specifications	1001	8-42210
Maintenance and Lubrication	1002	8-42211
General Engine Specifications (Case Engine)	1010	8-25770
General Cleaning Instructions	1055	8-38240
Detailed Engine Specifications (Case Engine)	1320	8-20040
2 ENGINE		
Engine Removal and Installation	2000	8-42210
Engine Accessories (Air Cleaner, Ether Injection System,		
Turbocharger, Mufflers)	2001	8-42210
Engine Tune-Up	2002	9-76379
Cylinder Head, Valve Train, and Camshaft	2015	8-22560
Cylinder Block, Sleeves, Pistons, and Rods	2025	9-76176
Crankshaft, Main Bearings, Flywheel, and Oil Seal		
Replacement	2035	9-76187
Lubrication System	2046	8-22780
Pump Drive Plate	2053	8-42210
Cooling System	2055	9-76337
Engine Troubleshooting	2201	8-20110
Reconditioning Large Bore Case Engine Blocks	2290	8-21170
Detroit Diesel Engine Manual - Series 71		6-SE-250
3 FUEL SYSTEM		
Fuel Lines, Fuel Tank, and Engine Controls	3001	8-42210
Fuel System and Filters	3010	9-75297
Robert Bosch Fuel Injection Pumps	3012	9-74937
Roosa Master Fuel Injectors	3213	8-20240
4 ELECTRICAL		
Electrical System Specifications and Troubleshooting	4002	8-42211
Wiring Diagrams and Sealed Connector Repair	4003	8-42211
Battery	4005	8-44360
Starter	4006	8-41430
Alternator	4007	8-42680
5 TRACK AND SUSPENSION		
Troubleshooting	5502	8-38240
Track Chain and Shoes, 1187	5503	8-42211
Track Chain and Shoes, 1187B	5504	8-42210
Track Rollers, Carriers, Idler, and Sprocket	5506	8-42211
6 POWER TRAIN		
Troubleshooting	6302	8-38240
Drive Motor Circuit and Lines	6311	8-42210
Drive Motor	6312	8-42210
Final Drive Transmission - 1187	6317	8-42201
Final Drive Transmission - 1187B	6318	8-42201

7 BRAKES

Swing Brake	7011	8-42210
Track Brake	7012	8-42210

8 HYDRAULICS

Maintenance and Service	8201	8-42210
Hydraulic System Specifications, Schematics, Troubleshooting, and Pressure Checks	8202	8-42211
Hydraulic Pump	8205	8-42210
Control Valves	8207	8-42210
Swing Hydraulic Circuit, Swing Motor, and Swing Relief Valve	8210	8-42210
Boom Hydraulic Circuit	8211	8-42210
Dipper Hydraulic Circuit	8212	8-42210
Rotary Cutter or Tree Shear Hydraulic Circuit	8213	8-42210
Leveler Hydraulic Circuit	8215	8-42211
Hydraulic Swivel	8218	8-42681
Pilot Control System	8220	8-42210
Cylinders	8290	8-42210

9 MOUNTED EQUIPMENT

Troubleshooting the Swing Mechanism	9202	8-42210
Swing Gearbox	9210	8-42680
Boom and Dipper	9211	8-42210
Tree Shear	9212	8-42210
Rotary Cutter	9213	8-42210
Leveler	9215	8-42210
Turntable Bearing	9216	8-42210
Decals, Painting, and Noise Control	9221	8-42211

1001

SAFETY RULES SERVICE MANUAL INTRODUCTION AND TORQUE SPECIFICATIONS

TABLE OF CONTENTS

Safety Rules	1001-2
Service Manual Introduction	1001-4
Torque Specifications - U.S. Hardware	1001-5
Torque Specifications - Steel Hydraulic Fittings	1001-6

Written In <i>Clear And Simple English</i>
--

SAFETY RULES




*This symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED.** The message that follows the symbol contains important information about safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death. 1-1-C*

NOTE: To prevent injury on job, follow the Warning, Caution, and Danger notes in this section and other sections throughout this manual. Follow the instructions carefully.

The procedures recommended and shown in this manual are good, effective service methods. However, all possible procedures and service hazards may not be covered. Therefore, if you use a tool or procedure not recommended, you must make sure that the method you select is a safe method.

Put the warning tag shown below on the key for the key switch when you are servicing or repairing this machine. One warning tag is on every new machine. You can buy additional warning tags, part number 331-4614, from Service Parts Supply.



780449



WARNING: Read operator's manual to familiarize yourself with control lever functions.

46-27



WARNING: Operate tractor and equipment controls from the seat position only. Any other method could result in serious injury.

48-55



WARNING: This is a one man machine, no riders allowed.

35-8



WARNING: Before starting engine, study operator's manual safety messages. Read all safety signs on machine. Clear the area of other persons. Learn and practice safe use of controls before operating.

It is your responsibility to understand and follow manufacturer's instructions on machine operation, service, and to observe pertinent laws and regulations. Operator's and service manuals may be obtained from your J I Case dealer.

45-2



WARNING: If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.

45-3-A



CORRECT



WARNING: When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.

35-4

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. **DO NOT** change the procedure. 47-44



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way. 47-45



WARNING: Use insulated gloves or mittens when working with hot parts. 47-41A



CAUTION: Lower all attachments to the ground or use stands to safely support the attachments before you do any maintenance or service. 49-11



CAUTION: Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection. If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately. Maintain all hoses and tubes in good condition. Make sure all connections are tight. Make a replacement of any tube or hose that is damaged or thought to be damaged. **DO NOT** use your hand to check for leaks; use a piece of cardboard or wood. 40-6-A



CAUTION: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer. 46-17



CAUTION: When using a hammer to remove and install pivot pins or separate parts, using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors). 46-13



CAUTION: When servicing or repairing the machine, keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and/or shop cloths as required. Use safe practices at all times. 40-8



CAUTION: Use suitable floor (service) jacks or chain hoists to raise wheels or track off the floor. Always block machine in place with suitable safety stands. 40-7-A



CAUTION: Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in this service manual. 40-10



DANGER: Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. If you do not have an exhaust pipe extension, open the doors and get outside air into the area. 48-56

SERVICE MANUAL INTRODUCTION

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures, and complete specifications and tightening references can be found in most sections. Some sections have drawings but no written procedure because the job is so easily done.

Right, Left, Front, and Rear

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.




Table of Contents

A Table of Contents is in the front of this manual. The Table of Contents shows the main divisions and the sections that are in each division. The individual sections also have a Table of Contents.

Page Numbers

All page numbers are made of two numbers separated by a dash, such as 4002-9. The number before the dash is the section number. The number following the dash is the page number in that section. Page numbers will be found at the upper right or left of each page.

Illustrations

Illustrations are put as near as possible to the text and are to be used as part of the text.

Clear and Simple English

This manual is written in C.A.S.E. (Clear and Simple English). C.A.S.E. is easier to read and understand than "regular" English because C.A.S.E. uses a small number of common words and has special rules for writing.

All sections written in C.A.S.E. are indicated by the symbol below.

Written In *Clear
And
Simple
English*

Special Tools

Special tools are needed to remove and install, disassemble and assemble, check and adjust some component parts of this machine. Some special tools can be easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and are available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.




Order special tools from either of the following companies.




Service Tools
P.O. Box 314
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.
97 Frid Street
Hamilton, Ontario L8P 4M3
Canada

TORQUE SPECIFICATIONS - U.S. HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers, dry, or when lubricated with engine oil. Not applicable if special graphites, moly-disulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs   			
Size	Pound-Feet	Newton metres	Kilogram metres
1/4 in 6.4 mm	9-11	12-15	1.2-1.5
5/16 in 7.9 mm	17-21	23-28	2.4-2.9
3/8 in 9.5 mm	35-42	48-57	4.8-5.8
7/16 in 11.1 mm	54-64	73-87	7.5-8.8
1/2 in 12.7 mm	80-96	109-130	11.1-13.3
9/16 in 14.3 mm	110-132	149-179	15.2-18.2
5/8 in 15.9 mm	150-180	203-244	20.8-24.9
3/4 in 19.0 mm	270-324	366-439	37.3-44.8
7/8 in 22.2 mm	400-480	542-651	55.3-66.4
1.0 in 25.4 mm	580-696	787-944	80.2-96.2
1-1/8 in 28.6 mm	800-880	1085-1193	111-122
1-1/4 in 31.8 mm	1120-1240	1519-1681	155-171
1-3/8 in 34.9 mm	1460-1680	1980-2278	202-232
1-1/2 in 38.1 mm	1940-2200	2631-2983	268-304

Grade 8 Bolts, Nuts, and Studs   			
Size	Pound-Feet	Newton metres	Kilogram metres
1/4 in 6.4 mm	12-15	16-20	1.7-2.1
5/16 in 7.9 mm	24-29	33-39	3.3-4.0
3/8 in 9.5 mm	45-54	61-73	6.2-7.5
7/16 in 11.1 mm	70-84	95-114	9.7-11.6
1/2 in 12.7 mm	110-132	149-179	15.2-18.2
9/16 in 14.3 mm	160-192	217-260	22.1-26.5
5/8 in 15.9 mm	220-264	298-358	30.4-36.5
3/4 in 19.0 mm	380-456	515-618	52.5-63.0
7/8 in 22.2 mm	600-720	814-976	83.0-99.5
1.0 in 25.4 mm	900-1080	1220-1465	124-149
1-1/8 in 28.6 mm	1280-1440	1736-1953	177-199
1-1/4 in 31.8 mm	1820-2000	2468-2712	252-277
1-3/8 in 34.9 mm	2380-2720	3227-3688	329-376
1-1/2 in 38.1 mm	3160-3560	4285-4827	437-492

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
37 Degree Flare Fittings				
1/4 in 6.4 mm	7/16-20	6-12	8-16	0.8-1.7
5/16 in 7.9 mm	1/2-20	8-16	11-21	1.1-2.2
3/8 in 9.5 mm	9/16-18	10-25	14-33	1.4-3.5
1/2 in 12.7 mm	3/4-16	15-42	20-56	2.1-5.8
5/8 in 15.9 mm	7/8-14	25-58	34-78	3.5-8.0
3/4 in 19.0 mm	1-1/16-12	40-80	54-108	5.5-11.1
7/8 in 22.2 mm	1-3/16-12	60-100	81-135	8.3-13.9
1.0 in 25.4 mm	1-5/16-12	75-117	102-158	10.4-16.2
1-1/4 in 31.8 mm	1-5/8-12	125-165	169-223	17.3-22.8
1-1/2 in 38.1 mm	1-7/8-12	210-250	285-338	29.0-34.6

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres	Kilogram metres
Straight Threads with O-ring				
1/4 in 6.4 mm	7/16-20	12-19	16-25	1.7-2.6
5/16 in 7.9 mm	1/2-20	16-25	22-33	2.2-3.5
3/8 in 9.5 mm	9/16-18	25-40	34-54	3.5-5.5
1/2 in 12.7 mm	3/4-16	42-67	57-90	5.8-9.3
5/8 in 15.9 mm	7/8-14	58-92	79-124	8.0-12.7
3/4 in 19.0 mm	1-1/16-12	80-128	108-174	11.1-17.8
7/8 in 22.2 mm	1-3/16-12	100-160	136-216	13.8-22.1
1.0 in 25.4 mm	1-5/16-12	117-187	159-253	16.2-25.9
1-1/4 in 31.8 mm	1-5/8-12	165-264	224-357	22.8-36.5
1-1/2 in 38.1 mm	1-7/8-12	250-400	339-542	34.6-55.3

Split Flange Mounting Bolts			
Size	Pound- Feet	Newton metres	Kilogram metres
5/16-18	15-20	20-27	2.1-2.8
3/8-16	20-25	26-33	2.8-3.5
7/16-14	35-45	47-61	4.7-6.2
1/2-13	55-65	74-88	7.6-9.0
5/8-11	140-150	190-203	19.4-20.7

1002

MAINTENANCE AND LUBRICATION

TABLE OF CONTENTS

Fluids and Lubricants	1002-2	Run-In Period	1002-4
Systemgard Lubricant Analysis		Run-In Maintenance Schedule	1002-5
Service	1002-4	Maintenance Schedule	1002-5
Systemgard Testing Schedule	1002-4		

Written In <i>Clear And Simple English</i>
--

FLUIDS AND LUBRICANTS

Fuel tank

Capacity 122 U.S. gallons (462 litres)
Specifications See Operators Manual

Cooling system

Capacity 8.5 U.S. gallons (32.2 litres)
Specifications Mix ethylene glycol antifreeze and water according to the antifreeze manufacturers instructions.

Engine crankcase (1187 Machines)

Capacity (Case engine)
Without filter change 19 U.S. quarts (18 litres)
With filter change 23 U.S. quarts (21.8 litres)


Capacity (Detroit Diesel)
Without filter change 14 U.S. quarts (13.2 litres)
With filter change 16 U.S. quarts (15.1 litres)

Engine crankcase (1187B Machines)

Capacity (Case engine)
Without filter change 24 U.S. quarts (22.7 litres)
With filter change 28 U.S. quarts (26.5 litres)

Capacity (Detroit Diesel)
Without filter change 18 U.S. quarts (17 litres)
With filter change 20 U.S. quarts (19 litres)

Specifications (Case engine) Case HDM oil



850678

Specifications (Detroit Diesel) See the Detroit Diesel Service Manual

Hydraulic system

Capacity
Total system 55 U.S. gallons (208 litres)
Reservoir 25.3 U.S. gallons (95.7 litres)
Specifications Case TCH Fluid
Alternate oil C3 hydraulic fluid

Final drive transmission

Capacity
1187 machine (each) 12 U.S. quarts (11.4 litres)
1187B machine (each) 16.5 quarts (15.6 litres)
Specifications Case FDL Fluid
Alternate oil SAE 80 to 90 API-GL-5

Swing gearbox

Capacity 17 U.S. quarts (16.1 litres)
Specifications Case FDL Fluid
Alternate oil SAE 80 to 90 API-GL-5

Rotary cutter flywheel housing

Capacity 3 U.S. pints (1.4 litres)
Specifications Case FDL Fluid
Alternate oil SAE 80 to 90 API-GL-5

Turntable ring gear

Specifications Symquip Spray Lube for Open Gears (OGLD-20)
Case part number 331-437

Batteries

Specifications Clean or distilled water

Grease fittings

Specifications Case molydisulfide grease

SYSTEMGARD LUBRICANT ANALYSIS SERVICE



830752

Through this service your machine lubricants are tested in a laboratory. The results of these tests show lubricant contamination and component wear rates. You will get service recommendations to increase the life of your machine. See your Case dealer for more information.

Systemgard Testing Schedule

Get samples of lubricants for Systemgard analysis at the intervals shown below. Follow the instructions with the Systemgard kits.

NOTE: *Get your sample before you drain the lubricant.*

Engine oil	Every 250 hours of operation or every oil change
Hydraulic fluid	Every 500 hours of operation or 3 times each year
Final Drive transmission fluid	Every 500 hours of operation or 3 times each year
Swing gearbox oil	Every 500 hours of operation or 3 times each year

RUN-IN PERIOD

During the first hours of operation for a new machine, or a machine with a rebuilt engine, make sure you do the following:

1. Operate the machine with normal bucket loads for the first 8 hours.
2. Keep the engine at normal operating temperatures.
3. Do not run the engine at idle speeds for long periods of time.
4. See the Run-In Maintenance Chart on this page for additional information.
5. After the first 20 hours of machine operation, do the After Delivery Check in the Operators Manual.

RUN-IN MAINTENANCE SCHEDULE

The items listed in this maintenance chart are to be done during the run-in-period and are in addition to the items listed under the Maintenance Schedule.

After First 20 Hours of Operation

Change the engine oil	See Operators Manual
Change the engine oil filter(s)	See Operators Manual
Check the drive belt tension	See Section 4007
Change the hydraulic oil filters	See Section 8201
Check the torque for the turntable bearing mounting bolts	See Section 9216

After First 250 Hours of Operation

Check the torque for the turntable bearing mounting bolts	See Section 9216
---	------------------

MAINTENANCE SCHEDULE

The items listed below are separated into maximum hourly intervals. These intervals are based on "average" operating conditions. When operating under "severe" conditions, such as excessive heat, cold, dust, mud or water, shorten the intervals.

As Required

Check and adjust track tension	See Section 5503
Service the air cleaner if the service indicator red band is in full view	See Section 2001
Replace hydraulic filters elements if warning lamp illuminates	See Section 8201
Clean debris from muffler area	See Operators Manual
Clean debris from shear or rotary cutter	See Operators Manual

Every 10 Hours of Operation or Each Day Whichever Occurs First

Check the air cleaner restriction indicator	See Section 2001
Check the radiator coolant level	See Operators Manual
Check the fuel sediment bowl for contamination (Case engine only)	See Operators Manual
Check the engine oil level	See Operators Manual
Check feller buncher shear for correct knife alignment	See Section 9212
Check the hydraulic reservoir fluid level	See Section 8201

Every 10 Hours of Operation or Each Day Whichever Occurs First

Check swing gearbox reservoir oil level	See Section 9210
Check the drive brakes for correct operation	See Operators Manual
Check swing brake for proper operation	See Operators Manual
Lubricate the turntable ring gear	See Section 9216
Lubricate the boom, arm, and attachments	See Operators Manual

Every 50 Hours of Operation

Check oil level for the rotary cutter (if equipped)	See Operators Manual
Drain water from the fuel tank and sediment bowl	See Operators Manual
Clean swing gearbox reservoir breather	See Operators Manual
Clean the air cleaner dust valve	See Section 2001
Lubricate the turntable pivot pins	See Operators Manual
Lubricate the pivot pins for the leveler (tilt) cylinders	See Operators Manual
Lubricate the turntable bearing raceway	See Operators Manual
Lubricate the drive belt pulley (Detroit Diesel only)	See Operators Manual

Every 100 Hours of Operation

Change engine oil and filters	See Operators Manual
-------------------------------------	----------------------

Every 250 Hours of Operation

Clean debris from cooler and radiator	See Operators Manual
Check the fluid level for each battery	See Section 4005
Check the oil level for each final drive transmission	See Section 6317 or 6318
Check the drive belt tension	See Section 4007
Check the torque of the turntable bearing mounting bolts	See Section 9216
Lubricate hydraulic swivel grease fitting	See Operators Manual
Lubricate control lever pivot points	See Operators Manual
Check the torque of pivot pin bolt on rotary cutter (if equipped)	See Section 9213

Every 500 Hours of Operation

- Replace fuel filters See Section 3010
- Replace the hydraulic filters See Section 8201
- Replace the 25 micron inline filter element See Section 8201
- Clean the hydraulic reservoir breather See Operators Manual

Every 1000 Hours of Operation or 6 Months

- Clean battery case, posts and connections See Section 4005
- Change the oil for the rotary cutter (if equipped) See Operators Manual
- Change the oil of each final drive transmission See Section 6317 or 6318
- Change the oil in the swing gearbox See Section 9210
- Check blower screen and clean if required
(Detroit Diesel) See Detroit Diesel Operators Manual

Every 2000 Hours of Operation or Each Year

- Change the hydraulic oil and clean the screens See Section 8201
- Drain engine coolant, flush and refill See Operators Manual

Section

1010

GENERAL ENGINE SPECIFICATIONS

1187 Logger Crawler

(504 DIESEL TURBOCHARGED ENGINE)

Written In *Clear
And
Simple
English*

504 DIESEL TURBOCHARGED ENGINE

General

Type	6 Cylinder, 4 Stroke Cycle, Valve-In-Head, Turbocharged
Firing Order	1-5-3-6-2-4
Bore	4-5/8 Inch (117.48 mm)
Stroke	5 Inch (127.00 mm)
Piston Displacement	504 Cubic Inch (8 259 cm ³)
Compression Ratio	15.8 to 1
No Load Governed Speed	2280 to 2320 RPM
Rated Engine Speed	2100 RPM
Engine Idle Speed	700 to 750 RPM
Valve Tappet Clearance (Exhaust)	(Cold) 0.025 Inch (0.635 mm)
(Intake)	(Cold) 0.015 Inch (0.381 mm)
Intake and Exhaust Valve Rotators	Positive Type
Thermostat Operating Range	175°F to 202°F (79°C to 94°C)

Piston and Connecting Rods

Rings Per Piston	3
Number of Compression Rings	2
Number of Oil Rings	1
Type Pins	Full Floating
Type Bearing	Replaceable, Precision Steel Back Liners

Main Bearings

Number of Bearings	7
Type Bearings	Replaceable, Precision Steel Back Liners

Engine Lubricating System

Oil Pressure	45 to 60 PSI (310 to 414 kPa)(3.10 to 4.14 bar) with Engine Warm and Operating at Rated Engine Speed
Type System	Pressure and Spray Circulation
Oil Pump	Gear Type
Oil Filter	Full Flow Turn On Type
Oil Capacity (With Filter)	23 Quarts (21.77 Litres)
(Without Filter)	19 Quarts (17.98 Litres)

Fuel System

Fuel Injection Pump	Robert Bosch
Pump Timing	27 Degrees Before Top Center
Fuel Injectors	Pencil Type, Opening Pressure (New) 3950 to 4100 PSI (27 235 to 28 270 kPa)(272 to 283 bar)
Fuel Transfer Pump	Plunger Type, Integral Part of Injection Pump
Governor	Variable Speed, Fly-Weight Centrifugal Type, Integral Part of Injection Pump
First Stage Fuel Filter	Full Flow Turn On Type
Second Stage Fuel Filter	Full Flow Turn On Type

NOTE: The J I Case Company reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

Section 1055

GENERAL CLEANING INSTRUCTIONS

Written In *Clear
And
Simple
English*

GENERAL CLEANING INSTRUCTIONS

Complete Assemblies

Completely assembled components can be steam cleaned on the OUTSIDE only, before removal or disassembly. All openings and breathers must be closed before steam cleaning to prevent water or moisture entering the component.

Rough Parts

Rough parts, for example — housings, castings, etc., can be cleaned in hot solution tanks with mild alkali solutions ONLY IF these parts do not have ground or machined surfaces. Leave the parts in the hot solution tank long enough to be completely cleaned and heated. Flush the parts completely with clear water after cleaning to remove all residue of the cleaning solution.

Finished or Machined Parts

Parts which have ground or machined surfaces, for example — gears, bearings, shafts and collars, can be cleaned in a solvent that is not flammable.

IMPORTANT: DO NOT clean machined parts in hot solution tanks with water and alkaline solutions.



WARNING: To prevent injury from burns, always use a solvent that is not flammable for cleaning component parts. DO NOT use gasoline or other flammable substances.

Rubber Parts

Clean rubber parts by washing in clean denatured alcohol. DO NOT use cleaning solvents with a mineral base, for example — acetone or paint thinner. If a mineral base solvent is used, the rubber will start to wear away and continue to wear away after the part is put back into service. This rapid wearing away of the rubber part can cause failure of the component in service.

Drying

After cleaning, all parts must be dried immediately. Use compressed air free of moisture, and a soft cloth free of lint and abrasive materials.

Bearings can be dried with compressed air, but make sure the air is moved across the bearings in a direction which prevents spinning. DO NOT let bearings spin when drying. Bearings can be turned slowly by hand to shorten the drying time.

Corrosion Prevention

Parts that have been cleaned, dried, inspected and are to be immediately assembled into the component — Apply a light oil to prevent corrosion. If these parts are to be put in storage for any length of time, apply a good RUST PREVENTIVE then put the parts in special paper or other material to prevent corrosion.

Section 1320

SPECIFICATION DETAILS

504BDT ENGINE

Written In *Clear
And
Simple
English*