



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4




1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4



1. Trim along dashed line.
2. Slide into pocket on Binder Spine.

TYPE 1-4

1818 Uni-Loader Service Manual

8-66102

Table of Contents

Description	Section No.	Form No.
General		
	Tab 1	
Safety Rules, Service Manual Introduction, and Torque Specifications	1001	8-68110
Fluids and Lubricants	1002	8-17800
Engine Specifications for Onan P218 2 Cylinder Gasoline Engine	1010	8-58750
Engine Specifications for Kubota D850 3 Cylinder Diesel Engine	1024	8-58740
General Machine Specifications	1210	8-68120
Engines		
	Tab 2	
Engine Removal and Installation and Radiator Removal and Installation	2000	8-68160
Engine Accessories (Air Cleaner and Muffler)	2001	8-68170
Cylinder Head, Valves and Camshaft for Onan P218 2 Cylinder Gasoline Engine	2015	8-57810
Cylinder Head and Valve Train for Kubota D850 3 Cylinder Diesel Engine	2015	8-57730
Engine Camshaft and Fuel Camshaft for Kubota D850 3 Cylinder Diesel Engine	2020	8-58610
Cylinder Block, Pistons and Connecting Rods for Onan P218 2 Cylinder Gasoline Engine	2025	8-57820
Cylinder Block, Pistons and Connecting Rods for Kubota D850 3 Cylinder Diesel Engine	2025	8-57740
Crankshaft, Main Bearings, Flywheel, and Oil Seals for Onan P218 2 Cylinder Gasoline Engine	2035	8-57830
Crankshaft, Main Bearings, Flywheel, and Oil Seals for Kubota D850 3 Cylinder Diesel Engine	2035	8-57750
Lubrication Components for Onan P218 2 Cylinder Gasoline Engine	2045	8-57840
Lubrication Components for Kubota D850 3 Cylinder Diesel Engine	2045	8-57760
Cooling System for Kubota D850 3 Cylinder Diesel Engine	2055	8-57770
Ignition System for Onan P218 2 Cylinder Gasoline Engine	2065	8-58690
Engine Lubrication for Kubota D850 3 Cylinder Diesel Engine	2555	8-57780
Fuel Systems		
	Tab 3	
Carburetor and Fuel Pump for Onan P218 2 Cylinder Gasoline Engine	3002	8-58680
Fuel Pump and Injection Pump for Kubota D850 3 Cylinder Diesel Engine	3312	8-58540
Fuel Injectors and Glow Plugs for Kubota D850 3 Cylinder Diesel Engine	3313	8-58530
Electrical		
	Tab 4	
Removal and Installation for Electrical Components	4000	8-68190
Electrical Specifications and Troubleshooting	4002	8-68201
Electrical Schematics	4003	8-68211
Instruments and Gauges	4004	8-68220

CASE CORPORATION
700 State Street
Racine, WI 53404 U.S.A.

CASE CANADA CORPORATION
450 Sherman Avenue
Hamilton, ON L8N 4C4 CANADA

Bur 8-69352

© 2001 Case Corporation
Printed in U.S.A.
May, 1991 (Revised January, 2001)

1818 Uni-Loader Service Manual

8-66102

Table of Contents

Description	Section No.	Form No.
Battery	4005	8-44360
Starter and Solenoid for Onan P218 2 Cylinder Gasoline Engine	4006	8-57860
Starter Motor for Kubota D850 3 Cylinder Diesel Engine	4006	8-57790
Alternator and Rectifier / Regulator Unit for Onan P218 2 Cylinder Gasoline Engine	4007	8-57870
Alternator and Regulator for Kubota D850 3 Cylinder Diesel Engine	4007	8-57800
Power Train		Tab 6
Removal and Installation of Power Train Components	6000	8-68230
Maintenance	6001	8-68240
Hydrostatic System Troubleshooting	6002	8-17820
Piston Pump	6004	8-68260
Motor	6005	8-68270
Sprocket, Chains, and Axles	6007	8-68290
Drive Belts	6010	8-68300
Wheels and Tires	6011	8-68310
Hydraulics		Tab 8
Removal and Installation of Hydraulic Components	8000	8-68330
Maintenance	8001	8-68340
Hydraulic Schematics, Specifications and Troubleshooting	8002	8-17830
Cleaning the Hydraulic System and Hydrostatic System	8003	8-68360
Hydraulic pump	8004	8-68370
Loader Control Valve	8005	8-68380
Auxiliary Control Valve	8006	8-68390
Cylinders	8090	8-68400
Mounted Equipment		Tab 9
Pedals and Levers	9000	8-17840
Loader	9001	8-68410
ROPS Canopy, Seat, Seat Belts, and Operators Compartment	9003	8-68420
Auxiliary Hydraulic Installation	9004	8-68430
Rear Pocket		In Rear Pocket
Electrical Schematic, Gasoline Engine		B87793
Electrical Schematic, Diesel Engine		B87794
Hydraulic Schematic		B87969
Electrical Schematic Foldout Gasoline and Diesel Engines		6-41550

1001

SAFETY RULES SERVICE MANUAL INTRODUCTION AND TORQUE SPECIFICATIONS

TABLE OF CONTENTS

Safety Rules	1001-2	Grade 8.8 Bolts, Nuts, and Studs	1001-7
Service Manual Introduction	1001-5	Grade 10.9 Bolts, Nuts, and Studs	1001-7
Torque Specifications	1001-6	Grade 12.9 Bolts, Nuts, and Studs	1001-7
Grade 5 Bolts, Nuts, and Studs	1001-6	Steel Hydraulic Fittings	1001-8
Grade 8 Bolts, Nuts, and Studs	1001-6	Split Flange Mounting Bolts	1001-8

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**



SAFETY RULES



Most accidents involving machine operation and maintenance can be avoided by following basic safety rules and precautions. Read and understand all the safety messages in this manual, the safety manual, and the safety signs on the machine before you operate or service the machine.

Read the operators manual and make sure you understand the operation of the machine.



Operators Manual Storage

876245

The safety information given in this manual does not replace safety codes, insurance needs, federal, state, and local laws.

IMPORTANT: *Safety messages in this section point out situations which can be encountered during the normal operation and maintenance of your machine. These safety messages also give possible ways of dealing with these conditions.*

Additional safety messages are used in the text of the manual to show specific safety hazards.




BEFORE OPERATION



Do not wear loose clothing or jewelry that can catch on controls, etc. Safety shoes, heavy gloves, ear protection, etc., can also be required for your protection.

Foreign material or grease on the steps and hand rails can cause an accident. Keep the steps and hand rails clean.



Remove all loose objects from the operators area and from the machine. Loose objects can jam controls and cause accidents.

Engine exhaust fumes can cause death. If you operate this machine in an enclosed area, use good ventilation to replace the exhaust fumes with fresh air.

Make sure all persons are away from the machine before you start the engine.

Before you start the engine, always fasten the seat belt and pull down the operators protection bars.

Use hand rails and step provided. Do not rush.



MACHINE OPERATION



Check all controls in a clear area and make sure the machine is operating correctly.

Do not allow another person to ride on the machine. This other person can fall or can cause an accident.

Be alert, always know the location of all workers in your area. Keep all other persons completely away from your machine. Injury or death can result if you do not follow these instructions.



PARKING THE MACHINE




When you park the machine and before you leave the operators area, lower the loader bucket to the ground or support the loader lift arms with the support strut and stop the engine.



MAINTENANCE



When you service the machine, put a Do Not Operate tag on the instrument panel. A Do Not Operate tag (Case part number 321-4614) is included with each new machine. Extra tags are available from your Case dealer.



780449

Improper service or repair can cause injury or death. If you do not understand a service or adjustment procedure, see the correct section in this manual.

Unauthorized modifications to this machine can cause injury or death. Do not make unauthorized modifications to this machine.

If you must service this machine with the engine running, have another person help you. Follow the instructions in this manual. Do not leave the operators seat with the engine running.

Metal chips or debris can cause eye injury. Always wear eye or face protection when you use a hammer on this machine. Use a hammer with a soft face, such as brass, to drive hardened pins.

When adding air to a tire, always stand behind the tread of the tire and use a self-adjusting chuck. Explosive separation of the tire can result if you overinflate. When tire service is necessary, have a qualified tire mechanic service the tire.

Hydraulic fluid or grease injected into your skin can cause severe injury or death. Keep your hands and body away from any pressurized leak. If fluid is injected into your skin, see a doctor immediately and have the fluid removed.



FIRE OR EXPLOSION PREVENTION



Engine fuel can cause an explosion or fire. Do not fill the fuel tank with the engine running, if you are near an open fire, or if you are welding, smoking, etc.

Use nonflammable cleaning solvent to clean parts.

Sparks or flame can cause the hydrogen gas in a battery to explode. To prevent an explosion, do the following:

1. When disconnecting the battery cables, disconnect the negative (-) cable first; when connecting the battery cables, connect the negative (-) cable last.
2. When connecting jumper cables to start the engine, use the procedure shown in this manual.
3. Do not short circuit the battery posts with metal items.

4. Do not weld, grind, or smoke near a battery.

Sparks from the electrical system or engine exhaust can cause a fire or an explosion. Before you operate this machine in an area with flammable dust or vapors, use good ventilation to remove all flammable dust or vapors.

A fire can cause injury or death. Always have a fire extinguisher near the machine. Make sure the fire extinguisher is serviced according to the manufacturer's instructions.

Remove all trash or debris from the machine. Make sure that oily rags or other flammable materials are not stored on the machine.

Check for fuel, oil, and hydraulic fluid leaks. Replace worn or damaged hoses/lines. After repairs are made, clean the machine before you operate.



BURN PREVENTION



Battery acid causes severe burns. Batteries contain sulfuric acid. Avoid contact with skin, eyes, or clothing. Antidote - EXTERNAL: flush with water. INTERNAL: drink large quantities of water or milk. Follow with milk of magnesia, beaten egg or vegetable oil. Call a doctor immediately. EYES: flush with water for 15 minutes and get prompt medical attention.

When the battery electrolyte is frozen, the battery can explode if, (1) you try to charge the bat-

tery, (2) you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.


Hot coolant can spray out if the radiator cap is removed. To remove the radiator cap, let the cooling system cool, turn to the first notch, then wait until the pressure is released.

SERVICE MANUAL INTRODUCTION

This service manual has been prepared with the latest service information available. Troubleshooting, removal, disassembly, inspection and installation procedures, and complete specifications and tightening references can be found in most sections. Some sections have drawings but no written procedure because the job is so easily done. This service manual is one of the most important tools available to the service technician.

Right, Left, Front, and Rear

The terms right-hand and left-hand and front and rear as used in this manual indicate the right and left sides, and front and rear of the machine as seen from the operator's seat for correct operation of the machine or attachment.



821019

Text

If the service manual is for more than one machine or different models of components (planetary axles, gear boxes, control valves, etc.) the procedures have the steps necessary to service each model.

Table of Contents

A Table of Contents is in the front of this manual. The Table of Contents shows the main divisions and the sections that are in each division. The individual sections, where necessary, have a Table of Contents on the cover or second page of that section.

Page Numbers

All page numbers are made of two numbers the separated by a dash, such as 4002-9. The number dash before the dash is the section number. The number following is the page number in that section. Page numbers will be found at the upper right or left of each page.

Illustrations

Illustrations are put as near as possible to the text and are to be used as part of the text.

Special Tools

Special tools are needed to remove and install, disassemble and assemble, check, and adjust some components parts of this machine. Some special tools can be easily made locally and the necessary information to make the tool is in this service manual. Other special tools are more difficult to make locally and are available from Service Tools in the U.S. and from Jobborn Manufacturing in Canada. Use these tools according to the instructions in this service manual for your personal safety and to do the job correctly.


Order special tools from either of the following companies:


Service Tools
P.O. Box 314
Owatonna, Minnesota 55060

Jobborn Manufacturing Co.
97 Frid Street
Hamilton, Ontario L8P 4M3
Canada

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers, dry, or when lubricated with engine oil. Not applicable if special graphites, molydisulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs		
		
Size	Pound-Feet	Newton metres
1/4 in	9-11	12-15
5/16 in	17-21	23-28
3/8 in	35-42	48-57
7/16 in	54-64	73-87
1/2 in	80-96	109-130
9/16 in	110-132	149-179
5/8 in	150-180	203-244
3/4 in	270-324	366-439
7/8 in	400-480	542-651
1.0 in	580-696	787-944
1-1/8 in	800-880	1085-1193
1-1/4 in	1120-1240	1519-1681
1-3/8 in	1460-1680	1980-2278
1-1/2 in	1940-2200	2631-2983


Grade 8 Bolts, Nuts, and Studs		
		
Size	Pound-Feet	Newton metres
1/4 in	12-15	16-20
5/16 in	24-29	33-39
3/8 in	45-54	61-73
7/16 in	70-84	95-114
1/2 in	110-132	149-179
9/16 in	160-192	217-260
5/8 in	220-264	298-358
3/4 in	380-456	515-618
7/8 in	600-720	814-976
1.0 in	900-1080	1220-1465
1-1/8 in	1280-1440	1736-1953
1-1/4 in	1820-2000	2468-2712
1-3/8 in	2380-2720	3227-3688
1-1/2 in	3160-3560	4285-4827


NOTE: Use thick nuts with Grade 8 bolts.

TORQUE SPECIFICATIONS - METRIC HARDWARE

Use the following torques when special torques are not given

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs		
		
Size	Pound-Feet	Newton metres
M4	2-3	3-4
M5	5-6	6.5-8
M6	8-9	10.5-12
M8	19-23	26-31
M10	38-45	52-61
M12	66-79	90-107
M14	106-127	144-172
M16	160-200	217-271
M20	320-380	434-515
M24	500-600	675-815
M30	920-1100	1250-1500
M36	1600-1950	2175-2600

Grade 10.9 Bolts, Nuts, and Studs		
		
Size	Pound-Feet	Newton metres
M4	3-4	4-5
M5	7-8	9.5-11
M6	11-13	15-17.5
M8	27-32	37-43
M10	54-64	73-87
M12	93-112	125-150
M14	149-179	200-245
M16	230-280	310-380
M20	450-540	610-730
M24	780-940	1050-1275
M30	1470-1770	2000-2400
M36	2580-3090	3500-4200

Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
37 Degree Flare Fittings			
1/4 in 6.4 mm	7/16-20	6-12	8-16
5/16 in 7.9 mm	1/2-20	8-16	11-21
3/8 in 9.5 mm	9/16-18	10-25	14-33
1/2 in 12.7 mm	3/4-16	15-42	20-56
5/8 in 15.9 mm	7/8-14	25-58	34-78
3/4 in 19.0 mm	1-1/16-12	40-80	54-108
7/8 in 22.2 mm	1-3/16-12	60-100	81-135
1.0 in 25.4 mm	1-5/16-12	75-117	102-158
1-1/4 in 31.8 mm	1-5/8-12	125-165	169-223
1-1/2 in 38.1 mm	1-7/8-12	210-250	285-338

Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
Straight Threads with O-ring			
1/4 in 6.4 mm	7/16-20	12-19	16-25
5/16 in 7.9 mm	1/2-20	16-25	22-23
3/8 in 9.5 mm	9/16-18	25-40	34-54
1/2 in 12.7 mm	3/4-16	42-67	57-90
5/8 in 15.9 mm	7/8-14	58-92	79-124
3/4 in 19.0 mm	1-1/16-12	80-128	108-174
7/8 in 22.2 mm	1-3/16-12	100-160	136-216
1.0 in 25.4 mm	1-5/16-12	117-187	159-253
1-1/4 in 31.8 mm	1-5/8-12	165-264	224-357
1-1/2 in 38.1 mm	1-7/8-12	250-400	339-542

Split Flange Mounting Bolts		
Size	Pound- Feet	Newton metres
5/16-18	15-20	20-27
3/8-16	20-25	26-33
7/16-14	35-45	47-61
1/2-13	55-65	74-88
5/8-11	140-150	190-203

Section 1002

FLUIDS AND LUBRICANTS

CAPACITIES AND LUBRICANTS

Fuel Tank

Capacity..... 8. 5 U.S. gallons (32.2 litres)

Diesel Engine Crankcase

Capacity - with filter change 4.9 U.S. quarts (4.6 litres)

Type of oil..... See Engine Oil Recommendations on page 3

Gasoline Engine Crankcase

Capacity - with filter change 2.3 U.S. quarts (2.2 litres)

Type of oil..... See Engine Oil Recommendations on page 3

Hydraulic Reservoir

Capacity - with filter change 5.75 U.S. gallons (21.8 litres)

Capacity - without filter change 5.5 U.S. gallons (20.8 litres)

Capacity - total system 7.5 U.S. gallons (28.4 litres)

Type of oil..... SAE 10W30 engine oil with additive, see below

When you change the hydraulic oil, add one U.S. quart (0.95 litre) of Case HTO (Hydrostatic Transmission Oil Additive) Case part number B17508.

When you add oil to the hydraulic reservoir between oil changes, use a mixture of SAE 10W30 engine oil and HTO additive. Mix one U.S. quart (0.95 litre) of HTO additive with five U.S. gallons (19 litres) of 10W30 engine oil. (20 to 1 ratio).

Drive Chain Compartments

Capacity - each side 3 U.S. quarts (2.8 litres)

Type of oil..... SAE 10W30 engine oil

Engine Cooling System (Diesel)

Capacity..... 7 U.S. quarts (6.6 litres)

Type of coolant..... Ethylene glycol type antifreeze and water that is mixed for lowest ambient temperature at least 50/50 mix

Grease Fittings


Type of lubricant..... Case IH molydisulfide grease

Hydrostatic Motor Shaft Spline

Type of lubricant..... Molykote, Type G grease

GASOLINE ENGINE OIL RECOMMENDATIONS

Use Case IH Engine Oil of the correct viscosity. See the chart for the temperatures and the recommended viscosity.



B87735J

DIESEL ENGINE OIL RECOMMENDATIONS

Use Case IH Engine Oil of the correct viscosity. See the chart for the temperatures and the recommended viscosity.

- Above 77°F (25°C) SAE 30
- 32 to 77°F (0 to 25°C) SAE 10W30
- Below 32°F (0°C) SAE 10W or SAE 10W30

FUEL

Gasoline Engines

Use clean, unleaded regular grade gasoline. Do not use leaded gasoline in the engine.

Diesel Engines


Use the diesel fuel recommended for the temperatures in your area. If the ambient temperature lowers to the "cloud point" of the fuel, wax particles will form in the fuel. The wax particles can cause a restriction in the fuel filters decreasing engine power. See your fuel dealer.

Section 1010


ENGINE SPECIFICATIONS

**For Onan P218
2 Cylinder Gasoline Engine**

ENGINE IDENTIFICATION



How to interpret MODEL and SPEC NO.



1. Factory code for general identification of basic engine series
2. Number of cylinders
3. BHP rating
4. Fuel required (G = gasoline)
5. Engine duty cycle
6. Factory code for designated optional equipment, if any.
7. Specification (spec letter) which advances with factory production modifications.

A PIN (Product Identification Number) plate is fastened to the top of the flywheel guard. The bottom number on the plate is the serial number for the engine. Always use both numbers when ordering service parts or when making service enquiries.

GENERAL SPECIFICATIONS

Engine

Type	Horizontal Air Cooled 4-Cycle Gasoline Engine	
Number of Cylinders	2	
Stroke	2.875 inch	73 mm
Total Displacement	47.7 cubic inch	782 cm ³
Compression Ratio	7:1	
Cylinder Compression	75 to 115 PSI	517 to 793 kPa
Lubrication	Pressure Lubrication By Rotor Type Pump	
Ignition Order	Both Together	
Direction Of Rotation	Clockwise Looking From Flywheel End	
Governor	Mechanical On End Of Camshaft	

DETAILED SPECIFICATIONS

Valve Clearance (Cold)

Intake	0.005 inch	0.13 mm
Exhaust	0.013 inch	0.33 mm

Intake Valve

Stem Diameter	0.2795 to 0.2800 inch	7.099 to 7.112 mm
Clearance (Stem to Guide)	0.0010 to 0.0025 inch	0.025 to 0.064 mm
Valve Face Angle	44°	

Intake Valve Seat

Seat Diameter	1.4395 to 1.4405 inch	36.56 to 36.59 mm
Seat Outside Diameter	1.470 to 1.471 inch	37.34 to 37.36 mm
Valve Seat Width	0.031 to 0.047 inch	0.787 to 1.194 mm
Valve Seat Angle	45°	

Exhaust Valve

Stem Diameter	0.2780 to 0.2785 inch	7.061 to 7.074 mm
Clearance (Stem to Guide)	0.0020 to 0.0035 inch	0.051 to 0.089 mm
Valve Face Angle	44°	

Exhaust Valve Seat

Seat Diameter	1.189 to 1.190 inch	30.20 to 30.23 mm
Seat Outside Diameter	1.192 to 1.193 inch	30.28 to 30.30 mm
Valve Seat Width	0.031 to 0.047 inch	0.787 to 1.194 mm
Valve Seat Angle	45°	

Valve Guide

Intake Inside Diameter	0.281 to 0.282 inch	7.137 to 7.163 mm
Exhaust Inside Diameter	0.2805 to 0.2815 inch	7.124 to 7.150 mm

Valve Springs Intake And Exhaust

Valve Spring Free Length (Approx.)	1.60 inch	40.64 mm
Valve Spring Length		
Valve Open	1.055 inch	26.80 mm
Valve Closed	1.346 inch	34.19 mm
Spring Load At 1.35 inch (Valve Closed)	25 lb	11.3 kg
Spring Load At 1.05 inch (Valve Open)	55 lb	24.9 kg

Camshaft

Journal Diameter	1.3740 to 1.3745 inch	34.90 to 34.91 mm
Bearing Clearance	0.0015 to 0.0030 inch	0.038 to 0.076 mm
End Play	0.0110 to 0.0480 inch	0.280 to 1.22 mm
Cam Lobe Lift		
Intake	0.275 inch	6.98 mm
Exhaust	0.295 inch	7.49 mm
Camshaft Gear		
Backlash	0.001 to 0.005 inch	0.025 to 0.127 mm

Gear Backlash

Timing Gear	0.001 to 0.005 inch	0.025 to 0.127 mm
-------------	---------------------	-------------------

Tappet

Body Diameter	0.7475 to 0.7480 inch	18.99 to 19.00 mm
Bore Diameter	0.7500 to 0.7515 inch	19.05 to 19.09 mm
Clearance In Bore	0.002 to 0.004 inch	0.051 to 0.102 mm

DETAILED SPECIFICATIONS**Cylinder Liners**

Standard Bore	3.2490 to 3.2500 inch	82.53 to 82.55 mm
Oversize Bore	+ 0.005 inch	+ 0.127 mm
	+ 0.010 inch	+ 0.254 mm
	+ 0.020 inch	+ 0.508 mm
	+ 0.030 inch	+ 0.762 mm
	+ 0.040 inch	+ 1.016 mm
Maximum Out Of Round	0.003 inch	0.08 mm
Maximum Taper	0.005 inch	0.13 mm
Cross Hatch Pattern	23 degrees to horizontal	
Surface Finish	20 to 40 RMS	

Piston Rings

Ring Gap In Liner:		
Top Compression	0.010 to 0.020 inch	0.250 to 0.510 mm
Bottom Compression	0.010 to 0.020 inch	0.250 to 0.510 mm
Oil Control	0.010 to 0.020 inch	0.250 to 0.510 mm
Side Clearance In Top Groove	0.003 to 0.008 inch	0.076 to 0.203 mm
Oversize Rings	See Oversize Pistons	

Pistons

Clearance In Liner	0.0033 to 0.0053 inch	0.084 to 0.135 mm
Piston Pin Bore	0.687 to 0.688 inch	17.47 to 17.48 mm
Ring Groove Width:		
Top Compression Ring	0.080 to 0.081 inch	2.032 to 2.057 mm
Bottom Compression Ring	0.080 to 0.081 inch	2.032 to 2.057 mm
Oil Control Ring	0.188 to 0.189 inch	4.775 to 4.801 mm
Available Oversizes	+ 0.005 inch	+ 0.127 mm
	+ 0.010 inch	+ 0.254 mm
	+ 0.020 inch	+ 0.508 mm
	+ 0.030 inch	+ 0.762 mm
	+ 0.040 inch	+ 1.016 mm

Piston Pins

Diameter	0.6875 to 0.6877 inch	17.463 to 17.468 mm
Clearance In Piston	0.00004 to 0.00064 inch	0.001 to 0.0162 mm
Clearance In Connecting Rod	0.0002 to 0.0007 inch	0.005 to 0.018 mm

Connecting Rods

Big End Bore (Bolts Torqued)	1.6280 to 1.6285 inch	41.35 to 41.36 mm
Side Clearance On Crankshaft	0.002 to 0.016 inch	0.051 to 0.406 mm
Piston Pin Bore	0.6879 to 0.6882 inch	17.47 to 17.48 mm
Big End To Crankshaft Clearance	0.0020 to 0.0033 inch	0.051 to 0.084 mm
Available Oversizes	+ 0.010 inch	+ 0.254 mm
	+ 0.020 inch	+ 0.508 mm
	+ 0.030 inch	+ 0.762 mm

DETAILED SPECIFICATIONS


Crankshaft

Main Bearing Journal Diameter	1.9992 to 2.0000 inch	50.78 to 50.80 mm
Main Bearing Clearance	0.0024 to 0.0042 inch	0.061 to 0.107 mm
Connecting Rod Journal Diameter	1.6252 to 1.6260 inch	41.28 to 41.30 mm
Connecting Rod Bearing Clearance	0.0020 to 0.0033 inch	0.051 to 0.084 mm
Main Bearing Journal Taper (Max)	0.001 inch	0.03 mm
Connecting Rod Bearing Journal Taper (Max)	0.001 inch	0.03 mm
Crankshaft Gear Installation Temperature	350°F	177°C
Starter Ring Gear Installation Temperature	400°F	204°C
Crankshaft End Play	0.006 to 0.012 inch	0.15 to 0.30 mm

Lubricant

Capacity	1.5 Quarts	1.4 Litre
Change Period	Every 25 Hours	
Grade	See Table Below	

USE THESE SAE VISCOSITY GRADES



Oil Strainer

Location	In Oil Pan
Cleaning Period	Every 100 Hours

Oil Relief Valves

Location	One In Engine Block One In Oil Filter Adaptor	
Open At (Both)	20 PSI	138 kPa
Valve Diameter (Both)	0.3105 to 3.125 inch	7.89 to 7.94 mm
Valve Spring (Both)		
Free Length	1.00 inch	25.4 mm
Compress To	0.50 inch	12.7 mm
With A Load Of	2.4 to 2.8 lb	10.7 to 12.5 N

DETAILED SPECIFICATIONS

Low Oil Pressure Switch

Location	On Oil Filter Adaptor Block	
Operation	Stops Voltage Flow To Ignition When Oil Pressure Is Below 8 PSI	55 kPa

Engine Block Breather

Location	Above Left Hand Valve Cover
Cleaning Period	Every 200 Hours

Oil Pump

Location	At Front Of Engine Inside Timing Cover	
Drive	Gear In Mesh With Crankshaft Gear	
Gear Backlash	0.001 to 0.008 inch	0.025 to 0.203 mm
Minimum Pressure at 1500 RPM	8 PSI	55 kPa
Shim Gasket Thickness	0.005 inch	0.127 mm
	0.007 inch	0.178 mm
	0.009 inch	0.229 mm

Ignition System

Type	Electronic Battery Ignition System Using An Ignition Module And Trigger Ring
Location	Behind Flywheel On Engine Crankshaft And Timing Gear Cover

Ignition Coil

Primary Coil Resistance	2.90 to 3.60 Ohms At 70°F
Secondary Coil Resistance	14.5 to 19.8k Ohms At (21°C)

Ignition Timing

Degress Before Top Center	20
---------------------------	----

Spark Plug

Type	RS14YC	
Electrode Gap	0.025 inch	1.64 mm

Carburetor

Type	Fixed Power Jet With Adjustable Low Idle Needle
------	--

Governor

Type	Throwout Balls In Cup On End Of Camshaft. Actuates On Throttle Control Lever
------	--

Fuel Pump

Type	Diaphragm Operated By Vacuum In Engine Block	
Inlet Vacuum (Min)		
Low Idle Speed	2.6 in Hg at 32°F	0.767 kPa at 0°C
Maximum Speed	2.6 in Hg at 32°F	0.767 kPa at 0°C
Outlet Pressure (Min)		
Low Idle Speed	1.7 PSI	11.72 kPa
Maximum Speed	1.7 PSI	11.72 kPa