




SERVICE MANUAL

Lep 84512399 EN



CX470C Tier 4
Crawler Excavator

CRAWLER EXCAVATORS CX470C TIER 4 SERVICE MANUAL

TABLE OF CONTENTS

DIVISION/SECTION	SECTION N°
1 GENERAL INFORMATION	
Safety, general information and standard torque data	1001
Specifications	1002A
Main Equipment Table	1002B
Main Unit Weight	1002C
Maintenance Standards	1002D
Bolt Size and Torque Table	1002E
Overall View	1002F
List of Special Tools	1003
Fluid and Lubricants	1004
Conversion Table	1005
Abbreviations	1900
2 ENGINE	
Removal and Installation of Engine Assembly	2000
Removal and Installation of the Fuel Cooler Engine Inter-Cooler Radiator and Oil Cooler	2001
Removal and Installation of Turbo Charger	2004
Removal and Installation of EGR Cooler and EGR Valve	2005
Removal and Installation of Engine Hood	2006
Removal and Installation of Muffler	2007
Primary specifications	2401
Removal and Installation of Cylinder Head	2415
Removal and Installation of Cylinder Block	2425
Lubrication System	2445
Cooling System	2455
Removal and Installation of Exhaust Manifold	2465
Disassembly, Removal and Installation of DPD Assembly	2470
3 FUEL SYSTEM	
Removal and Installation of Fuel Tank	3001
Removal and Installation of Fuel Supply Pump	3004A
Removal and Installation of Common Rail Assembly	3004B
Removal and Installation of Injector	3005
4 ELECTRICAL SYSTEM	
Electrical and Engine Basic Functions	4001A
Service Support	4001B
Engine Function, Structure, Operation	4001C
Symptom	4001E
Functional Inspection	4001F
Engine, Electronic and Programming Maintenance Precautions	4001G
Removal and Installation of Starter Motor	4004
Removal and Installation of Alternator	4005
Preheating System	4008
Electrical Equipment Layout Diagram	4020A
Connection Connector Pin Layout	4020B
Sequence Circuit Diagram	4020C
Engine-side DTC List	4021
Main Unit-side DTC List	4022
Introduction to the trouble diagnosis	4023B
Engine Control System	4023D
Engine-side Trouble	4023G

TABLE OF CONTENTS

DIVISION/SECTION	SECTION N°
Main Unit-side Trouble	4023H
Data Reference Values	4023K
Electrical Wiring Diagram	4040
5 UNDERCARRIAGE	
Removal and Installation of Shoe Assembly	5001A
Removal and Installation of Shoe Plate	5001B
Removal and Installation of Upper Roller	5003A
Assembly and Disassembly of Upper Roller	5003B
Removal and Installation of Lower Roller	5003C
Assembly and Disassembly of Lower Roller	5003D
Removal and Installation of the Sprocket	5004
Removal and Installation of Take-up Roller	5005A
Assembly and Disassembly of Take-up Roller	5005B
Removal and Installation of Grease Cylinder	5005C
Assembly and Disassembly of Grease Cylinder	5005D
6 DRIVE TRAIN	
Removal and Installation of Travel Motor	6001
Assembly and Disassembly of Travel Motor	6002
Removal and Installation of Swing Unit	6003
Assembly and Disassembly of Swing Unit	6004
7 UNDERCARRIAGE HYDRAULICS	
8 UPPERSTRUCTURE HYDRAULICS	
Overall view	8001A
Port Diagram	8001B
Pressure Measurement and Adjustment Procedures	8001D
Hydraulic Pump Flow Measurement Procedures	8001E
Drain Volume Measurement Procedures	8001F
Air Bleed Procedure	8001G
Removal and Installation of Hydraulic Oil Tank	8002
Removal and Installation of Hydraulic Pump	8003
Removal and Installation of Control Valve	8004
Removal and Installation of Bucket Cylinder	8005A
Removal and Installation of Arm Cylinder	8005B
Removal and Installation of Boom Cylinder	8005C
Removal and Installation of Center Joint	8006
Removal and Installation of Travel Remote Control Valve	8007A
Removal and Installation of Operation Remote Control Valve	8007B
Removal and Installation of 5 Stack Solenoid	8007C
Removal and Installation of Cushion Valve	8007D
Procedures for Assembly and Disassembly of Hydraulic Pump Main Unit	8008
Pump Main Unit Maintenance Standards	8010
Procedures for Assembly and Disassembly of Control Valve	8011
Procedures for Operation/Assembly and Disassembly of Hydraulic Cylinder	8012
Procedures for Assembly and Disassembly of Operation Remote Control Valve	8013
Procedures for Assembly and Disassembly of Travel Remote Control Valve	8014
Assembly and Disassembly of Cushion Valve	8016
Removal and Installation of Arm HBCV	8017A
Removal and Installation of Boom HBCV	8017B
Assembly and Disassembly of Center Joint	8018
Assembly and Disassembly of Swing Motor	8019
Explanation of Hydraulic Circuit and Operations (standard model)	8020A
Explanation of Hydraulic Circuit and Operations (option)	8020B

TABLE OF CONTENTS

DIVISION/SECTION	SECTION N°
Structure and Operation Explanation of Hydraulic Pump	8030A
Structure and Operation Explanation of Travel Motor	8030B
Structure and Operation Explanation of Swing Motor	8030C
Structure and Operation Explanation of Control Valve	8030D
5 Stack Solenoid Valve Operation Explanation	8030E
Structure and Operation Explanation of Upper Pilot Valve (remote control valve)	8030F
Structure and Operation Explanation of Travel Pilot Valve (remote control valve)	8030G
Structure and Operation Explanation of Cushion Valve	8030H
9 UPPERSTRUCTURE	
Removal and Installation of Counterweight	9002
Removal and Installation of Bucket	9003A
Removal and Installation of Bucket Link	9003B
Removal and Installation of Arm	9003C
Removal and Installation of Boom	9003D
Removal and Installation of Operator's Seat	9004
Removal and Installation of Cab Assembly	9005A
Removal and Installation of Wiper	9005B
Removal and Installation of Wiper Controller	9005C
Removal and Installation of Wiper Motor	9005D
Removal and Installation of Monitor	9005E
Removal and Installation of Cab Front Glass	9005F
Window Lock Adjustment Procedures	9005G
Cab Tightening torque	9005H
Air Conditioner Overall Diagram	9006
Assembly and Disassembly of Air Conditioner Units	9007
Removal and Installation of Compressor	9009
Removal and Installation of Condenser	9010
Removal and Installation of Receiver Dryer	9011
Air Conditioning Gas Vacuum and Filling Operations	9015
10 LARGE SIZE SCHEMATICS	
Large size hydraulic schematics	84499648EN
Large size electrical schematics	84499647EN

NOTE: CNH France S.A. Company reserves the right to make changes in the specification and design of the machine without prior notice and without incurring any obligation to modify units previously sold.

The description of the models shown in this manual has been made in accordance with the technical specifications known as of the date of design of this document.

All data given in this manual is subject to production variations. Dimensions and weights are provided with approximate values and the machine fitting shown in the illustrations may not correspond with standard models. For precise information on specific machine models and versions, please contact your CASE dealer.

Reproduction or translation, even partial, is prohibited without written authorization from CNH France SA Company.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**



Section

1001

Safety, general information and standard torque data

CONTENTS

GENERAL INFORMATION.....	3
Safety.....	4
Bolt and Nut Tightening.....	6

Safety, general information and standard torque data

GENERAL INFORMATION

CLEANING

Clean all metal parts except bearings, in a suitable cleaning solvent or by steam cleaning.

Do not use caustic soda for steam cleaning.

After cleaning, dry and put oil on all parts.

Clean oil passages with compressed air.

Clean bearings in a suitable cleaning solvent, dry the bearings completely and put oil on the bearings.

INSPECTION

Check all parts when the parts are disassembled.

Replace all parts that have wear or damage.

Small scoring or grooves can be removed with a hone or crocus cloth.

Complete a visual inspection for indications of wear, pitting and the replacement of parts necessary to prevent early failures.

BEARINGS

Check bearings for easy action.

If bearings have a loose fit or rough action replace the bearing.

Wash bearings with a suitable cleaning solvent and permit to air dry.

DO NOT DRY BEARINGS WITH COMPRESSED AIR.

NEEDLE BEARINGS

Before you press needle bearings in a bore always remove any metal protrusions in the bore or edge of the bore.

Before you press bearings into position put petroleum jelly on the inside and outside diameter of the bearings.

GEARS

Check all gears for wear and damage.

Replace gears that have wear or damage.

Oil seals, O-rings and gaskets.

Always install new oil seals, O-rings and gaskets.

Put petroleum jelly on seals and O-rings.

SHAFTS

Check all shafts that have wear or damage.

Check the bearing and oil seal surfaces of the shafts for damage.

SERVICE PARTS

Always install genuine Case service parts.

When ordering refer to the

Parts Catalogue for the correct part number of the genuine Case replacement items.

Failures due to the use of other than genuine Case replacement parts are not covered by warranty.


LUBRICATION

Only use the oils and lubricants specified in the Operator's or Service Manuals.

Failures due to the use of non-specified oils and lubricants are not covered by warranty.

Safety, general information and standard torque data

Safety



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

To prevent injury always follow the Warning, Caution and Danger notes in this section and throughout the manual. Put the warning tag shown below on the key for the key switch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags are available from your service parts supplier.

⚠ WARNING

Read the operator's manual to familiarize yourself with the correct control functions.

⚠ WARNING

Operate the machine and equipment controls from the seat position only. Any other method could result in serious injury.

⚠ WARNING

This is a one man machine, no riders allowed.

⚠ WARNING

**Before starting engine, study Operator's Manual safety messages.
Read all safety signs on machine.
Clear the area of other persons.
Learn and practice safe use of controls before operating.
It is your responsibility to understand and follow manufacturers instructions on machine operation, service and to observe pertinent laws and regulations.
Operator's and Service Manuals may be obtained from your CASE dealer.**

⚠ WARNING

**If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured.
Always wear clothing that will not catch on objects.
Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.**

⚠ WARNING

When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.

⚠ WARNING

When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.

⚠ WARNING

When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way.

⚠ WARNING

Use insulated gloves or mittens when working with hot parts.

Safety, general information and standard torque data

⚠ WARNING

Lower all attachments to the ground or use stands to safely support the attachments before you do any maintenance or service.

⚠ WARNING

Pin sized and smaller streams of hydraulic oil under pressure can penetrate the skin and result in serious infection.

If hydraulic oil under pressure does penetrate the skin, seek medical treatment immediately.

Maintain all hoses and tubes in good condition.

Make sure all connections are tight.

Make a replacement of any tube or hose that is damaged or thought to be damaged.

DO NOT use your hand to check for leaks, use a piece of cardboard or wood.

⚠ WARNING

When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer.

⚠ WARNING

When using a hammer to remove and install pivot pins or separate parts using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors).

⚠ WARNING

Use suitable floor (service) jacks or chain hoist to raise wheels or tracks off the floor.
Always block machine in place with suitable safety stands.

⚠ WARNING

When servicing or repairing the machine, keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc.

Use an oil absorbing material and/or shop cloths as required.

Use safe practices at all times.

⚠ WARNING

Some components of this machine are very heavy.
Use suitable lifting equipment or additional help as instructed in this Service Manual.

⚠ WARNING

Engine exhaust fumes can cause death.

If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension.

Open the doors and get outside air into the area.

⚠ WARNING

When the battery electrolyte is frozen, the battery can explode if (1), you try to charge the battery, or (2), you try to jump start and run the engine.


To prevent the battery electrolyte from freezing, try to keep the battery at full charge.

If you do not follow these instructions, you or others in the area can be injured.

Safety, general information and standard torque data

Bolt and Nut Tightening

- Tighten alternating between left and right and top and bottom so that uniform tightening force is applied.



a96o6r-001

- If Loctite was used on a removed bolt (there is something white sticking to the bolt when it is removed), clean the old Loctite off with cleaning fluid, dry the bolt, then apply 2 - 3 drops of Loctite to the thread section of the bolt.

Torque table

Bolt nominal diameter (size)		M6	M8	M10	M12	M14	M16	M18	M20	
Hexagon bolt	Wrench	[mm]	10	13	17	19	22	24	27	30
	Tightening torque	[N · m]	6.9	19.6	39.2	58.8	98.1	156.9	196.1	294.2
Hexagon socket head bolt	Wrench	[mm]	5	6	8	10	12	14	14	17
	Tightening torque	[N · m]	8.8	21.6	42.1	78.5	117.7	176.5	245.2	343.2

Bolt nominal diameter (size)		M6	M8	M10	M12	M14	M16	M18	M20	
Hexagon bolt	Wrench	[in]	0.394	0.512	0.669	0.748	0.866	0.945	1.063	1.181
	Tightening torque	[lbf · ft]	5.090	14.459	28.917	43.376	72.367	115.743	144.661	217.028
Hexagon socket head bolt	Wrench	[in]	0.197	0.236	0.315	0.394	0.472	0.551	0.551	0.669
	Tightening torque	[lbf · ft]	6.492	15.934	217.028	57.909	86.826	130.202	180.881	253.175



Section

1002A

Specifications

CONTENTS

Overall (CX470C)	3
Main Data	3
Performance	3
Main Unit Dimensions	3
Engine	5
Cooling System	5
Upper Side Work System	5
Operating Device	6
Swing Units	7
Travel Lower Body	7
Hydraulic Equipment	8
Hydraulic Device	8
Control Valve, Cylinder	8
Capacities, Filters	8
Coolant and Oil Capacities	8
Hydraulic Oil Filters	8
Fuel Filter	9

Specifications

Overall (CX470C)

Main Data

Model name	CX470C Fixed Sideframe	CX470C Retractable frame	Side- MASS Excavator (Fixed Sideframe)	CX470C MASS Excavator (Retractable Side- frame)
Operating weight	47800 kg	49300 kg	48200 kg	49700 kg
Engine output	270 kW/2000 min ⁻¹			

Performance

	CX470C Fixed Sideframe	CX470C Retractable frame	Side- MASS Excavator (Fixed Sideframe)	CX470C MASS Excavator (Retractable Side- frame)
Standard weight	26.5 kN		37.1 kN	38.8 kN
Swing speed	9.1 min ⁻¹			
Travel speed	Low speed 3.2 km/h			
	High speed 5.3 km/h			
Maximum pulling force	340 kN			
Grade ability	70 % (35°)			
Ground pressure	82 kPa (600 mm grouser shoe)	84 kPa (600 mm grouser shoe)	83 kPa (600 mm grouser shoe)	85 kPa (600mm grouser shoe)
	67 kPa (750 mm grouser shoe)	69 kPa (750 mm grouser shoe)	67 kPa (750 mm grouser shoe)	69 kPa (750 mm grouser shoe)
	56 kPa (900 mm grouser shoe)	58 kPa (900 mm grouser shoe)	57 kPa (900 mm grouser shoe)	58 kPa (900 mm grouser shoe)

Main Unit Dimensions

	CX470C Fixed Sideframe	CX470C Retractable Sideframe	CX470C MASS Excavator (Fixed Side- frame)	CX470C MASS Excavator (Retractable Sideframe)
Main unit length	6445 mm			
Main unit width	3560 mm	3700 mm (maximum track retraction for transport = 3200 mm)	3560 mm	3700 mm (maximum track retraction for transport = 3200 mm)
Upper swing body width	3060 mm (3590 mm with catwalk)			
Cab width	1000 mm			
Main unit height	3440 mm	3590 mm	3440 mm	3590 mm
Swing radius (rear end)	3730 mm			
Swing body rear end distance	3720 mm			
Swing body rear section bottom height	1330 mm	1480 mm	1330 mm	1480 mm
Distance between tumblers	4400 mm			
Overall track length	5450 mm			
Overall track width	3350 mm	3490 mm (maximum track retraction for transport = 2990 mm)	3350 mm	3490 mm (maximum track retraction for transport = 2990 mm)

Specifications

	CX470C Fixed Sideframe	CX470C Retractable Sideframe	CX470C MASS Excavator (Fixed Side- frame)	CX470C MASS Excavator (Retractable Sideframe)
Distance between tracks	2750 mm	2890 mm (maximum track retraction for transport = 2390 mm)	2750 mm	2890 mm (maximum track retraction for transport = 2390 mm)
Track shoe width	600 mm (option 750 mm, 900 mm)			
Minimum ground clearance	540 mm (to bottom of lower frame)	740 mm (to bottom of lower frame)	540 mm (to bottom of lower frame)	740 mm (to bottom of lower frame)

Specifications

Engine

	CX470C Fixed Sideframe / CX470C Retractable (Sideframe) / CX470C MASS Excavator (Fixed Sideframe) / CX470C MASS Excavator (Retractable Sideframe)
Name	ISUZU 6UZ1X diesel engine
Model	4-cycle, water cooled, overhead camshaft type Common rail system (electronic control), cooled EGR, with turbocharger, DPD system
Number of cylinders - bore x stroke	6 - D120 mm x 145 mm
Total stroke volume	9.839 L
Maximum torque	1435 N•m/1500 min ⁻¹
Starter	24 V 5.5 kW Reduction type
Charging generator	24 V 50 A AC type
Battery	12 V 128 Ah/5 HR x 2

Cooling System

	CX470C Fixed Sideframe / CX470C Retractable (Sideframe) / CX470C MASS Excavator (Fixed Sideframe) / CX470C MASS Excavator (Retractable Sideframe)
Fan type	D1016 mm, 6 blades, suction
Radiator	
Fin type	Wavy
Fin pitch	1.75 mm
Oil cooler	
Fin type	Wavy
Fin pitch	1.75 mm
Inter cooler	
Fin type	Triangular straight
Fin pitch	2.0 mm
Fuel cooler	
Fin type	Wavy
Fin pitch	2.25 mm

Upper Side Work System

	CX470C Fixed Sideframe	CX470C Retractable Sideframe		CX470C MASS Ex- cavator (Fixed Side- frame)	CX470C MASS Ex- cavator (Re- tractable Side- frame)
Model	Backhoe attachment				
Components, dimensions, working dimensions					
Standard bucket capacity	Heaped 2.00 m ³ (leveled 1.47 m ³)			Heaped 3.0 m ³ (leveled 2.2 m ³)	
Bucket width	1530 mm			2020 mm	
Bucket width with side cutter	1640 mm			-	
Bucket weight with side cutter	1920 kg			2910 kg (no side cutter)	
Boom length	6980 mm			6550 mm	
Arm type	Standard (HD) (3.38 m)	Short (2.53 m)	Standard (HD) (3.38 m)	Short (2.53 m)	Short (2.53 m)
Arm length	3380 mm	2530 mm	3380 mm	2530 mm	2530 mm

Specifications

	CX470C Fixed Sideframe		CX470C Retractable Sideframe		CX470C MASS Ex- cavator (Fixed Side- frame)	CX470C MASS Ex- cavator (Re- tractable Side- frame)
Bucket radius	1840 mm				1850 mm	
Bucket wrist angle	176°				161°	
Maximum digging radius	12000 mm	11230 mm	12000 mm	11230 mm	10810 mm	
Maximum digging radius at ground line	11770 mm	10990 mm	11740 mm	10950 mm	10560 mm	10520 mm
Maximum digging depth	7720 mm	6870 mm	7570 mm	6720 mm	6490 mm	6340 mm
Maximum vertical straight wall digging depth	6570 mm	5670 mm	6420 mm	5520 mm	4920 mm	4770 mm
Maximum digging height	11140 mm	10820 mm	11290 mm	10970 mm	10520 mm	10670 mm
Maximum dump height	7740 mm	7420 mm	7890 mm	7570 mm	7180 mm	7340 mm
Minimum swing radius at front	4990 mm	5140 mm	4990 mm	5130 mm	4800 mm	4800 mm
Height for minimum swing radius at front	9250 mm	9320 mm	9400 mm	9470 mm	9050 mm	9200 mm

Operating Device

		CX470C Fixed Sideframe / CX470C Retractable Sideframe / CX470C MASS Excavator (Fixed Sideframe) / CX470C MASS Excavator (Retractable Sideframe)
Operator's seat		
Position		Left side
Structure		Adjustable forward and back and up and down, reclining mechanism, with seat suspension
Cab		Sealed steel type, all reinforced glass, ROPS, with sun-roof
Levers and pedals		
For travel use		Lever and pedal type (hydraulic pilot type) × 2
For operating machine use		Lever type (hydraulic pilot type) × 2
Instruments and switches		
Work mode switchover		3 modes (SP/H/A)
Travel mode switchover		Low-speed/high-speed switch type
One-touch idle		Knob switch type
Engine emergency stop		Switch type
Monitor device		
Machine status display (TFT color liquid crystal)		
Message display		
Work mode select status		SP/H/A
Instruments		
Fuel gauge		
Engine coolant temperature gauge		
Hydraulic oil temperature gauge		
Hour meter		
Rear view camera monitor		
Warning display and warning alarm * has warning alarm		
Overheat (*) Battery charge (*) Electrical system abnormality (*) Refill fuel (*) Engine oil pressure (*) Refill coolant (*) Engine pre-heat Warm up Air cleaner (*) Anti-theft device triggered Engine system abnormality (*) Engine emergency stop (*)		
Illumination equipment		
Working light	Right front tool box front surface:	24 V 70 W × 1
	Cab top:	24 V 70 W × 2
	Boom side:	24 V 70 W × 2