

SERVICE REPAIR

MANUAL

Hyster B219 (E30HSD2, E35HSD2, E40HSD2) Forklift


HYSTER

USER INTERFACE

**SERVICE-LEVEL FUNCTIONS
ON-BOARD DASH DISPLAY**

⇒S/N B219N02184L

**E30HSD₂, E35HSD₂, E40HSD₂
[B219]**



HYSTER

SAFETY PRECAUTIONS

MAINTENANCE AND REPAIR

- The Service Manuals are updated on a regular basis, but may not reflect recent design changes to the product. Updated technical service information may be available from your local authorized Hyster® dealer. Service Manuals provide general guidelines for maintenance and service and are intended for use by trained and experienced technicians. Failure to properly maintain equipment or to follow instructions contained in the Service Manual could result in damage to the products, personal injury, property damage or death.
- When lifting parts or assemblies, make sure all slings, chains, or cables are correctly fastened, and that the load being lifted is balanced. Make sure the crane, cables, and chains have the capacity to support the weight of the load.
- Do not lift heavy parts by hand, use a lifting mechanism.
- Wear safety glasses.
- **DISCONNECT THE BATTERY CONNECTOR** before doing any maintenance or repair on electric lift trucks. Disconnect the battery ground cable on internal combustion lift trucks.
- Always use correct blocks to prevent the unit from rolling or falling. See **HOW TO PUT THE LIFT TRUCK ON BLOCKS** in the **Operating Manual** or the **Periodic Maintenance** section.
- Keep the unit clean and the working area clean and orderly.
- Use the correct tools for the job.
- Keep the tools clean and in good condition.
- Always use **HYSTER APPROVED** parts when making repairs. Replacement parts must meet or exceed the specifications of the original equipment manufacturer.
- Make sure all nuts, bolts, snap rings, and other fastening devices are removed before using force to remove parts.
- Always fasten a **DO NOT OPERATE** tag to the controls of the unit when making repairs, or if the unit needs repairs.
- Be sure to follow the **WARNING** and **CAUTION** notes in the instructions.
- Gasoline, Liquid Petroleum Gas (LPG), Compressed Natural Gas (CNG), and Diesel fuel are flammable. Be sure to follow the necessary safety precautions when handling these fuels and when working on these fuel systems.
- Batteries generate flammable gas when they are being charged. Keep fire and sparks away from the area. Make sure the area is well ventilated.

NOTE: The following symbols and words indicate safety information in this manual:



WARNING

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury and property damage.

On the lift truck, the WARNING symbol and word are on orange background. The CAUTION symbol and word are on yellow background.

TABLE OF CONTENTS

General	1
Description	1
Button Keypad.....	1
LED Indicator Lights	1
LCD Screen.....	1
Dash Display Menu Access	2
Menu Navigation	2
Service-Level Menu.....	5
View Hour Meters.....	6
Truck Hours.....	6
Pump Hours.....	6
Tract Hours.....	7
Software Version	7
Master	8
Slave.....	8
Display	8
Pump	8
Password	9
Add Password	9
Delete Password	10
Edit Password.....	10
Operator Passw	11
Clear Oper Log	11
Diagnostic.....	11
Error Log.....	12
Run Diagnostics.....	12
Left Traction Motor Speed.....	13
Left Traction Motor Current	13
Left Traction Motor Temp	13
Left Traction Controller Temp	13
Right Traction Motor Speed	14
Right Traction Motor Current.....	14
Right Traction Motor Temp.....	14
Right Traction Controller Temp.....	14
Steer Position	14
Pump Motor Speed.....	14
Pump Motor Current	15
Pump Motor Temp	15
Pump Controller Temp	15
No Run Diagnostics.....	15
Brake Switch	16
Mast Proximity Switch	16
Horn Switch - Joystick.....	16
Tilt Up Switch - Joystick	16
Tilt Down Switch - Joystick.....	17
Shift Right Switch - Joystick.....	17
Shift Left Switch - Joystick	17
4th-Aux In Switch - Joystick	17
4th-Aux Out Switch - Joystick.....	17
Traction - Joystick.....	17
Lift / Lower - Joystick	18

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

TABLE OF CONTENTS (Continued)

Setup	18
Traction Settings	18
Top Speed Forward	19
Top Speed Reverse	19
Acceleration (Modes 1 through 4)	19
Auto Deceleration	20
Plugging Deceleration	20
Steering Calibration	20
Hydraulic Settings	21
Lift Acceleration	22
Max Lift Speed	23
Max Lower Speed	23
Tilt Speed Free	23
Tilt Speed Main	23
Tilt Valve Acceleration	24
Tilt Valve Deceleration	24
Hydraulic Motor Deceleration	24
Side Shift Speed	24
4th Aux Speed In	25
4th Aux Speed Out	25
4th Aux Type	25
Truck Settings	26
Serial Number	28
Battery Type	28
BDI Max Adjust	28
BDI Min Adjust	28
BDI Adjust Startup	29
BDI Delta Reset	29
Lift Interrupt	29
Motion Alarms (Audible or Visible)	30
Travel Speed Reduction	30
Lift Limit Override	30
Service Reminder	31
Truck Inspection	31
Simultaneity	31
Restore Defaults	31
Speed Unit	32
Temp Unit	32

This section is for the following models:

E30HSD₂, E35HSD₂, E40HSD₂ [B219]

General

DESCRIPTION

This topic describes the functions of the display panel that are available to the service technician. With a proper Service-level password, a service technician can access menu items that are not visible at Operator or Supervisor-level access.

NOTE: Some menu functions can only be accessed through the dash display by using a Service-level password. These functions include truck speed settings, acceleration rates, and audible/visual alarm settings.

NOTE: The initial setup of the Supervisor password must be performed by a service technician accessing the menu system with a Service-level password. The Supervisor password must be set up before a supervisor can access the menu functions. The default Service-level password as shipped from the factory is 55555. This should be changed to a different number by the technician during initial setup.

The dash display is a multifunction device. It contains a button keypad, a series of LED indicator lights, and an LCD screen. See Figure 1.




Figure 1. Dash Display

Button Keypad

The button keypad is located on the right side of the display. It consists of four buttons arranged in a circle with a fifth button in the center. The buttons are numbered 1 through 5, starting with button 1 at the top and continuing clockwise and ending with button 5 situated in the center of the keypad.

LED Indicator Lights

The LED indicator lights are located on the display below the LCD screen and to the left of the button keypad. The lights illuminate to notify the operator of certain conditions. The function of each light (in order from left to right) is as follows:

- Battery
- Wrench
- Thermometer
- Operator Pedal
- Optional

LCD Screen

The LCD screen displays the following when the key is ON:

1. Battery Charge Indicator
2. Turtle Mode Indicator
3. Hourmeter (Tenths)
4. Hourmeter (Hours)
5. Throttle Command
6. Actual Speed
7. Steer Tire Position
8. Run Direction
9. Performance Mode Indicator


DASH DISPLAY MENU ACCESS

To access the dash display menu system:

1. Turn the key or keyless switch to the **ON** position.
2. Depress the center button (#5) on the display two times.
3. The Enter Password screen will now appear on the LCD. Enter your five-digit Service-level password. The factory default Service-level password is 55555.

To enter your password at the ENTER PASSWORD screen, enter the appropriate digit in the highlighted area of the display. Use the appropriate button on the display keypad to enter any digit between 1 and 5. The cursor will automatically move to the next position after a number has been entered. Repeat until all five digits of your password have been entered. Upon successful entry of your Service-level

password, the display will enter the Service menu system. If an incorrect password is entered, the display will ask for the password to be entered again. The menu system can be exited at any time by pressing the **LEFT** (#4) button repeatedly.



Menu Navigation

NOTE: The display menus are revolving and will repeat when you scroll beyond the last menu item.

Upon successful entry of your Service-level password, the Service menu screen will appear on the dash display LCD screen. See Figure 2 for lift trucks equipped with Display Software v3.0. See Figure 3 for lift trucks equipped with Display Software v3.02. Menu navigation is accomplished by using the display buttons. From inside the menu, the buttons function as follows:

1. **UP** - Scroll up within a menu, or increase the value of a setting when making a parameter adjustment.
2. **RIGHT** - Scroll right within a menu. Will move you into the next submenu or activate the highlighted parameter to allow parameter value adjustments.
3. **DOWN** - Scroll down within a menu, or decrease the value of a setting when making a parameter adjustment.
4. **LEFT** - Scroll left within a menu. Will move you to the previous menu when depressed. Press repeatedly to exit the menu system.
5. **ENTER** - Press to accept parameter value adjustments. Press twice to access the Enter Password screen.




Figure 2. Menu Navigation Flowchart (Display Software v3.0)





Figure 3. Menu Navigation Flowchart (Display Software v3.02)

Service-Level Menu

The Service-Level menu allows a service technician access to the dash display menu system to troubleshoot or adjust truck systems and settings. With a proper Service-level password, a service technician can access menu items that are not visible at Operator or Supervisor-level access. See Table 1. At the Service-Level Menu, the following submenu choices are available:

- VIEW HOURMETERS
- SOFTWARE VERSIONS
- PASSWORD
- DIAGNOSTIC
- SET UP
- VIEW OPERAT LOG


Table 1. Service-Level Menu



VIEW HOUR METERS


Hour meter data is incrementally stored in the display during operation and the data is recorded in the RH Traction controller every 6 minutes. If there is a loss of power, data is not lost. At every key on, the display hours synchronize with the master. Within the VIEW HOUR METERS menu you can view the three different hour meter functions. See Table 2. Scroll through the VIEW HOUR METERS menu using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.

Table 2. View Hour Meters Menu




Truck Hours

The TRUCK HOURS hour meter accumulates time when the key is ON and the brake pedal is DOWN. This hour meter is secure and cannot be reset manually.




Pump Hours

The PUMP HOURS hour meter shows the accumulated time for operation of any hydraulic function, including lowering.



Tract Hours


The TRACT HOURS hour meter shows the accumulated time for all traction motor activity.



SOFTWARE VERSION


Within the SOFTWARE VERSION menu, you can view the software version number for the RH Traction Controller (Master), LH Traction Controller (Slave), Dash Display, and Pump Controller. See Table 3. Scroll through the SOFTWARE VERSION menu using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.

Table 3. Software Version Menu




Master

MASTER shows the revision level of the software currently installed on the RH Traction controller.



Display


DISPLAY shows the revision level of the software currently installed on the Dash Display.



Slave


NOTE: The master and slave controllers should always have the same software version. If not, contact Resident Service Engineering through the Contact Management System.

SLAVE shows the revision level of the software currently installed on the LH Traction controller.



Pump


PUMP shows the revision level of the software currently installed on the Pump Motor controller.



PASSWORD

The passwords are stored in a directory which can be accessed from this menu. The service technician can add, edit, or delete supervisor or operator passwords and clear the operator log from this menu. See Table 4. Scroll through the PASSWORD menu using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.

Table 4. Password Menu




- **Password** - In the password display, you are allowed a five digit password utilizing the numbers 1 through 5 (zero is not a valid number). Values between 11111 and 55555 are valid.

- **Alphanumeric Name** - In the password display, you are allowed characters to insert a name. All characters and numbers are allowed. Use the UP (#1) and DOWN (#3) buttons to scroll through the characters and press the Enter (#5) button to enter the desired selection.
- **Mode Limit** - For each password, you can set the maximum performance mode allowed. This is set under the "M" character of the password display. The number correlates directly to the performance modes 1 through 4.
- **User Type** - For each password, you can set the access level or "User Type" under the "V" character. The "O" is selected for operator, the "S" for supervisor, and the "T" for service technician.


Add Password

Use this menu to add operator, supervisor, or technician passwords. To enter a new password at the ADD PASSWORD screen, enter the password to be added and press enter to activate.




Delete Password

Use this menu to delete operator or supervisor passwords. To delete a password at the DELETE PASSWORD screen, enter the password to be deleted and press enter to finalize.




Edit Password

Use this menu to edit operator or supervisor passwords. To edit a password at the EDIT PASSWORD screen, enter the password to be edited and press enter to select. Change the password and press enter to select.




Operator Passw

Use this screen to turn the operator password feature ON or OFF.



Clear Oper Log


Use this screen to clear all stored information from the operator log.



DIAGNOSTIC


The DIAGNOSTIC MENU allows the service technician to view the ERROR LOG, and to enter submenus for RUN DIAGNOSTICS and NO RUN DIAGNOSTICS. See Table 5. Scroll through the DIAGNOSTIC menu using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.

Table 5. Diagnostic Menu



Error Log

The ERROR LOG keeps record of fault codes as they occur. The code number, occurrence, and hour meter time are displayed for each event. Scroll through the ERROR LOG using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.



Run Diagnostics

The RUN DIAGNOSTICS menu allows the service technician to view data from truck components while the truck is operating. See Table 6. Scroll through the RUN DIAGNOSTICS menu using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.

Table 6. Run Diagnostics Menu




Table 6. Run Diagnostics Menu (Continued)







Table 6. Run Diagnostics Menu (Continued)




Left Traction Motor Speed




Left Traction Motor Current




Left Traction Motor Temp




Left Traction Controller Temp




Right Traction Motor Speed




Right Traction Controller Temp




Right Traction Motor Current




Steer Position




Right Traction Motor Temp




Pump Motor Speed




Pump Motor Current



Pump Motor Temp



Pump Controller Temp



No Run Diagnostics

The NO RUN DIAGNOSTICS menu allows the service technician to view data from truck components while the truck is not operating. The truck is disabled while the NO RUN DIAGNOSTICS menu is activated. All joystick commands can be viewed through the display, as well as brake pedal switch, and mast proximity switch (if equipped). See Table 7. Scroll through the NO RUN DIAGNOSTICS menu using the UP (#1) and DOWN (#3) buttons and press the RIGHT (#2) button to enter the desired selection. Press the LEFT (#4) button to return to the previous menu.

Table 7. No Run Diagnostics Menu

