

# **SERVICE REPAIR**


# **MANUAL**

Hyster N005 (H80FT, H90FT, H100FT, H110FT, H120FT)  
Forklift Service Repair Manual

**HYSTER**

# **PERIODIC MAINTENANCE**

**S80, 100, 120FT; S80, 100FTBCS; S120FTS;  
S120FTPRS [G004];  
H80, 90, 100, 110, 120FT [N005, P005]**



# **HYSTER**

# **SAFETY PRECAUTIONS**

## **MAINTENANCE AND REPAIR**

- The Service Manuals are updated on a regular basis, but may not reflect recent design changes to the product. Updated technical service information may be available from your local authorized Hyster® dealer. Service Manuals provide general guidelines for maintenance and service and are intended for use by trained and experienced technicians. Failure to properly maintain equipment or to follow instructions contained in the Service Manual could result in damage to the products, personal injury, property damage or death.
- When lifting parts or assemblies, make sure all slings, chains, or cables are correctly fastened, and that the load being lifted is balanced. Make sure the crane, cables, and chains have the capacity to support the weight of the load.
- Do not lift heavy parts by hand, use a lifting mechanism.
- Wear safety glasses.
- DISCONNECT THE BATTERY CONNECTOR before doing any maintenance or repair on electric lift trucks. Disconnect the battery ground cable on internal combustion lift trucks.
- Always use correct blocks to prevent the unit from rolling or falling. See HOW TO PUT THE LIFT TRUCK ON BLOCKS in the **Operating Manual** or the **Periodic Maintenance** section.
- Keep the unit clean and the working area clean and orderly.
- Use the correct tools for the job.
- Keep the tools clean and in good condition.
- Always use **HYSTER APPROVED** parts when making repairs. Replacement parts must meet or exceed the specifications of the original equipment manufacturer.
- Make sure all nuts, bolts, snap rings, and other fastening devices are removed before using force to remove parts.
- Always fasten a DO NOT OPERATE tag to the controls of the unit when making repairs, or if the unit needs repairs.
- Be sure to follow the **WARNING** and **CAUTION** notes in the instructions.
- Gasoline, Liquid Petroleum Gas (LPG), Compressed Natural Gas (CNG), and Diesel fuel are flammable. Be sure to follow the necessary safety precautions when handling these fuels and when working on these fuel systems.
- Batteries generate flammable gas when they are being charged. Keep fire and sparks away from the area. Make sure the area is well ventilated.

**NOTE:** The following symbols and words indicate safety information in this manual:



### **WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



### **CAUTION**

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury and property damage.

On the lift truck, the **WARNING** symbol and word are on orange background. The **CAUTION** symbol and word are on yellow background.

## TABLE OF CONTENTS

General .....	1
Serial Number Data .....	1
How to Move Disabled Lift Truck .....	2
How to Tow Lift Truck .....	2
How to Put Lift Truck on Blocks .....	2
How to Raise Drive Tires .....	2
How to Raise Steering Tires .....	3
How to Clean a Lift Truck .....	4
Maintenance Schedule .....	4
Maintenance Procedures Every 8 Hours or Daily .....	21
How to Make Checks With Engine Stopped .....	21
Tires and Wheels .....	21
Safety Labels .....	22
Mast, Carriage, Lift Chains, Header Hoses, Attachment .....	22
Operator Restraint System .....	23
Emergency Locking Retractor (ELR) .....	23
Adjust Seat - Full Suspension .....	25
Adjust Seat - Internal Suspension .....	26
Hood and Seat Latches .....	27
Engine Compartment .....	27
Paper Application .....	27
Fuel, Oil, and Coolant Leaks, Check .....	28
Hydraulic Hoses .....	28
Coolant Hoses .....	28
Steering Column Gas Cylinder .....	28
Transmission .....	28
Hydraulic System Oil .....	29
Engine Oil .....	29
Air Filter .....	29
Forks .....	29
Remove .....	29
Inspect .....	31
Install .....	33
Adjust .....	33
Forks .....	33
Remove .....	33
Inspect .....	34
How to Make Checks With Engine Running .....	34
Indicator Lights, Horn, Fuses, and Relays .....	34
Service Brakes .....	36
Brake Fluid Level .....	36
Operation, Check .....	37
Parking Brake .....	37
Engine Oil Pressure .....	37
Cooling System .....	38
Steering System .....	39
Control Levers and Pedals .....	39
Lift System, Operate .....	39
First Service After First 100 Hours of Operation .....	40
PSI 2.0L LPG Engine Oil and Oil Filter .....	40

## Table of Contents

### TABLE OF CONTENTS (Continued)

Maintenance Procedures Every 250 Hours or 6 Months .....	40
Mazda and Kubota Engine Oil and Oil Filter .....	40
Drain Tar From LPG Converter .....	41
Maintenance Procedures Every 500 Hours or 6 Months .....	42
Hydraulic System Oil .....	42
Hydraulic Tank Breather .....	42
Inspect .....	42
Battery .....	43
Cummins 4.5L and QSB 3.3L Engine Oil and Oil Filter .....	43
Fuel/Water Separator Filter Replacement, Cummins 4.5L and QSB 3.3L Engine .....	44
Remove .....	45
Install .....	45
Final Fuel Filter Replacement (Cummins QSB 3.3L Engine) .....	48
Priming the Fuel System (Cummins 4.5L and QSB 3.3L Engine) .....	49
Controlled Venting .....	49
Manual Bleeding .....	49
Drive Belt .....	50
Cummins 4.5L and QSB 3.3L Diesel Engine .....	50
Fan and Alternator Drive Belt .....	50
Clean Debris From Radiator Core .....	51
Transmission Oil Level .....	51
Wet Brake Center Body Oil Level Check .....	53
Forks .....	54
Mast Lubrication .....	54
Header Hose Checks .....	58
Lift Chain Lubrication .....	58
Tilt Cylinder Lubrication .....	59
Master Brake Cylinder Rod End Pin Lubrication .....	60
Manual Hydraulic Levers Lubrication .....	60
Brake Oil .....	60
Tie Rod Lubrication for Lift Truck Models S80, 100, 120FT; S80, 100FTBCS; S120FTS; S120FTPERS (G004).....	61
Tie Rod Lubrication for Lift Truck Models H80, 90, 100, 110, 120FT (N005, P005).....	61
Differential and Drive Axle Oil, Lift Truck Models With Dry Brakes .....	62
Parking Brake Adjustment .....	63
Maintenance Procedures Every 1000 Hours or 6 Months .....	64
Valve Clearance, Check and Adjust .....	64
Ignition System .....	64
GM 4.3L Engine .....	64
LPG Fuel Filter Element Replace, Engine GM 4.3L.....	64
Remove .....	64
Install .....	65
In-Line Filter Replacement, Cummins 4.5L Engine .....	65
Remove .....	65
Install .....	65
Lift Chains Wear Check .....	67
Lift Chain Lubrication .....	67
Integral Sideshift Carriage, Check Sliding Surfaces .....	67
Steering Axle (Spindle Bearings) for Lift Truck Models S80, 100, 120FT; S80, 100FTBCS; S120FTS; S120FTPERS (G004).....	68

**Thanks very much for your reading,**  
**Want to get more information,**  
**Please click here, Then get the complete**  
**manual**

**JustClickHere** 

**NOTE:**

**If there is no response to click on the link above,  
please download the PDF document first, and then  
click on it.**

**Have any questions please write to me:  
[admin@servicemanualperfect.com](mailto:admin@servicemanualperfect.com)**

## TABLE OF CONTENTS (Continued)

Steering Axle (Spindle Bearings) for Lift Truck Models H80, 90, 100, 110, 120FT (N005, P005).....	68
Control Levers and Pedals .....	69
Parking Brake Lever Lubrication, Wet Brake Axle .....	69
Normal Operating Environment .....	69
Heavy Duty or Contaminated Environment .....	70
Remove .....	70
Clean and Inspect .....	71
Install .....	71
Inspect Engine Electrical System, Connectors .....	72
Maintenance Procedures Every 2000 Hours or Annually .....	72
Hydraulic System .....	72
Hydraulic Filter, Replace .....	72
Hydraulic Tank Breather, Replace .....	74
Ignition System; Distributor Cap, Rotor, and Spark Plug Wires .....	74
Cooling System .....	74
Air Filter .....	75
Oxygen Sensor GM 4.3L LPG Engines with GFI Installed.....	76
LPG Regulator Fuel Filter, GM 4.3L Engines With GFI Installed.....	77
Remove .....	77
Install .....	78
Gasoline Fuel Filter .....	79
Remove and Replace for Lift Trucks Equipped with GFI .....	79
Remove and Replace for Lift Trucks Equipped with PSI .....	79
LPG Fuel Injector, GM 4.3L Engines With GFI Installed.....	80
Gasoline Fuel Injector, GM Engines .....	80
Fuel Injector, Cummins 4.5L and QSB 3.3L Engine .....	80
Forks .....	80
Transmission Oil and Filter (Dry Brake), Replace .....	81
Transmission and Wet Brake Planetary Carrier Housing Oil Change .....	82
Wet Brake Center Section Oil Change .....	85
Remove .....	85
Install .....	85
Brake Oil (Master Cylinder), Change .....	86
Brake Oil (Dry Brake), Remove .....	87
Service Brakes (Dry Brake) .....	87
Differential (Dry Brake) .....	88
Test LPG/GAS Regulator Pressure .....	88
Test LPG Regulator Pressure .....	88
Check Throttle Shaft for Sticking .....	89
Inspect Exhaust Manifold and Piping for Leaks .....	89
Valve Clearance, Check and Adjust for Cummins QSB 3.3L Diesel Engine .....	89
Wheel Bearings .....	90
Steer Wheels, Lubrication .....	90
Maintenance Procedures Every 4000 Hours or 2 Years .....	91
Hydraulic Oil, Replace .....	91
Valve Clearance, Check and Adjust for Cummins 4.5L Diesel Engine .....	92
Weld Inspection .....	94
Safety Procedures When Working Near Mast .....	97
Fuel Filter Water Removal .....	99
Hood Latch Check .....	99

## Table of Contents

### TABLE OF CONTENTS (Continued)

Lift Chain Adjustments .....	100
Jump-Starting the Lift Truck .....	102
Jump-Starting Using a Battery Charger .....	102
Jump-Starting a Lift Truck Using Another Lift Truck .....	102
Welding Repairs .....	102
Overhead Guard Changes .....	103
Wheel and Tire Replacement .....	103
General .....	103
Solid Rubber Tire, Change (Series) S.....	103
Remove and Install Tire on Wheel .....	103
Pneumatic Tire With Tube, Repair .....	104
Remove Wheels From Lift Truck .....	104
Remove Tire From Wheel .....	105
Remove Tire From Two-Piece Wheel .....	105
Remove Tire From Three- and Four-Piece Wheels .....	106
Install Wheel in Tire .....	107
Install Three-Piece or Four-Piece Wheel in Tire .....	108
Install Tire on Two-Piece Wheel .....	109
Install Two-Piece Wheel in Tire .....	110
Add Air to Pneumatic Tires With Tube .....	110
Install the Wheels .....	111
Dual Drive Wheels, Install .....	111
Pneumatic Tubeless Tire, Repair .....	112
Remove Wheels From Lift Truck .....	112
Remove Tire From Wheel .....	112
Install Tire on Wheel .....	114
Add Air to Pneumatic Tubeless Tire .....	117
Wheels, Install .....	117
Solid Rubber Tires on Pneumatic Wheels, Change .....	117
Remove Tire From Wheel .....	118
Install Tire on Wheel .....	119
Adhesives and Sealants .....	121

This section is for the following models:

(S80, 100, 120FT; S80, 100FTBCS; S120FTS; S120FTPRS) [G004];  
(H80, 90, 100, 110, 120FT) [N005, P005]

## General



### WARNING

**DO NOT make repairs or adjustments unless you have both authorization and training. Repairs and adjustments that are not correct can make a dangerous operating condition.**



### WARNING

**DO NOT operate a lift truck that needs repairs. Report the need for repairs immediately. If repair is necessary, put a DO NOT OPERATE tag in the operator's area. Remove the key from the key switch.**



### CAUTION

**Disposal of lubricants and fluids must meet local environmental regulations.**

This section contains a **Maintenance Schedule** and instructions for maintenance and inspection.

The **Maintenance Schedule** has time intervals for inspection, lubrication, and maintenance of your lift truck. The service intervals are provided in both operating hours recorded on the lift truck hourmeter and in calendar time. The recommendation is to use the interval that comes first.

The recommendations for the time intervals provided is for eight hours of operation per day. The time intervals must be decreased from the recommendations in the **Maintenance Schedule** for the following conditions:

- The lift truck is used more than eight hours per day.
- The lift truck must work in dirty operating conditions.
- Poor ground conditions.
- Intensive usage at high performance levels or other abnormal conditions will require more frequent servicing.

Your dealer for Hyster lift trucks has the equipment and trained service personnel to do a complete program of inspection, lubrication, and maintenance. A regular program of inspection, lubrication, and maintenance will help your lift truck provide more efficient performance and operate for a longer period of time.

Some users have service personnel and equipment to do the inspection, lubrication, and maintenance shown in the **Maintenance Schedule**. Service manuals are available from your dealer for Hyster lift trucks to help users who do their own maintenance.

## SERIAL NUMBER DATA

The serial number for the lift truck is on the Nameplate. It is also on the right side of the frame, under the floor plate.

## HOW TO MOVE DISABLED LIFT TRUCK

### How to Tow Lift Truck

#### **WARNING**

**Use extra caution when towing a lift truck if any of the following conditions exist:**

- Brakes do not operate correctly.
- Steering does not operate correctly.
- Tires are damaged.
- Traction conditions are bad.
- The lift truck must be towed on a slope.

If the engine cannot run, there is no power available for the hydraulic steering system and the service brakes. This condition can make the lift truck difficult to steer and stop. If the lift truck uses power from the engine to help apply the brakes, the application of the brakes will be more difficult. Poor traction can cause the disabled lift truck or towing vehicle to slide. A slope will also make the lift truck more difficult to stop.

Never lift and move a disabled lift truck unless the disabled lift truck **MUST** be moved and cannot be towed. A lift truck used to move a disabled lift truck **MUST** have a capacity rating equal to or greater than the weight of the disabled lift truck. The capacity of the lift truck used to move a disabled lift truck must have a load center equal to half the width of the disabled lift truck. See the Nameplate of the disabled lift truck for the approximate total weight. The forks must extend the full width of the disabled lift truck. Put the weight center of the disabled lift truck on load center of the forks. Be careful to not damage the underside of the lift truck.

1. The towed lift truck must have an operator.
2. Tow truck slowly.

3. Using a lift truck or a lifting device that could be attached to the mast (I.E. come-a-long), raise carriage and forks approximately 30 cm (12 in.) from surface. Install chain around a mast crossmember and carriage to prevent carriage and mast channels from moving.

4. If another lift truck is used to tow the disabled lift truck, that lift truck must have an equal or larger capacity than the disabled lift truck. Install approximately 1/2 of a capacity load on forks of lift truck that is being used to tow disabled lift truck. This 1/2 capacity load will increase traction of lift truck. Keep load as low as possible.

## HOW TO PUT LIFT TRUCK ON BLOCKS

### How to Raise Drive Tires

#### **WARNING**

The lift truck must be put on blocks for some types of maintenance and repair. The removal of the following assemblies will cause large changes in the center of gravity: mast, drive axle, engine, transmission, and counterweight. When the lift truck is put on blocks, put additional blocks in the following positions to maintain stability:

- Before removing the mast and drive axle, put blocks under the counterweight so the lift truck cannot fall backward.
- Before removing the counterweight, put blocks under the mast assembly so the lift truck cannot fall forward.

The surface must be solid, even, and level when the lift truck is put on blocks. Make sure any blocks used to support the lift truck are solid, one-piece units.

**CAUTION**


**These lift trucks are equipped with cowl lifting eyes. The cowl lifting eyes are to be used to lift the front of the lift truck only. Lifting more than the front of the lift truck with the cowl lifting eyes will damage the cowl section.**

1. Put blocks on each side (front and back) of steering tires to prevent movement of lift truck. See Figure 1.
2. Put mast in vertical position. Put a block under each outer mast channel.
3. Tilt mast fully forward until drive tires are raised from surface.
4. Put additional blocks under frame behind drive tires.
5. If hydraulic system will not operate, use a hydraulic jack under the side of the frame near the front. Make sure jack has a capacity equal to at least half the weight of the lift truck. See Nameplate.

**How to Raise Steering Tires**

**NOTE:** Some lift trucks are equipped with lifting eyes for the purpose of lifting the entire lift truck. If lift truck is equipped with these type of lifting eyes, the lift truck can be lifted and blocks installed.

1. Apply parking brake. Put blocks on both sides (front and back) of drive tires to prevent movement of lift truck. See Figure 1.
2. Use hydraulic jack to raise steering tires. Make sure jack has a capacity of at least 2/3 of total weight of lift truck as shown on the Nameplate.
3. Put jack under steering axle or frame to raise lift truck. Put blocks under frame to support lift truck.



1. DRIVE TIRES

2. STEERING TIRES

*Figure 1. Put Lift Truck on Blocks*

## HOW TO CLEAN A LIFT TRUCK



### WARNING

**Engine, exhaust system components and other components are hot to the touch. Be sure lift truck components are cool before starting inspection and cleaning, or personal injury may occur.**



### WARNING

**Compressed air can move particles so that they cause injury to the user or to other personnel. Make sure that the path of the compressed air is away from all personnel. Wear protective goggles or a face shield to prevent injury to the eyes.**



### CAUTION

**Units may be washed with a non-heated pressure washer. Steam cleaning is not recommended in most instances, as condensation may form in electrical components causing damage or erratic behavior.**

**NOTE:** Lift trucks used in paper applications may need cleaning beyond what is described here. Please refer to Paper Application section in the applicable **Operating Manual** and to available Service Gram/Bulletin for more detail.

If it becomes necessary to clean the fork lift, follow the guidelines listed below.

1. Assure truck components are cool before starting the cleaning procedure.
2. Disconnect the battery. If an electric truck, remove the traction battery.
3. Remove accumulated debris using a compressed air line and nozzle.

4. Lightly spray a non-corrosive cleaning agent onto the areas to be cleaned. This will help loosen grime, so close contact direct spraying will not be necessary.
5. Be sure to avoid directing the spray into electrical panel compartment. Ensure overspray does not come in contact with electrical components; do not spray water directly at electrical components, wiring connectors or electrical enclosures. Even sealed connectors may allow water egress under pressure or if connector is damaged.
6. Avoid spraying in areas containing electrical components such as:
  - Floor Plates
  - Battery Compartment
  - Dash/cowl assembly
  - Armrests with electrical components
7. Clean the battery compartment by using a clean cloth to wash the battery with water. Dry with compressed air. Care should be taken to keep moisture at a minimum as some units have a traction or hydraulic motor directly below the battery compartment.
8. DO NOT pressure wash the battery. Do not use hot water. For cleaning traction batteries, refer to the Battery section of the **Service Manual**.
9. DO NOT pressure wash lift chains, sheaves or load rollers in the mast assembly. Refer to the Chains, Sheaves and Load Rollers maintenance section in the **Service Manual** for proper cleaning procedures.
10. After cleaning, immediately start and run the lift truck to dry out components.

## Maintenance Schedule

**NOTE:** The lift trucks shown in Figure 2 and Figure 3, represent all lift trucks covered in this manual that are equipped with a GM 4.3L LPG engine.

**NOTE:** The 250-hour, 500-hour, and 1000-hour/6-month maintenance services are performed either at the specified hours or at 6 months whichever occurs first.





Figure 2. GM 4.3L LPG Trucks With GFI Installed



BM211024

Figure 3. GM 4.3L LPG Trucks With PSI Installed





Figure 4. GM 4.3L Gasoline Trucks With GFI Installed for Lift Truck Models S80, 100, 120FT; S80, 100FTBCS; S120FTS; S120FTPMS (G004)



BM210582

Figure 5. Cummins QSB 3.3L Diesel for Lift Truck Models H80, 90, 100, 110, 120FT (P005)

**Table 1. Maintenance Schedule**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
25	Tires and Wheels	X						Check Condition	See Nameplate
	Safety Labels	X						Replace as Necessary	See Parts Manual
28, 29	Mast, Carriage, Header Hoses, Lift Chains, Attachment	X						Check Condition and Lubrication	See Parts Manual
	Seat Belt, Hip Restraints, and Seat Rails	X						Check Condition and Operation	
	Hood and Seat Latches	X						Check Condition and Operation	
	Engine Compartment	X						Remove Combustible Materials See NOTE 5.	
	Paper Application: Engine Compartment, Truck Components, Exhaust Wraps, Radiator, Radiator Screen if equipped, Belly Pan if equipped	X						Check Condition. Clean as Required, Replace as Required See NOTE 8.	
	Check for Leaks - Fuel, Oil, Water	X						Check for Leaks See NOTE 1.	
	Hydraulic Hoses	X						Check Condition	See Parts Manual
13	Coolant Hoses	X						Check Condition	See Parts Manual
16	Fuel Tank (LPG)	CIL						15.1 - 20.4 kg (33.5 - 45.0 lb) Full	LPG - HD 5, HD 10
16	Fuel Tank GM 4.3L (Gasoline) S80, 100, 120FT; S80, 100FTBCS; S120FTS; S120FTPRS (G004)	CIL						44.7 liter (11.8 gal)	86 Octane - Gasoline Minimum

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
16	Fuel Tank (Short Wheel Base) GM 4.3L (Gasoline) H80, 90, 100, 110, 120FT (N005, P005)	CIL						79 liter (20.8 gal)	86 Octane Minimum
16	Fuel Tank (Long Wheel Base) GM 4.3L (Gasoline) H80, 90, 100, 110, 120FT (N005, P005)	CIL						100.3 liter (26.5 gal)	86 Octane Minimum
16	Fuel Tank (Short Wheel Base) Cummins 4.5L and QSB 3.3L (Diesel) H80, 90, 100, 110, 120FT (N005, P005)	CIL						79 liter (20.8 gal)	Diesel No. 2
16	Fuel Tank (Long Wheel Base) Cummins 4.5L and QSB 3.3L (Diesel) H80, 90, 100, 110, 120FT (N005, P005)	CIL						100.3 liter (26.5 gal)	Diesel No. 2
	Horn, Lights, Alarms, Fuses, and Relays	X						Check Operation	
1	Service Brakes	X						Check Operation	
23	Parking Brake	X						Check Operation	
	Steering Controls and Steering Column Gas Cylinder	X						Check Condition and Operation	

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
22	Transmission	X						Check for Leaks	John Deere JDM J20C
22	Transmission	X						Check Operation	
3	Hydraulic Oil GM 4.3L [S80, 100, 120FT]; S80, 100FTBCS, S120FTS; S120FTPRS (G004)	X		X			C	39.4 liter (41.6 qt) See <b>NOTE 2</b> , <b>NOTE 3</b> and <b>NOTE 17</b> .	ISO VG 46 Hydraulic Oil -15°C (5°F) and Above
3	Hydraulic Oil (Short Wheel Base) H80, 90, 100, 110, 120FT (N005, P005)	X		X			C	62.0 liter (65.5 qt) See <b>NOTE 2</b> , <b>NOTE 3</b> , and <b>NOTE 17</b> .	ISO VG 46 Hydraulic Oil -15°C (5°F) and Above
3	Hydraulic Oil (Long Wheel Base) H80, 90, 100, 110, 120FT (N005, P005)	X		X			C	78.0 liter (82.4 qt) See <b>NOTE 2</b> , <b>NOTE 3</b> and <b>NOTE 17</b> .	ISO VG 46 Hydraulic Oil -15°C (5°F) and Above
6	Hydraulic Oil Filter					C		1 Filter . See <b>NOTE 17</b> .	See <b>Parts Manual</b>
10	Hydraulic Tank Breather			X		C		Inspect and Replace as Required See <b>NOTE 5</b> .	See <b>Parts Manual</b>
8	Battery and Cable Terminals			X				Clean	

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
9	Engine Oil GM 4.3L Engine (Gasoline/ LPG)	X CIL	C					4.7 liter (5.0 qt) See NOTE 4 and NOTE 5.	-7°C (20°F) and Below SAE 5W-20 16°C (60°F) and Below SAE 5W-30 -18°C (0°F) and Above SAE 10W-30 API SM ILSAC GF4 SAE J2362
19	Engine Oil Filter GM 4.3L Engine		C					1 Filter See NOTE 4 and NOTE 5.	See Parts Manual
9	Engine Oil Cummins 4.5L Engine (Diesel)	X CIL		C				13.0 liter (13.7 qt) See NOTE 4 and NOTE 5.	0°C (32°F) and Below SAE 0W-30 -25 to 20°C (-13 to 68°F) SAE 5W-30 -20 to 20°C (-4 to 68°F) SAE 10-30 -15°C (5°F) and Above SAE 5W-40 or 15W-40 API CH-4 or CI-4
9	Engine Oil Cummins QSB 3.3L Engine (Diesel)	X CIL		C				7.5 liter (8 qt) See NOTE 4 and NOTE 5.	0°C (32°F) and Below SAE 0W-30 -25 to 20°C (-13 to 68°F) SAE 5W-30 -20 to 20°C (-4 to 68°F) SAE 10-30 -15°C (5°F) and Above SAE 5W-40 or 15W-40 API CH-4 or CI-4

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
19	Engine Oil Filter Cummins 4.5L and QSB 3.3L (Diesel)			C				1 Filter See NOTE 4 and NOTE 5.	See Parts Manual
18	Air Filter (with premium monitoring)	CIL				C		1 Filter See NOTE 5, NOTE 6, and NOTE 12.	See Parts Manual
18	Air Filter	X				C		1 Filter See NOTE 5, NOTE 6, and NOTE 12.	See Parts Manual
	Engine Oil Pressure	CIL						Check Oil Pressure	GM Engine 207 to 380 kPa (30 to 55 psi) Cummins 4.5L Diesel Engine at High Idle 207 kPa (30 psi) at Low Idle 69 kPa (10 psi) Cummins QSB 3.3L Diesel Engine
15	Drive Belt GM Engine		X					Check for Wear and Damage. No Adjustment Needed. See NOTE 5.	
15	Drive Belt Cummins 4.5L and QSB 3.3L (Diesel)			X				Check for Wear and Damage. No Adjustment Needed. See NOTE 5.	
	LPG Regulator GM 4.3L Engine With GFI Installed		X					Drain Tar See NOTE 5.	
33	LPG Converter 4.3L LPG Engine With PSI Installed		X					Drain Tar See NOTE 5.	

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
	Engine Idle Speed GM 4.3L (Gasoline/ LPG)		X						750 ±25 rpm
	Engine Governed Speed GM 4.3L (Gasoline/ LPG)		X						2400 ±25 rpm
	Engine Idle Speed <b>Cold Engine</b> Cummins 4.5L (Diesel)			X				Coolant Temperature Less than 77°C (170°F)	770 ±50 rpm
	Engine Idle Speed <b>Hot Engine</b> Cummins 4.5L (Diesel)			X				Coolant Temperature Greater than 77°C (170°F)	800 ±50 rpm
	Engine Governed Speed (No Load) Cummins 4.5L Diesel			X					2250 ±50 rpm
	PCV Valve GM 4.3L Engine with GFI Installed			X				Replace as Necessary See NOTE 14.	See Parts Manual
	Engine Idle Speed <b>Cold Engine</b> Cummins QSB 3.3L (Diesel)			X				Coolant Temperature Less than 30°C (86°F)	1000 ±25 rpm
	Engine Idle Speed <b>Hot Engine</b> Cummins QSB 3.3L (Diesel)			X				Coolant Temperature Greater than 30°C (86°F)	800 ±25 rpm

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
	Engine Governed Speed Cummins QSB 3.3L (Diesel)			X					2230 ±25 rpm
	Oxygen Sensor GM 4.3L Engine With GFI Installed					X CIL		Replace as Necessary	
4	Valve Adjustment GM 4.3L Engine							Not Adjustable	
4	Valve Adjustment Cummins 4.5L Diesel Engines						X	Adjust as Required	Intake 0.254 mm (0.010 in.) Cold Exhaust 0.508 mm (0.020 in.) Cold
4	Valve Adjustment Cummins QSB 3.3L Diesel Engines					X		Adjust as Required See NOTE 13.	Intake 0.35 mm (0.014 in.) Cold Exhaust 0.50 mm (0.02 in.) Cold
17	Fuel Filter, LPG (GM)				C			1 Filter	See <b>Parts Manual</b>
17	Fuel Filter Gasoline (GM)					C		1 Filter	See <b>Parts Manual</b>
17	Fuel Water Separator Filter Cummins 4.5L and QSB 3.3L Diesel Engine	CIL		C				1 Filter Drain Water from Filter as Required	See <b>Parts Manual</b>

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
17	In-Line Fuel Filter Cummins 4.5L Diesel Engine				C			1 Filter	See Parts Manual
17	Final Fuel Filter Cummins QSB 3.3L Diesel Engine			C				1 Filter	See Parts Manual
20	Fuel Injectors GM 4.3L Gas				X			Check and Replace If Required 6 Injectors	
20	Fuel Injectors GM 4.3L LPG With GFI Installed				X			Check and Replace If Required 6 Injectors	
5	Spark Plugs GM 4.3L Engine				C			Check Plug Wires 6 Plugs	See NOTE 9.
12, 14	Cooling System GM 4.3L Engine	X CIL				C		15.1 liter (15.9 qt)	See NOTE 15.
12, 14	Cooling System Cummins 4.5L Diesel Engine	X CIL				C		13.5 liter (14.2 qt)	See NOTE 15.
12, 14	Cooling System Cummins QSB 3.3L Diesel Engine	X CIL				C		10.4 liter (11 qt)	See NOTE 15.
	Clean Debris From Radiator Core			X				See NOTE 5.	
7	Transmission Oil <b>Dry Brake</b>			X		C		20 liter (21 qt)	John Deere JDM J20C
21	Transmission Oil Filter and Breather					C		1 Filter 1 Breather See NOTE 4.	See Parts Manual
26	Forks	X		X		X		Check Condition	

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
26	Fork Latches			L				Lubricate as Necessary	Multipurpose Grease See NOTE 7.
	Lift System, Operate	X						Check Operation	
27	Mast Sliding Surfaces and Load Roller Surfaces			L				Lubricate as Required See NOTE 10 and NOTE 11.	Multipurpose Grease See NOTE 7.
27	Header Hoses			X				Check Condition	
28	Lift Chains	X						Check Condition/ Lube if Necessary. See NOTE 11.	SAE 30W Engine Oil
28	Lift Chains			L	L, X			Check for Wear. Lube as Required.	SAE 30W Engine Oil
	Mast Pivots			L				2 Fittings	Multipurpose Grease See NOTE 7.
	Mast Integral Sideshift Carriage Sliding Surfaces	X		L	X			Lube as Required. 8 Fittings 4 Bearing Strips Check Bearing Strips for Wear.	Multipurpose Grease See NOTE 7 2.0 mm (0.08 in.) Minimum Thickness.
	Tilt Cylinder Ends			L				4 Fittings	Multipurpose Grease See NOTE 7
	Brake Master Cylinder Rod End Pin			L					SAE 10W-30 API SM ILSAC GF4 SAE J2362
	Manual Hydraulic Hand Levers			L					SAE 10W-30 API SM ILSAC GF4 SAE J2362
24	Brake Oil (Master Cylinder)	CIL		X		C		0.35 liter (0.74 pt)	Dexron III from Sealed Container

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
11	Steering Axle Spindle Bearings				L			4 Fittings	Multipurpose Grease See NOTE 7.
11	Steering Axle			L				2 Fittings	Multipurpose Grease See NOTE 7.
11	Steering Axle			L				4 Fittings	Multipurpose Grease See NOTE 7.
34	Wheel Bearings Steer Wheels					L		Check Grease.	Multipurpose Grease See NOTE 7.
2	Pedals, Levers, Seat Rails, Cables, Hinges, Linkages, Hood Latch				L			Lubricate as Necessary	Use Silicone Spray Hyster Part No. 328388
1	Service Brakes <b>(Dry Brake)</b>					X		Check Lining Thickness	1.0 mm (0.040 in.) Minimum
23	Parking Brake Adjustment			X				Adjust as Necessary.	Must Hold a Full Capacity Load on a 15% Grade.
23	Parking Brake				L			Lubricate as Necessary	Use Silicone Spray (Hyster Part Number 328388)
30	Differential and Drive Axle Oil <b>(Dry Brake)</b>			X		C		6.0 liter (6.3 qt)	SAE 80W-90 or 85W-140
7/30	Transmission and Planetary Carrier Housing Oil S80FT, FTBCS (G004)			X		C		28.8 liter (30.4 qt)	John Deere JDM J20C
7/30	Transmission and Planetary Carrier Housing Oil S100FT, FTBCS S120FT, FTS, FTPRS (G004)			X		C		29.8 liter (31.4 qt)	John Deere JDM J20C
7/30	Transmission and Planetary Carrier Housing Oil H80, 90, 100, 110, 120FT (N005, P005)			X		C		31.3 liter (33.0 qt)	John Deere JDM J20C

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation

**Table 1. Maintenance Schedule (Continued)**

Item No.	Item	8 hr/ 1 day	250 hr/ 6 mo	500 hr/ 6 mo	1000 hr/ 6 mo	2000 hr/ 1 yr	4000 hr/ 2 yr	Procedure or Quantity	Specification
35	Wet Brake Center Section Oil S80, 100, 120FT; S80, 100FTBCS; S120FTS; S120FTPERS (G004)			X		C		2.0 liter (2.1 qt)	SAE 80W/90
35	Wet Brake Center Section Oil H80, 90, 100, 110, 120FT (N005, P005)			X		C		2.0 liter (2.1 qt)	SAE 80W-90
36	Parking Brake Levers (Wet Brake Axle)				X			Check and Lubricate as Necessary	Normal Operating Environment: Spray Lubricant (Hyster P/N 4066494) Heavy Duty or Contaminated Environment: Multipurpose Grease See NOTE 7.
	Inspect Engine Electrical System, Connectors				X				
	Inspect Engine Vacuum, Fuel Lines, and Fittings					X			
	Inspect Lock-Off for Leaks, and Ensure Lock-Off Closing					X			
	Test LPG/GAS Regulator Pressure - GFI equipped engines					X			
	Check Air Induction System for Leaks					X			

X=Check C=Change L=Lubricate CIL=Check Indicator Light during operation