

**SERVICE REPAIR**

**MANUAL**

Hyster F007 (H8.00-12.00XM Europe) Forklift

***HYSTER***

# **WET BRAKE SYSTEM**

**H16.00-18.00XM/XMS-12  
(H400-450HD/HDS) [A236];**

**H16.00-22.00XM-12EC  
(H400-500HD/HDS-EC) [B214];**

**H8.00-12.00XM (H170-280HD)  
[F007, G007, H007];**

**H13.00-14.00XM  
(H300-330HD) [E019, F019, G019];**

**H16.00XM-6 (H360HD) [E019, F019, G019];**

**H10.00-12.00XM-12EC (H360HD-EC)  
[E019, F019, G019]**

# ***HYSTER***

# SAFETY PRECAUTIONS

## MAINTENANCE AND REPAIR

- When lifting parts or assemblies, make sure all slings, chains, or cables are correctly fastened, and that the load being lifted is balanced. Make sure the crane, cables, and chains have the capacity to support the weight of the load.
- Do not lift heavy parts by hand, use a lifting mechanism.
- Wear safety glasses.
- **DISCONNECT THE BATTERY CONNECTOR** before doing any maintenance or repair on electric lift trucks. Disconnect the battery ground cable on internal combustion lift trucks.
- Always use correct blocks to prevent the unit from rolling or falling. See **HOW TO PUT THE LIFT TRUCK ON BLOCKS** in the **Operating Manual** or the **Periodic Maintenance** section.
- Keep the unit clean and the working area clean and orderly.
- Use the correct tools for the job.
- Keep the tools clean and in good condition.
- Always use **HYSTER APPROVED** parts when making repairs. Replacement parts must meet or exceed the specifications of the original equipment manufacturer.
- Make sure all nuts, bolts, snap rings, and other fastening devices are removed before using force to remove parts.
- Always fasten a **DO NOT OPERATE** tag to the controls of the unit when making repairs, or if the unit needs repairs.
- Be sure to follow the **WARNING** and **CAUTION** notes in the instructions.
- Gasoline, Liquid Petroleum Gas (LPG), Compressed Natural Gas (CNG), and Diesel fuel are flammable. Be sure to follow the necessary safety precautions when handling these fuels and when working on these fuel systems.
- Batteries generate flammable gas when they are being charged. Keep fire and sparks away from the area. Make sure the area is well ventilated.

**NOTE:** The following symbols and words indicate safety information in this manual:



### **WARNING**

**Indicates a condition that can cause immediate death or injury!**



### **CAUTION**

**Indicates a condition that can cause property damage!**

## TABLE OF CONTENTS

General .....	1
Description and Operation .....	1
Service Brakes .....	1
Parking Brake.....	1
Oil Cooler Circuit.....	1
Pressure Switch Replacement.....	5
Accumulators Replacement .....	5
Brake Treadle Valve Repair .....	5
Remove and Disassemble.....	5
Clean and Inspect.....	6
Assemble and Install.....	6
Parking Brake Valve Repair.....	6
Remove .....	6
Clean and Inspect.....	6
Repair .....	6
Install .....	6
Parking Brake Caliper Repair .....	7
Remove .....	7
Disassemble .....	9
Inspect .....	9
Install .....	9
Adjust .....	9
Brake Pad Repair.....	10
Inspect .....	10
Remove .....	10
Install .....	10
Seals Repair .....	10
Remove .....	10
Install .....	11
Service Brake Repair .....	11
Remove and Disassemble.....	11
Drain Lubricating Oil .....	11
Drain Coolant Oil .....	18
Disconnect Brake Lines .....	18
Wheel End With Outer Bearing on Ring Gear Hub Journal H13.00-14.00XM (H300-330HD), H16.00XM-6 (H360HD), and H10.00-12.00XM-12EC (H360HD-EC) .....	18
Wheel End With Outer Bearing on Spindle Journal H8.00-12.00XM (H170-280HD), H16.00-22.00XM-12EC (H400-500HD/HDS-EC) and H16.00-18.00XM/XMS-12 (H400-450HD/HDS) .....	19
Brake Disc Housing Assembly Wheel End .....	20
Brake Piston Housing .....	21
Brake Piston Housing and Wheel Spindle.....	22
Inspect .....	22
Clean .....	24
Assemble .....	25
Wheel Spindle.....	25
Brake Piston Housing .....	25
Piston Assembly .....	27
Brake Disc Housing.....	27
Duo-Cone Face Seal Into Brake Disc Housing and Into Hub.....	29
Check for Correct Installation of Duo-Cone Seal .....	30

**Thanks very much for your reading,  
Want to get more information,  
Please click here, Then get the complete  
manual**

**JustClickHere** 

**NOTE:**

**If there is no response to click on the link above,  
please download the PDF document first, and then  
click on it.**

**Have any questions please write to me:  
[admin@servicemanualperfect.com](mailto:admin@servicemanualperfect.com)**

**TABLE OF CONTENTS (Continued)**

Wheel Hub to Brake Disc Housing..... 31  
 Adjust ..... 32  
 Fill Brake System With Coolant Oil..... 32  
 System Air Removal..... 33  
 Adjust Brake With New Disc Pack..... 33  
 Coolant Change Intervals ..... 34  
 Coolant Draining and Filling..... 34  
 Specifications..... 36  
 Minimum Brake Disc Thickness..... 39  
 Hydraulic Fluid for Brake Actuation..... 39  
 Brake Coolant Specifications ..... 39  
 Coolant Change Intervals ..... 39  
 Hydraulic Fluid Specifications..... 39  
 Troubleshooting..... 39

This section is for the following models:

H16.00-18.00XM/XMS-12 (H400-450HD/HDS) [A236];  
 H16.00-22.00XM-12EC (H400-500HD/HDS-EC) [B214];  
 H8.00-12.00XM (H170-280HD) [F007, G007, H007];  
 H13.00-14.00XM (H300-330HD) [E019, F019, G019];  
 H16.00XM-6 (H360HD) [E019, F019, G019];  
 H10.00-12.00XM-12EC (H360HD-EC) [E019, F019, G019]

## General

This manual has description, operation, and repair procedures for components of the brake system.

The main parts of the system are the hydraulic pump with charge valve, two brake pedals, brake

pedal valve, two accumulators, oil cooler, two wet disc brakes, park brake, and park brake valve. See Figure 1, Figure 2, and Figure 8.

## Description and Operation

The hydraulic pump (see Figure 1 and Figure 2) supplies the oil to operate the brakes and cool the brakes and the parking brake. Oil pressure for the brakes is maintained between 14.8 and 18.5 MPa (2146.5 and 2683 psi). The accumulators have a precharge pressure of  $9.0 \pm 0.5$  MPa ( $1305 \pm 72.5$  psi). When the brake pedal is operated, the brake treadle allows oil to flow to the brake pistons. There are two oil pressure checkpoints near the brake treadle. One detects pressure and is used for the brake lights and the other one detects insufficient pressure and is used for indicating/signaling at the instrument panel and instruments. When the brake pedal is released, oil pressure in the brake cylinders is relieved to the hydraulic tank. Brakes can be bled at the manifold. When pressure in the system reaches 18.5 MPa (2683 psi), the charge valve switches to provide pressurized oil for the cooling of the brakes. A return line carries the cooling oil back to the hydraulic tank via a filter. A filter bypass is also provided. When pressure drops below 14.8 MPa (2146.5 psi), the charge valve switches back to provide pressurized oil to the brake system. The parking brake is operated via the parking brake valve.

### SERVICE BRAKES

There is an oil-cooled brake assembly at each drive wheel as shown in Figure 3. There are discs that rotate with the wheel hub and stationary discs that are locked to the brake housing. The discs are assembled so that there is a friction (rotating) disc between each stationary disc. A piston, moved by hydraulic pressure, pushes the discs together for the braking


action. A separate oil cooling system circulates oil through the sealed case to cool the discs. The brake pedal activates the brake treadle and controls the flow of oil to the service brakes. Pushing the inching pedal will at first control the declutch action and further pushing will activate the brakes due to the mechanical coupling to the brake pedal.

### PARKING BRAKE

The parking brake system uses a spring-applied caliper and is installed at the rear of the differential. Under normal conditions, the red knob on the instrument panel is pushed in, and an electrical signal triggers the parking brake valve. Oil pressure compresses the spring and the parking brake is released. The parking brake is applied by pulling out the red knob on the instrument panel. The parking brake valve position changes, and oil pressure in the parking brake cylinder is relieved. This causes the springs to apply the brakes for parking. The spring automatically applies the brake if the system loses oil pressure. The minimum system oil pressure is 14.8 MPa (2146.5 psi).

### OIL COOLER CIRCUIT

The oil for cooling of the brakes is cooled by the oil cooler. See Figure 4. In the event that measured oil temperature is above  $97^{\circ}\text{C}$  ( $206.6^{\circ}\text{F}$ ), a cooling fan is activated. When the temperature of the oil drops below  $92^{\circ}\text{C}$  ( $197.6^{\circ}\text{F}$ ) the fan is switched off. The cooling system oil pressure is 0.1 MPa (14.5 psi).




HM070198

- |                      |                          |
|----------------------|--------------------------|
| 1. PUMP/CHARGE VALVE | 8. RH BRAKE              |
| 2. ACCUMULATORS      | 9. LH BRAKE              |
| 3. BRAKE TREADLE     | 10. PRESSURE CHECK PORTS |
| 4. OIL COOLER        | 11. HYDRAULIC TANK       |
| 5. PARK BRAKE        | 12. MANIFOLD             |
| 6. PARK BRAKE VALVE  | 13. MANIFOLD             |
| 7. OIL FILTER        | 14. BLEEDER              |

**Figure 1. Brake System Schematic**






HM070196

- 1. PUMP/CHARGE VALVE
- 2. ACCUMULATORS
- 3. BRAKE TREADLE
- 4. OIL COOLER
- 5. PARK BRAKE
- 6. PARK BRAKE VALVE
- 7. OIL FILTER
- 8. RH BRAKE


- 9. LH BRAKE
- 10. MANIFOLD
- 11. MANIFOLD
- 12. HYDRAULIC TANK
- 13. PRESSURE SWITCH
- 14. PRESSURE CHECK PORTS
- 15. BLEEDER

**Figure 2. Brake System Arrangement**



- |                            |                              |
|----------------------------|------------------------------|
| 1. INNER BEARING           | 11. PLANETARY GEAR           |
| 2. WHEEL STUD              | 12. PLANETARY SPIDER         |
| 3. OUTER BEARING           | 13. WHEEL HUB                |
| 4. LOCK NUT                | 14. O-RING                   |
| 5. PIN                     | 15. FACE SEAL                |
| 6. MAGNETIC DRAIN PLUG     | 16. WET BRAKE DISC HOUSING   |
| 7. SUN GEAR                | 17. WET BRAKE PISTON HOUSING |
| 8. SUN GEAR THRUST WASHER  | 18. SPINDLE                  |
| 9. THRUST BUTTON           | 19. AXLE SHAFT               |
| 10. PLANETARY PINION SHAFT | 20. OIL SEAL                 |

**Figure 3. Service Brake**



**Figure 4. Oil Cooler Circuit Pump**

## Pressure Switch Replacement



### WARNING

Before disconnecting any hydraulic lines, release pressure from hydraulic circuit as follows:

1. Shut engine OFF and completely lower mast. Install blocks at wheels to prevent vehicle from moving.
2. Operate brake pedal until hydraulic pressure is released.

**NOTE:** There are two pressure switches, one for detection of low pressure and the other detects when the brake pedal is applied and activates the brake lights.

1. Raise cab. See the section **Operators Cab** for your lift truck.
2. Put tags for identification on lines. See Figure 2. Disconnect lines from switch.
3. Put caps on open lines. Disconnect electrical connector.
4. Install new switch. Connect hydraulic lines and connector at switch.
5. Remove air from hydraulic system and check pressure at switch as described in System Air Removal.

## Accumulators Replacement



### WARNING

The accumulator has a pressure charge and can cause an injury if the pressure is released too fast. Follow the manufacturer's instructions during removal and installation.

Before disconnecting any hydraulic lines, release pressure from hydraulic circuit as follows:

1. Shut off engine and completely lower mast. Install blocks at wheels to prevent vehicle from moving.

2. Operate brake pedal until hydraulic pressure is released.
1. Put tags for identification on lines. See Figure 2. Slowly disconnect hydraulic lines from accumulator to release any pressure slowly. Put caps on open lines. Remove accumulator.
2. Follow the manufacturer's instructions during installation of the new accumulator. Tighten bracket nuts. Connect lines.
3. Operate system and check for leaks.

## Brake Treadle Valve Repair

### REMOVE AND DISASSEMBLE



### WARNING

Before disconnecting any hydraulic lines, release pressure from hydraulic circuit as follows:

1. Shut off engine and completely lower mast. Install blocks at wheels to prevent vehicle from moving.
2. Operate brake pedal until hydraulic pressure is released.

**NOTE:** The brake treadle valve is mounted to the base of the operator's cab in line with the brake pedal.

1. Put tags for identification on lines. Disconnect lines from valve. See Figure 2. Put caps on open lines.
2. If valve assembly will be repaired or replaced, remove bolts that fasten brake treadle valve assembly to floor plate of cab.

**CLEAN AND INSPECT** **WARNING**

**Cleaning solvents are flammable and toxic and can cause skin irritation. When using cleaning solvents, always follow the solvent manufacturer's recommended safety precautions.**

Clean parts in solvent. Inspect spool and bores for scratches. If there are scratches or other damage, parts must be replaced. Lubricate parts with clean hydraulic oil for assembly.

**ASSEMBLE AND INSTALL**

1. Install valve assembly using bolts that fasten valve assembly to floor plate of cab.
2. Install lines to brake treadle valve.
3. Operate system and check valve connections for leaks. Remove air from hydraulic system as described in System Air Removal.

**Parking Brake Valve Repair****REMOVE** **WARNING**

**Before disconnecting any hydraulic lines, release pressure from hydraulic circuit as follows:**

1. **Shut engine OFF and completely lower mast. Install blocks at wheels to prevent vehicle from moving.**
  2. **Operate brake pedal until hydraulic pressure is released.**
1. Put blocks in front and back of tires so the vehicle cannot move.
  2. Disconnect electrical connector. Put tags for identification on hydraulic lines.
  3. Disconnect lines from parking brake valve. See Figure 2. Put caps on open lines. Remove valve.

**CLEAN AND INSPECT** **WARNING**

**Cleaning solvents are flammable and toxic and can cause skin irritation. When using cleaning solvents, always follow the solvent manufacturer's recommended safety precautions.**

Clean parts in solvent. Inspect parts and bores for scratches. Replace valve if there are scratches or other damage. Lubricate parts with clean hydraulic oil for assembly.

**REPAIR**

Install new O-rings at each port.

**INSTALL**

1. Install parking brake valve. Connect lines.
2. Operate system and check for leaks and correct operation of parking brake system. Remove air from brake system as described in System Air Removal.

## Parking Brake Caliper Repair

### REMOVE

#### WARNING

Before disconnecting any hydraulic lines, release pressure from hydraulic circuit as follows:

1. Shut off engine and completely lower mast. Install blocks at wheels to prevent vehicle from moving.
  2. Operate brake pedal until hydraulic pressure is released.
1. Put blocks in front and back of tires so the vehicle cannot move.
  2. Remove cap.
  3. Loosen lock nut.
  4. Turn setscrew counterclockwise until brake pads no longer touch brake disc.


5. Slowly release pressure from accumulator. Disconnect hydraulic line at caliper. Put a cap on open line.

#### WARNING

Brake linings can contain dangerous fibers. Breathing dust from these linings can be a cancer or lung disease hazard. Do not make dust! Do not clean brake parts with compressed air or by brushing. Use vacuum equipment approved for brake dust or follow the cleaning procedure in this section. When calipers are removed, do not make dust.


Do not sand, grind, chisel, hammer, or change linings in any way that will make dust. Any changes to linings must be done in a restricted area with special ventilation. Protective clothing and a respirator must be used.

6. Remove bolts that hold caliper to bracket. See Figure 5 and Figure 6. Remove caliper and brake linings.



- |                    |                  |                         |
|--------------------|------------------|-------------------------|
| 1. LOCK NUT        | 5. YOKE ASSEMBLY | 9. SPECIAL SCREW (LONG) |
| 2. FLAT WASHER     | 6. DISC BRAKE    | 10. HARDENED WASHER     |
| 3. CAPSCREW        | 7. LOCK NUT      | 11. BRAKE ADAPTER       |
| 4. HARDENED WASHER | 8. SEAL ASSEMBLY | 12. BRAKE DISC ASSEMBLY |

Figure 5. Parking Brake Assembly



HM040236

- |                     |                 |
|---------------------|-----------------|
| 1. BRAKE HOUSING    | 14. SETSCREW    |
| 2. RETAINING RING   | 15. LOCKING NUT |
| 3. PISTON STOP      | 16. NUT         |
| 4. PISTON           | 17. COTTER PIN  |
| 5. CAP              | 18. O-RING SEAL |
| 6. 145MM LONG BOLTS | 19. O-RING SEAL |
| 7. RETAINING CUP    | 20. O-RING SEAL |
| 8. DUST BOOT        | 21. DISC SPRING |
| 9. BRAKE PADS       | 22. WEAR PLATE  |
| 10. FRICTION SLEEVE | 23. RAM         |
| 11. MAGNET          | 24. BLEEDER     |
| 12. CUP SEAL        | 25. WASHER      |
| 13. CUP SEAL        | 26. ADAPTER     |


**Figure 6. Parking Brake Caliper**

**DISASSEMBLE**

Disassemble caliper to remove and service as necessary.

**INSPECT**

Inspect parts and bores for scratches. If there are scratches or other damage, replace damaged parts. Inspect rotor as shown in Figure 7.



- 1. MAXIMUM ROTOR WEAR 1.5 mm (0.06 in.)
- 2. MINIMUM ROTOR THICKNESS 11.0 mm (0.43 in.)
- 3. ROTOR THICKNESS 13.0 mm (0.51 in.)

*Figure 7. Inspect Rotor for Parking Brake Caliper*

**INSTALL**

**NOTE:** Brake setting is required after mounting new brake pads or brake disc, as well as during all repair stages and in the event of insufficient braking performance.

**NOTE:** All mounting and setting work must be carried out on the brake when cold.

1. Remove cap.
2. Release lock nut and turn setscrew counterclockwise until ram comes to rest against face of piston.
3. Mount caliper to bracket and secure with bolts.
4. Mount pressure connection and apply the necessary release pressure to brake until bank of disc springs are completely pretensioned.
5. Adjust brakes.

**ADJUST**

**NOTE:** During this adjustment process, the parking brake must be released and the disc springs pretensioned.

1. Put blocks in front and back of tires so the vehicle cannot move.
2. Remove cap.
3. Release lock nut and turn setscrew clockwise until brake pads touch brake disc.
4. Turn setscrew counterclockwise and set clearance specified. See Table 1.
5. Hold setscrew in position and tighten lock nut.
6. Replace cap and tighten.
7. Bleed piston chamber using bleeder. See Figure 6.
8. Operate brake valve several times and check braking efficiency of parking brake on a slope.

*Table 1. Brake Pad Adjustment*

Type	Adjustment Screw	Clearance mm (in.)		Revolutions
		Minimum	Rated Clearance	
Small	M16 (size 8)	0.5 mm (0.020 in.)	<b>1.0 mm (0.039 in.)</b>	1/4
		1.5 mm (0.059 in.)		3/4
		1.0 mm (0.039 in.)	<b>2.0 mm (0.079 in.)</b>	2/5
Large	M20 (size 10)	1.0 mm (0.039 in.)	<b>2.0 mm (0.079 in.)</b>	4/5
		3.0 mm (0.118 in.)		1-1/5
		1.5 mm (0.059 in.)		

## Brake Pad Repair

**NOTE:** The brake pads themselves are maintenance free. All that is required here is a check for damaged parts, as well as, inspection to ensure that the brake disc spins freely.

### INSPECT

The thickness of the brake lining must be subjected to a visual inspection at regular intervals, which depends on vehicle usage, but every 6 months at the latest. In the event of a minimal residual lining thickness, these intervals must be reduced accordingly in order to avoid major damage to the brake or disk.

- Small brake: Minimum residual thickness 1.0 mm (0.039 in.) per brake lining plate [6 mm (0.236 in.) carrier plate thickness]
- Large brake: Minimum residual thickness 2.0 mm (0.079 in.) per brake lining plate [8 mm (0.315 in.) carrier plate thickness]

### REMOVE



#### CAUTION

**If the pressure hose is too short, it must be disconnected in order to allow the brake to be removed. Step 2 and Step 3 must be performed beforehand. Then release pressure by actuating hand brake valve.**

**NOTE:** During this adjusting process, the parking brake must be released.

1. Release cap and unscrew. See Figure 6.

2. Release lock nut and turn setscrew clockwise until it is flush with inside of piston.
3. Press back ram bolt using a suitable screwdriver until it comes to rest against piston.

**NOTE:** In the event there is insufficient clearance to remove brake pads, brake must be completely removed. To do this, pull 145 mm (5.708 in.) long bolts out of brake housing.

4. Depending on free space available, release one of two 145 mm (5.708 in.) bolts, remove cotter pin, unscrew nut, and pull 145 mm (5.708 in.) long bolt out of brake housing. Remove brake pads.

### INSTALL

**NOTE:** If magnets do not have sufficient force, they must also be replaced. Remove by prying out with a screwdriver.

**NOTE:** When brake has been completely removed, pressure hose must be reconnected to brake housing. Brake must then be bled.

1. Replace brake pads and insert 145 mm (5.708 in.) long bolts into brake housing. Verify magnets have sufficient force to hold brake pads.
2. Secure to bracket with 145 mm (5.708 in.) long bolts, nuts, and cotter pins.
3. Adjust brakes. See Adjust.

## Seals Repair

### REMOVE

1. Release lock nut and turn setscrew clockwise until it is flush with inside of piston.
2. Release pressure by actuating hand brake valve; then remove pressure hose and completely remove brake. The disc springs are now completely depressurized.

3. Remove piston stop and remove retaining ring from housing.
4. Remove bank of disc springs and piston.



**INSTALL****CAUTION**

Verify mounting direction of seal rings, otherwise leaks may occur.

**CAUTION**

When mounting new seal rings, use caution not to damage sealing lip by using a suitable mounting needle with rounded edges.

**NOTE:** When replacing piston, sliding and sealing surfaces must be greased lightly using lubricating grease.

1. Replace seals as needed.
2. Replace remaining individual parts in reverse order of removal.
3. Install caliper assembly and adjust. See Adjust.

## Service Brake Repair

The service brake assemblies are hydraulically actuated wet brakes. Most repairs are seal replacement at the hub and brake disc housing. Replace these seals any time the hub is removed. See Figure 8.

**REMOVE AND DISASSEMBLE**

**NOTE:** Disassembly of the wet disc brake is required to replace a leaky seal or worn brake disc pack. Various fluids must be drained from the wheel ends. Prepare the truck as follows:

**WARNING**

Allow the brakes to cool to ambient temperature (cool to the touch) before draining fluid. Wear protective gloves. Personal injury can result.

Use only the type of fluid specified by the equipment manufacturer. Do not use or mix different types of fluid. An incorrect fluid can damage the rubber parts of the assemblies, which could cause loss of braking and serious personal injury.

Do not reuse hydraulic fluid or coolant. Used fluid may be contaminated and can cause incorrect operation, which can result in serious personal injury and damage to components.

**WARNING**


Block the wheels to prevent the vehicle from moving. Support vehicle with safety stands.

**Do not work under a vehicle that is supported only by jacks. Jacks can slip or fall over. Serious personal injury can result.**

1. Verify vehicle is on level surface.
2. Place blocks under wheels not being serviced to keep vehicle from moving.
3. Raise vehicle so that wheels of axle to be serviced are off the ground. Support vehicle with safety stands. See the section **Periodic Maintenance** for your lift truck.
4. Remove wheel nuts and dual tire/rim assemblies from both wheel ends.

**Drain Lubricating Oil**


1. Rotate wheel ends so magnetic drain plug in planetary spider is at bottom. See Figure 9 and Figure 10.
2. Place a suitable container under wheel end. Remove magnetic drain plug from spider, then drain lubricant. Dispose of lubricant according to local recommendations.
3. If necessary, remove magnetic drain plug from bottom of brake piston housing. Drain and dispose of lubricant from carrier center section. See Figure 11, Figure 12, and Figure 13.



HM040251

- |                                       |                                       |
|---------------------------------------|---------------------------------------|
| 1. BRAKE DISC HOUSING                 | 13. BRAKE BLEEDER SCREW               |
| 2. PISTON                             | 14. FORCED COOLING INLET PLUG         |
| 3. D-SEAL                             | 15. BRAKE PISTON HOUSING              |
| 4. D-SEAL                             | 16. PISTON RETURN SPRING              |
| 5. ADJUSTING SCREW                    | 17. SHOULDER BOLT                     |
| 6. ADJUSTING SCREW JAM NUT            | 18. HARDENED WASHER                   |
| 7. PLUG ASSEMBLY, SERVICE BRAKE INLET | 19. STATIONARY DISC                   |
| 8. CAPSCREW                           | 20. FRICTION DISC ASSEMBLY            |
| 9. HARDENED WASHER                    | 21. STATIONARY DISC LOCKING DOWEL PIN |
| 10. MAGNETIC DRAIN PLUG (COOLANT)     | 22. SEAL RING                         |
| 11. AIR EVACUATION PLUG (COOLANT)     | 23. DUO-CONE FACE SEAL HALF           |
| 12. FORCED COOLING OUTLET PLUG        |                                       |


*Figure 8. Wet Brake System*



HM070190


- |                           |                              |
|---------------------------|------------------------------|
| 1. SPINDLE                | 12. SUN GEAR                 |
| 2. OIL SEAL               | 13. SUN GEAR THRUST WASHER   |
| 3. WHEEL HUB              | 14. LOCK                     |
| 4. WHEEL STUD             | 15. MAGNETIC DRAIN PLUG      |
| 5. WHEEL HUB O-RING       | 16. RING GEAR HUB            |
| 6. OUTER BEARING          | 17. PLANETARY SPIDER         |
| 7. PLANETARY GEAR         | 18. INNER BEARING            |
| 8. O-RING                 | 19. FACE SEAL                |
| 9. PLANETARY PINION SHAFT | 20. WET DISC BRAKE HOUSING   |
| 10. ADJUSTING NUT         | 21. WET BRAKE PISTON HOUSING |
| 11. THRUST BUTTON         | 22. AXLE SHAFT               |

**Figure 9. Wheel End Cross Section H13.00-14.00XM (H300-330HD), H16.00XM-6 (H360HD), and H10.00-12.00XM-12EC (H306HD-EC)**



- |                            |                              |
|----------------------------|------------------------------|
| 1. INNER BEARING           | 11. PLANETARY GEAR           |
| 2. WHEEL STUD              | 12. PLANETARY SPIDER         |
| 3. OUTER BEARING           | 13. WHEEL HUB                |
| 4. LOCK NUT                | 14. O-RING                   |
| 5. PIN                     | 15. FACE SEAL                |
| 6. MAGNETIC DRAIN PLUG     | 16. WET BRAKE DISC HOUSING   |
| 7. SUN GEAR                | 17. WET BRAKE PISTON HOUSING |
| 8. SUN GEAR THRUST WASHER  | 18. SPINDLE                  |
| 9. THRUST BUTTON           | 19. AXLE SHAFT               |
| 10. PLANETARY PINION SHAFT | 20. OIL SEAL                 |

**Figure 10. Wheel End Cross Section H8.00-12.00XM (H170-280HD), H16.00-22.00XM-12EC (H400-500HD/HDS-EC) and H16.00-18.00XM/XMS-12 (H400-450HD/HDS)**



HM040252

- |                           |                             |
|---------------------------|-----------------------------|
| 1. MAGNETIC DRAIN PLUG    | 16. OUTER THRUST WASHER     |
| 2. SETSCREW               | 17. PLANETARY PINION SHAFT  |
| 3. PLANETARY SPIDER       | 18. OUTER BEARING CONE      |
| 4. THRUST BUTTON          | 19. OUTER BEARING CUP       |
| 5. SNAP RING              | 20. O-RING                  |
| 6. PLANETARY SUN GEAR     | 21. WHEEL NUT               |
| 7. THRUST WASHER          | 22. HUB                     |
| 8. PLANETARY RING GEAR    | 23. WHEEL STUD              |
| 9. PIN                    | 24. FACE SEAL ASSEMBLY      |
| 10. SPINDLE NUT           | 25. INNER BEARING CUP       |
| 11. FLAT WASHER           | 26. INNER BEARING CONE      |
| 12. CAPSCREW              | 27. OIL SEAL ASSEMBLY       |
| 13. SNAP RING             | 28. SPINDLE                 |
| 14. INNER THRUST WASHER   | 29. SHAFT                   |
| 15. PLANETARY PINION GEAR | 30. WET DISC BRAKE ASSEMBLY |

**Figure 11. Wheel End H8.00-12.00XM (H170-280HD)**