

H35332

-UN-01JAN94



JOHN DEERE 8820 COMBINE WITH 844 CORN HEAD

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

NOTE

IN ADDITION TO TITAN COMBINES, PARTS INFORMATION FOR TITAN II COMBINES IS ALSO LOCATED IN THIS CATALOG. SERIAL NUMBER (610701-) INDICATES TITAN II PARTS.

THIS CATALOG CONTAINS PARTS INFORMATION FOR THE 6466-03 EXPORT MACHINE.

FOR 200 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE 200 SERIES PLATFORM PARTS CATALOG - PC-1558.

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE 900 SERIES PLATFORM PARTS CATALOG - PC-2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 40 SERIES CORN HEAD PARTS CATALOG - PC-1223.

FOR 50 SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE 50 SERIES ROW-CROP HEAD PARTS CATALOG - PC-1549.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE 50A SERIES ROW-CROP HEAD PARTS CATALOG - PC-1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE THREE-ROLLER BELT PICKUP PARTS CATALOG - PC-1189 (200 SERIES) OR PC-2210 (900 SERIES).

IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 8820 COMBINE. MACHINE VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

SERIAL NUMBER AND PRODUCT IDENTIFICATION NUMBER (PIN) PLATES

USE ALL NUMBERS, LETTERS AND SPACES SHOWN ON THE SERIAL NUMBER PLATE OR THE PRODUCT IDENTIFICATION NUMBER PLATE IN WARRANTY CORRESPONDENCE.

COMBINES (-564100)

ON THESE COMBINES, THE SERIAL NUMBER PLATE IS LOCATED ON THE REAR LEFT-HAND UPRIGHT.

AN EXAMPLE OF THE SERIAL NUMBER ON THIS PLATE IS:

E8820564100H

E - EQUIPMENT
8820 - COMBINE MODEL
564100 - COMBINE SEPARATOR SERIAL NUMBER
H - MANUFACTURING UNIT (HARVESTER WORKS)

COMBINES (564101-)

ON THESE COMBINES, THE PRODUCT IDENTIFICATION PLATE (PIN) IS LOCATED NEAR THE RIGHT-HAND SIDE OF THE TOOL BOX. AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

H08820X564101
COMBINE

(FIRST LINE)

H0 - MANUFACTURING UNIT (HARVESTER WORKS)
8820 - MODEL IDENTIFIER
X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX
564101 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

COMBINE - TYPE OF PRODUCT

ENGINE SERIAL NUMBER

THE ENGINE SERIAL NUMBER PLATE IS LOCATED ON THE RIGHT-HAND SIDE OF THE ENGINE BLOCK.

ENGINES (-227599)

AN EXAMPLE OF THE ONE-LINE, SIXTEEN-DIGIT NUMBER ON THIS SERIAL NUMBER PLATE IS:

6466TH01227599RG

6 - NUMBER OF CYLINDERS
466 - CUBIC INCH DISPLACEMENT
A - FUEL TYPE (TURBOCHARGED INTERCOOLED DIESEL)
H - MANUFACTURING UNIT OF MACHINE (HARVESTER WORKS)
01 - ENGINE VERSION
227599 - ENGINE SERIAL NUMBER
RG - MANUFACTURING UNIT OF ENGINE (JOHN DEERE ENGINE WORKS)

ENGINES (227600-)

AN EXAMPLE OF THE TWO-LINE NUMBER ON THIS SERIAL NUMBER PLATE IS:

RG6466227600
6466AH02

(FIRST LINE)

RG - MANUFACTURING UNIT (JOHN DEERE ENGINE WORKS)
6 - NUMBER OF CYLINDERS
466 - CUBIC INCH DISPLACEMENT
A - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX
227600 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

6 - NUMBER OF CYLINDERS
466 - CUBIC INCH DISPLACEMENT
A - FUEL TYPE (TURBOCHARGED INTERCOOLED DIESEL)
H - MANUFACTURING UNIT OF MACHINE (HARVESTER WORKS)
02 - ENGINE VERSION

PARTS LISTING INFORMATION

SERIAL NUMBER OR PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION SHOWS ON WHICH MACHINES A PART MAY BE USED. FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.

-000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.

000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.

000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE, BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRINTED.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

KITS

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM FOR RELATIONSHIP.

JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-MATIC™
HARVESTRAK™
POSI-TORQ™

TORQ-GARD SUPREME®
QUIK-TATCH™

CHANGE INDICATOR LINE (MICROFICHE CATALOGS ONLY)

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

SECTIONAL INDEX

	SECTION
GENERAL INFORMATION	10
BASIC ENGINE	20
FUEL AND AIR	30
ELECTRICAL	40
POWER TRAIN	50
STEERING AND BRAKES	60
HYDRAULICS	70
SEPARATOR SHELL	80
OPERATOR'S STATION	90
HEADERS - REFER TO INDIVIDUAL HEADER PARTS CATALOGS	100
FEEDER HOUSE	110
SEPARATOR	120
GRAIN TANK AND UNLOADING AUGER	130
MAJOR DRIVES	140
HEADER HEIGHT CONTROL	160
DECALS, BELTS AND CHAINS	170
NUMERICAL INDEX	180

ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
	A				
2D7	ACCESSORIES, INSTRUMENT PANEL	40-55	5I23	AUGER, UPPER TAILINGS AUGER	120-154
2B25	ACCUMULATOR PRESSURE GAUGE	40-21	6C10	AUGER, VERTICAL, LOWER GEAR CASE	130-33
4F11	ACCUMULATOR,PRESSURE CTL.VALVE AND MTG. BRKT.	70-107	6C8	AUGER,CROSS,DRIVE TIGHTENERS,GRAIN TANK	130-31
2B24	ADAPTER HARNESS, HARVESTRAK	40-20	6C18	AUGER,HORIZONTAL UNLDG. DRIVE GEAR CASE	130-41
1D22	ADAPTER, ENGINE COOLANT HEATER.....	20-69	6B15	AUGER,HORIZONTAL UNLOADING SWIVEL SHROUD....	130-11
1D7	AFTERCOOLER	20-54	5G16	AUGERS, HOUSING, SHOE GRAIN SUPPLY	120-95
1F4	AIR CLEANER	30-17	5G20	AUGERS, SHOE GRAIN SUPPLY, DRIVE SHAFT	120-99
4I21	AIR CONDITIONER EVAPORATOR	90-58	5G18	AUGERS, SUPPLY, SHOE GRAIN	120-97
4I21	AIR CONDITIONER EXPANSION VALVE.....	90-58	6D21	AUTO.HEADER HEIGHT CONTROL CHECK BLOCK.....	160-1
4I8	AIR CONDITIONER HI PRESSURE SWITCH	90-43	6E8	AUTOMATIC HDR.HGT.CTL.WIRING HARNESS	160-13
4I16	AIR CONDITIONER LINES	90-53	6E2	AUTOMATIC HDR.HGT.CTL.DROP RATE VALVE	160-7
4I19	AIR CONDITIONER LINES	90-56	6E2	AUTOMATIC HDR.HGT.CTL.FULL FLOW PLUG.....	160-7
4I21	AIR CONDITIONER LINES	90-58	6E2	AUTOMATIC HDR.HGT.CTL.HYDRAULIC OIL LINE	160-7
4I3	AIR CONDITIONING COMPRESSOR.....	90-38	6E8	AUTOMATIC HEADER HEIGHT CONTROL LINKAGE	160-13
4I6	AIR CONDITIONING, O-RING KIT	90-41	6E12	AUTOMATIC HEADER HEIGHT CONTROL SWITCH	160-17
5H16	AIR DUCTS, CLEANING FAN	120-121	6D21	AUTOMATIC HEADER HEIGHT CONTROL VALVE	160-1
4H24	AIR FILTER, CAB.....	90-35	3C12	AXLE SHAFT FINAL DRIVE	50-31
1F3	AIR INTAKE TUBES (PRECLNR.TO AIR CLNR.)	30-16	3B24	AXLE, DRIVE WHEEL	50-16
1F5	AIR INTAKE TUBES-AIR CLEANER TO MANIFOLD.....	30-18	3C18	AXLE, FINAL DRIVE (CRAWLER TRACKS).....	50-37
4H22	AIR LOUVER	90-32	3I14	AXLE, REAR.....	60-29
2E16	ALTERNATOR ADJUSTING STRAP	40-92	3I15	AXLE, REAR.....	60-31
2E17	ALTERNATOR ADJUSTING STRAP	40-93	3I18	AXLE,REAR,SPINDLE HSGS-HVY-DTY REAR AXLE	60-34
2E16	ALTERNATOR BRACKET	40-92			
2E17	ALTERNATOR BRACKET	40-93		B	
2E14	ALTERNATOR SHEAVE AND BELT.....	40-90	4B16	BACK PLATE, MAIN HYDRAULIC PUMP.....	70-10
2E15	ALTERNATOR, COMPLETE, 90 AMP	40-91	6B18	BAFFLE, GRAIN TANK SUMP	130-14
2E10	ALTERNATOR, 72 AMP.....	40-86	5F9	BAR, CYLINDER SHEAR.....	120-58
2E12	ALTERNATOR, 90 AMP.....	40-88	2C5	BATTERY CABLES	40-27
2E7	AM AND AM-FM PUSH-BUTTON RADIO (MOTOROLA).....	40-82	2C5	BATTERY MOUNTINGS	40-27
2E8	AM PUSH-BUTTON RADIO.....	40-83	2B13	BEACON LIGHTS (EXPORT)	40-8
2E8	AM-FM PUSH-BUTTON RADIO.....	40-83	3G19	BEARING AND COVER, QUILL	50-144
6E11	AMPLIFIER	160-16	3C21	BEARING CAP, FINAL DRIVE (CRAWLER TRACKS)	50-40
1G23	ANEROID ACTIVATOR, HYDRAULIC (AH 03).....	30-64	3G12	BEARING, AND SEALS, SHAFT, OUTER COVER	50-136
5D20	ARM, CONCAVE ADJUSTING SHAFT	120-19	3D16	BEARING,SEAL,HYDRO.DR.PUMP FRONT COVER ASSY (EATON)	50-59
5E16	ARM, DUAL-RANGE CYLINDER DRIVE	120-40	3F14	BEARINGS, CRAWLER	50-109
1C16	ARM, ROCKER (AH 01)	20-39	3F16	BEARINGS, CRAWLER	50-111
1C17	ARM, ROCKER (AH 02, 03)	20-40	3F19	BEARINGS, CRAWLER DRIVE	50-115
2E22	ARMATURE, STARTER	40-99	3C12	BEARINGS, FINAL DRIVE	50-31
4H10	ARMREST (PERSONAL POSTURE SEAT)	90-19	3C16	BEARINGS, FINAL DRIVE	50-35
2C19	ARMS, PIVOT, TAIL-LAMP (EXPORT)	40-41	3C18	BEARINGS, FINAL DRIVE (CRAWLER TRACKS).....	50-37
3H1	ARMS, STEERING, CAM LOBE MOTOR.....	50-150	3C19	BEARINGS, FINAL DRIVE (CRAWLER TRACKS).....	50-38
4H13	ASH TRAY	90-22	1C13	BEARINGS, MAIN.....	20-35
1F6	ASPIRATOR	30-19	1C13	BEARINGS, MAIN THRUST.....	20-35
6C12	AUGER AND HOUSING, VERTICAL, GRAIN TANK	130-35	5I21	BEARINGS, TAILINGS ELEVATOR CONVEYOR.....	120-152
6C19	AUGER HOUSING, HORIZONTAL UNLOADING, 14 FT. AND 17 FT.	130-42	3E1	BEARINGS,HYDRO. DRIVE PUMP (EATON)	50-69
6C20	AUGER HOUSING, HORIZONTAL UNLOADING, 17 FT. AND 20 FT.	130-43	3C5	BEARINGS,TRANSMISSION COUNTERSHAFT,GEARS....	50-23
2B10	AUGER LIGHT, UNLOADING	40-5	3C5	BEARINGS,TRANSMISSION INPUT SHAFT,GEARS.....	50-23
4D15	AUGER SWING HYD.OIL LINES AND HOSES	70-61	3C7	BEARINGS,TRANSMISSION PINION SHAFT,GEARS.....	50-25
4D16	AUGER SWING HYD.OIL LINES AND HOSES	70-62	6F6	BEATER AND CYLINDER TACHOMETER	170-13
6B24	AUGER, CROSS, FRONT, GRAIN TANK.....	130-21	5F2	BEATER BEARING LUBE BANK SYS-LH-HYDRO.....	120-51
6B25	AUGER, CROSS, REAR, GRAIN TANK	130-22	5F1	BEATER BEARING LUBE BANK SYSTEM-RH	120-50
6C14	AUGER, HORIZONTAL UNLOADING SWIVEL	130-37	5E23	BEATER BELT	120-47
6C15	AUGER, HORIZONTAL UNLOADING SWIVEL	130-38	5E24	BEATER BELT	120-48
6C21	AUGER, HORIZONTAL UNLOADING, 14 FT. AND 17 FT.	130-44	6F6	BEATER BELT	170-13
6C22	AUGER, HORIZONTAL UNLOADING, 20 FT.	130-45	5F3	BEATER DRIVE	120-52
5I9	AUGER, LOADING	120-139	5F4	BEATER DRIVE	120-53
5I14	AUGER, LOWER TAILINGS	120-145	5F5	BEATER DRIVE	120-54
5H20	AUGER, LOWER, CLEAN GRAIN.....	120-125	5F6	BEATER DRIVE, DUAL-RANGE	120-55
6C17	AUGER, UNLOADING, LUBE BANK SYSTEM.....	130-40	5D12	BEATER GRATE, OPEN-BAR CONCAVE	120-9
2B9	AUGER, UNLOADING, WIRING HARNESS	40-3	5E23	BEATER, CYLINDER TACHOMETER.....	120-47
			5E24	BEATER, CYLINDER TACHOMETER.....	120-48
			2C16	BECON LIGHTS, DECAL (EXPORT)	40-38
			1F2	BELL CRANK, THROTTLE LINKAGE	30-15
			6F5	BELT AND SHEAVES	170-12

ALPHABETICAL INDEX - CONTINUED

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
6F5	BELT AND SHEAVES TORQ-SENSING CTRSHFT.	170-12	2D1	BOX, CONTROL, LOW SHAFT SPEED MONITORING	40-48
6D18	BELT GUIDES, SEPARATOR DRIVE	140-18	2D3	BOX, CONTROL, LOW SHAFT SPEED MONITORING	40-50
6D18	BELT GUIDES, UNLOADING AUGER DRIVE	140-18	4G2	BOX, TOOL	80-15
3C24	BELT TENSIONING MECHANISM, HYDROSTATIC DR.	50-43	5C16	BRACE, FEEDER HOUSE MIDDLE BELT	110-39
3D2	BELT TENSIONING SYSTEM, HYDRAULIC	50-45	6B6	BRACE, GRAIN TANK	130-2
4I3	BELT, AIR CONDITIONING COMPRESSOR	90-38	4F23	BRACES, SEPARATOR CROSS	80-10
2E14	BELT, ALTERNATOR	40-90	5E9	BRACES, SUPPORT CYLINDER INTERMEDIATE DRIVE	120-32
5D8	BELT, BEATER	120-5	5E4	BRACES, SUPPORT, CYLINDER DRIVE	120-27
5E23	BELT, BEATER	120-47	2E16	BRACKET, ALTERNATOR	40-92
5E24	BELT, BEATER	120-48	2E17	BRACKET, ALTERNATOR	40-93
6F6	BELT, BEATER	170-13	5B23	BRACKET, FEEDER CONVEYOR	110-18
4I9	BELT, COMPRESSOR	90-44	1F24	BRACKET, FUEL SHUT-OFF (AH 02, 03)	30-38
4I10	BELT, COMPRESSOR	90-45	2C1	BRACKET, HARNESS, REAR CAB	40-23
5D24	BELT, CYLINDER DRIVE INTERMEDIATE SHAFT	120-23	2E8	BRACKET, RADIO	40-83
5E1	BELT, CYLINDER DRIVE INTERMEDIATE SHAFT (DUAL-RANGE CYLINDER DRIVE)	120-24	2C14	BRACKETS FRONT LAMPS (EXPORT)	40-36
6F6	BELT, CYLINDER TACHOMETER	170-13	5H8	BRACKETS, CHAFFER FRAME	120-111
6E24	BELT, DRIVE, HYDRAULIC REEL LIFT	170-6	3H11	BRAKE CONTROLS, PARKING	60-1
6F17	BELT, DRIVE, SECONDARY COUNTERSHAFT	170-25	3H13	BRAKE LINES	60-3
1D23	BELT, FLAT ROTARY SCREEN	20-70	3H15	BRAKE MASTER CYLINDER	60-5
5I11	BELT, GEAR CASE, LOADING AUGER	120-141	3H12	BRAKE PEDALS AND LINKAGE	60-2
4E14	BELT, HYDROSTATIC REEL PUMP	70-85	4G25	BRAKE PLATE	90-9
5I14	BELT, LOWER TAILINGS AUGER	120-145	3G1	BRAKE PLATES (FOUR-WHEEL DRIVE)	50-123
3C22	BELT, PROPULSION DRIVE CTRSHAFT. SHEAVE	50-41	3H19	BRAKE SHOES AND DRUM	60-9
1E10	BELT, RADIATOR FAN	20-81	3H16	BRAKE SLAVE CYLINDER	60-6
5D8	BELT, RASP-BAR CYLINDER	120-5	2C7	BREAKER, CIRCUIT	40-29
5G9	BELT, REAR, STRAW CHOPPER	120-87	3D14	BRG.-SEAL-HYDRO.DR.PUMP FRONT COVER ASSY	50-57
6E22	BELT, ROTARY SCREEN	170-4	3D24	BRGS,TRUNNIONS,HYDRO.DR.PUMP SWASHPLATE	50-67
5G8	BELT, STRAW CHOPPER DRIVE	120-85	2C18	BRKT.,GRAIN TANK FILL INDICATOR (EXPORT)	40-40
5F16	BELT, STRAW SPREADER DRIVE	120-65	4F11	BRKT,MTG,ACCUMULATOR AND PRES.CTL.VALVE	70-107
5E23	BELT, TACHOMETER CYLINDER DRIVE	120-47	2D7	BUZZER, WARNING	40-55
5E24	BELT, TACHOMETER CYLINDER DRIVE	120-48	2C5	BUZZER, WATER TEMPERATURE, SENDING UNIT	40-27
6B22	BELT, UNLOADING AUGER COUNTERSHAFT	130-19	1D1	BYPASS VALVE, OIL COOLER	20-48
5I5	BELT,DR.CTRSHAFT.,CLEAN GRAIN ELEVATOR	120-135	1D6	BYPASS VALVE, OIL COOLER	20-53
5C10	BELT,FDR.HSE.LOWER SHAFT-VARIABLE DRIVE	110-31			
5G20	BELT,SHOE GRAIN SUPPLY AUGERS DR. SHAFT	120-99		C	
6F13	BELTS, CLEAN GRAIN ELEVATOR	170-21	4H14	CAB	90-23
6F10	BELTS, DRIVE, CLEANING FAN	170-17	4H24	CAB AIR FILTER	90-35
6E21	BELTS, DRIVE, ENGINE R.H. SIDE	170-3	4H17	CAB COVERS	90-27
6F2	BELTS, DRIVE, FEEDER HOUSE (LONG)	170-9	4H17	CAB DOORS	90-27
6F3	BELTS, FEEDER HOUSE DRIVE (LONG)	170-10	4H17	CAB HANDLE	90-27
6F13	BELTS, LOADING AUGER	170-21	4H18	CAB ROOF AND SUPPORTS	90-28
6D9	BELTS, PRIMARY COUNTERSHAFT SHEAVES	140-9	4H20	CAB ROOF HEADLINER	90-30
6D10	BELTS, PRIMARY COUNTERSHAFT SHEAVES (DUAL-RANGE CYLINDER DRIVE)	140-10	2D12	CAB ROOF WIRING HARNESS	40-61
1E2	BELTS, ROTARY SCREEN	20-73	4H5	CAB SEAL	90-14
6F16	BELTS,DRIVE,ENGINE TO PRIMARY CTRSHAFT	170-24	4H17	CAB SHIELDS	90-27
6E25	BELTS,DRIVE,FEEDER HOUSE (VARIABLE DR.)	170-7	4H15	CAB WINDOWS	90-25
6F9	BELTS,DRIVE,SHOE GRAIN SUPPLY AUGERS	170-16	2C1	CAB, REAR, HARNESS BRACKET	40-23
6E23	BELTS,HYDROSTATIC GROUND DRIVE	170-5	3D6	CABLE AND LEVER, HYDRO. DRIVE CONTROL	50-49
4H22	BEZEL, AIR LOUVER	90-32	3D8	CABLE MOUNTING, HYDRO. DRIVE CONTROL	50-51
5G13	BLADE, STRAW SPREADER	120-91	1F2	CABLE SUPPORTS, THROTTLE LINKAGE	30-15
2D15	BLADE, WINDSHIELD WIPER	40-65	1E20	CABLE, FUEL SHUT-OFF CONTROL	30-8
5G4	BLADES AND ROTOR, STRAW CHOPPER	120-80	1E21	CABLE, FUEL SHUT-OFF CONTROL	30-9
5G5	BLADES AND ROTOR, STRAW CHOPPER	120-82	5C8	CABLE, REVERSER CONTROL	110-29
1B10	BLOCK, CYLINDER	20-6	4C25	CABLE, VARIABLE CYLINDER CONTROL	70-45
1B14	BLOCK, CYLINDER	20-10	2F2	CABLE, WIRING	40-104
1B12	BLOCK, CYLINDER (6466AH 01)	20-8	3B13	CABLES AND MOUNTINGS, GEARSHIFT	50-5
1B16	BLOCK, ENGINE SHORT	20-12	2C5	CABLES, BATTERY	40-27
1B20	BLOCK, ENGINE SHORT	20-16	3G24	CAM LOBE MOTOR DESTROKE PUMP	50-149
1B22	BLOCK, ENGINE SHORT	20-18	3G23	CAM LOBE MOTOR, COMPLETE	50-148
6D21	BLOCK,CHECK,AUTO.HEADER HEIGHT CONTROL	160-1	3G14	CAM, CARRIER, PISTONS AND	50-138
3F25	BLOCK,MOTOR CYLINDER (FOUR-WHEEL DRIVE)	50-122	3C3	CAM, SHIFTER	50-21
2D12	BLOWER SWITCH	40-61	1C15	CAMSHAFT	20-37
4I2	BLOWER, PRESSURIZER	90-37	1C15	CAMSHAFT GEAR	20-37
3H11	BOOT, PARKING BRAKE CONTROL	60-1	1D22	CAP, ENGINE COOLANT HEATER	20-69
5B16	BOTTOM, FALSE	110-11			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1F6	CAP, EXHAUST RAIN	30 - 19	2E24	COIL, STARTER.....	40 - 101
4B9	CAP, HYDRAULIC OIL RESERVOIR	70 - 3	1E22	COLD WEATHER STARTING AID	30 - 11
3G21	CAP, YOKE, PIVOTS AND	50 - 146	3H21	COLUMN AND WHEEL, STEERING.....	60 - 11
3G2	CARRIER, FIRST PLANET (FOUR-WHEEL DRIVE).....	50 - 124	2E23	COMMUTATOR END FRAME, STARTER	40 - 100
3G14	CARRIER, PISTONS AND CAM	50 - 138	4I10	COMPRESSOR BELT	90 - 45
1D16	CENTER HOUSING, TURBOCHARGER.....	20 - 63	4I11	COMPRESSOR CLUTCH AND SERVICE VALVES.....	90 - 47
3E18	CENTER SECTION, HYDRO, DRIVE (EATON).....	50 - 86	4I14	COMPRESSOR HARDWARE KIT	90 - 51
3E16	CENTER SECTION, HYDROSTATIC DRIVE	50 - 84	4I7	COMPRESSOR HARNESS	90 - 42
5G23	CHAFFER	120 - 102	4I12	COMPRESSOR KIT	90 - 48
5H6	CHAFFER FRAME	120 - 109	4I9	COMPRESSOR MOUNTING AND SUPPORTS	90 - 44
5H8	CHAFFER FRAME BRACKETS.....	120 - 111	4I10	COMPRESSOR MOUNTING AND SUPPORTS	90 - 45
5H6	CHAFFER FRAME COVER	120 - 109	4I12	COMPRESSOR PARTS	90 - 48
5H8	CHAFFER FRAME SWINGERS.....	120 - 111	4I7	COMPRESSOR RELAY	90 - 42
5B24	CHAIN GUIDES, FEEDER CONVEYOR DRIVE.....	110 - 19	2C5	COMPRESSOR, WIRING HARNESS	40 - 27
5D22	CHAIN, CONCAVE ADJUSTING CONTROLS	120 - 21	5D22	CONCAVE ADJUSTING CONTROLS	120 - 21
5I4	CHAIN, CONVEYOR	120 - 133	5D20	CONCAVE ADJUSTING SHAFT	120 - 19
5I3	CHAIN, CONVEYOR, CLEAN GRAIN ELEVATOR	120 - 132	5D12	CONCAVE, OPEN-BAR	120 - 9
5H11	CHAIN, CRANK SHOE.....	120 - 115	5D17	CONCAVE, SPIKE-TOOTH	120 - 15
5B23	CHAIN, DRIVE, FEEDER CONVEYOR.....	110 - 18	4I16	CONDENSER	90 - 53
5B22	CHAIN, FEEDER CONVEYOR	110 - 17	4I19	CONDENSER	90 - 56
6F4	CHAIN, FEEDER HOUSE (LONG)	170 - 11	4I19	CONDENSER, RECEIVER AND AIR CONDITIONER LINES.....	90 - 56
5F17	CHAIN, STRAW WALKER	120 - 67	1B8	CONDITIONER, COOLANT	20 - 3
5I21	CHAIN, TAILINGS ELEVATOR CONVEYOR	120 - 152	1C18	CONNECTING RODS	20 - 41
5I23	CHAIN, UPPER TAILINGS AUGER	120 - 154	2F4	CONNECTOR, ELECTRICAL, SERVICE KIT	40 - 106
6F10	CHAINS, DRIVE, STRAW WALKER	170 - 17	2C21	CONNECTOR, TRAILER HARNESS (EXPORT)	40 - 43
6F1	CHAINS, FEEDER HOUSE (VARIABLE DRIVE	170 - 8	1F11	CONNECTORS, FUEL INJECTION PUMP HOUSING (AH 01).....	30 - 24
4G23	CHANNEL SUPPORTS	90 - 7	1F18	CONNECTORS, FUEL INJECTION PUMP HOUSING (AH 02).....	30 - 32
6C1	CHANNELS, GRAIN TANK INNER UNLDG. AUGER.....	130 - 23	1G10	CONNECTORS, FUEL INJECTION PUMP HOUSING (AH 02).....	30 - 50
3F1	CHARGE PRESSURE RELIEF VALVE BLOCK, KIT (EATON)	50 - 95	1G19	CONNECTORS, FUEL INJECTION PUMP HOUSING (AH 02,03)	30 - 60
3D13	CHARGE PUMP MOUNTING, HYDROSTATIC DRIVE	50 - 56	2F8	CONNECTORS, SUPPLEMENTARY TERMINALS.....	40 - 110
3D11	CHARGE PUMP, HYDROSTATIC DRIVE.....	50 - 54	6F24	CONSOLE COVER DECALS.....	170 - 33
6D21	CHECK BLOCK, AUTO.HEADER HEIGHT CONTROL	160 - 1	4H12	CONSOLE COVERS	90 - 21
1G8	CHECK VALVE, FUEL (AH 01, 02).....	30 - 48	4H12	CONSOLE PANEL	90 - 21
3G16	CHECK VALVES, CAM LOBE MOTOR	50 - 140	2B22	CONSOLE, GRAIN LOSS (HARVESTRAK)	40 - 18
5F19	CHOPPER HOUSING, STRAW	120 - 69	4E10	CONT. LEVER, PLAT. FORE AND AFT (EXPORT)	70 - 81
5F20	CHOPPER HOUSING, STRAW	120 - 70	2D1	CONTROL BOX, LOW SHAFT SPEED MONITORING	40 - 48
5G3	CHOPPER, STRAW, KNIFE AND SUPPORT	120 - 78	3D6	CONTROL CABLE AND LEVER, HYDRO. DRIVE.....	50 - 49
5F23	CHOPPER, STRAW, PLATE AND FINS.....	120 - 73	3D8	CONTROL CABLE MOUNTING HYDRO. DRIVE.....	50 - 51
2D7	CIGAR LIGHTER	40 - 55	3E14	CONTROL HANDLE, HYDRO. DR. DISPLACEMENT	50 - 82
2B22	CIRCUIT BOX, HARVESTRAK	40 - 18	4E10	CONTROL LEVER, HYD. REEL LIFT (EXPORT).....	70 - 81
2C7	CIRCUIT BREAKER AND RELAY PANEL	40 - 29	4E9	CONTROL LEVER, HYDRAULIC REEL LIFT	70 - 80
2D10	CIRCUIT BREAKER, ELECTRIC CLUTCH.....	40 - 59	4E9	CONTROL LEVER, PLATFORM LIFT	70 - 80
2D10	CIRCUIT BREAKER, HARVESTRAK.....	40 - 59	1E24	CONTROL LEVER, THROTTLE LINKAGE	30 - 13
2C1	CLAMPS, HARNESS, REAR CAB.....	40 - 23	1G17	CONTROL LINES, FUEL	30 - 58
5I4	CLEAN GRAIN ELEVATOR.....	120 - 133	6E9	CONTROL LINKAGE	160 - 14
6F13	CLEAN GRAIN ELEVATOR DRIVE.....	170 - 21	2B22	CONTROL PANEL, HARVESTRAK COMBINE MONITOR	40 - 18
5I5	CLEAN GRAIN ELEVATOR DRIVE COUNTERSHAFT	120 - 135	4C16	CONTROL PLUG, FLOW.....	70 - 35
5I7	CLEAN GRAIN ELEVATOR DRIVE IDLER.....	120 - 137	3H3	CONTROL VALVE	50 - 152
5I7	CLEAN GRAIN ELEVATOR DRIVE TIGHTENER.....	120 - 137	3G4	CONTROL VALVE (FOUR-WHEEL DRIVE)	50 - 126
5H24	CLEAN GRAIN ELEVATOR HOUSING.....	120 - 129	4D11	CONTROL VALVE KIT, SECONDARY	70 - 57
5I2	CLEAN GRAIN ELEVATOR HOUSING.....	120 - 131	4D13	CONTROL VALVE KIT, SECONDARY	70 - 59
6F13	CLEAN GRAIN ELEVATOR SHEAVES AND BELTS.....	170 - 21	4E12	CONTROL VALVE LINKAGE, REEL SPEED	70 - 83
5H20	CLEAN GRAIN LOWER AUGER AND HOUSING	120 - 125	3G5	CONTROL VALVE SOLENOID (FOUR-WHEEL DRIVE)	50 - 127
5H22	CLEAN GRAIN LOWER AUGER HOUSING.....	120 - 127	3H4	CONTROL VALVE SOLENOID (FOUR-WHEEL DRIVE)	50 - 153
5H13	CLEANING FAN	120 - 117	3E12	CONTROL VALVE, HYDRO. DR. DISPLACEMENT (EATON).....	50 - 80
5H16	CLEANING FAN AIR DUCTS	120 - 121	3E7	CONTROL VALVE, HYDRO. DRIVE DISPLACEMENT	50 - 75
6F10	CLEANING FAN DRIVE BELTS	170 - 17	4E24	CONTROL VALVE, HYDROSTATIC DR. REEL FLOW	70 - 95
6F10	CLEANING FAN DRIVE SHEAVES.....	170 - 17	4D3	CONTROL VALVE, SECONDARY.....	70 - 49
5H15	CLEANING FAN HOUSING	120 - 119			
2C3	CLEANING FAN MAGNETIC SENSOR.....	40 - 25			
5H15	CLEANING FAN PROTECTOR SHIELD.....	120 - 119			
5H18	CLEANING FAN SPEED CONTROL.....	120 - 123			
2B22	CLEANING SHOE SENSOR	40 - 18			
4G25	CLUTCH COVER	90 - 9			
2D7	CLUTCH, ELECTRIC, SWITCH.....	40 - 55			
2B16	CLUTCH, ELECTROMAGNETIC HEADER.....	40 - 11			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4D4	CONTROL VALVE, SECONDARY.....	70-50	6C3	COVERS, GRASS SEED UNLOADING AUGER	130-25
4D6	CONTROL VALVE, SECONDARY.....	70-52	6C1	COVERS, GRAIN TANK INNER UNLOADING AUGER	130-23
3H6	CONTROL VALVES, FLOW.....	50-155	1C14	CRANKSHAFT	20-36
3G8	CONTROL VALVES, FLOW (FOUR-WHEEL DRIVE)	50-131	1C14	CRANKSHAFT DAMPER	20-36
2D3	CONTROL, DIAL-A-MATIC HEADER HEIGHT	40-50	5H11	CRANKSHAFT DRIVE TIGHTENER, SHOE	120-115
6E11	CONTROL, DIAL-A-MATIC HEADER HEIGHT	160-16	1C4	CRANKSHAFT OIL SEAL	20-26
1E20	CONTROL, FUEL SHUT-OFF	30-8	1C4	CRANKSHAFT OIL SEAL HOUSING	20-26
1E21	CONTROL, FUEL SHUT-OFF	30-9	1C14	CRANKSHAFT PULLEY	20-36
5H18	CONTROL, SPEED, CLEANING FAN.....	120-123	5F14	CRANKSHAFT, STRAW WALKER FRONT	120-63
4C25	CONTROL, VARIABLE CYLINDER	70-45	5F16	CRANKSHAFT, STRAW WALKER REAR.....	120-65
4F11	CONTROL, PRES. VALVE, ACCUMULATOR AND MTG. BRKT.	70-107	3F14	CRAWLER BEARINGS.....	50-109
5D22	CONTROLS, CONCAVE ADJUSTING	120-21	3F16	CRAWLER BEARINGS.....	50-111
3H11	CONTROLS, PARKING BRAKE	60-1	3F19	CRAWLER DRIVE BEARINGS	50-115
5J2	CONTROLS, SEPARATOR DRIVE	120-159	3F19	CRAWLER DRIVE SHIELD	50-115
4E21	CONVERSION HOSES AND COUPLERS	70-92	3F19	CRAWLER DRIVE SPROCKET.....	50-115
6E15	CONVERSION, DIAL-A-MATIC HEADER HEIGHT CONTROL CONVERSION.....	160-21	3F11	CRAWLER FRAME, R.H. AND L.H.	50-105
5I4	CONVEYOR CHAIN	120-133	3F14	CRAWLER IDLER.....	50-109
5I3	CONVEYOR CHAIN, CLEAN GRAIN ELEVATOR	120-132	3F11	CRAWLER ROLLERS	50-105
1B8	COOLANT CONDITIONER.....	20-3	3F14	CRAWLER SHAFT	50-109
1D21	COOLANT HEATER, ENGINE.....	20-68	3F16	CRAWLER SHAFTS.....	50-111
1C23	COOLER, ENGINE OIL	20-46	3F9	CRAWLER SHOES	50-103
1C24	COOLER, ENGINE OIL	20-47	3F10	CRAWLER SHOES	50-104
6E6	COOLER, LINES AND HOSE, OIL	160-11	3F16	CRAWLER TIGHTENER	50-111
1D22	CORD, ENGINE COOLANT HEATER.....	20-69	3F9	CRAWLER TRACKS.....	50-103
4I16	CORE, VALVE	90-53	3F10	CRAWLER TRACKS.....	50-104
4G4	CORNER FRAME.....	80-17	6C8	CROSS AUGER DRIVE TIGHTENERS, GRAIN TANK	130-31
6D15	COUNTERSHAFT DRIVE IDLER, SECONDARY	140-15	6F15	CROSS AUGER DRIVES.....	170-23
6D9	COUNTERSHAFT SHEAVES, PRIMARY	140-9	6B24	CROSS AUGER, FRONT, GRAIN TANK	130-21
6D10	COUNTERSHAFT SHEAVES, PRIMARY (DUAL- RANGE CYLINDER DRIVE)	140-10	6B25	CROSS AUGER, REAR, GRAIN TANK	130-22
6D5	COUNTERSHAFT, PRIMARY AND MOUNTINGS	140-5	4F23	CROSS BRACES, SEPARATOR.....	80-10
6E24	COUNTERSHAFT, PRIMARY TO HYD. REEL LIFT	170-6	5E20	CTRSHAFT.CYL.DR.BRG.HSG.LUBE BANK-RH	120-44
6D13	COUNTERSHAFT, SECONDARY	140-13	5G2	CURTAIN, STRAW CHOPPER	120-77
6B22	COUNTERSHAFT, UNLOADING AUGER.....	130-19	5F10	CURTAINS, SEPARATOR	120-59
5I5	COUNTERSHAFT, DRIVE, CLEAN GRAIN ELEVATOR.....	120-135	4H9	CUSHIONS, SEAT (PERSONAL POSTURE SEAT).....	90-18
3C5	COUNTERSHAFT, GEARS, BEARINGS, TRANSMISSION ...	50-23	5E20	CYL.DRIVE CTRSHAFT.BRG.HSG.LUBE BANK-RH	120-44
5C18	COUNTERSHAFT, UPPER, FDR.HSE.-VARIABLE DR.	110-41	5E19	CYL.SHAFT BRG.HSG.LUBE BANK (R.H.)	120-43
5B8	COUPLER, QUIK-TATCH (LONG)(L.H.)	110-3	1B10	CYLINDER BLOCK.....	20-6
5B6	COUPLER, QUIK-TATCH (R.H.)	110-1	1B14	CYLINDER BLOCK.....	20-10
5B7	COUPLER, QUIK-TATCH (VARIABLE DR.)(L.H.).....	110-2	1B12	CYLINDER BLOCK (6466AH 01)	20-8
3D10	COUPLER, HYDROSTATIC DRIVE MOTOR MOUNTING ..	50-53	3D18	CYLINDER BLOCK ASSEMBLY, HYDRO. DR. PUMP	50-61
4E19	COUPLERS, HOSES (USED WITH PLATFORMS)	70-90	3D21	CYLINDER BLOCK ASSEMBLY, HYDROSTATIC DRIVE PUMP (EATON).....	50-64
2C6	COVER PLATES, ELEC., ENGINE COMPT. FIREWALL.....	40-28	3F25	CYLINDER BLOCK, MOTOR (FOUR-WHEEL DRIVE)	50-122
5H6	COVER, CHAFFER FRAME	120-109	5F8	CYLINDER COVER DEFLECTOR.....	120-57
4G25	COVER, CLUTCH.....	90-9	5F8	CYLINDER COVERS	120-57
5E11	COVER, DUAL-RANGE CYLINDER DRIVE GEAR CASE	120-34	5D24	CYLINDER DRIVE INTERMEDIATE SHAFT.....	120-23
3G2	COVER, FIRST PLANET (FOUR-WHEEL DRIVE).....	50-124	5E1	CYLINDER DRIVE INTERMEDIATE SHAFT DUAL-RANGE CYLINDER DRIVE).....	120-24
3D16	COVER, FRONT, HYDRO. DRIVE PUMP (EATON)	50-59	5E4	CYLINDER DRIVE SUPPORT BRACES.....	120-27
3D14	COVER, FRONT, HYDROSTATIC DRIVE PUMP.....	50-57	5E6	CYLINDER DRIVE TIGHTENER	120-29
6B19	COVER, GRAIN TANK.....	130-15	1C6	CYLINDER HEAD.....	20-28
1C3	COVER, INJECTION PUMP GEAR.....	20-25	1C6	CYLINDER HEAD GASKET.....	20-28
3G16	COVER, INNER	50-140	1D11	CYLINDER HEAD GASKET KIT	20-58
3G19	COVER, QUILL, BEARING AND	50-144	5E9	CYLINDER INTERMEDIATE DRIVE SUPPORT BRACES	120-32
1C12	COVER, ROCKER ARM	20-34	1C18	CYLINDER LINER	20-41
2E20	COVER, STARTER SOLENOID	40-97	1B8	CYLINDER LINER PACKING LUBRICANT.....	20-3
1C19	COVER, TACHOMETER DRIVE GEAR	20-42	5E18	CYLINDER SHAFT BRG.HSG.LUBE BANK SYS-RH.....	120-42
1D18	COVER, THERMOSTAT	20-65	5E21	CYLINDER SHAFT BRG.LUBE BANK-LH-HYDRO	120-45
1C3	COVER, TIMING GEAR.....	20-25	5F9	CYLINDER SHEAR BAR	120-58
4H19	COVERS AND INNER ROOF	90-29	5D19	CYLINDER SPEED TACHOMETER	120-17
4H17	COVERS, CAB	90-27	5E23	CYLINDER TACHOMETER BEATER	120-47
4H12	COVERS, CONSOLE	90-21	5E24	CYLINDER TACHOMETER BEATER	120-48
5F8	COVERS, CYLINDER.....	120-57	6F6	CYLINDER TACHOMETER BELT	170-13
6C2	COVERS, GRAIN TANK FRONT AND REAR ADJ.....	130-24	5E23	CYLINDER TACHOMETER DRIVE	120-47
			5E24	CYLINDER TACHOMETER DRIVE	120-48
			6F6	CYLINDER TACHOMETER SHEAVE	170-13

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3H15	CYLINDER, BRAKE MASTER	60 - 5	5I18	DOOR, TAILINGS ELEVATOR HOUSING	120 - 149
3H16	CYLINDER, BRAKE SLAVE.....	60 - 6	4G8	DOOR, UPPER, ENGINE COMPARTMENT	80 - 21
4F8	CYLINDER, HYDRAULIC, HEADER LIFT.....	70 - 104	4H17	DOORS, CAB	90 - 27
5D9	CYLINDER, RASP BAR (DUAL-RANGE CYLINDER DRIVE)	120 - 6	6F17	DR.,PRIMARY CTRSHFT TO SECONDARY CTRSHFT	170 - 25
5D8	CYLINDER, RASP-BAR	120 - 5	4I21	DRAIN TUBES, EVAPORATOR	90 - 58
5D15	CYLINDER, SPIKE TOOTH (DUAL-RANGE CYLINDER DRIVE)	120 - 13	6E24	DRIVE BELT, HYDRAULIC REEL LIFT	170 - 6
5D14	CYLINDER, SPIKE-TOOTH	120 - 11	5B24	DRIVE CHAIN GUIDES, FEEDER CONVEYOR.....	110 - 19
3I9	CYLINDER, STEERING	60 - 24	5B23	DRIVE CHAIN, FEEDER CONVEYOR	110 - 18
4D19	CYLINDER,UNLOADING AUGER SWING HYDRAULIC	70 - 65	5I5	DRIVE COUNTERSHAFT,CLEAN GRAIN ELEVATOR	120 - 135
4D21	CYLINDER,UNLOADING AUGER SWING HYDRAULIC	70 - 67	6D19	DRIVE IDLER, FEEDER HOUSE	140 - 19
4D22	CYLINDER,UNLOADING AUGER SWING HYDRAULIC	70 - 68	6D15	DRIVE IDLER, SECONDARY COUNTERSHAFT	140 - 15
4D24	CYLINDER,UNLOADING AUGER SWING HYDRAULIC	70 - 70	5G20	DRIVE SHAFT, SHOE GRAIN SUPPLY AUGERS.....	120 - 99
D					
1C14	DAMPER, CRANKSHAFT	20 - 36	6E24	DRIVE SHEAVES, HYDRAULIC REEL LIFT	170 - 6
2C16	DECAL, BECON LIGHTS (EXPORT)	40 - 38	5G22	DRIVE TGHTR., SHOE GRAIN SUPPLY AUGERS	120 - 101
6F22	DECAL, PANEL	170 - 31	5I7	DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR	120 - 137
6F25	DECALS	170 - 34	5E6	DRIVE TIGHTENER, CYLINDER.....	120 - 29
6F24	DECALS, CONSOLE COVER	170 - 33	5G21	DRIVE TIGHTENERS.....	120 - 100
6F21	DECALS, FRONT AND REAR.....	170 - 29	6C8	DRIVE TIGHTENERS,CROSS AUGER,GRAIN TANK	130 - 31
6F24	DECALS, INSTRUMENT PANEL.....	170 - 33	3B24	DRIVE WHEEL AXLE.....	50 - 16
6F19	DECALS, RIGHT-HAND AND LEFT-HAND.....	170 - 27	3B14	DRIVE WHEELS.....	50 - 6
6D17	DECLUTCHING IDLER.....	140 - 17	3B15	DRIVE WHEELS, DUAL.....	50 - 7
5F8	DEFLECTOR, CYLINDER COVER	120 - 57	3B17	DRIVE WHEELS, HIGH FLOATATION	50 - 9
5I9	DEFLECTOR, LOADING AUGER	120 - 139	5F3	DRIVE, BEATER.....	120 - 52
3G24	DESTROKE PUMP, CAM LOBE MOTOR.....	50 - 149	5F4	DRIVE, BEATER.....	120 - 53
6E13	DIAL-A-MATIC HDR. HEIGHT CONTROL SWITCH.....	160 - 19	5F5	DRIVE, BEATER.....	120 - 54
2D3	DIAL-A-MATIC HEADER HEIGHT CONTROL	40 - 50	5F6	DRIVE, BEATER, DUAL-RANGE.....	120 - 55
6E9	DIAL-A-MATIC HEADER HEIGHT CONTROL	160 - 14	6F13	DRIVE, CLEAN GRAIN ELEVATOR	170 - 21
6E11	DIAL-A-MATIC HEADER HEIGHT CONTROL	160 - 16	5E23	DRIVE, CYLINDER TACHOMETER	120 - 47
6E15	DIAL-A-MATIC HEADER HEIGHT CONTROL CONVERSION	160 - 21	5E24	DRIVE, CYLINDER TACHOMETER	120 - 48
3C9	DIFFERENTIAL GEARS AND SHAFTS	50 - 27	5C3	DRIVE, FIXED	110 - 24
3C10	DIFFERENTIAL GEARS AND SHAFTS	50 - 28	5C4	DRIVE, FIXED	110 - 25
3C1	DIFFERENTIAL HOUSING.....	50 - 18	5C13	DRIVE, FIXED	110 - 35
3C3	DIFFERENTIAL HOUSING COVER	50 - 21	6F13	DRIVE, LOADING AUGER.....	170 - 21
2E10	DIODE RING, ALTERNATOR, 72 AMP.....	40 - 86	5C16	DRIVE, LONG FEEDER HOUSE FIXED.....	110 - 39
2E12	DIODE TRIO ASSEMBLY, ALTERNATOR, 90 AMP	40 - 88	5E8	DRIVE, SLOW SPEED CYLINDER	120 - 31
1C1	DIPSTICK TUBE.....	20 - 22	3F21	DRIVE, TRANSMISSION, MUD SHIELDS	50 - 117
1C1	DIPSTICK, ENGINE OIL	20 - 22	6F15	DRIVES, CROSS AUGER	170 - 23
6E22	DISK, ROTARY SCREEN	170 - 4	1E10	DRIVES, RADIATOR FAN	20 - 81
3E12	DISPLACEMENT CONTROL VALVE, HYDRO. DR. (EATON)	50 - 80	6F8	DRIVES, STRAW CHOPPER	170 - 15
3E7	DISPLACEMENT CONTROL VALVE, HYDRO. DRIVE	50 - 75	6F8	DRIVES, STRAW SPREADER	170 - 15
1E4	DISPLACER, ROTARY SCREEN DRIVE BELT	20 - 75	6F12	DRIVES, TAILINGS ELEVATOR AND AUGER.....	170 - 19
2D13	DOME LIGHT	40 - 63	6F15	DRIVES, UNLOADING AUGER	170 - 23
4G14	DOOR AND SEALS, ROTARY SCREEN	80 - 27	6F15	DRIVES, VERTICAL UNLOADING AUGER	170 - 23
5B12	DOOR LEVER, TOP, FEEDER HOUSE	110 - 7	6E2	DROP RATE VALVE,AUTO.HDR.HGT.CONTROL	160 - 7
5H24	DOOR, CLEAN GRAIN ELEVATOR	120 - 129	6E3	DROP RATE VLV.,AUTO HDR. HGHT. CONTROL	160 - 8
5H22	DOOR, CLEAN GRAIN LOWER AUGER	120 - 127	6E3	DROP RATE VLV.,DIAL-A MATIC HDR. HGHT. CONTROL	160 - 8
4G9	DOOR, ENGINE COMPARTMENT MIDDLE.....	80 - 22	3H19	DRUM, BRAKE SHOES.....	60 - 9
6B9	DOOR, GRAIN TANK.....	130 - 5	5B21	DRUM, FEEDER CONVEYOR.....	110 - 16
6B10	DOOR, GRAIN TANK.....	130 - 6	3B15	DUAL DRIVE WHEELS	50 - 7
6B11	DOOR, GRAIN TANK.....	130 - 7	3B16	DUAL WHEELS, WIDE SPACED (PLANETARY FINAL DRIVE)	50 - 8
6B17	DOOR, GRAIN TANK.....	130 - 13	5F6	DUAL-RANGE BEATER DRIVE.....	120 - 55
6B19	DOOR, GRAIN TANK COVER.....	130 - 15	5E16	DUAL-RANGE CYLINDER DRIVE ARM	120 - 40
4G25	DOOR, INSPECTION, OPERATOR'S PLATFORM.....	90 - 9	5E11	DUAL-RANGE CYLINDER DRIVE GEAR CASE	120 - 34
4H12	DOOR, PANEL	90 - 21	5E14	DUAL-RANGE CYLINDER DRIVE LOCKOUT ARM.....	120 - 37
4F14	DOOR, SEPARATOR CYLINDER	80 - 1	5E13	DUAL-RANGE CYLINDER DRIVE PINION GEARS	120 - 36
5D6	DOOR, STONE TRAP	120 - 3	5E16	DUAL-RANGE CYLINDER DRIVE TIGHTENER	120 - 40
5D12	DOOR, STONE TRAP	120 - 9	5E1	DUAL-RANGE CYLINDER DRIVE, CYLINDER DRIVE INTERMEDIATE SHAFT	120 - 24
4H2	DOOR, TAILINGS ELEVATOR	90 - 11	6D10	DUAL-RANGE CYLINDER DRIVE, PRIMARY COUNTERSHAFT SHEAVES	140 - 10
5I19	DOOR, TAILINGS ELEVATOR	120 - 150	5D9	DUAL-RANGE CYLINDER DRIVE, RASP-BAR CYLINDER	120 - 6
			5H16	DUCTS, AIR, CLEANING FAN	120 - 121

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
	E				
2D10	ELECTRIC CLUTCH CIRCUIT BREAKER	40 - 59	4G4	FAN SHROUD	80 - 17
2D7	ELECTRIC CLUTCH SWITCH	40 - 55	2E10	FAN, ALTERNATOR, 72 AMP	40 - 86
6E9	ELECTRIC HARNESS	160 - 14	2E12	FAN, ALTERNATOR, 90 AMP	40 - 88
2F4	ELECTRICAL CONNECTOR SERVICE KIT	40 - 106	5H13	FAN, CLEANING	120 - 117
2B16	ELECTROMAGNETIC CLUTCH, HEADER	40 - 11	5H16	FAN, CLEANING, AIR DUCTS	120 - 121
1F4	ELEMENT, AIR CLEANER	30 - 17	5H18	FAN, CLEANING, SPEED CONTROL	120 - 123
5I2	ELEVATOR HOUSING, CLEAN GRAIN	120 - 131	1E10	FAN, RADIATOR	20 - 81
5I4	ELEVATOR, CLEAN GRAIN	120 - 133	1E10	FAN, RADIATOR, DRIVES	20 - 81
5H24	ELEVATOR, HOUSING, CLEAN GRAIN	120 - 129	4F14	FEED PLATE, SEPARATOR	80 - 1
2E23	END FRAME, STARTER COMMUTATOR	40 - 100	5B23	FEEDER CONVEYOR BRACKET	110 - 18
4G6	ENGINE COMPARTMENT FIREWALL	80 - 19	5B22	FEEDER CONVEYOR CHAIN	110 - 17
4G9	ENGINE COMPARTMENT MIDDLE DOOR AND FRAME ..	80 - 22	5B23	FEEDER CONVEYOR DRIVE CHAIN	110 - 18
4G6	ENGINE COMPARTMENT REAR SHEETS	80 - 19	5B24	FEEDER CONVEYOR DRIVE CHAIN GUIDES	110 - 19
4G8	ENGINE COMPARTMENT UPPER DOOR	80 - 21	5B21	FEEDER CONVEYOR DRUM	110 - 16
4G8	ENGINE COMPARTMENT UPPER DOOR HINGE	80 - 21	5B23	FEEDER CONVEYOR IDLER	110 - 18
4G12	ENGINE COMPARTMENT WALKWAY	80 - 25	5B21	FEEDER CONVEYOR IDLER SHAFT	110 - 16
2C5	ENGINE COMPARTMENT WIRING HARNESSSES	40 - 27	5B14	FEEDER HOUSE BOTTOM SHEETS	110 - 9
2C6	ENGINE COMPT.FIREWALL ELEC.COVER PLATES	40 - 28	6F4	FEEDER HOUSE CHAIN (LONG)	170 - 11
1D21	ENGINE COOLANT HEATER	20 - 68	6F1	FEEDER HOUSE CHAINS (VARIABLE DRIVE)	170 - 8
1D22	ENGINE COOLANT HEATER	20 - 69	6F2	FEEDER HOUSE DRIVE BELTS (LONG)	170 - 9
1D20	ENGINE MOUNTS	20 - 67	6F3	FEEDER HOUSE DRIVE BELTS (LONG)	170 - 10
1B7	ENGINE OIL	20 - 2	6E25	FEEDER HOUSE DRIVE BELTS (VARIABLE DR.)	170 - 7
1C23	ENGINE OIL COOLER	20 - 46	6D19	FEEDER HOUSE DRIVE IDLER	140 - 19
1C24	ENGINE OIL COOLER	20 - 47	6F3	FEEDER HOUSE DRIVE IDLERS (LONG)	170 - 10
1C1	ENGINE OIL DIPSTICK	20 - 22	6F2	FEEDER HOUSE DRIVE SHEAVES (LONG)	170 - 9
1C21	ENGINE OIL FILTER	20 - 44	6F3	FEEDER HOUSE DRIVE SHEAVES (LONG)	170 - 10
1E11	ENGINE OIL PRESSURE GAUGE LINE	20 - 82	6E25	FEEDER HOUSE DRIVE SHEAVES (VAR.DR.)	170 - 7
1D1	ENGINE OIL PUMP	20 - 48	6F3	FEEDER HOUSE DRIVE TIGHTENERS (LONG)	170 - 10
1D3	ENGINE OIL PUMP (AH 02, 03)	20 - 50	5B20	FEEDER HOUSE FALSE BOTTOM (LONG)	110 - 15
1B24	ENGINE OVERHAUL KIT	20 - 20	5B18	FEEDER HOUSE FALSE BOTTOM (VARIABLE)	110 - 13
1C18	ENGINE OVERHAUL KIT	20 - 41	5C16	FEEDER HOUSE FIXED DRIVE, LONG	110 - 39
6D3	ENGINE POWERSHAFT	140 - 3	5B16	FEEDER HOUSE FRAME AND FALSE BOTTOM	110 - 11
6E21	ENGINE R.H. SIDE BELT TIGHTENERS	170 - 3	5B10	FEEDER HOUSE FRONT SHEETS	110 - 5
6E21	ENGINE R.H. SIDE DRIVE BELTS	170 - 3	4F2	FEEDER HOUSE HYD. HOSE, VARIABLE DRIVE	70 - 98
6E21	ENGINE R.H. SIDE DRIVE SHEAVES	170 - 3	4F3	FEEDER HOUSE HYDRAULIC HOSE	70 - 99
1D11	ENGINE REBUILD GASKET KIT	20 - 58	6F2	FEEDER HOUSE IDLER (LONG)	170 - 9
1B16	ENGINE SHORT BLOCK	20 - 12	6E25	FEEDER HOUSE IDLERS (VARIABLE DRIVE)	170 - 7
1B20	ENGINE SHORT BLOCK	20 - 16	5C1	FEEDER HOUSE L.H.SHIELDS-VARIABLE DR.	110 - 21
1B22	ENGINE SHORT BLOCK	20 - 18	5C15	FEEDER HOUSE LOWER BELT TIGHTENER-LONG	110 - 37
1B9	ENGINE SHORT BLOCK SERIAL NUMBER PLATE	20 - 5	5C13	FEEDER HOUSE LOWER MOUNTINGS	110 - 35
1D20	ENGINE SUPPORTS	20 - 67	5C13	FEEDER HOUSE LOWER SHAFT	110 - 35
1C9	ENGINE TEMPERATURE SENDER	20 - 31	2C23	FEEDER HOUSE LOWER SHAFT SPEED SENSOR-LG ..	40 - 45
1C9	ENGINE TEMPERATURE SWITCH	20 - 31	5C11	FEEDER HOUSE LOWER SHAFT-LONG	110 - 33
6F16	ENGINE TO PRIMARY CTRSHAFT.DRIVE BELTS	170 - 24	5C10	FEEDER HOUSE LOWER SHAFT-VARIABLE DRIVE	110 - 31
1B8	ENGINE VALVE STEM LUBRICANT	20 - 3	5C13	FEEDER HOUSE LOWER SHEAVE	110 - 35
2D7	ETHER START SWITCH	40 - 55	5C10	FEEDER HOUSE LOWER SHEAVE-VARIABLE DRIVE ..	110 - 31
1D9	ETHER STARTING AID	20 - 56	5C16	FEEDER HOUSE MIDDLE BELT BRACE	110 - 39
4I21	EVAPORATOR	90 - 58	5C14	FEEDER HOUSE MIDDLE BELT IDLER-VAR.DRIVE	110 - 36
4I21	EVAPORATOR DRAIN TUBES	90 - 58	5C16	FEEDER HOUSE MIDDLE BELT IDLERS	110 - 39
1D10	EXHAUST MANIFOLD	20 - 57	5C14	FEEDER HOUSE MIDDLE IDLER BRACES-VAR.DR.	110 - 36
1D10	EXHAUST MANIFOLD GASKET	20 - 57	5C6	FEEDER HOUSE REVERSE GEAR BOX	110 - 27
1F6	EXHAUST PIPE	30 - 19	5C11	FEEDER HOUSE SHEAVE-LONG	110 - 33
1C6	EXHAUST VALVES	20 - 28	5C22	FEEDER HOUSE SHEAVES (LONG)	110 - 45
4I21	EXPANSION VALVE, AIR CONDITIONER	90 - 58	5B25	FEEDER HOUSE SHIELD (R.H.)	110 - 20
6B17	EXTENSIONS, GRAIN TANK	130 - 13	5C2	FEEDER HOUSE SHIELD,L.H.-LONG	110 - 23
5E9	EYEBOLTS, CYLINDER INTERMEDIATE DRIVE SUPPORT	120 - 32	5C3	FEEDER HOUSE SHIELDS (L.H.)	110 - 24
			5C4	FEEDER HOUSE SHIELDS (L.H.)	110 - 25
			5B20	FEEDER HOUSE SHIELDS (LONG)	110 - 15
			5B18	FEEDER HOUSE SHIELDS (VARIABLE)	110 - 13
			5B20	FEEDER HOUSE SIDE SHEETS (LONG)	110 - 15
			5B18	FEEDER HOUSE SIDE SHEETS (VARIABLE)	110 - 13
			2C9	FEEDER HOUSE SPEED MONITORING HARNESS	40 - 31
			5C22	FEEDER HOUSE SPROCKETS (LONG)	110 - 45
			6F4	FEEDER HOUSE SPROCKETS (LONG)	170 - 11
5B16	FALSE BOTTOM	110 - 11	5C20	FEEDER HOUSE SPROCKETS (VARIABLE DR.)	110 - 43
5B20	FALSE BOTTOM, FEEDER HOUSE (LONG)	110 - 15	6F1	FEEDER HOUSE SPROCKETS (VARIABLE DRIVE)	170 - 8
5B18	FALSE BOTTOM, FEEDER HOUSE (VARIABLE)	110 - 13	6F2	FEEDER HOUSE TIGHTENERS (LONG)	170 - 9
5H15	FAN HOUSING, CLEANING	120 - 119			
	F				

ALPHABETICAL INDEX - CONTINUED

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
6E25	FEEDER HOUSE TIGHTENERS (VAR. DR.)	170-7	3F3	FOUR-WHEEL DRIVE	50-97
5B12	FEEDER HOUSE TOP DOOR LEVER	110-7	3F22	FOUR-WHEEL DRIVE	50-119
5B12	FEEDER HOUSE TOP SHEETS	110-7	3F24	FOUR-WHEEL DRIVE	50-121
5C18	FEEDER HOUSE UPPER CTRSHAFT.SUPTS-VAR.DR	110-41	3F25	FOUR-WHEEL DRIVE	50-122
5C18	FEEDER HOUSE UPPER CTRSHAFT-VARIABLE DR.	110-41	3G1	FOUR-WHEEL DRIVE	50-123
5C24	FEEDER HOUSE UPPER SHAFT (LONG RICE)	110-47	3G2	FOUR-WHEEL DRIVE	50-124
5C22	FEEDER HOUSE UPPER SHAFT (LONG)	110-45	3G3	FOUR-WHEEL DRIVE	50-125
5C20	FEEDER HOUSE UPPER SHAFT (VARIABLE DR.)	110-43	3G4	FOUR-WHEEL DRIVE	50-126
5C24	FEEDER HOUSE UPPER SHEAVE (LONG RICE)	110-47	3G5	FOUR-WHEEL DRIVE	50-127
4F4	FEEDER HOUSE VARIABLE DRIVE HOSES (EXPORT)	70-100	3G6	FOUR-WHEEL DRIVE	50-129
2C22	FEEDER HSE.LOWER SHAFT SPD.SENSOR-REG	40-44	3G8	FOUR-WHEEL DRIVE	50-131
2C11	FIELD LIGHTS	40-33	3G9	FOUR-WHEEL DRIVE	50-133
4H24	FILTER AND HOUSING, CAB AIR	90-35	3G11	FOUR-WHEEL DRIVE	50-135
4H24	FILTER, CAB AIR	90-35	3H3	FOUR-WHEEL DRIVE	50-152
1C21	FILTER, ENGINE OIL	20-44	3H4	FOUR-WHEEL DRIVE	50-153
1E17	FILTER, FUEL	30-5	3H5	FOUR-WHEEL DRIVE	50-154
1G6	FILTER, FUEL	30-46	3H6	FOUR-WHEEL DRIVE	50-155
1G3	FILTER, FUEL (AH 01)	30-42	3H8	FOUR-WHEEL DRIVE	50-157
1G4	FILTER, FUEL (AH 02, 03)	30-43	3I6	FOUR-WHEEL DRIVE	60-21
1E19	FILTER, FUEL (EXPORT)	30-7	3I9	FOUR-WHEEL DRIVE	60-24
3G11	FILTER, HYDRAULIC OIL RETURN LINES	50-135	3I14	FOUR-WHEEL DRIVE	60-29
4B9	FILTER, HYDRAULIC RESERVOIR	70-3	3I15	FOUR-WHEEL DRIVE	60-31
3F3	FILTER, HYDROSTATIC	50-97	3I19	FOUR-WHEEL DRIVE	60-35
3H8	FILTER, OIL RETURN LINES	50-157	3I20	FOUR-WHEEL DRIVE	60-36
3C17	FINAL DRIVE (CRAWLER TRACKS)	50-36	3I23	FOUR-WHEEL DRIVE	60-39
3C18	FINAL DRIVE AXLE (CRAWLER TRACKS)	50-37	3I24	FOUR-WHEEL DRIVE	60-40
3C12	FINAL DRIVE AXLE SHAFT	50-31	4F16	FRAME AND SIDE SHEET, SEPARATOR R.H.	80-3
3C21	FINAL DRIVE BEARING CAP (CRAWLER TRACKS)	50-40	4F18	FRAME AND SIDE SHEETS, SEPARATOR L.H.	80-5
3C12	FINAL DRIVE BEARINGS	50-31	5H6	FRAME, CHAFFER	120-109
3C16	FINAL DRIVE BEARINGS	50-35	4G4	FRAME, CORNER	80-17
3C18	FINAL DRIVE BEARINGS (CRAWLER TRACKS)	50-37	3F11	FRAME, CRAWLER, R.H. AND L.H.	50-105
3C19	FINAL DRIVE BEARINGS (CRAWLER TRACKS)	50-38	4G9	FRAME, ENGINE COMPARTMENT MIDDLE	80-22
3C18	FINAL DRIVE GEAR (CRAWLER TRACKS)	50-37	5B16	FRAME, FEEDER HOUSE	110-11
3C16	FINAL DRIVE GEARS	50-35	4G25	FRAME, OPERATOR'S PLATFORM	90-9
3C21	FINAL DRIVE HOUSING (CRAWLER TRACKS)	50-40	3I13	FRAME, REAR AXLE	60-28
3C16	FINAL DRIVE INNER HOUSING	50-35	4H4	FRAME, SEALS, AND SEAT CONSOLE	90-13
3C12	FINAL DRIVE OUTER HOUSING	50-31	5H4	FRAME, SIEVE	120-107
3C19	FINAL DRIVE PINION (CRAWLER TRACKS)	50-38	3F12	FRAME, TRACK ROLLER	50-106
3C16	FINAL DRIVE PINION SHAFT	50-35	6C2	FRONT AND REAR GRAIN TANK AUGER COVERS, ADJ.	130-24
3C12	FINAL DRIVE PLANETARY PINION	50-31	3D16	FRONT COVER, HYDRO. DRIVE PUMP (EATON)	50-59
3C19	FINAL DRIVE SHAFTS (CRAWLER TRACKS)	50-38	3D14	FRONT COVER, HYDROSTATIC DRIVE PUMP	50-57
2B22	FINGERS, TRASH (HARVESTRAK)	40-18	6B24	FRONT CROSS AUGER, GRAIN TANK	130-21
5F23	FINS, PLATE, STRAW CHOPPER	120-73	5G21	FRONT DRIVEN SHEAVE SHIELD	120-100
5F24	FINS, STRAW CHOPPER	120-74	4G11	FRONT ENGINE COMPARTMENT PANEL	80-24
4G6	FIREWALL, ENGINE COMPARTMENT	80-19	1C3	FRONT OIL SEAL	20-25
3G2	FIRST PLANET CARRIER (FOUR-WHEEL DRIVE)	50-124	1G8	FUEL CHECK VALVE (AH 01, 02)	30-48
3G2	FIRST PLANET COVER (FOUR-WHEEL DRIVE)	50-124	1G9	FUEL CHECK VALVE (AH-03)	30-49
3G2	FIRST PLANET PINION (FOUR-WHEEL DRIVE)	50-124	1G17	FUEL CONTROL LINES	30-58
5E19	FITTING,CYL.SHAFT BRG.HSG.LUBE BANK-RH	120-43	1E17	FUEL FILTER	30-5
3F4	FITTINGS, HYDROSTATIC DRIVE OIL COOLER	50-98	1G6	FUEL FILTER	30-46
2C16	FLASHER HAZARD WARNING (EXPORT)	40-38	1G3	FUEL FILTER (AH 01)	30-42
2C16	FLASHER, HAZARD WARNING (EXPORT)	40-38	1G4	FUEL FILTER (AH 02, 03)	30-43
2C9	FLASHER, SIGNAL	40-31	1E19	FUEL FILTER (EXPORT)	30-7
1D23	FLAT ROTARY SCREEN	20-70	1G5	FUEL FILTER KIT	30-44
6B17	FLIP-UPS, GRAIN TANK	130-13	2D10	FUEL GAUGE	40-59
4G25	FLOORBOARD, OPERATOR'S PLATFORM	90-9	2C3	FUEL GAUGE SENDING UNIT	40-25
4H2	FLOORMAT, L.H. REAR	90-11	1G15	FUEL INJECTION LINES (AH 03)	30-56
4G25	FLOORMAT, OPERATOR'S PLATFORM	90-9	1G1	FUEL INJECTION NOZZLE	30-40
4C16	FLOW CONTROL PLUG	70-35	1F9	FUEL INJECTION NOZZLES	30-22
4E24	FLOW CONTROL VALVE, HYDROSTATIC DR. REEL	70-95	1F7	FUEL INJECTION NOZZLES (AH 01)	30-20
3H6	FLOW CONTROL VALVES	50-155	1G15	FUEL INJECTION NOZZLES (AH 03)	30-56
3G8	FLOW CONTROL VALVES (FOUR-WHEEL DRIVE)	50-131	1F9	FUEL INJECTION PIPES	30-22
1C14	FLYWHEEL	20-36	1F7	FUEL INJECTION PIPES (AH 01)	30-20
4E10	FORE AND AFT CONT. LEVER, PLAT. (EXPORT)	70-81	1F9	FUEL INJECTION PUMP	30-22
3C1	FORKS, SHIFTER	50-18	1F7	FUEL INJECTION PUMP (AH 01)	30-20
2B9	FOUR-WHEEL DRIVE	40-3			

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE	
1G11	FUEL INJECTION PUMP GOVERNOR LEVERS AND CONTROL (AH 02)	30 - 52	5E13 GEARS, PINION, DUAL-RANGE CYLINDER DRIVE	120 - 36
1F14	FUEL INJECTION PUMP GOVERNOR LEVERS AND CONTROLS (AH 01)	30 - 28	3C5 GEARS,BEARINGS,TRANSMISSION COUNTERSHAFT....	50 - 23
1F20	FUEL INJECTION PUMP GOVERNORS LEVERS AND CONTROL (AH 02)	30 - 34	3C5 GEARS,BEARINGS,TRANSMISSION INPUT SHAFT.....	50 - 23
1G21	FUEL INJECTION PUMP GOVERNORS LEVERS AND CONTROL (AH 02,03)	30 - 62	3C7 GEARS,BEARINGS,TRANSMISSION PINION SHAFT.....	50 - 25
1G10	FUEL INJECTION PUMP HOUSING CONNECTOR (AH 02)	30 - 50	3B13 GEARSHIFT CABLES AND MOUNTINGS	50 - 5
1F11	FUEL INJECTION PUMP HOUSING CONNECTORS (AH 01)	30 - 24	3B9 GEARSHIFT LEVER ASSEMBLY	50 - 1
1F18	FUEL INJECTION PUMP HOUSING CONNECTORS (AH 02)	30 - 32	3B11 GEARSHIFT RANGE SHIFTER AND SUPPORT	50 - 3
1G19	FUEL INJECTION PUMP HOUSING CONNECTORS (AH 02,03)	30 - 60	4B9 GLASS, LEVEL SIGHT, HYDRAULIC RESERVOIR.....	70 - 3
1G17	FUEL INJECTION PUMP LUBE LINES.....	30 - 58	1F14 GOVERNOR LEVERS AND CONTROLS, FUEL INJECTION PUMP (AH 01).....	30 - 28
1E17	FUEL LINES	30 - 5	1F20 GOVERNOR LEVERS AND CONTROLS, FUEL INJECTION PUMP (AH 02).....	30 - 34
1E18	FUEL LINES (EXPORT).....	30 - 6	1G11 GOVERNOR LEVERS AND CONTROLS, FUEL INJECTION PUMP (AH 02).....	30 - 52
1E17	FUEL PUMP	30 - 5	1G21 GOVERNOR LEVERS AND CONTROLS, FUEL INJECTION PUMP (AH 02,03)	30 - 62
1F24	FUEL SHUT-OFF BRACKET (AH 02, 03).....	30 - 38	5I2 GRAIN ELEVATOR HOUSING, CLEAN	120 - 131
1E20	FUEL SHUT-OFF CONTROL.....	30 - 8	5I4 GRAIN ELEVATOR, CLEAN	120 - 133
1E21	FUEL SHUT-OFF CONTROL.....	30 - 9	2B22 GRAIN LOSS CONSOLE, HARVESTRAK	40 - 18
1E15	FUEL TANK	30 - 3	6B6 GRAIN TANK	130 - 2
1E15	FUEL TANK SUPPORTS	30 - 3	6B9 GRAIN TANK	130 - 5
1F23	FUEL TRANSFER PUMP.....	30 - 37	6B11 GRAIN TANK	130 - 7
1G13	FUEL TRANSFER PUMP.....	30 - 54	2C16 GRAIN TANK AUGER MONITOR (EXPORT).....	40 - 38
1F17	FUEL TRANSFER PUMP (AH 01)	30 - 31	6B19 GRAIN TANK COVER	130 - 15
1F22	FUEL TRANSFER PUMP (AH 02)	30 - 36	6B19 GRAIN TANK COVER DOOR	130 - 15
1G24	FUEL TRANSFER PUMP (AH 03)	30 - 65	6C8 GRAIN TANK CROSS AUGER DRIVE TIGHTENERS.....	130 - 31
1G25	FUEL TRANSFER PUMP (ROBERT BOSCH)	30 - 66	6B17 GRAIN TANK DOOR	130 - 13
6E2	FULL FLOW PLUG, AUTOMATIC HDR.HGT.CTL.....	160 - 7	6B17 GRAIN TANK EXTENSIONS	130 - 13
G				
1D11	GASKET KIT, CYLINDER HEAD.....	20 - 58	2C18 GRAIN TANK FILL INDICATOR (EXPORT)	40 - 40
1D11	GASKET KIT, ENGINE REBUILD	20 - 58	2C18 GRAIN TANK FILL INDICATOR BRKT. (EXPORT)	40 - 40
1C6	GASKET, CYLINDER HEAD	20 - 28	6B17 GRAIN TANK FLIP-UPS	130 - 13
1D10	GASKET, EXHAUST MANIFOLD	20 - 57	6B24 GRAIN TANK FRONT CROSS AUGER	130 - 21
1D7	GASKET, INTAKE MANIFOLD	20 - 54	6C1 GRAIN TANK INNER UNLDG.AUGER CHANNELS.....	130 - 23
1C11	GASKET, OIL PAN.....	20 - 33	6C1 GRAIN TANK INNER UNLOADING AUGER COVERS	130 - 23
1C5	GASKET, OIL PAN (AH 01).....	20 - 27	2B12 GRAIN TANK LIGHT	40 - 7
1C12	GASKET, ROCKER ARM COVER	20 - 34	5I12 GRAIN TANK LOADING AUGER GEAR CASE	120 - 143
1C3	GASKET, TIMING GEAR COVER	20 - 25	6B25 GRAIN TANK REAR CROSS AUGER	130 - 22
3C3	GASKET, TRANSMISSION AND DIFFERENTIAL	50 - 21	6B10 GRAIN TANK SKIRTS	130 - 6
1D17	GASKET, WATER PUMP.....	20 - 64	6B13 GRAIN TANK SKIRTS	130 - 9
3E14	GASKET,HYDRO.DR.DISPLACEMENT CTL.VALVE	50 - 82	6B18 GRAIN TANK SUMP BAFFLE	130 - 14
2B25	GAUGE, ACCUMULATOR PRESSURE	40 - 21	6C5 GRAIN TANK SUMP HOUSING AND SHIELD.....	130 - 27
2D10	GAUGE, FUEL	40 - 59	6C12 GRAIN TANK VERTICAL AUGER AND HOUSING	130 - 35
2D10	GAUGE, OIL PRESSURE	40 - 59	6C3 GRASS SEED UNLDG.AUGER COVERS ATTACHMENT	130 - 25
2D10	GAUGE, WATER TEMPERATURE	40 - 59	2E8 GRILLE, RADIO	40 - 83
2C5	GAUGE, WATER TEMPERATURE, SENDING UNIT.....	40 - 27	4I22 GROMMET, HEATER HOSES.....	90 - 59
2D10	GAUGES, INSTRUMENT PANEL	40 - 59	5G11 GUARD, STRAW SPREADER.....	120 - 89
5C6	GEAR BOX, REVERSER.....	110 - 27	5B24 GUIDES, FEEDER CONVEYOR DRIVE CHAIN.....	110 - 19
5C6	GEAR BOX, REVERSER, FEEDER HOUSE	110 - 27	H	
5E11	GEAR CASE, DUAL-RANGE CYLINDER DRIVE	120 - 34	4H17 HANDLE, CAB	90 - 27
5I12	GEAR CASE, GRAIN TANK LOADING AUGER	120 - 143	5B14 HANDLE, FEEDER HOUSE BOTTOM SHEETS	110 - 9
5I11	GEAR CASE, LOADING AUGER	120 - 141	5G2 HANDLE, STRAW CHOPPER CURTAIN	120 - 77
6C10	GEAR CASE, LOWER, VERTICAL AUGER	130 - 33	5F19 HANDLE, STRAW CHOPPER HOUSING	120 - 69
6C18	GEAR CASE,DRIVE,HORIZONTAL UNLDG.AUGER	130 - 41	5F20 HANDLE, STRAW CHOPPER HOUSING	120 - 70
1C19	GEAR COVER, TACHOMETER DRIVE	20 - 42	5G3 HANDLE, STRAW CHOPPER KNIFE AND SUPPORT	120 - 78
1C15	GEAR, CAMSHAFT	20 - 37	6B6 HANDRAIL, GRAIN TANK	130 - 2
3C18	GEAR, FINAL DRIVE (CRAWLER TRACKS)	50 - 37	6B11 HANDRAIL, GRAIN TANK	130 - 7
3C9	GEARS AND SHAFTS, DIFFERENTIAL	50 - 27	4G19 HANDRAIL, OPERATOR'S PLATFORM	90 - 3
3C10	GEARS AND SHAFTS, DIFFERENTIAL	50 - 28	4G21 HANDRAILS, OPERATOR'S PLATFORM (TRACKS).....	90 - 5
3C16	GEARS, FINAL DRIVE.....	50 - 35	4I14 HARDWARE KIT, COMPRESSOR	90 - 51
			6E9 HARNESS ADAPTER, DIAL-A-MATIC	160 - 14
			4I7 HARNESS, COMPRESSOR.....	90 - 42
			6E9 HARNESS, ELECTRIC.....	160 - 14
			2C9 HARNESS, FEEDER HOUSE SPEED MONITORING	40 - 31
			2B24 HARNESS, HARVESTRAK ADAPTER	40 - 20

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2D3	HARNESS, INSTRUMENT PANEL WIRING	40 - 50	1E8	HOSES	20 - 79
2B19	HARNESS, LOW SHAFT SPEED MONITOR'S	40 - 15	4E19	HOSES AND COUPLERS (USED WITH PLATFORMS)	70 - 90
2E18	HARNESS, MAGNETIC PICK-UP	40 - 95	4D15	HOSES AND LINES, AUGER SWING HYD. OIL	70 - 61
2C3	HARNESS, SEPARATOR, RIGHT-HAND	40 - 25	4D16	HOSES AND LINES, AUGER SWING HYD. OIL	70 - 62
2D12	HARNESS, WIRING, CAB ROOF	40 - 61	4F7	HOSES AND LINES, HEADER LIFT OIL	70 - 103
2D1	HARNESS, WIRING, INSTRUMENT PANEL	40 - 48	3G9	HOSES AND LINES, HYD. (FOUR-WHEEL DR.)	50 - 133
2C9	HARNESS, WIRING, LEFT-HAND LIGHTS	40 - 31	4C19	HOSES AND LINES, HYDRAULIC OIL	70 - 38
2C9	HARNESS, WIRING, OPERATOR'S PLATFORM	40 - 31	4C23	HOSES AND LINES, HYDRAULIC OIL	70 - 43
2B9	HARNESS, WIRING, REAR HOOD	40 - 3	4C20	HOSES AND LINES, HYDRAULIC OIL (EXPORT)	70 - 39
2B9	HARNESS, WIRING, SEPARATOR (L.H.)	40 - 3	3G11	HOSES AND LINES, HYDRAULIC OIL RETURN	50 - 135
2B9	HARNESS, WIRING, UNLOADING AUGER	40 - 3	3H8	HOSES AND LINES, HYDRAULIC OIL RETURN	50 - 157
6E8	HARNESS, WIRING, AUTOMATIC HDT. HGT. CTL.	160 - 13	3I4	HOSES AND LINES, STEERING OIL-FRONT	60 - 19
2D15	HARNESS, WIRING, WINDSHIELD WIPER MOTOR	40 - 65	3F4	HOSES AND OIL COOLER, HYDROSTATIC DRIVE	50 - 98
2C5	HARNESSES, WIRING, ENGINE COMPARTMENT	40 - 27	3I6	HOSES AND OIL LINES, STEERING-REAR	60 - 21
2B24	HARVESTRAK ADAPTER HARNESS	40 - 20	1E6	HOSES AND RADIATOR	20 - 77
2D10	HARVESTRAK CIRCUIT BREAKER	40 - 59	1E8	HOSES AND RADIATOR	20 - 79
2B22	HARVESTRAK COMBINE MONITOR	40 - 18	4F4	HOSES, FEEDER HOUSE VARIABLE DRIVE (EXPORT)	70 - 100
2B22	HARVESTRAK CONTROL PANEL	40 - 18	4I22	HOSES, HEATER	90 - 59
2B22	HARVESTRAK, PREAMPLIFIER	40 - 18	4I23	HOSES, HEATER	90 - 60
2C16	HAZARD WARNING (EXPORT)	40 - 38	3H6	HOSES, HYDRAULIC	50 - 155
1C6	HEAD, CYLINDER	20 - 28	3G8	HOSES, HYDRAULIC (FOUR-WHEEL DRIVE)	50 - 131
2B16	HEADER ELECTROMAGNETIC CLUTCH	40 - 11	4C21	HOSES, HYDRAULIC OIL	70 - 41
6E9	HEADER HEIGHT CONTROL, DIAL-A-MATIC	160 - 14	4C17	HOSES, MAIN CONTROL VALVE (EXPORT)	70 - 36
6E15	HEADER HEIGHT CONTROL CONVERSION, DIAL-A-MATIC	160 - 21	4E18	HOSES, REEL HYDRAULIC	70 - 89
4F8	HEADER LIFT HYDRAULIC CYLINDER	70 - 104	3I8	HOSES, STEERING OIL	60 - 23
4F7	HEADER LIFT OIL LINES AND HOSES	70 - 103	2D7	HOURLY METER	40 - 55
4H20	HEADLINER, CAB ROOF	90 - 30	5B14	HOUSE, FEEDER, BOTTOM SHEETS	110 - 9
4I22	HEATER CONTROL VALVE	90 - 59	6C12	HOUSING AND AUGER, VERTICAL, GRAIN TANK	130 - 35
4I21	HEATER CORE	90 - 58	4H24	HOUSING AND FILTER, CAB AIR	90 - 35
4I22	HEATER HOSES	90 - 59	6C5	HOUSING AND SHIELD, SUMP, GRAIN TANK	130 - 27
4I23	HEATER HOSES	90 - 60	2E10	HOUSING, ALTERNATOR, 72 AMP	40 - 86
1D21	HEATER, ENGINE COOLANT	20 - 68	2E12	HOUSING, ALTERNATOR, 90 AMP	40 - 88
1D22	HEATER, ENGINE COOLANT	20 - 69	5H24	HOUSING, CLEAN GRAIN ELEVATOR	120 - 129
6E16	HEIGHT INDICATOR, PLATFORM (FRANCE)	160 - 22	5I2	HOUSING, CLEAN GRAIN ELEVATOR	120 - 131
4I24	HI PRESSURE SWITCH LIGHT ASSEMBLY	90 - 61	5H20	HOUSING, CLEAN GRAIN LOWER AUGER	120 - 125
4I8	HI PRESSURE SWITCH, AIR CONDITIONER	90 - 43	5H22	HOUSING, CLEAN GRAIN LOWER AUGER	120 - 127
3B17	HIGH FLOATATION DRIVE WHEELS	50 - 9	5H15	HOUSING, CLEANING FAN	120 - 119
3E25	HIGH PRESSURE RELIEF VALVE (EATON)	50 - 94	1C4	HOUSING, CRANKSHAFT OIL SEAL	20 - 26
6B10	HINGE, GRAIN TANK	130 - 6	3C1	HOUSING, DIFFERENTIAL	50 - 18
4G8	HINGE, UPPER DOOR, ENGINE COMPARTMENT	80 - 21	3C21	HOUSING, FINAL DRIVE (CRAWLER TRACKS)	50 - 40
3I13	HITCH, REAR AXLE SUPPORT	60 - 28	6C19	HOUSING, HORIZONTAL UNLOADING AUGER, 14 FT. AND 17 FT.	130 - 42
3I13	HITCH, TRAILER (EXPORT)	60 - 28	6C20	HOUSING, HORIZONTAL UNLOADING AUGER, 17 FT. AND 20 FT.	130 - 43
4F20	HOOD, REAR	80 - 7	3D18	HOUSING, HYDROSTATIC DRIVE PUMP	50 - 61
4F22	HOOD, REAR	80 - 9	3D21	HOUSING, HYDROSTATIC DRIVE PUMP (EATON)	50 - 64
2B9	HOOD, REAR, WIRING HARNESS	40 - 3	3C16	HOUSING, INNER, FINAL DRIVE	50 - 35
6C18	HORIZONTAL UNLDG. AUGER DRIVE GEAR CASE	130 - 41	3G3	HOUSING, KNEE AND MOTOR (FOUR-WHEEL DRIVE)	50 - 125
6B15	HORIZONTAL UNLDG. AUGER SWIVEL SHROUD	130 - 11	5I9	HOUSING, LOADING AUGER	120 - 139
6C19	HORIZONTAL UNLOADING AUGER HOUSING, 14 FT. AND 17 FT.	130 - 42	5I16	HOUSING, LOWER TAILINGS	120 - 147
6C20	HORIZONTAL UNLOADING AUGER HOUSING, 17 FT. AND 20 FT.	130 - 43	3C12	HOUSING, OUTER, FINAL DRIVE	50 - 31
6C14	HORIZONTAL UNLOADING AUGER SWIVEL	130 - 37	5G16	HOUSING, SHOE GRAIN SUPPLY AUGERS	120 - 95
6C15	HORIZONTAL UNLOADING AUGER SWIVEL	130 - 38	2E22	HOUSING, STARTER DRIVE	40 - 99
6C21	HORIZONTAL UNLOADING AUGER, 14 FT. AND 17 FT.	130 - 44	5F19	HOUSING, STRAW CHOPPER	120 - 69
6C22	HORIZONTAL UNLOADING AUGER, 20 FT.	130 - 45	5F20	HOUSING, STRAW CHOPPER	120 - 70
2C9	HORN	40 - 31	5I19	HOUSING, TAILING ELEVATOR	120 - 150
2D7	HORN SWITCH	40 - 55	5I18	HOUSING, TAILINGS ELEVATOR	120 - 149
4E21	HOSE AND COUPLER CONVERSION	70 - 92	1E24	HOUSING, THROTTLE LINKAGE, CONTROL LEVER	30 - 13
6E6	HOSE AND LINES, OIL COOLER	160 - 11	3C1	HOUSING, TRANSMISSION	50 - 18
4F6	HOSE, HYDRAULIC, REEL LIFT (EXPORT)	70 - 102	5I23	HOUSING, UPPER TAILINGS AUGER	120 - 154
1C5	HOSE, OIL DRAIN	20 - 27	3G1	HOUSING, PLANETARY (FOUR-WHEEL DRIVE)	50 - 123
1C11	HOSE, OIL DRAIN	20 - 33	3F24	HOUSING, WHEEL HUB, AND MOTOR (FOUR-WHEEL DRIVE)	50 - 121
5E19	HOSE, CYL. SHAFT BRG. HSG. LUBE BANK (R.H.)	120 - 43	3I19	HOUSING, WHEEL MOTOR (FOUR-WHEEL DRIVE)	60 - 35
4F2	HOSE, HYDRAULIC, VARIABLE DRIVE FDR. HSE.	70 - 98			
1E6	HOSES	20 - 77			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1D15	HOUSINGS, TURBOCHARGER	20 - 62	4E23	HYDRAULIC PUMP MTG.,REEL,HYDROSTATIC DR.....	70 - 94
3F24	HUB,MOTOR,AND HOUSING,WHEEL (FOUR-WHEEL DRIVE)	50 - 121	4E14	HYDRAULIC PUMP, HYDROSTATIC DRIVE REEL.....	70 - 85
3I17	HUB,REAR AXLE SPINDLES-HVY-DTY REAR AXLE	60 - 33	4B11	HYDRAULIC PUMP, MAIN	70 - 5
3G9	HYD. LINES AND HOSES (FOUR-WHEEL DR.)	50 - 133	4B12	HYDRAULIC PUMP, MAIN	70 - 6
6E3	HYD. OIL LINE, DIAL-A-MATIC HDR. HGHT. CONTROL)	160 - 8	4E9	HYDRAULIC REEL LIFT CONTROL LEVER	70 - 80
6E3	HYD. OIL LINE,AUTO HDR. HGHT.CONTROL	160 - 8	6E24	HYDRAULIC REEL LIFT DRIVE SHEAVES	170 - 6
4E10	HYD. REEL LIFT CONTROL LEVER (EXPORT)	70 - 81	3E18	HYDRO. DR. CENTER SECTION (EATON).....	50 - 86
4C8	HYD.CONTROL VALVE POPPETS,MAIN (EXPORT)	70 - 27	3E12	HYDRO. DR. DISPLACEMENT CONTROL VALVE (EATON)	50 - 80
4C10	HYD.CONTROL VALVE POPPETS,MAIN (EXPORT)	70 - 29	3D10	HYDRO. DR. MOTOR MTG. AND COUPLER	50 - 53
4C12	HYD.CONTROL VALVE POPPETS,MAIN-POSI-TORQ	70 - 31	3D18	HYDRO. DR. PUMP CYLINDER BLOCK ASSEMBLY	50 - 61
4C13	HYD.CONTROL VALVE SPOOLS-MAIN-POSI-TORQ	70 - 32	3E3	HYDRO. DR. PUMP SERVO PISTON ASSEMBLIES	50 - 71
4C9	HYD.CONTROL VALVE SPOOLS,MAIN-POSI-TORQ	70 - 28	3E5	HYDRO. DR. PUMP SERVO PISTON ASSEMBLIES (EATON)	50 - 73
4C11	HYD.CONTROL VALVE SPOOLS,MAIN-POSI-TORQ	70 - 30	3D6	HYDRO. DRIVE CONTROL CABLE AND LEVER	50 - 49
4C8	HYD.CONTROL VALVE SPRINGS,MAIN (EXPORT)	70 - 27	3D8	HYDRO. DRIVE CONTROL CABLE MOUNTING.....	50 - 51
4C10	HYD.CONTROL VALVE SPRINGS,MAIN (EXPORT)	70 - 29	3E7	HYDRO. DRIVE DISPLACEMENT CONTROL VALVE.....	50 - 75
4C12	HYD.CONTROL VALVE SPRINGS,MAIN-POSI-TORQ	70 - 31	3E14	HYDRO. DRIVE PRESSURE OVERRIDE VALVE	50 - 82
4C9	HYD.CONTROL,MAIN,RELIEF VALVE-POSI-TORQ	70 - 28	3E2	HYDRO. DRIVE PUMP CYLINDER BLOCK KIT (EATON)	50 - 70
4C11	HYD.CONTROL,MAIN,RELIEF VALVE-POSI-TORQ	70 - 30	3D16	HYDRO. DRIVE PUMP FRONT COVER(EATON)	50 - 59
4C13	HYD.CONTROL,MAIN,RELIEF VALVE-POSI-TORQ	70 - 32	3E2	HYDRO. DRIVE PUMP HOUSING KIT (EATON).....	50 - 70
4D15	HYD.OIL LINES AND HOSES, AUGER SWING	70 - 61	3E1	HYDRO. DRIVE PUMP SWASHPLATE (EATON)	50 - 69
4D16	HYD.OIL LINES AND HOSES, AUGER SWING	70 - 62	3E1	HYDRO. DRIVE PUMP,SWASHPLATE,BEARINGS, AND TRUNNIONS (EATON)	50 - 69
1G23	HYDRAULIC ANEROID ACTIVATOR (AH 03)	30 - 64	3E2	HYDRO. DRIVE SHAFT KIT (EATON)	50 - 70
3D2	HYDRAULIC BELT TENSIONING SYSTEM	50 - 45	3E14	HYDRO.DR.DISPLACEMENT CONTROL HANDLE	50 - 82
4B23	HYDRAULIC CONTROL MAIN, RELIEF VALVE	70 - 17	3E14	HYDRO.DR.DISPLACEMENT CTL.VALVE GASKET	50 - 82
4B25	HYDRAULIC CONTROL MAIN, RELIEF VALVE	70 - 19	3E14	HYDRO.DR.DISPLACEMENT CTL.VALVE ORIFICE	50 - 82
4B22	HYDRAULIC CONTROL VALVE POPPETS, MAIN	70 - 16	3D14	HYDRO.DR.PUMP FRONT COVER-BRG-SEAL ASSY.....	50 - 57
4B24	HYDRAULIC CONTROL VALVE POPPETS, MAIN	70 - 18	3D16	HYDRO.DR.PUMP FRONT COVER,BRG,SEAL ASSY (EATON)	50 - 59
4B23	HYDRAULIC CONTROL VALVE SPOOLS, MAIN	70 - 17	3D24	HYDRO.DR.PUMP SWASHPLATE,BRGS,TRUNNIONS	50 - 67
4B25	HYDRAULIC CONTROL VALVE SPOOLS, MAIN	70 - 19	4E24	HYDROSTATIC DR. REEL FLOW CONTROL VALVE.....	70 - 95
4C2	HYDRAULIC CONTROL VALVE SPOOLS, MAIN	70 - 21	3C24	HYDROSTATIC DR.BELT TENSIONING MECHANISM.....	50 - 43
4C4	HYDRAULIC CONTROL VALVE SPOOLS, MAIN	70 - 23	3E16	HYDROSTATIC DRIVE CENTER SECTION.....	50 - 84
4B22	HYDRAULIC CONTROL VALVE SPRINGS, MAIN.....	70 - 16	3D11	HYDROSTATIC DRIVE CHARGE PUMP	50 - 54
4B24	HYDRAULIC CONTROL VALVE SPRINGS, MAIN.....	70 - 18	3D13	HYDROSTATIC DRIVE CHARGE PUMP MOUNTING.....	50 - 56
4C1	HYDRAULIC CONTROL VALVE SPRINGS, MAIN.....	70 - 20	3D23	HYDROSTATIC DRIVE CYLINDER BLOCK KIT	50 - 66
4C3	HYDRAULIC CONTROL VALVE SPRINGS, MAIN.....	70 - 22	3F7	HYDROSTATIC DRIVE LOWER OIL LINES.....	50 - 101
4C2	HYDRAULIC CONTROL, MAIN RELIEF VALVE	70 - 21	3F8	HYDROSTATIC DRIVE LUBE BANK SYSTEM	50 - 102
4F8	HYDRAULIC CYLINDER, HEADER LIFT	70 - 104	3E20	HYDROSTATIC DRIVE MOTOR	50 - 89
4D21	HYDRAULIC CYLINDER,UNLOADING AUGER SWING	70 - 67	3E23	HYDROSTATIC DRIVE MOTOR (EATON)	50 - 92
4D22	HYDRAULIC CYLINDER,UNLOADING AUGER SWING	70 - 68	3F4	HYDROSTATIC DRIVE OIL COOLER AND HOSES	50 - 98
4D24	HYDRAULIC CYLINDER,UNLOADING AUGER SWING	70 - 70	3F4	HYDROSTATIC DRIVE OIL COOLER FITTINGS.....	50 - 98
4F3	HYDRAULIC HOSE, FEEDER HOUSE.....	70 - 99	3F3	HYDROSTATIC DRIVE OIL RESERVOIR.....	50 - 97
4F4	HYDRAULIC HOSE, FEEDER HOUSE VARIABLE DRIVE (EXPORT)	70 - 100	3F3	HYDROSTATIC DRIVE OIL RESERVOIR MOUNTING	50 - 97
4F6	HYDRAULIC HOSE, REEL LIFT(EXPORT)	70 - 102	3D21	HYDROSTATIC DRIVE PUMP CYLINDER BLOCK ASSEMBLY (EATON)	50 - 64
4F2	HYDRAULIC HOSE,VARIABLE DRIVE FDR.HOUSE.....	70 - 98	3D14	HYDROSTATIC DRIVE PUMP FRONT COVER.....	50 - 57
3H6	HYDRAULIC HOSES	50 - 155	3D18	HYDROSTATIC DRIVE PUMP HOUSING	50 - 61
3G8	HYDRAULIC HOSES (FOUR-WHEEL DRIVE)	50 - 131	3D1	HYDROSTATIC DRIVE PUMP HOUSING (EATON)	50 - 64
4E18	HYDRAULIC HOSES, REEL	70 - 89	3D23	HYDROSTATIC DRIVE PUMP HOUSING KIT	50 - 66
4F5	HYDRAULIC HOSES, REEL LIFT	70 - 101	3D24	HYDROSTATIC DRIVE PUMP SWASHPLATE.....	50 - 67
3G8	HYDRAULIC LINES (FOUR-WHEEL DRIVE)	50 - 131	4E23	HYDROSTATIC DRIVE REEL HYD.PUMP MOUNTING	70 - 94
4D21	HYDRAULIC MOUNTING,UNLOADING AUGER SWING....	70 - 67	4E14	HYDROSTATIC DRIVE REEL HYDRAULIC PUMP	70 - 85
4D22	HYDRAULIC MOUNTING,UNLOADING AUGER SWING....	70 - 68	3D23	HYDROSTATIC DRIVE SHAFT KIT	50 - 66
4D24	HYDRAULIC MOUNTING,UNLOADING AUGER SWING....	70 - 70	3D9	HYDROSTATIC DRIVE UNIT.....	50 - 52
3G11	HYDRAULIC OIL FILTER.....	50 - 135	3D9	HYDROSTATIC DRIVE UNIT, SHEAVES	50 - 52
4C21	HYDRAULIC OIL HOSES.....	70 - 41	3D9	HYDROSTATIC DRIVE UNIT, SUPPORTS	50 - 52
6E2	HYDRAULIC OIL LINE AUTO.HDR.HGT.CONTROL	160 - 7	3F5	HYDROSTATIC DRIVE UPPER OIL LINES	50 - 99
4C19	HYDRAULIC OIL LINES AND HOSES	70 - 38	3F3	HYDROSTATIC FILTER	50 - 97
4C23	HYDRAULIC OIL LINES AND HOSES	70 - 43	6E23	HYDROSTATIC GROUND DRIVE BELTS	170 - 5
4C20	HYDRAULIC OIL LINES AND HOSES (EXPORT).....	70 - 39	6E23	HYDROSTATIC GROUND DRIVE SHEAVES	170 - 5
4B9	HYDRAULIC OIL RESERVOIR	70 - 3			
3G11	HYDRAULIC OIL RETURN LINES AND HOSES	50 - 135			
3H8	HYDRAULIC OIL RETURN LINES AND HOSES	50 - 157			
3H7	HYDRAULIC OIL RETURN LINES AND HOSES (FROM RESERVOIR TO WHEEL MOTORS).....	50 - 156			
1E10	HYDRAULIC PUMP DRIVE IDLER	20 - 81			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
I					
5H9	I.D. AH093010	120-112	4C18	KIT, FLOW CONTROL PLUG	70-37
3F17	IDLER SUPPORT PLATES, FRONT	50-113	1G5	KIT, FUEL FILTER	30-44
5F3	IDLER, BEATER	120-52	3E2	KIT, HYDRO. DRIVE PUMP CYLINDER BLOCK (EATON)	50-70
5F4	IDLER, BEATER	120-53	3E2	KIT, HYDRO. DRIVE PUMP HOUSING (EATON)	50-70
5F5	IDLER, BEATER	120-54	3E2	KIT, HYDRO. DRIVE PUMP SHAFT (EATON)	50-70
5I7	IDLER, CLEAN GRAIN ELEVATOR	120-137	3D12	KIT, HYDROSTATIC DRIVE CHARGE PUMP	50-55
3F14	IDLER, CRAWLER	50-109	3D23	KIT, HYDROSTATIC DRIVE CYLINDER BLOCK	50-66
6D17	IDLER, DECLUTCHING	140-17	3D23	KIT, HYDROSTATIC DRIVE PUMP HOUSING	50-66
1E10	IDLER, DRIVE, HYDRAULIC PUMP	20-81	3D23	KIT, HYDROSTATIC DRIVE SHAFT	50-66
5B23	IDLER, FEEDER CONVEYOR	110-18	4C14	KIT, MAIN HYD. CONTROL VALVE (POSI-TORQ)	70-33
6F2	IDLER, FEEDER HOUSE (LONG)	170-9	4C15	KIT, MAIN HYD. CONTROL VALVE (POSI-TORQ)	70-34
6D19	IDLER, FEEDER HOUSE DRIVE	140-19	4C1	KIT, MAIN HYDRAULIC CONTROL VALVE	70-20
6F16	IDLER, PRIMARY COUNTERSHAFT	170-24	4C3	KIT, MAIN HYDRAULIC CONTROL VALVE	70-22
6F17	IDLER, SECONDARY COUNTERSHAFT	170-25	4C4	KIT, MAIN HYDRAULIC CONTROL VALVE	70-23
6D15	IDLER, SECONDARY COUNTERSHAFT DRIVE	140-15	4C5	KIT, MAIN HYDRAULIC CONTROL VALVE	70-24
5G22	IDLER, SHOE GRAIN SUPPLY AUGERS	120-101	4C6	KIT, MAIN HYDRAULIC CONTROL VALVE	70-25
5G8	IDLER, STRAW CHOPPER DRIVE	120-85	4C7	KIT, MAIN HYDRAULIC CONTROL VALVE	70-26
5C14	IDLER,MIDDLE,FDR.HSE.,VARIABLE DRIVE	110-36	4B19	KIT, MAIN HYDRAULIC PUMP	70-13
5G21	IDLERS	120-100	4B21	KIT, MAIN HYDRAULIC PUMP	70-15
5C16	IDLERS, BELT, FEEDER HOUSE MIDDLE	110-39	6D24	KIT, MAIN VALVE BLOCK SOLENOID	160-5
6E25	IDLERS, FEEDER HOUSE (VARIABLE DRIVE)	170-7	4I6	KIT, O-RING - AIR CONDITIONING	90-41
6F3	IDLERS, FEEDER HOUSE DRIVE (LONG)	170-10	2E9	KIT, RADIO EXTERNAL ANTENNA	40-85
5C16	IDLERS, FEEDER HOUSE MIDDLE BELT	110-39	4B16	KIT, RELIEF VALVE, MAIN HYDRAULIC PUMP	70-10
6F8	IDLERS, STRAW CHOPPER	170-15	4I4	KIT, SEAL	90-39
4I24	INDICATOR LIGHT ASSEMBLY, HI PRESSURE	90-61	3D4	KIT, SEAL REPAIR	50-47
2B13	INDICATOR LIGHTS,REVOLVING (EXPORT)	40-8	4F9	KIT, SEAL REPAIR	70-105
2C18	INDICATOR, GRAIN TANK FILL (EXPORT)	40-40	4D9	KIT, SECONDARY CONTROL VALVE	70-55
1G1	INJECTION NOZZLE, FUEL	30-40	4D13	KIT, SECONDARY CONTROL VALVE	70-59
1C3	INJECTION PUMP GEAR COVER	20-25	2E20	KIT, STARTER SOLENOID COVER	40-97
3G16	INNER COVER	50-140	3I10	KIT, STEERING CYLINDER	60-25
4H19	INNER ROOF	90-29	3I2	KIT, STEERING PUMP INPUT SHAFT SEAL	60-17
4H19	INNER ROOF AND COVERS	90-29	3H25	KIT, STEERING PUMP SEAL	60-15
6C1	INNER UNLOADING AUGER COVERS	130-23	4I5	KIT, SUPER HEAT	90-40
3C5	INPUT SHAFT,GEARS,BEARINGS,TRANSMISSION	50-23	2D23	KIT, TAPE PLAYER	40-73
1B18	INSTALLATION KIT, SHORT BLOCK	20-14	2F2	KIT, TERMINAL AND WIRING	40-104
4H12	INSTRUMENT PANEL	90-21	4E2	KIT, UNLOADING AUGER SWING HYD. CYLINDER	70-73
2D7	INSTRUMENT PANEL ACCESSORIES	40-55	4E5	KIT, UNLOADING AUGER SWING HYDRAULIC CYLINDER	70-76
6F24	INSTRUMENT PANEL DECALS	170-33	4E7	KIT, UNLOADING AUGER SWING HYDRAULIC CYLINDER	70-78
2D10	INSTRUMENT PANEL GAUGES	40-59	2D25	KIT,AM-FM RADIO,PUSH BUTTON,TAPE PLAYER	40-75
2D1	INSTRUMENT PANEL WIRING HARNESS	40-48	4E25	KIT,HYDRO.DRIVE REEL FLOW CONTROL VALVE	70-96
2D3	INSTRUMENT PANEL WIRING HARNESS	40-50	4E16	KIT,HYDROSTATIC DR.REEL HYDRAULIC PUMP	70-87
2D5	INSTRUMENT PANEL WIRING HARNESS (EXPORT)	40-53	4E16	KIT,HYDROSTATIC DR.REEL HYDRAULIC SHEAVE	70-87
4H2	INSULATION, SEAT CONSOLE	90-11	2E2	KIT,SPEAKERS,RADIO,TAPE PLAYER,HARNESS	40-77
1D7	INTAKE MANIFOLD	20-54	4E4	KIT,UNLOADING AUGER SWING HYD.CYLINDER	70-75
1D7	INTAKE MANIFOLD GASKET	20-54	3G3	KNEE AND MOTOR HOUSING (FOUR-WHEEL DRIVE)	50-125
1C6	INTAKE VALVES	20-28	5G3	KNIFE AND SUPPORT, STRAW CHOPPER	120-78
K					
2D7	KEY, IGNITION SWITCH	40-55	1E20	KNOB, FUEL SHUT-OFF CONTROL	30-8
4F1	KIT, ADJUSTING SCREW	70-97	1E21	KNOB, FUEL SHUT-OFF CONTROL	30-9
2E4	KIT, AM RADIO, PUSH BUTTON	40-79	6B17	KNOB, GRAIN TANK DOOR	130-13
2D19	KIT, AM RADIO, PUSH BUTTON, TAPE PLAYER	40-69	4I22	KNOB, HEATER CONTROL	90-59
2E6	KIT, AM-FM RADIO, PUSH BUTTON	40-81	2E8	KNOB, RADIO	40-83
2D21	KIT, ANTENNA WITH CLIPS	40-71	4E12	KNOB, REEL SPEED	70-83
3H17	KIT, BRAKE SLAVE CYLINDER	60-7	4C25	KNOB, VARIABLE CYLINDER CONTROL	70-45
6D22	KIT, CHECK BLOCK	160-2	L		
4I12	KIT, COMPRESSOR	90-48	4G19	LADDER, OPERATOR'S PLATFORM	90-3
4I14	KIT, COMPRESSOR HARDWARE	90-51	4G21	LADDER, OPERATOR'S PLATFORM (TRACKS)	90-5
3G6	KIT, CONTROL VALVE SOLENOID	50-129	4F24	LADDER, REAR	80-11
3H5	KIT, CONTROL VALVE SOLENOID	50-154	2C19	LAMPS, TAIL, TURN SIGNAL AND LICENSE PLATE (EXPORT)	40-41
6E5	KIT, DROP RATE VALVE	160-10	2C14	LAMPS, TURN SIGNAL FRONT (EXPORT)	40-36
2F4	KIT, ELECTRICAL CONNECTOR SERVICE	40-106			
1C18	KIT, ENGINE OVERHAUL	20-41			

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
4G23	LANDING SUPPORTS	90-7	
4G19	LANDING, OPERATOR'S PLATFORM	90-3	
4G21	LANDING, OPERATOR'S PLATFORM (TRACKS)	90-5	
5H24	LATCH, CLEAN GRAIN ELEVATOR	120-129	
6B17	LATCH, GRAIN TANK DOOR	130-13	
2C9	LEFT-HAND LIGHTS WIRING HARNESS	40-31	
3B9	LEVER ASSEMBLY, GEARSHIFT	50-1	
5B12	LEVER, DOOR, FEEDER HOUSE TOP	110-7	
4E10	LEVER, HYD. REEL LIFT CONTROL (EXPORT).....	70-81	
4E9	LEVER, HYDRAULIC REEL LIFT CONTROL	70-80	
3D6	LEVER, HYDRO. DRIVE CONTROL CABLE	50-49	
4G19	LEVER, OPERATOR'S PLATFORM	90-3	
3H11	LEVER, PARKING BRAKE CONTROL	60-1	
4E9	LEVER, PLATFORM LIFT CONTROL.....	70-80	
4E10	LEVER, PLATFORM, FORE AND AFT (EXPORT)	70-81	
5J2	LEVER, SEPARATOR CONTROL	120-159	
6B20	LEVER, UNLOADING AUGER CONTROL	130-17	
4D1	LEVER, UNLOADING AUGER SWING CONTROL	70-47	
4C25	LEVER, VARIABLE CYLINDER CONTROL	70-45	
2C19	LICENSE PLATE LAMP (EXPORT)	40-41	
4E10	LIFT CONTROL LEVER, HYD. REEL (EXPORT).....	70-81	
4E9	LIFT CONTROL LEVER, HYDRAULIC REEL.....	70-80	
4E9	LIFT CONTROL LEVER, PLATFORM.....	70-80	
4F7	LIFT OIL LINES AND HOSES, HEADER	70-103	
1C20	LIFT STRAPS	20-43	
2D7	LIGHT SWITCH	40-55	
2D13	LIGHT, DOME.....	40-63	
2B12	LIGHT, GRAIN TANK.....	40-7	
2B10	LIGHT, UNLOADING AUGER	40-5	
2B12	LIGHT, WARNING	40-7	
2C17	LIGHT, WARNING EMBLEM (EXPORT).....	40-39	
2D7	LIGHTER, CIGAR.....	40-55	
2C11	LIGHTS, FIELD.....	40-33	
2C14	LIGHTS, FRONT (EXPORT)	40-36	
2B13	LIGHTS,REVOLVING AND MOUNTINGS (EXPORT).....	40-8	
3G9	LINE AND HOSES, HYD. (FOUR-WHEEL DR.).....	50-133	
1E11	LINE, ENGINE OIL PRESSURE GAUGE	20-82	
6E2	LINE,HYDRAULIC OIL,AUTO.HDR.HGT.CONTROL.....	160-7	
1C18	LINER SHIM	20-41	
1C18	LINER, CYLINDER	20-41	
6E6	LINES AND HOSE, OIL COOLER.....	160-11	
4D15	LINES AND HOSES, AUGER SWING HYD. OIL.....	70-61	
4D16	LINES AND HOSES, AUGER SWING HYD. OIL	70-62	
4F7	LINES AND HOSES, HEADER LIFT OIL	70-103	
4C19	LINES AND HOSES, HYDRAULIC OIL.....	70-38	
4C23	LINES AND HOSES, HYDRAULIC OIL	70-43	
4C20	LINES AND HOSES, HYDRAULIC OIL (EXPORT)	70-39	
3G11	LINES AND HOSES, HYDRAULIC OIL RETURN	50-135	
3H8	LINES AND HOSES, HYDRAULIC OIL RETURN	50-157	
314	LINES AND HOSES,STEERING OIL-FRONT	60-19	
316	LINES AND HOSES,STEERING OIL-REAR	60-21	
4116	LINES, AIR CONDITIONER	90-53	
4121	LINES, AIR CONDITIONER	90-58	
3H13	LINES, BRAKE	60-3	
1E17	LINES, FUEL	30-5	
1E18	LINES, FUEL (EXPORT)	30-6	
1G17	LINES, FUEL CONTROL	30-58	
1G15	LINES, FUEL INJECTION (AH 03)	30-56	
1G17	LINES, FUEL INJECTION PUMP LUBE	30-58	
3G8	LINES, HYDRAULIC (FOUR-WHEEL DRIVE).....	50-131	
3F5	LINES, HYDROSTATIC DRIVE UPPER OIL.....	50-99	
3F7	LINES, LOWER OIL, HYDROSTATIC DRIVE.....	50-101	
1F13	LINES, REPLACEMENT FUEL INJECTION LUBE.....	30-26	
1F16	LINES, REPLACEMENT FUEL INJECTION LUBE (AH 02, 03).....	30-30	
318	LINES, STEERING OIL	60-23	
5E14	LINK, DUAL-RANGE CYLINDER DRIVE LOCKOUT ARM	120-37	
3H12	LINKAGE AND BRAKE PEDALS.....	60-2	
5H18	LINKAGE, CLEANING FAN SPEED CONTROL.....	120-123	
6E9	LINKAGE, CONTROL.....	160-14	
4E12	LINKAGE, REEL SPEED CONTROL VALVE	70-83	
5C8	LINKAGE, REVERSER CONTROL	110-29	
6E8	LINKAGE,AUTOMATIC HEADER HEIGHT CONTROL	160-13	
5I9	LOADING AUGER AND HOUSING.....	120-139	
6F13	LOADING AUGER BELTS	170-21	
6F13	LOADING AUGER DRIVE	170-21	
5I11	LOADING AUGER GEAR CASE	120-141	
6F13	LOADING AUGER SHEAVES	170-21	
5E14	LOCKOUT ARM, DUAL-RANGE CYLINDER DRIVE	120-37	
4H22	LOUVER, AIR	90-32	
2B21	LOW SHAFT SPD.MONITORS MOUNTING BRACKET.....	40-17	
2B19	LOW SHAFT SPEED MONITOR'S HARNESS	40-15	
2D1	LOW SHAFT SPEED MONITORING CONTROL BOX.....	40-48	
2D3	LOW SHAFT SPEED MONITORING CTL. BOX	40-50	
2B21	LOW SHAFT SPEED MONITORS.....	40-17	
5H20	LOWER AUGER, CLEAN GRAIN	120-125	
6C10	LOWER GEAR CASE, VERTICAL AUGER	130-33	
3F7	LOWER OIL LINES, HYDROSTATIC DRIVE	50-101	
5I14	LOWER TAILINGS AUGER	120-145	
5I16	LOWER TAILINGS HOUSING	120-147	
5F2	LUBE BANK SYS.,BEATER BEARING LH-HYDRO.	120-51	
5E18	LUBE BANK SYS-RH-CYLINDER SHAFT BRG.HSG.	120-42	
6D6	LUBE BANK SYSTEM-RH-PRIMARY COUNTERSHAFT....	140-6	
3F8	LUBE BANK SYSTEM, HYDROSTATIC DRIVE	50-102	
5F1	LUBE BANK SYSTEM, RH, BEATER BEARING	120-50	
6C17	LUBE BANK SYSTEM, UNLOADING AUGER	130-40	
5E21	LUBE BANK-LH-CYLINDER SHAFT BRG.-HYDRO	120-45	
6D7	LUBE BANK-LH-PRIMARY COUNTERSHAFT-HYDRO.	140-7	
5E20	LUBE BANK-RH-CYL.DR.CTRSHAFT.BRG.HSG.	120-44	
5I12	LUBE BANK, GR.TANK LDG.AUGER GEAR CASE (R.H.)	120-143	
5E19	LUBE BANK,CYL.SHAFT BRG.HSG.(R.H.)	120-43	
1G17	LUBE LINES, FUEL INJECTION PUMP	30-58	
1B8	LUBRICANT, CYLINDER LINER PACKING	20-3	
1B8	LUBRICANT, ENGINE VALVE STEM	20-3	
M			
2E18	MAGNETIC PICK-UP	40-95	
2E18	MAGNETIC PICK-UP HARNESS.....	40-95	
2B9	MAGNETIC PICKUP SENSOR	40-3	
2C3	MAGNETIC SENSOR (CLEANING FAN)	40-25	
1C13	MAIN BEARINGS	20-35	
4C17	MAIN CONTROL VALVE HOSES (EXPORT).....	70-36	
2E24	MAIN FRAME, STARTER	40-101	
4C9	MAIN HYD.CONTROL RELIEF VALVE-POSI-TORQ	70-28	
4C11	MAIN HYD.CONTROL RELIEF VALVE-POSI-TORQ	70-30	
4C13	MAIN HYD.CONTROL RELIEF VALVE-POSI-TORQ	70-32	
4C8	MAIN HYD.CONTROL VALVE POPPETS (EXPORT)	70-27	
4C10	MAIN HYD.CONTROL VALVE POPPETS (EXPORT)	70-29	
4C12	MAIN HYD.CONTROL VALVE POPPETS-POSI-TORQ	70-31	
4C9	MAIN HYD.CONTROL VALVE SPOOLS-POSI-TORQ	70-28	
4C11	MAIN HYD.CONTROL VALVE SPOOLS-POSI-TORQ	70-30	
4C13	MAIN HYD.CONTROL VALVE SPOOLS-POSI-TORQ	70-32	
4C8	MAIN HYD.CONTROL VALVE SPRINGS (EXPORT).....	70-27	
4C10	MAIN HYD.CONTROL VALVE SPRINGS (EXPORT).....	70-29	
4C12	MAIN HYD.CONTROL VALVE SPRINGS-POSI-TORQ	70-31	
4B23	MAIN HYDRAULIC CONTROL RELIEF VALVE	70-17	
4B25	MAIN HYDRAULIC CONTROL RELIEF VALVE	70-19	
4C2	MAIN HYDRAULIC CONTROL RELIEF VALVE	70-21	
4C4	MAIN HYDRAULIC CONTROL RELIEF VALVE	70-23	

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4C1	MAIN HYDRAULIC CONTROL VALVE HOUSING	70-20	4D24	MOUNTING, UNLOADING AUGER SWING HYDRAULIC....	70-70
4C3	MAIN HYDRAULIC CONTROL VALVE HOUSING	70-22	5F3	MOUNTINGS AND BEATER IDLER	120-52
4C4	MAIN HYDRAULIC CONTROL VALVE HOUSING	70-23	5F4	MOUNTINGS AND BEATER IDLER	120-53
4C1	MAIN HYDRAULIC CONTROL VALVE KIT	70-20	5F5	MOUNTINGS AND BEATER IDLER	120-54
4C3	MAIN HYDRAULIC CONTROL VALVE KIT	70-22	2C5	MOUNTINGS, BATTERY	40-27
4C4	MAIN HYDRAULIC CONTROL VALVE KIT	70-23	5C13	MOUNTINGS, FEEDER HOUSE LOWER.....	110-35
4C6	MAIN HYDRAULIC CONTROL VALVE KIT	70-25	3B13	MOUNTINGS, GEARSHIFT CABLES	50-5
4C7	MAIN HYDRAULIC CONTROL VALVE KIT	70-26	6D5	MOUNTINGS, PRIMARY COUNTERSHAFT.....	140-5
4B22	MAIN HYDRAULIC CONTROL VALVE POPPETS.....	70-16	2B13	MOUNTINGS, REVOLVING LIGHTS (EXPORT)	40-8
4B24	MAIN HYDRAULIC CONTROL VALVE POPPETS.....	70-18	1D20	MOUNTS, ENGINE.....	20-67
4C1	MAIN HYDRAULIC CONTROL VALVE POPPETS.....	70-20	3D10	MTG. AND COUPLER, HYDRO. DR. MOTOR	50-53
4C3	MAIN HYDRAULIC CONTROL VALVE POPPETS.....	70-22	3B19	MUD SHIELD (L.H. SIDE)	50-11
4B23	MAIN HYDRAULIC CONTROL VALVE SPOOLS.....	70-17	3B21	MUD SHIELDS (R.H. SIDE).....	50-13
4B25	MAIN HYDRAULIC CONTROL VALVE SPOOLS.....	70-19	3B22	MUD SHIELDS, R.H. SIDE (PLANETARY FINAL DRIVE)	50-14
4C2	MAIN HYDRAULIC CONTROL VALVE SPOOLS.....	70-21	3F21	MUD SHIELDS, TRANSMISSION DRIVE	50-117
4C4	MAIN HYDRAULIC CONTROL VALVE SPOOLS.....	70-23	1F6	MUFFLER	30-19
4B22	MAIN HYDRAULIC CONTROL VALVE SPRINGS.....	70-16			
4B24	MAIN HYDRAULIC CONTROL VALVE SPRINGS.....	70-18		N	
4C1	MAIN HYDRAULIC CONTROL VALVE SPRINGS.....	70-20	2B9	NEUTRAL SAFETY SWITCH.....	40-3
4C3	MAIN HYDRAULIC CONTROL VALVE SPRINGS.....	70-22	1G1	NOZZLE, FUEL INJECTION	30-40
4B11	MAIN HYDRAULIC PUMP	70-5	1F9	NOZZLES, FUEL INJECTION	30-22
4B12	MAIN HYDRAULIC PUMP	70-6	1F7	NOZZLES, FUEL INJECTION (AH 01)	30-20
4B16	MAIN HYDRAULIC PUMP BACK PLATE AND RELIEF VALVE KIT	70-10	1G15	NOZZLES, FUEL INJECTION (AH 03)	30-56
4B14	MAIN HYDRAULIC PUMP SEAL KIT	70-8		O	
1C13	MAIN THRUST BEARINGS	20-35	4I6	O-RING KIT - AIR CONDITIONING	90-41
6D23	MAIN VALVE BLOCK SOLENOID.....	160-3	3B17	O-RING, HIGH FLOATATION DRIVE WHEELS.....	50-9
3G18	MANIFOLD AND PACKINGS.....	50-143	3F4	OIL COOLER AND HOSES, HYDROSTATIC DRIVE	50-98
1C8	MANIFOLD SHIELD	20-30	1D1	OIL COOLER BYPASS VALVE	20-48
1D10	MANIFOLD, EXHAUST.....	20-57	1D6	OIL COOLER BYPASS VALVE	20-53
1D7	MANIFOLD, INTAKE.....	20-54	1C23	OIL COOLER, ENGINE	20-46
3F22	MANIFOLD, STEERING WHEEL (4-WHEEL DRIVE).....	50-119	1C24	OIL COOLER, ENGINE	20-47
1D18	MANIFOLD, WATER OUTLET.....	20-65	6E6	OIL COOLER, LINES, AND HOSE	160-11
4H14	MIRROR	90-23	1C5	OIL DRAIN HOSE	20-27
4H23	MIRROR, R.H. REAR VIEW	90-33	1C11	OIL DRAIN HOSE	20-33
4H21	MIRROR, RIGHT HAND (EXPORT)	90-31	1C21	OIL FILTER, ENGINE.....	20-44
4H14	MIRROR, REAR VIEW (EXPORT)	90-23	4C21	OIL HOSES, HYDRAULIC	70-41
4G19	MOLDING, OPERATOR'S PLATFORM LANDING	90-3	6E2	OIL LINE, HYDRAULIC, AUTO.HDR.HGT.CONTROL.....	160-7
4G21	MOLDING, OPERS. PLATFORM LANDING (TRACKS)	90-5	4D15	OIL LINES AND HOSES, AUGER SWING HYD.....	70-61
2C16	MONITOR, GRAIN TANK (EXPORT)	40-38	4D16	OIL LINES AND HOSES, AUGER SWING HYD.....	70-62
2B22	MONITOR, HARVESTRAK.....	40-18	4F7	OIL LINES AND HOSES, HEADER LIFT.....	70-103
2B19	MONITOR'S HARNESS, LOW SHAFT SPEED	40-15	4C23	OIL LINES AND HOSES, HYDRAULIC.....	70-43
2B21	MONITORS, LOW SHAFT SPEED	40-17	3I4	OIL LINES AND HOSES, STEERING-FRONT.....	60-19
3F24	MOTOR AND HOUSING, WHEEL HUB (FOUR-WHEEL DRIVE)	50-121	3I6	OIL LINES AND HOSES, STEERING-REAR.....	60-21
2D15	MOTOR AND WIPER, WINDSHIELD	40-65	3F7	OIL LINES, HYDROSTATIC DRIVE LOWER	50-101
3F25	MOTOR CYLINDER BLOCK (FOUR-WHEEL DRIVE)	50-122	3F5	OIL LINES, HYDROSTATIC DRIVE UPPER.....	50-99
3G3	MOTOR HOUSING AND KNEE (FOUR-WHEEL DRIVE)	50-125	1C11	OIL PAN	20-33
3E20	MOTOR, HYDROSTATIC DRIVE	50-89	1C5	OIL PAN (AH 01)	20-27
3E23	MOTOR, HYDROSTATIC DRIVE (EATON)	50-92	1C11	OIL PAN GASKET	20-33
2E19	MOTOR, STARTING.....	40-96	1C5	OIL PAN GASKET (AH 01)	20-27
4G25	MOUNT, OPERATOR'S PLATFORM.....	90-9	1C10	OIL PAN REPLACEMENT KIT (AH 01)	20-32
2B21	MOUNTING BRACKET, LOW SHAFT SPD. MONITORS.....	40-17	1D13	OIL PIPES, TURBOCHARGER	20-60
4I9	MOUNTING, COMPRESSOR.....	90-44	2D10	OIL PRESSURE GAUGE.....	40-59
4I10	MOUNTING, COMPRESSOR.....	90-45	1D1	OIL PUMP, ENGINE.....	20-48
4B9	MOUNTING, HYDRAULIC OIL RESERVOIR	70-3	1D3	OIL PUMP, ENGINE (AH 02, 03)	20-50
3D8	MOUNTING, HYDRO. DRIVE CONTROL CABLE	50-51	1D5	OIL PUMP, REPLACEMENT	20-52
3D13	MOUNTING, PUMP, HYDROSTATIC DRIVE CHARGE.....	50-56	4B9	OIL RESERVOIR, HYDRAULIC.....	70-3
4H6	MOUNTING, SEAT.....	90-15	3F3	OIL RESERVOIR, HYDROSTATIC DRIVE	50-97
5G11	MOUNTING, STRAW SPREADER	120-89	1C4	OIL SEAL, CRANKSHAFT	20-26
6B20	MOUNTING, UNLOADING AUGER CONTROL LEVER.....	130-17	1B7	OIL, ENGINE	20-2
4E23	MOUNTING, HYDRO. DR. REEL HYDRAULIC PUMP	70-94	5D12	OPEN-BAR CONCAVE.....	120-9
3F3	MOUNTING, HYDROSTATIC DRIVE OIL RESERVOIR	50-97	4G25	OPERATOR' PLATFORM FLOORBOARD	90-9
4D19	MOUNTING, UNLOADING AUGER SWING HYDRAULIC....	70-65			
4D21	MOUNTING, UNLOADING AUGER SWING HYDRAULIC....	70-67			
4D22	MOUNTING, UNLOADING AUGER SWING HYDRAULIC....	70-68			