
TT60A, TT75A REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCHES	8
SECTION 21 - TRANSMISSION SYSTEM	10
SECTION 25 - FRONT DRIVE AXLE	12
SECTION 27 - MECHANICAL REAR WHEEL DRIVE	14
SECTION 31 - POWER TAKE-OFF	16
SECTION 33 - BRAKING SYSTEM	17
SECTION 35 - HYDRAULIC SYSTEMS	18
SECTION 41 - STEERING SYSTEMS	22
SECTION 44 - FRONT AXLE	24
SECTION 55 - ELECTRICAL SYSTEM	25
SECTION 90 - BODYWORK	31

The following pages are the collation of the contents pages from each section and chapter of the TT60A, TT75A Repair manual. Complete Repair part # 84154801.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TT60A, TT75A Tractors.

SECTION 00 - GENERAL

BOOK 1 - 84154802

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	2
	Important Notice	2
	Shimming	2
	Rotating Shaft Seals	2
	O-Rings	3
	Sealers	3
	Bearings	3
	Spring Pins	3
	Precautionary Notice	4
	Equipment Notice	4
	Spare Parts Notice	4
	General Notices	4
	Health and Safety	5
	Health and Safety Precautions	6
	General Workshop Tools and Equipment	11
	Legal Aspects	11
	Lubricants and Greases	11
	Precautionary Statements	15
	Safety	16
	The Tractor	16
	Driving the Tractor	17
	Operating the Tractor	18
	Operating the PTO	19
	Servicing the Tractor	19
	Diesel Fuel	20
	Ecology and the Environment	21
	Minimum Hardware Tightening Torques	22
	General Dimensions	24
	Federal Emissions Warranty	30
	California Emission Control Warranty Statement	31
	Universal Symbols	33
	Safety Decals	34
	Safety Decals	35
	Instructional Decals	38

SECTION 10 - ENGINE

BOOK 1 - 84154802

Chapter 1 - Engine System

CONTENTS

Section	Description	Page
	Specifications	5
	Engine Bolt Torque Specifications	13
	Metric Bolt Torque Specifications	14
	Special Tools	15
	Troubleshooting	16
	Description and Operation - Engine Components	20
	Cylinder Head Assembly	20
	Camshaft Assembly	20
	Cylinder Block Assembly	20
	Crankshaft Assembly	20
	Connecting Rods	20
	Pistons	20
	Manifolds	20
	Timing Gears	21
	Lubrication System	22
	Cooling System	23
	Fuel System	24
	Fuel Shut Off (Injection Pump)	24
	Lift Pump	24
	Fuel Filters	24
	Engine Preparation	25
	Engine Removal - Installation	26
	Separating Engine from Transmission Housing	26
	Separating Front Axle from Engine	36
	Engine Installation	38
	Engine Compression Test	39
	Test Procedure	39
	Test Readings	39
	Test Conclusion	39
	Rebuild Instructions	39
	Overhaul	40

SECTION 10 - ENGINE

BOOK 1 - 84154802

Chapter 1 - Engine System (Continued)

CONTENTS

Section	Description	Page
	Cylinder Head	40
	Removal	40
	Disassembly	45
	Repair and Inspection	46
	Injector Sleeves	47
	Valve Settings	49
	Valves	49
	Valve Guides	50
	Valve Springs	51
	Tappets and Pushrods	51
	Rocker Shaft	52
	Assembly	52
	Installation	53
	Front Engine Cover	54
	Removal	54
	Timing Gear	56
	Removal	56
	Idler Gear	57
	Removal	57
	Fuel Pump Drive Gear	57
	Removal	57
	Fuel Injection Pump Drive Gear	59
	Removal	59
	Camshaft Drive Gear	59
	Removal	59
	Hydraulic and Power Steering Pump Drive Gear	60
	Removal	60
	Inspection and Repair	60
	Camshaft	60
	Inspection and Repair	60
	Camshaft Drive Gear	61
	Inspection and Repair	61

SECTION 10 - ENGINE

BOOK 1 - 84154802

Chapter 1 - Engine System (Continued)

CONTENTS

Section	Description	Page
	Camshaft Bearings	62
	Replacement	62
	Idler Gear Bushing	63
	Inspection and Repair	63
	Camshaft, Fuel Pump Drive Gear, Hydraulic and Power Steering Drive Gears	63
	Installation	63
	Front Oil Seal	64
	Removal - Installation	64
	Valve Timing - TT60A/TT75A	65
	Adjustment	65
	Oil Pan	66
	Removal	66
	Inspection and Repair	66
	Installation	66
	Dynamic Balancer (TT75A Model only)	67
	Removal	67
	Disassembly	68
	Inspection and Installation	68
	Connecting Rods, Bearings, Pistons and Rings	69
	Removal	69
	Inspection and Repair	70
	Connecting Rod Alignment	71
	Cylinder Block	73
	Inspection and Repair	73
	Flywheel	75
	Removal	75
	Inspection and Repair	76
	Installation	76
	Main Bearing and Crankshaft	77
	Removal	77
	Inspection and Repair	80
	Installation	82

SECTION 10 - ENGINE

BOOK 1 - 84154802

Chapter 1 - Engine System (Continued)

CONTENTS

Section	Description	Page
	Fuel System	86
	Air Cleaner	86
	Service the Engine Air Cleaner Outer Element	86
	Method A	87
	Method B	88
	Fuel Injection Pump	89
	Removal	89
	Inspection	89
	Installation	89
	Checking the Fuel Injection Pump Timing with Pump on the Tractor	90
	Lock-Time the Fuel Injection Pump with Pump Removed from the Tractor	94
	Fuel System Air Bleeding	99
	Injector	100
	Removal	100
	Testing and Overhaul	100
	Fuel Pump	102
	Removal	102
	Disassembly	102
	Inspection	104
	Assembly and Installation	104
	Lubrication System	105
	Oil Pump	105
	Removal	105
	Disassembly	106
	Inspection and Repair	107
	Assembly	108
	Oil Filter	108
	Oil Pressure Warning System	108
	Engine Oil Consumption Diagnosing Procedure	109
	Oil Consumption Test Procedure	109
	Compression Test	110
	Test Readings	110

SECTION 10 - ENGINE

BOOK 1 - 84154802

Chapter 1 - Engine System (Continued)

CONTENTS

Section	Description	Page
	Test Conclusion	110
	Rework Instructions	110
	Oil Consumption Test Form	111
	Cooling System	115
	Radiator	115
	Removal	115
	Repair and Inspection	117
	Installation	117
	Thermostat	118
	Removal	118
	Testing	118
	Installation	118
	Water Pump	119
	Removal	119
	Disassembly	119
	Assembly	120
	Installation	120
	Water Temperature Gauge	120
	Belt Tension Adjustment	120

SECTION 18 - CLUTCHES

BOOK 1 - 84154802

Chapter 1 - Clutches

CONTENTS

Section	Description	page
	Specifications	3
	Description	3
	Tightening Torques	4
	Special Tools	5
	Sealants	5
	Sectional Views	6
	Clutch Assembly	6
	Clutch Plate	7
	Longitudinal Section of 11"/11" LUK Clutch	8
	Troubleshooting	9
	Description and Operation	10
	Operation	10
	Overhaul	11
	Clutch Mechanical Release Control	11
	Clutch Pedal	11
	Removal	11
	Installation	13
	PTO Clutch Lever	15
	Removal	15
	Installation	16
	Cross Shafts	17
	Removal	17
	Assembly	19
	Installation	19
	Transmission/PTO Release Bearing Assembly	21
	Disassembly	21
	Assembly	22
	Transmission Clutch Pedal Free-Travel and Adjustment	23
	Adjusting PTO Clutch Linkage	24

SECTION 18 - CLUTCHES

BOOK 1 - 84154802

Chapter 1 - Clutches (Continued)

CONTENTS

Section	Description	page
	Clutch Assembly	25
	Removal	25
	Installation	26
	Disassembly	28
	Release Fingers	30
	Disassembly	30
	Assembly	31
	Inspection and Repair	33
	Installation	34
	Release Lever Height Adjustment	37
	Important Points To Be Taken Into Account While Replacing Clutch	38

SECTION 21 - TRANSMISSION SYSTEM

BOOK 1 - 84154802

Chapter 1 - Transmission System

CONTENTS

Section	Description	Page
	Specifications	3
	Description	3
	Tightening Torques	3
	Troubleshooting	4
	General Recommendations for Overhauling Operations	5
	Precaution at Flange and Tool Ends	5
	Reassembling Methods	5
	Recommendations Regarding Lubrication	5
	Shaft Seals	5
	O-ring	5
	Adjusting Shims	5
	Bearings	5
	Sealing	5
	Oil Drain	5
	Cleaning	5
	Inspections	5
	Sealants	6
	Special Tools	6
	Description and Operation	7
	8 + 2 Transmission	7
	Overhaul	9
	Transmission Assembly	9
	Removal	9
	Installation	13
	Transmission - Internal Components	17
	Drive Shaft Removal	17
	Drive Shaft Installation	21
	End Play Specification	23

SECTION 21 - TRANSMISSION SYSTEM

BOOK 1 - 84154802

Chapter 1 - Transmission System (Continued)

CONTENTS

Section	Description	Page
	Gear Rails	24
	Removal	24
	Special Tool Required	24
	Inspection	24
	Assembly	25
	Range Gear (Epi-Cyclic) Assembly	27
	Removal	27
	Disassembly	27
	Inspection	28
	Assembly	29
	Reverse Gears and Drive Shaft	29
	Disassembly	29
	Installation	31
	Driven Gears and Drive Shaft	32
	Disassembly	32
	Inspection	34
	Assembly	34
	Checking Driven Gear Shaft Endplay	38
	Specifications	38
	External Components - Gear Shift Lever	39
	Disassembly	39
	Installation	40
	Reverse Lever and Cover	41
	Removal	41
	Installation	43

SECTION 25 - FRONT DRIVE AXLE

BOOK 2 - 84154803

Chapter 1 - Front Axle Mechanical Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	4
	Special Tools	6
	Description and Operation	11
	Front to Rear Axle Ratio	11
	TT60A, TT75A	11
	Front Axle	14
	Removal	14
	Installation	18
	Disassembly	19
	Assembly	27
	Steering Knuckle Pins and Bearings	28
	Replacement	28
	Stub Axle Adjustment	29
	Wheel Hub Bearing Adjustment	30
	Bevel Drive Adjustments	31
	Adjustment of the Preload of the Pinion Shaft Bearings	31
	Determining the Thickness of the Drive Pinion Position Adjustment Shim	33
	Ring/Pinion Adjustments	36
	Adjustment of the Ring Gear Bearings and Checking the Backlash Between the Pinion and Ring Gear	36
	Front Axle Differential	39
	End Float Adjustment	39
	Toe In Adjustment	41

SECTION 25 - FRONT DRIVE AXLE

BOOK 2 - 84154803

Chapter 2 - Four Wheel Drive (FWD) Transfer Box

CONTENTS

Section	Description	Page
	Description of Operation	2
	Four-wheel Drive Lever	2
	Drive Shaft	4
	Removal	4
	Transfer Box	4
	Removal	4
	Disassembly	4
	Intermediate Gear and Shaft	5
	Removal	5
	Installation	5
	Transfer Box	6
	Assembly	6
	Installation	7
	Drive Shaft	8
	Installation	8

SECTION 27 - MECHANICAL REAR WHEEL DRIVE

BOOK 2 - 84154803

Chapter 1 - Ring and Pinion Gears

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	3
	Sealants	4
	Special Tools	4
	Sectional View - Ring/Pinion and Differential Assembly	5
	Troubleshooting	6
	Description and Operation - Mechanical Rear Wheel Drives	6
	Differential Lock	6
	Rear Wheel Drive Housing	7
	Removal	7
	Repair and Inspection	11
	Installation	12
	Differential Unit	18
	Disassembly	18
	Inspection	23
	Assembly	24
	Pinion Shaft	29
	Disassembly	29
	Inspection	31
	Assembly	32
	Shift Rails	34
	Removal	34
	Installation	35
	Adjustments and Settings	39
	Bevel Drive Shaft Bearing Preload Adjustment	39
	Bevel Pinion Shaft Depth Adjustment	40
	Assembling the Bevel and Pinion Shaft	41
	Differential Bearing Adjustment and Bevel Drive Backlash Check	41
	Differential Pinion and Side Gear Backlash Adjustment	44
	Adjustment of Ring Gear Bearings	45

SECTION 27 - MECHANICAL REAR WHEEL DRIVE

BOOK 2 - 84154803

Chapter 2 - Rear Axle and Final Drive

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	3
	Sealants	4
	Sectional Views	5
	Troubleshooting	6
	Description and Operation - Rear Axle and Final Drive	6
	Final Drive Housing	7
	Removal	7
	Installation	11
	Disassembly	16
	Rear Axle Housing	19
	Disassembly	19
	Inspection	19
	Assembly	21
	Final Drive Housing	22
	Assembly	22

SECTION 31 - POWER TAKE-OFF

BOOK 2 - 84154803

Chapter 1 - Rear Power Take-Off System

CONTENTS

Section	Description	Page
	Specifications	2
	Description	2
	Rear PTO	2
	Tightening Torques	3
	Sealants	4
	Sectional View	5
	Description and Operation	6
	Power Take-Off	6
	Adjustments	7
	PTO Clutch	7
	PTO Shaft Assembly	9
	Removal	9
	Installation	10
	PTO Assembly	12
	Disassembly	12
	Assembly	15
	PTO Brake	17
	Removal	17
	Inspection	18
	Assembly	19

SECTION 33 - BRAKING SYSTEM

BOOK 2 - 84154803

Chapter 1 - Braking System

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	3
	Metric Bolt Torque Specifications	4
	Sealants	5
	Sectional Views - Brake Control Assembly	6
	Troubleshooting	7
	Description and Operation - Brake System	8
	Brake Pedals and External Linkages	9
	Removal	9
	Inspection	10
	Assembly	11
	Parking Brake Linkage	13
	Removal	13
	Inspection	13
	Installation	13
	Brake Assembly	14
	Disassembly	14
	Repair and Inspection	16
	Assembly	17
	Brake Pedal Free Play Adjustment	22

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 84154803

Chapter 1 - Hydraulic Systems

CONTENTS

Section	Description	Page
	Introduction and Circuit Identification	2
	Pump	2
	Filter	2
	Mechanical Hydraulic Lift Assembly	3
	Remote Control Valve	4
	Open Center Hydraulic Circuit and Mechanical Lift	5
	Schematic View of Hydraulic System	5
	Hydraulic Circuit Diagram	6

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 84154803

Chapter 2 - Hydraulic Pump

CONTENTS

Section	Description	Page
	Specifications	2
	Description	2
	Tightening Torques	3
	Special Tools	3
	Description and Operation	4
	Hydraulic Pump	5
	Removal	5
	Installation	6
	Disassembly	7
	Inspection	10
	Assembly	11
	Hydraulic Pump Testing	13
	Inlet Restriction Test	13
	Pump Efficiency Test	14
	Relief Valve Test	15
	With or Without Rear Remote Valves	15
	Special Tools	15
	Setting Relief Valve	16
	Servicing Faulty Relief Valve	16
	Inspection	17
	Installation	17

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 2 - 84154803

Chapter 3 - Hydraulic Lift Assembly

CONTENTS

Section	Description	Page
	Specifications	3
	Description	3
	Implement Attachments	5
	Description	5
	Tightening Torques	5
	Sealants	6
	Special Tools	6
	Sectional Views	7
	Hydraulic Lift	7
	Lift Hydraulic Control Valve	8
	Troubleshooting	9
	Description and Operation	10
	Hydraulic System	10
	Pre-Operation Checks	10
	Position Control Operation	11
	Draft Control Operation (If Applicable)	11
	Combined Position and Draft Control Operation	12
	Float Operation	12
	Sensitivity Control	12
	Response Control	13
	Operation of Distributor	14
	Neutral Phase	14
	Lifting Phase	15
	Lowering Phase	16
	Internal Linkage System	17
	Position Control	17
	Float Control	17
	Draft Control	18
	Combined Draft and Position Control	19

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**