
TD5030, TD5040 TD5050 SERVICE MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	2
SECTION 18 - CLUTCH	7
SECTION 21 - TRANSMISSIONS	8
SECTION 23 - DRIVE LINES	10
SECTION 25 - FWD FRONT AXLE	10
SECTION 27 - REAR AXLE AND TRANSMISSION	12
SECTION 31 - POWER TAKE-OFF	13
SECTION 33 - BRAKING SYSTEM	14
SECTION 35 - HYDRAULIC SYSTEM	15
SECTION 41 - STEERING	18
SECTION 44 - FRONT AXLE AND WHEELS (2WD)	20
SECTION 50 - CAB AIR CONDITIONING SYSTEM	21
SECTION 55 - ELECTRICAL SYSTEM	23
SECTION 90 - PLATFORM, CAB, BODYWORK AND DECALS	28

The following pages are the collation of the contents pages from each section and chapter of the TD5030, TD5040, TD5050 Service manual. Complete Service part # 84221704.

The sections used through out all New Holland product Service manuals may not be used for each product. Each Service manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Service manual and which sections are in each book.

The sections listed above are the sections utilized for the TD5030, TD5040, TD5050 Tractors.

SECTION 00 - GENERAL

BOOK 1 - 84221705

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	2
	Health and Safety	4
	Precautionary Statements	14
	Safety	15
	Ecology and the Environment	18
	Consumables	20

SECTION 10 - ENGINE

BOOK 1 - 84221705

Chapter 1 - Engine (F5C)

CONTENTS

Section	Description	Page
	Special Tools	2
	Troubleshooting	3
	Overhaul	7
10 001 10	Engine	7
	Removal	7
	Installation	22

SECTION 10 - ENGINE

BOOK 1 - 84221705

Chapter 2 - Engine (NEF)

CONTENTS

Section	Description	Page
	Specifications	5
	General	5
	Fuel System Data	8
	Crankcase/Cylinder Block Data	9
	Crankshaft and Bearings Data	9
	Connecting Rod Data	10
	Piston Data	10
	Valve Timing Gear Data	11
	Tappet Data	12
	Rocker Arm - Valve Data	12
	Cylinder Head Data	13
	Torques	14
	Torque Settings With Angle	15
	Special Tools	16
	Sectional Views	17
	Troubleshooting	22
	Overhaul	26
	Engine	26
	Removal	26
	Installation	42
	Disassembly	44
	Removing the Crankshaft Front Seal	47
	Removing the Crankshaft Rear Seal	48
	Engine Assembly on the Bench	58
	Installing the Bushings	58
	Installing the Tappets	59
	Installing the Camshaft	59
	Installing the Oil Nozzles	60
	Installing the Crankshaft	60
	Installing the Connecting Rod - Piston Assembly	63
	Installing the Piston Connecting Rod Assemblies in the Cylinder Liners	65

SECTION 10 - ENGINE

BOOK 1 - 84221705

Chapter 2 - Engine (NEF) (Continued)

CONTENTS

Section	Description	Page
	Big End Cap Assembly	66
	Installing the Thermostat Valve	67
	Installing the Cylinder Head	68
	Installing the Injectors	70
	Installing the Rocker Arm Assembly	71
	Installing the Timing Gear	71
	Installing the Injection Pump	74
	Installing the Additional Counterweights	75
	Installing the Hydraulic Pump Drive Gear	76
	Installing the Timing Gear Casing	76
	Installing the Crankshaft Rear Seal	77
	Installing the Flywheel	77
	Installing the Oil Pump	78
	Installing the Oil Sump	79
	Installing the Crankshaft Front Seal	79
	Installing the Crankshaft Front Pulley	79
	Installing the Cooling System Union	80
	Installing the Coolant Pump	80
	Installing the Fan-Alternator Pulley	81
	Installing the Auxiliary Member Drive Belt	82
	Installing the Exhaust Manifold - Turbine	83
	Installing the Injector Feed Pipes	83
	Install the Priming Pump - Feed Pipes	83
	Installing the Pipes Between the Fuel Supply and Injection Pumps, Pre-heating System and Tappet Cover	84
	Installing the Starter Motor	85
10 102 70	Crankshaft Front Seal Replacement	86
	Removal	86
	Installation	88
10 102 74	Crankshaft Rear Seal Replacement	89
	Removal	89
	Installation	90

SECTION 10 - ENGINE

BOOK 1 - 84221705

Chapter 2 - Engine (NEF) (Continued)

CONTENTS

Section	Description	Page
10 106 12	Valve-Rocker Arm Clearance	92
	Removal	92
	Installation	94
10 218 30	Engine Injector	95
	Removal	95
	Installation	96
10 246 14	Bosch Injection Pump	97
	Removal	97
	Installation	101
	Timing	103
	Fuel Circuit Air Bleeding	105
10 402 10	Coolant Pump	106
	Removal	106
	Installation	107
10 402 30	Thermostat Valve	108
	Removal	108
	Installation	109
10 406 10	Engine Radiator	110
	Removal	110
	Installation	114
10 414 10	Coolant Pump and Generator Drive Belts	115
	Adjusting Tension	115
	Checks, Measurements and Repairs	117
	Cylinder Block, Liners	117
	Checks and Measurements	117
	Crankshaft	120
	Connecting Rods	122
	Bushings	122
	Checking Connecting Rods	123
	Checking Twisting	123
	Checking Bending	124

SECTION 10 - ENGINE

BOOK 1 - 84221705

Chapter 2 - Engine (NEF) (Continued)

CONTENTS

Section	Description	Page
	Pistons	124
	Normal Dimensions (mm) Piston Data	124
	Measuring the Piston Diameter	125
	Piston Pins	126
	Conditions for Correct Pin-Piston Coupling	126
	Piston Rings	127
	Valves and Camshaft	129
	Valves	129
	Tappets	131
	Camshaft	132
	Cylinder Head	133
	Cylinder Head Mating Surface Check	133
	Cylinder Head Thickness	133
	Cylinder Head Hydraulic Seal Check	133
	Low Oil Pressure Indicator	134
	Functional Checks	134
	Oil Filter	134
	Replacement	134
	Cooling System	135
	Radiator - Flushing and Checks	135
	Coolant Thermometer - Testing	135
	Thermostat Valve - Replacement	135

SECTION 18 - CLUTCH

BOOK 1 - 84221705

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	5
	Special Tools	6
	Sectional Views	7
	Longitudinal Section of Clutch LUK 11"/11" (Not For All Markets)	8
	Longitudinal Section of the LUK 12"/11" Clutch (Not For All Markets)	8
	Troubleshooting	9
	Overhaul	10
18 110 10	Clutch	10
	Removal	10
	Installation	21
	Checks and Adjustments	22
	Dimensional Checks - Including Disassembly and Assembly	22
	Minimum Permissible Dimensions After Refacing Parts Subject to Wear for VALEO Clutches	26
	11"/11" Dual Clutches	26
	12"/12" Dual Clutches	26
	Adjusting the VALEO Clutch	27
18 100 40	Adjustment of the Main Clutch Control Linkage	29
	PTO Clutch Linkage Adjustment (VALEO Clutch)	30
	PTO Clutch Linkage Adjustment (LUK Clutch)	31
	Single Lever PTO (Not for all markets)	31
	PTO Clutch Linkage Adjustment (LUK Clutch)	31
	Single Lever PTO (Not for All Markets)	31

SECTION 21 - TRANSMISSIONS

BOOK 1 - 84221705

Chapter 1 - Mechanical Transmission (12 x 4)

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	3
	Special Tools	5
	Sectional Views	7
	Description and Operation	10
	Troubleshooting	10

SECTION 21 - TRANSMISSIONS

BOOK 1 - 84221705

Chapter 2 - Reverser

CONTENTS

Section	Description	Page
	Specifications	2
	Synchronizer Reverser Main Data	2
	Gearbox Main Data	2
	Torque	3
	Special Tools	4
	Sectional Views	4
	Description and Operation	6
	Troubleshooting	6
	Synchronizer Reverser	6
	Overhaul	7
	Clutch/Reverser Casing	7
	Disassembly	7
	Assembly	11

SECTION 21 - TRANSMISSIONS

BOOK 1 - 84221705

Chapter 3 - Reverser and Creeper Unit

CONTENTS

Section	Description	Page
	Specifications	2
	Synchronizer Reverser-Creeper Unit Main Data	2
	Creeper Unit Main Data	2
	Gearbox Main Data	2
	Torque	3
	Special Tools	4
	Sectional Views	5
	Description and Operation	7
	Troubleshooting	7
	Overhaul	8
	Clutch Casing - Synchronizer Reverser and Creeper Unit	8
21 110 87	Disassembly	8
	Assembly	14

SECTION 23 - DRIVE LINES

BOOK 1 - 84221705

Chapter 1 - Drive Lines

CONTENTS

Section	Description	Page
	Specifications	2
	Drive Shaft	2
	Torque	3
	Special Tools	3
	Sectional Views	4
	Overhaul	5
	Transmission Shafts and Guard	5
	Disassembly	5
	Assembly	5
	Drive Gear Housing Assembly	6
	Removal	6
	Installation	8
	Transfer Box, Unit Removed	9
23 101 42	Disassembly	9
	Assembly	10

SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION

BOOK 2 - 84221706

Chapter 1 - Front Axle Mechanical Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Torques	4
	Special Tools	6
	Sectional Views	7
	Description and Operation	10

SECTION 25 - FRONT AXLE MECHANICAL TRANSMISSION

BOOK 2 - 84221706

Chapter 1 - Front Axle Mechanical Transmission (Continued)

CONTENTS

Section	Description	Page
	Limited-Slip, Self-locking Differential Lock	10
	Operation	10
	No Spin Differential (Optional)	11
	Operation	12
	Overhaul	13
	Complete Front Axle	13
25 100 30	Removal	13
	Installation	17
	Front Axle	18
25 100 38	Removal	18
	Installation	29
25 108 46 or 25 108 47	Steering Knuckle Pins and Bearings	30
	Replacement	30
	Adjustments	31
	Stub Axle Adjustment	31
	Wheel Hub Bearing Adjustment	33
	Bevel Drive Adjustments	34
	Adjustment of the Preload of the Pinion Shaft Bearings	34
	Determining the Thickness of the Drive Pinion Position Adjustment Shim	35
	Adjustment of the Crown Wheel Bearings and Checking the Backlash Between the Pinion And Crown Wheel	36
25 102 24	Front Axle Differential Adjustment	39
	Front Axle Differential With Limited-Slip Unit	40
25 102 27	Removal	40
	Disassembly	40
	Installation	41
	Front Axle Differential With No Spin	42
25 102 26	Removal	42
	Disassembly	42
	Assembly	42
	Checking the Alignment of Steering Drive Wheels	43

SECTION 27 - REAR AXLE AND TRANSMISSION

BOOK 2 - 84221706

Chapter 1 - Rear Axle and Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Main Specifications of Final Drives	3
	Torque	4
	Special Tools	6
	Sectional Views	8
	Description and Operation	11
	Troubleshooting	11
	Bevel Gear Pinion and Differential	11
	Final Drives	11
	Overhaul	12
	Rear Transmission/Gearbox Case	12
21 118 10 - 21 118 12	Removal	12
	Installation	42
	Transmission/Gearbox Case	43
21 118 85	Removal	43
	Installation	48
	Adjustments	52
	Transmission/Gearbox Case	52
	Adjusting Gearbox Driving Shaft Axial Clearance	52
	Adjusting the Position of the Differential Lock Engagement Sleeve	54
	Bevel Gear Pair	55
	Determining the Bevel Pinion Positioning Adjustment Ring	55
	Adjusting the Taper-roller Bearings For Pinion Shaft	58
	Adjusting the Ring Bevel Gear Bearings and Checking the Clearance Between the Teeth of the Bevel Gear Pair	59
	Adjusting the Bevel Gear Pair	63
	Differential Pinion and Side Gear Backlash Adjustment	63
	Final Drive Removal	65
	Disassembly (Cover)	65
	Driven Gear Retaining Nut Removal	66
	Wheel Shaft Removal (Installation)	66
	Housing	67
	Disassembly	67
	Assembly	68

SECTION 31 - POWER TAKE-OFF

BOOK 2 - 84221706

Chapter 1 - Mechanical Power Take-off

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	4
	Special Tools	5
	Sectional Views	6
	Description of Operation	11
	Mechanical PTO	11
	Independent PTO	11
	Ground Speed PTO	12
	PTO Speed Selector Lever	12
	Single Lever Power Take-Off - (Optional)	13
	Troubleshooting	13
	Overhaul	14
	540/750 Mechanical PTO	14
31 112 20	Removal	14
	Installation	17
31 112 45 - 31 112 48	Disassembly	18
	Assembly	21
	540/1000 Mechanical PTO/ Interchangeable PTO Shaft - N.A. Version)	22
31-114	Disassembly	22
	Assembly	27

SECTION 33 - BRAKING SYSTEM

BOOK 2 - 84221706

Chapter 1 - Braking System

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	3
	Sectional Views	4
	Special Tools	8
	Description of Operation	8
	Service Brakes	8
	Parking Brake	8
	Troubleshooting	9
	Overhaul	10
	Service Brake	10
33 202 60	Removal	10
	Installation	14
	Hydraulic Front Brake Pump (Optional)	16
33 202 50	Removal	16
	Installation	19
	Hydraulic Brake Slave Cylinder	20
33 202 50	Removal	20
	Installation	20
	Hydraulic Front Brake System (Optional)	21
33 202 04	Air Bleeding	21
	Adjustments	23
	Service Brake Pedals	23
33 120 08	Adjusting the Height	23
	Hand Brake Control	24
33 110 08	Adjusting Travel	24

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84221706

Chapter 1 - Rear Mechanical Hydraulic Lift

CONTENTS

Section	Description	Page
	Specifications	2
	Rear Mechanical Hydraulic Lift	2
	Main Specification of Implement Hitching Device	4
	Main Specification of Hydraulic Pump (All Models)	4
	Lift Hydraulic Pump (Optional) Data	5
	Torque	6
	Special Tools	7
	Sectional Views	8
	Description and Operation	10
	Hydraulic Lift Circuit	10
	Arm Lift Phase	11
	Neutral Phase	12
	Arm Lowering Phase	13
	Troubleshooting	14
	Overhaul	16
	Rear Hydraulic Lift Assembly	16
35 110 30	Removal	16
	Installation	23
35 110 40 - 35 110 42 - 35 110 46	Disassembly	24
	Assembly	27
	Adjusting the Lift	29
	Position Control	30
	Maximum Height of the Lift Arms	31
	Draft Control	33
35 110 08	Adjusting the Linkages	37
	Position Control Linkage	37
	Draft Control Linkage	38
	Lift-O-Matic Device	39
35 110 30	Lift Pressure Relief Valve	40
35 110 32	Calibration	40
	Lift Control Valve Block, Detached	42

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84221706

Chapter 1 - Rear Mechanical Hydraulic Lift (Continued)

CONTENTS

Section	Description	Page
35 110 14	Disassembly	42
	Assembly	46
	Hydraulic Lift Control Oil Pump	47
35 0101 10	Disassembly	47
	Assembly	48

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84221706

Chapter 2 - Open Center System Auxiliary Control Valves

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	2
	Sectional Views	3
	Description of Operation	4
	Operating Stages of Auxiliary Control Valve for Operation of a Double-acting Cylinder With Automatic Detent Release and Float Position	4
	Float Control Operation	4
	Lifting	5
	Lowering	5
	Operating Stages of Auxiliary Control Valve for Operation of a Double-acting Cylinder	6
	Lifting	6
	Lowering	6
	Operating Stages of Auxiliary Control Valve for Operation of a Single-acting Cylinder	6
	Lifting	6
	Lowering	6

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84221706

Chapter 2 - Open Center System Auxiliary Control Valves (Continued)

CONTENTS

Section	Description	Page
	Operating Stages of Auxiliary Control Valve Operating a Double-acting Cylinder With Automatic Detent Release	7
	Lifting	7
	Lowering	7
	Overhaul	8
	Convertible Single/Double-acting Auxiliary Control Valve	8
	Disassembly - Assembly (valves removed from tractor)	8
	Convertible Single/Double-acting Auxiliary Control Valve With Float Control and Detent Release	9
	Disassembly - Assembly	9
	Double-acting Auxiliary Control Valve With Float Control and Automatic Detent Release	18
	Disassembly - Assembly	18
	Spool Binding Test	18
	Control Valve Spool Binding Test	18
	Spool Leakage Test	19
	Valve Leakage Test	19
	Adjustment of the Automatic Detent Release Pressure	20

SECTION 35 - HYDRAULIC SYSTEM

BOOK 2 - 84221706

Chapter 3 - Trailer Brake Auxiliary Control Valve

CONTENTS

Section	Description	Page
	Sectional Views	2
	Description and Operation	2
	Hydraulic Diagram of Trailer Brake Auxiliary Control Valve	3
	Description and Operation of Valve Phases	4
	Trailer Brakes Off	4
	Start of Braking	4
	Braking	5
	Trailer Brake Remote Control Valve Linkage Adjustment	7

SECTION 41 - STEERING

BOOK 3 - 84221707

Chapter 1 - Steering

CONTENTS

Section	Description	Page
	Specifications	2
	Torque	3
	Sectional Views	4
	Special Tools	7
	Description of Operation	8
	Neutral Position	8
	Steering to the Right	9
	Steering to the Left	9
	Steering to the Right Manually	9
	Steering to the Left Manually	9
	Troubleshooting	10

SECTION 41 - STEERING

BOOK 3 - 84221707

Chapter 1 - Steering (Continued)

CONTENTS

Section	Description	Page
	Overhaul	12
	Hydrostatic Steering Control Valve	12
41 204 30	Removal	12
	Installation	15
	Hydrostatic Steering Control Valve	15
41 204 34	Disassembly	15
	Assembly	22
	Bench Testing	33
	Checking the Hydrostatic Steering Pressure Relief Valve With Steering Control Valve Installed On Tractor	34
41 206 20	Hydrostatic Steering Oil Pump	35
	Disassembly	36
	Assembly	36
41 216 20	Front Axle Steering Cylinder (2WD)	37
	Removal - Installation	37
	Front Axle Steering Cylinder (FWD)	38
	Removal - Installation	38

SECTION 44 - FRONT AXLE AND WHEELS (2WD)

BOOK 3 - 84221707

Chapter 1 - Axle and Wheels

CONTENTS

Section	Description	Page
44 000	Specifications	2
	Tightening Torques	5
	Special Tools	6
	Troubleshooting	6
44 101 30	Overhaul	7
	Front Axle	7
	Removal	7
	Installation	9
44 101 22	Axle Wheel Hub	10
	Removal	10
	Installation	13
44 101 46	Stub Axle	17
	Removal	17
	Installation	19
44 101 80	Adjustments	21
	Toe-In	21

SECTION 50 - CAB AIR CONDITIONING SYSTEM

BOOK 3 - 84221707

Chapter 1 - Air Conditioning System

CONTENTS

Section	Description	Page
50 000	Safety	3
	Specifications	4
	Special Tools	5
	Description of Operation	6
	Cab Heating and Ventilation Controls	8
	Ventilation	8
	Fan	8
	Air Filter	8
	Heating	9
	Temperature Control Knob	9
	Ignition Switch	9
	Switching on the Air Conditioning and Temperature Control	10
	Air Conditioning and Temperature Control Button	10
	Heating Control Knob	10
	3-Speed Fan Control Knob	10
	Use of the Air Conditioning System	11
	Switching On the Air Conditioning	11
	Adjustment	11
	Switching Off the Air Conditioning System	11
	Components of the Air Conditioning System	12
	Compressor	12
	Condenser	13
	Receiver/Dryer	14
	Thermostatic Expansion Valve	15
	Air Conditioner Temperature Cycling Control Switch	16
	Thermostatic Switch (ANTIFROST)	16
	Evaporator	17
	Refrigerant Recovery-Recycling and Evacuation-Charging Stations	18
	Recovery and Recycling Station (380000559)	18
	Maintenance	18
	Evacuation/Charging Station (380000558)	19

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**