

SERVICE MANUAL

**CR6090 / CR7090 / CR8080 /
CR8090 / CR9090**

**Tier 4a
Combine**

Part number 84561155
1st edition English
July 2012



Contents

INTRODUCTION

| | |
|---|--------|
| Engine..... | 10 |
| Fuel filters | 10.206 |
| Aftercooler..... | 10.310 |
| Engine cooling system | 10.400 |
| Oil cooler and lines | 10.408 |
| Fan and drive..... | 10.414 |
| Rotary screen..... | 10.418 |
| Engine air compressor | 10.450 |
| Selective Catalytic Reduction (SCR) exhaust treatment | 10.500 |
| Main gearbox and drive | 14 |
| Main gearbox and drive | 14.100 |
| Transmission..... | 21 |
| Mechanical transmission | 21.114 |
| Mechanical transmission external controls | 21.130 |
| Gearbox internal components | 21.145 |
| Differential | 21.182 |
| Front axle system | 25 |
| Powered front axle | 25.100 |
| Final drives | 25.310 |
| Rear axle system..... | 27 |
| Powered rear axle | 27.100 |
| Hydrostatic drive..... | 29 |
| Transmission and steering hydrostatic control | 29.100 |
| Two-speed assembly | 29.134 |
| Hydrostatic transmission | 29.202 |
| Reservoir, cooler, and lines..... | 29.204 |

| | |
|--|-----------|
| Pump and motor components | 29.218 |
| Rear hydrostatic transmission | 29.300 |
| Brakes and controls | 33 |
| Parking brake / Parking lock | 33.110 |
| Hydraulic service brakes | 33.202 |
| Hydraulic systems..... | 35 |
| Hydraulic systems | 35.000 |
| Pump control valves | 35.102 |
| Variable displacement pump | 35.106 |
| Auxiliary hydraulic pump and lines | 35.220 |
| Reservoir, cooler, and filters | 35.300 |
| Main control valve | 35.359 |
| Header/Attachment height system | 35.410 |
| Header/Attachment tilting system | 35.415 |
| Grain tank unload system | 35.440 |
| Traction variator system | 35.450 |
| Reel control system | 35.518 |
| Crop processor system..... | 35.536 |
| Header/Attachment leveling system..... | 35.602 |
| Header reverser drive | 35.760 |
| Chaff spreader control..... | 35.796 |
| Stone trapping system..... | 35.992 |
| Steering..... | 41 |
| Steering control..... | 41.101 |
| Hydraulic control components..... | 41.200 |
| Pump | 41.206 |
| Cylinders | 41.216 |
| Autoguidance steering..... | 41.432 |
| Tracks and track suspension..... | 48 |

| | |
|--|-----------|
| Tracks | 48.100 |
| Track frame and driving wheels | 48.130 |
| Track tension units | 48.134 |
| Cab climate control | 50 |
| Heating | 50.100 |
| Ventilation | 50.104 |
| Air conditioning | 50.200 |
| Electrical systems | 55 |
| Electrical system | 55.000 |
| Fuel injection system | 55.010 |
| Fuel tank system | 55.011 |
| Engine cooling system | 55.012 |
| Engine oil system | 55.013 |
| Engine intake and exhaust system | 55.014 |
| Engine control system | 55.015 |
| Hydrostatic drive control system | 55.019 |
| Transmission control system | 55.024 |
| Gearbox electric system | 55.029 |
| Service brake electrical system | 55.030 |
| Parking brake electrical system | 55.031 |
| Hydraulic system control | 55.036 |
| Heating, Ventilation, and Air-Conditioning (HVAC) control system | 55.050 |
| Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls | 55.051 |
| Harnesses and connectors | 55.100 |
| Engine starting system | 55.201 |
| Cold start aid | 55.202 |
| Alternator | 55.301 |
| External lighting | 55.404 |
| Warning indicators, alarms, and instruments | 55.408 |

| | |
|--|-----------|
| Feeding control system..... | 55.421 |
| Cleaning control system..... | 55.423 |
| Harvest material flow control system..... | 55.426 |
| Cab controls..... | 55.512 |
| Wiper/Washer system..... | 55.518 |
| Cab brake controls..... | 55.519 |
| Cab harvesting controls..... | 55.520 |
| Ground speed control..... | 55.610 |
| Reverser electric control..... | 55.618 |
| Residue handling control..... | 55.624 |
| Threshing electrical control..... | 55.628 |
| Electronic modules..... | 55.640 |
| Cab header controls..... | 55.661 |
| Header height control..... | 55.662 |
| Header leveling control..... | 55.670 |
| Shaker shoe leveling system control..... | 55.780 |
| Precision farming system..... | 55.785 |
| Rotary screen drive and cleaning..... | 55.830 |
| Sieve electric control..... | 55.834 |
| Rotary separator control..... | 55.836 |
| Global Positioning System (GPS)..... | 55.911 |
| Selective Catalytic Reduction (SCR) electrical system..... | 55.988 |
| FAULT CODES..... | 55.DTC |
| Product feeding..... | 60 |
| Floating roll, feed chain, and drive..... | 60.105 |
| Feeder housing..... | 60.110 |
| Stone trapping system..... | 60.112 |
| Feeder housing shafts..... | 60.130 |
| Feeder drive system..... | 60.150 |

| | |
|---|-----------|
| Threshing | 66 |
| Threshing | 66.000 |
| Concave conveyor plate | 66.101 |
| Concave | 66.105 |
| Concave control system | 66.110 |
| Threshing mechanism drive system | 66.260 |
| Drum/Rotor variator with electrical control | 66.321 |
| Rotor | 66.331 |
| Drum/Rotor housing | 66.360 |
| Residue handling | 73 |
| Straw chopper drive system | 73.210 |
| Straw chopper frame | 73.220 |
| Straw chopper | 73.230 |
| Positive Straw Discharge (PSD) | 73.300 |
| Chaff spreader | 73.335 |
| Cleaning | 74 |
| Cleaning | 74.000 |
| Self-leveling frame | 74.100 |
| Cleaning drive systems | 74.101 |
| Grain pan | 74.110 |
| Upper shaker shoe | 74.114 |
| Lower shaker shoe | 74.118 |
| Fan housing | 74.130 |
| Fan drive system | 74.136 |
| Tailings return system | 74.140 |
| Crop storage / Unloading | 80 |
| Clean grain elevator | 80.101 |
| Grain tank | 80.150 |
| Grain tank unload drive system | 80.175 |

| | |
|---|-----------|
| Grain tank unload..... | 80.180 |
| Platform, cab, bodywork, and decals..... | 90 |
| Machine shields and guards..... | 90.105 |
| Protections and footboards..... | 90.118 |
| Pneumatically-adjusted operator seat..... | 90.124 |
| Cab..... | 90.150 |
| Cab interior..... | 90.151 |
| Cab doors and hatches..... | 90.154 |



INTRODUCTION

Contents

INTRODUCTION

| | |
|---|----|
| Basic instructions - Important notice regarding equipment servicing | 4 |
| CR6090 [YBG115106 -], CR6090 NA, CR8080 NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| International symbols | 5 |
| CR6090, CR8080, CR9090 NA, CR7090 [YBG115106 -] NA, CR7090, CR8090 [YBG115106 -] NA, CR8090 | |
| Foreword | 6 |
| CR6090 [YBG115106 -] NA, CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR9090 NA, CR7090 [YBG115106 -] NA, CR7090, CR8090 [YBG115106 -] NA, CR8090 | |
| Safety rules | 7 |
| CR6090, CR8080 [YBG115106 -], CR8080 NA, CR9090 [YBG115106 -], CR9090 NA, CR7090, CR8090 | |
| Safety rules - Personal safety | 8 |
| CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Personal safety | 9 |
| CR6090, CR8080 [YBG115106 -], CR8080 NA, CR9090 [YBG115106 -], CR9090 NA, CR7090, CR8090 | |
| Safety rules | 10 |
| CR6090 [YBG115106 -], CR6090 NA, CR8080 NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Safety rules | 11 |
| CR6090 [YBG115106 -], CR6090 NA, CR8080 NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Personal safety | 17 |
| CR6090 [YBG115106 -], CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Safety rules | 18 |
| CR6090 [YBG115106 -], CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Safety rules | 20 |
| CR6090, CR8080 [YBG115106 -], CR8080 NA, CR9090 [YBG115106 -], CR9090 NA, CR7090, CR8090 | |
| General specification - General Welding | 22 |
| CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Basic instructions - Shop and Assembly | 23 |
| CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Basic instructions - Chain Wear Tables - Roller Chains | 25 |
| CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| Torque - Minimum tightening torques for normal assembly | 27 |
| CR Series Tier IV | |
| Torque - Standard torque data for hydraulics | 32 |
| CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| General specification - Lubricant capacities | 34 |
| CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| General specification - Biodiesel fuels | 36 |
| Dimension | 39 |
| CR6090 [YBG115106 -], CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |
| General specification | 41 |
| CR6090 [YBG115106 -] NA, CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA | |

Selective Catalytic Reduction (SCR) exhaust treatment - Product overview 47
CR6090 [YBG115106 -] NA, CR6090, CR8080 NA, CR9090 NA, CR7090 [YBG115106 -] NA, CR7090, CR8090 [YBG115106 -] NA, CR8090

General specification 52
CR6090, CR8080 [YBG115106 -], CR8080 NA, CR9090 [YBG115106 -], CR9090 NA, CR7090, CR8090

Product identification 53
CR6090 [YBG115106 -], CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA

Basic instructions - Important notice regarding equipment servicing

CR6090 [YBG115106 -], CR6090 NA, CR8080 NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA

All repair and maintenance work listed in this manual must be carried out only by qualified dealership personnel, strictly complying with the instructions given, and using, whenever possible, the special tools.

Anyone who performs repair and maintenance operations without complying with the procedures provided herein shall be responsible for any subsequent damages.

The manufacturer and all the organizations of its distribution chain, including - without limitation - national, regional, or local dealers, reject any responsibility for damages caused by parts and/or components not approved by the manufacturer, including those used for the servicing or repair of the product manufactured or marketed by the manufacturer. In any case, no warranty is given or attributed on the product manufactured or marketed by the manufacturer in case of damages caused by parts and/or components not approved by the manufacturer.

The information in this manual is up-to-date at the date of the publication. It is the policy of the manufacturer for continuous improvement. Some information could not be updated due to modifications of a technical or commercial type, or changes to the laws and regulations of different countries.

In case of questions, refer to your NEW HOLLAND AGRICULTURE Sales and Service Networks.

International symbols

CR6090, CR8080, CR9090 NA, CR7090 [YBG115106 -] NA, CR7090, CR8090 [YBG115106 -] NA, CR8090

As a guide to the operation of the machine, various universal symbols have been utilized on the instruments, controls, switches, and fuse box. The symbols are shown below with an indication of their meaning.

| | | | | | | | |
|---|------------------------------|---|-------------------------------|---|-----------------------------|---|------------------------------------|
|  | Thermostat starting aid |  | Radio |  | PTO |  | Position Control |
|  | Alternator charge | KAM | Keep alive memory | N | Transmission in neutral |  | Draft Control |
|  | Fuel level |  | Turn signals |  | Creeper gears |  | Accessory socket |
|  | Automatic Fuel shut-off |  | Turn signals -one trailer |  | Slow or low setting |  | Implement socket |
|  | Engine speed (rev/min x 100) |  | Turn signals -two trailers |  | Fast or high setting |  | %age slip |
|  | Hours recorded |  | Front wind-screen wash/wipe |  | Ground speed |  | Hitch raise (rear) |
|  | Engine oil pressure |  | Rear wind-screen wash/wipe |  | Differential lock |  | Hitch lower (rear) |
|  | Engine coolant temperature |  | Heater temperature control |  | Rear axle oil temperature |  | Hitch height limit (rear) |
|  | Coolant level |  | Heater fan |  | Transmission oil pressure |  | Hitch height limit (front) |
|  | Tractor lights |  | Air conditioner |  | FWD engaged |  | Hitch disabled |
|  | Headlamp main beam |  | Air filter blocked |  | FWD dis-engaged |  | Hydraulic and transmission filters |
|  | Headlamp dipped beam |  | Parking brake |  | Warning! |  | Remote valve extend |
|  | Work lamps |  | Brake fluid level |  | Hazard warning lights |  | Remote valve retract |
|  | Stop lamps |  | Trailer brake |  | Variable control |  | Remote valve float |
|  | Horn |  | Roof beacon |  | Pressurised! Open carefully |  | Malfunction! See Operator's Manual |
| | |  | Warning ! Corrosive substance | | |  | Malfunction! (alternative symbol) |

Foreword

CR6090 [YBG115106 -] NA, CR8080 [YBG115106 -] NA, CR9090 [YBG115106 -] NA, CR9090 NA, CR7090 [YBG115106 -] NA, CR7090, CR8090 [YBG115106 -] NA, CR8090

Soil, air, and water are vital factors of agriculture and life in general. When legislation does not yet rule the treatment of some of the substances required by advanced technology, sound judgment should govern the use and disposal of products of a chemical and petrochemical nature.

NOTE: *The following are recommendations that may be of assistance:*

- Become acquainted with and ensure that you understand the relative legislation applicable to your country.
- Where no legislation exists, obtain information from suppliers of oils, filters, batteries, fuels, antifreeze, cleaning agents, etc., with regard to their effect on man and nature and how to safely store, use, and dispose of these substances.
- Agricultural consultants will, in many cases, be able to help you as well.

Helpful hints

- Avoid filling tanks using cans or inappropriate pressurized fuel delivery systems that may cause considerable spillage.
- In general, avoid skin contact with all fuels, oils, acids, solvents, etc. Most of them contain substances that may be harmful to your health.
- Modern oils contain additives. Do not burn contaminated fuels and or waste oils in ordinary heating systems.
- Avoid spillage when draining off used engine coolant mixtures, engine, gearbox and hydraulic oils, brake fluids, etc. Do not mix drained brake fluids or fuels with lubricants. Store them safely until they can be disposed of in a proper way to comply with local legislation and available resources.
- Modern coolant mixtures, i.e. antifreeze and other additives, should be replaced every two years. They should not be allowed to get into the soil, but should be collected and disposed of properly.
- Do not open the air-conditioning system yourself. It contains gases that should not be released into the atmosphere. Your NEW HOLLAND AGRICULTURE dealer or air conditioning specialist has a special extractor for this purpose and will have to recharge the system properly.
- Repair any leaks or defects in the engine cooling or hydraulic system immediately.
- Do not increase the pressure in a pressurized circuit as this may lead to a component failure.
- Protect hoses during welding as penetrating weld splatter may burn a hole or weaken them, allowing the loss of oils, coolant, etc.

Safety rules

CR6090, CR8080 [YBG115106 -], CR8080 NA, CR9090 [YBG115106 -], CR9090 NA, CR7090, CR8090


Personal safety





This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible death or injury.

Throughout this manual you will find the signal words DANGER, WARNING, and CAUTION followed by special instructions. These precautions are intended for the personal safety of you and those working with you.

Read and understand all the safety messages in this manual before you operate or service the machine.

 DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

 WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 CAUTION, used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

FAILURE TO FOLLOW DANGER, WARNING, AND CAUTION MESSAGES COULD RESULT IN DEATH OR SERIOUS INJURY.

Machine safety

NOTICE: Notice indicates a situation which, if not avoided, could result in machine or property damage.

Throughout this manual you will find the signal word Notice followed by special instructions to prevent machine or property damage. The word Notice is used to address practices not related to personal safety.

Information

NOTE: Note indicates additional information which clarifies steps, procedures, or other information in this manual.

Throughout this manual you will find the word Note followed by additional information about a step, procedure, or other information in the manual. The word Note is not intended to address personal safety or property damage.

Safety rules - Personal safety

CR6090, CR8080, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA

Carefully study these precautions, and those included in the external attachment operators manual, and insist that they be followed by those working with and for you.

1. Thoroughly read and understand this manual and the attachment Operator's Manual before operating this or any other equipment.
2. Be sure all people and pets are clear of the machine before starting. Sound the horn, if equipped, three times before starting engine.
3. Only the operator should be on the machine when in operation. Never allow anyone to climb on to the machine while it is in motion. If the machine is equipped with an Instructors Seat, this must only be used for training purposes. Passengers must not be allowed to use the Instructors Seat.
4. Keep all shields in place. Never work around the machine or any of the attachments while wearing loose clothing that might catch on moving parts.
5. Observe the following precautions whenever lubricating the machine or making adjustments.
 - Disengage all clutching levers or switches.
 - Lower the attachment, if equipped, to the ground or raise the attachment completely and engage the cylinder safety locks. Completing these actions will prevent the attachment from lowering unexpectedly.
 - Engage the parking brake.
 - Shut off the engine and remove the key.
 - Wait for all machine movement to stop before leaving the operators platform.
6. Always keep the machine in gear while travelling downhill.
7. The machine should always be equipped with sufficient front or rear axle weight for safe operation.
8. Under some field conditions, more weight may be required at the front or rear axle for adequate stability. This is especially important when operating in hilly conditions or/when using heavy attachments.
9. Always lower the attachment, shut off the engine, set the parking brake, engage the transmission gears, remove the key and wait for all machine movement to stop before leaving the operators platform.
10. If the attachment or machine should become obstructed or plugged; set the parking brake, shut off the engine and remove the key, engage the transmission gears, wait for all machine or attachment motion to come to a stop, before leaving the operators platform to removing the obstruction or plug.
11. Never disconnect or make any adjustments to the hydraulic system unless the machine and/or the attachment is lowered to the ground or the safety lock(s) is in the engaged position.
12. Use of the flashing lights is highly recommended when operating on a public road.
13. When transporting on a road or highway, use accessory lights and devices for adequate warning to the operators of other vehicles. In this regard, check local government regulations. Various safety lights and devices are available from your NEW HOLLAND AGRICULTURE dealer.
14. Practice safety 365 days a year.
15. Keep all your equipment in safe operating condition.
16. Keep all guards and safety devices in place.
17. Always set the parking brake, shut off the engine and remove the key, engage the transmission gears, wait for all machine or attachment motion to come to a stop, before leaving the operators platform to service the machine and attachment.
18. Remember: A careful operator is the best insurance against an accident.
19. Extreme care should be taken in keeping hands and clothing away from moving parts.

Personal safety

CR6090, CR8080 [YBG115106 -], CR8080 NA, CR9090 [YBG115106 -], CR9090 NA, CR7090, CR8090

⚠ WARNING

Maintenance hazard!

Before you start servicing the machine, attach a DO NOT OPERATE warning tag to the machine in a visible area.

Failure to comply could result in death or serious injury.

W0004A

Attach a DO NOT OPERATE (TAG) to the machine in an area that is clearly visible whenever the machine is not operating properly and/or requires service.

Complete the tag information for the "REASON" the tag is attached by describing the malfunction or service required. Validate the reason for attaching the tag by signing your name in the designated area on the tag.

The tag should only be removed by the person who signed and attached the tag, after validating the repairs or services have been completed.

| | | |
|-----|--|-----|
| (A) | | (D) |
| (B) | <p>See Other Side</p> | (E) |
| (C) | <p>CNH Part Number 87358697</p> <p>Printed in U.S.A.</p> | (F) |

87358697 1

Tag Components

- A. DO NOT REMOVE THIS TAG! - (Warning) The tag should only be removed by the person who signed and attached the tag, after validating the repairs or services have been completed.
- B. See Other Side - (Reference to additional information on opposite side of the tag.)
- C. CNH Part Number - (Request this part number from you Service Parts Dealer to obtain this DO NOT OPERATE tag.)
- D. DO NOT OPERATE - (Warning!)
- E. REASON - (Area for describing malfunction or service required before operation.)
- F. Signed by - (Signature area - to be signed by the person validating the reason for installation of the tag.)

Safety rules

CR6090 [YBG115106 -], CR6090 NA, CR8080 NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA

**CALIFORNIA
PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery post, terminals and related accessories contain lead and lead compounds.

Wash hands after handling

BT09A213 1

Safety rules

CR6090 [YBG115106 -], CR6090 NA, CR8080 NA, CR9090 [YBG115106 -] NA, CR7090 [YBG115106 -] NA, CR8090 [YBG115106 -] NA

Important notice to operators

Your machine may be equipped with special guarding or other devices in compliance with local legislation. Some of the guarding or safety devices require active use by the operator.

Check local legislation on the usage of this machine.

Accident prevention

Farm accidents can be prevented with your help.

No accident prevention program can be successful without the wholehearted cooperation of the person who is directly responsible for the operation of the equipment.

To read accident reports from all over the country is to be convinced that a large number of accidents can be prevented only by the operator anticipating the result before the accident is caused and doing something about it.

It is said that "The best kind of safety device is a careful operator who with care and mature consideration can save more lives and limbs than any accident prevention program which is not adhered to".

Further in this chapter you will find a list of the most important safety precautions.

Take time to read and follow the instructions and furthermore, be careful!

Some pictures in this manual may show the safety guarding open or removed to better illustrate a particular feature or adjustment.

Ensure to close or replace all guards before operating the machine.

General and operating safety

Most farm machinery accidents can be avoided by the observance of a few simple safety precautions.

1. The machine must only be used by a skilled operator familiar with all the controls and harvesting techniques on cultivated land with slopes up to maximum **26 % (15 °)** uphill and downhill.
2. Do not permit anyone other than the operator to ride on the machine.
3. Before starting the engine, ensure everyone is clear of the machine.
4. Warn bystanders by sounding the horn several times.
5. Keep children away from and off the machine at all times.
6. No-one should be standing on the ladders when the machine is moving.
7. When driving on public roads, observe traffic regulations, adapt your speed to road and traffic conditions and ensure that all lights and other safety mechanisms on the machine (if they are required) are fitted and work properly. The grain tank must be empty when driving on the road. Ensure that the unloading tube is locked in its closed position.
8. Ensure that both brake pedals are locked together when travelling on public roads.
9. Ensure the hazard warning signs provided are installed at the front and the rear of the machine and use the rotating amber traffic warning beacon(s) (if equipped) when driving on public roads to indicate the vehicle is of abnormal size and is slow-moving.
10. Do not brake abruptly to avoid tipping of the machine.
11. Do not exceed **20 km/h (12.5 mph)** when driving downhill. If necessary, change into a lower gear before starting the descent.
12. Never travel at high speed in crowded areas.
13. Avoid making turns at high speed.

14. When driving on public roads, either with the grain header loaded on a trailer and attached to the rear of the machine, or with the grain header still attached to the machine (provided local legislation allows), always be aware and conscious of its size.
15. Before operating the machine ensure that all safety guards are installed.
16. Check the wheel nuts torque as described in MAINTENANCE.
17. Do not enter the grain tank while the machine engine is running. With engine stopped, use a wooden clearing club should the grain tank unloading auger become bridged. Take utmost care not to be pulled into the grain tank in case un-bridging is required.
18. Do not attempt to clean, lubricate or carry out any adjustments on the machine while it is in motion or while the engine is running.
19. Never leave the operator's platform without first disengaging the machine drive mechanism, lowering the header, stopping the engine, applying the park brake and removing the ignition key.
20. Do not work under the machine header unless it is securely blocked and/or the header safety latch is engaged.
21. Do not work around the machine in loose clothing that might catch in any of the moving parts.
22. Keep hands away from moving parts of the machine.
23. Keep the fire extinguisher within easy reach of the operator. Ensure to replace it by a similar type of extinguisher or have it checked or refilled after every usage and/or date of expiry.
24. Do not step on the grain tank extensions, covers, or the cab roof.
25. Machine dust can cause "farmer's lung" disease. It may also contain harmful spraying residues. Keep the cab door and window closed during operation. Wear a dust mask when cleaning the accumulated dust and debris on the machine.

Hydraulic system safety

- Hydraulic oil leaking under pressure can penetrate the skin and cause infection or other injury. To prevent personal injury:
 - Relieve all pressure before disconnecting fluid lines.
 - Before applying pressure, make sure all connections are tight and components are in good condition.
 - Never use your hand to check for suspected leaks under pressure. Use a piece of cardboard or wood for this purpose.
 - If injured by leaking fluid, seek medical attention immediately.
- The hydraulic hoses and fittings on your machine meet engineering specifications for the particular function. When replacing damaged, blown or worn hoses or fittings, use only manufacture authorized service parts.
- Care in hydraulic hose installation is a must:
 - Make sure pressure is relieved before starting installation procedure.
 - DO NOT kink or twist a hose, failure may occur.
 - Properly route the hose.
 - Have a certified hydraulic technician install the hose.
 - Remove air from the hydraulic system after installing any hydraulic component.
- Periodically check hydraulic system for leaks or damage. check for:
 - Leaks at hose fitting or in hose.
 - Damaged hoses and/or fittings.
 - Kinked, crushed, flattened, hard blistered, heat cracked, charred, twisted, soft or loose covered hoses.
 - Corroded or damaged fittings.
 - Leaking ports.
 - Excessive dirt and debris around hoses and/or fittings.
 - Damaged or missing hose retaining clamps, guards, shields, etc.

- DO NOT stand on or use a hose as a step. DO NOT pull or apply external forces to the hose. The hose may fail and cause injury.
- Keep all persons away from the working area. Mechanisms controlled by fluid power can become hazardous if a hose fails. Lifted mechanisms can fall to the ground, machine steering may fail, etc.
- Stay clear of a pressurized hose assembly that has blown apart. Hose fittings can be thrown off at high speed and a loose hose can whip around with great force.
- Hydraulic fluid can reach high temperatures. Allow fluid to cool before servicing the system.
- Escaping fluid under pressure may form a mist or fine spray which can flash or explode upon contact with an ignition source.
- Vibration can reduce hose service life. Make sure all retaining clamps and/or devices are secured.
- Environmental conditions can cause hose and fittings to deteriorate. Inspect hydraulic hoses periodically. Replace worn or damaged hoses and fittings.

Safety requirements for fluid power systems and components - Hydraulics (European standard PR EN 982)

Flexible hose assemblies must not be constructed from hoses which have been previously used as part of a hose assembly.

Do not weld hydraulic piping.

When flexible hoses or piping are damaged, replace them immediately.

It is forbidden to modify a hydraulic accumulator by machining, welding or any other means.

Before removing hydraulic accumulators for servicing, the liquid pressure in the accumulator must be reduced to zero.

Pressure check on hydraulic accumulators shall be carried out by method recommended by the accumulator manufacturer.

Care must be taken not to exceed the maximum allowable pressure of the accumulator. After any check of adjustment there must be no leakage of gas.

Danger of death by electrocution!

Pay special attention to the overhead power lines. Make sure the machine has sufficient clearance to pass in all directions (also with raised or opened machine components). Also think of the radio aerial(s) or any other factory-fitted accessory or parts which may have been added afterwards.

Should a contact between the machine and an electric power line occur, then the following precautions must be taken: Stop the machine movement immediately, stop the engine and apply the hand-brake or parking brake.

Check if you can safely leave the cab or your actual position without direct contact with electric wires. If not, stay in your position and call for help. If you can leave your position without touching the lines, jump off the last step or support position to ensure that there is no contact between any part of your body and the ground at any time. Do not touch the machine afterwards until power to the lines has been shut off. When people approach the machine, warn them not to touch the machine but to ask the electric power supply company to shut off the power to the lines.

Engine safety

1. Keep the engine area clean of dust, chaff and straw to prevent the possibility of fires.
2. Never idle the engine in an enclosed area as harmful exhaust gases may build up.
3. Wear a suitable hearing protective device, such as ear muffs or ear plugs, if you are exposed to noise which you feel is uncomfortable.
4. The cooling system operates under pressure which is controlled by the radiator cap. It is dangerous to remove the cap while the engine is hot.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**