
TN55D, TN55S, TN65D, TN65S, TN70D, TN70S, TN75D, TN75S REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	2
SECTION 18 - CLUTCH	4
SECTION 21 - TRANSMISSIONS	5
SECTION 23 - FWD TRANSFER BOX AND AUTO FWD	9
SECTION 25 - FRONT AXLE (FWD)	11
SECTION 27 - REAR MECHANICAL DRIVE	15
SECTION 31 - MECHANICAL POWER TAKE-OFF	16
SECTION 33 - BRAKING SYSTEM	17
SECTION 35 - HYDRAULIC SYSTEM	18
SECTION 41 - STEERING	27
SECTION 44 - AXLES AND WHEELS	29
SECTION 50 - CAB AIR CONDITIONING SYSTEM	30
SECTION 55 - ELECTRICAL SYSTEM	32
SECTION 90 - CAB	48

The following pages are the collation of the contents pages from each section and chapter of the TND and TNS Series Repair manual. Complete Repair part # 87059380.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TND and TNS Series Tractors.

SECTION 00 - GENERAL

BOOK 1 - 87059381

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	2
	Safety Regulations	4
	Consumables	7

SECTION 10 - ENGINE

BOOK 1 - 87059381

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	3
	Lubrication	4
	Cooling System	4
	Speedometer/Tachometer	4
	Timing System	5
	Fuel System	5
	Fuel Supply Pump Data	15
	Crankcase/Cylinder Block Data	15
	Crankcase and Bearings Data	16
	Connecting Rod Data	17
	Piston Data	18
	Valve Timing Gear Data	19
	Tappet Data	19
	Rocker Arm - Valve Data	20
	Cylinder Head Data	21
	Lubrication System Data	22
	Cooling System Data	22
	Torque Settings	23
	Special Tools	24
	Sectional Views	26

SECTION 10 - ENGINE

BOOK 1 - 87059381

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	Troubleshooting	30
	Overhaul	34
10 001 10	Engine	34
	Removal	34
	Installation	35
10 001 30	Compression Test	36
10 001 54	Disassembly	37
	Assembly	47
	Checks, Dimensions and Repairs	56
	Cylinder Block and Cylinder Liners	56
	Crankshaft, Main Bearings and Flywheel	58
	Connecting Rods	62
	Pistons	63
	Camshaft, Tappets and Valves	66
	Valve Seats In Cylinder Head	70
	Lubrication System	71
	Cooling System	72
10 101 53	Valve Guides	74
10 101 60	Injector Sleeves	77
10 102 70	Crankshaft Front Oil Seal	79
	Removal	79
	Installation	80
10 106 12	Valve/Rocker Arm Clearance Adjustment	81
10 216 10	Fuel Tank	83
	Removal	83
	Installation	84
10 218 30	Fuel Injectors	85
	Removal	85
	Installation	86
10 246 14	Bosch Injection Pump	87
	Removal	87
	Installation	89
	Timing	90
	Fuel Circuit Air Bleeding	92

SECTION 18 - CLUTCH

BOOK 1 - 87059381

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	Luk 11"/11" Clutch	2
	Luk 11" Clutch	3
	Tightening Torques	3
	Special Tools	3
	Description and Operation	4
	Sectional Views	4
	Troubleshooting	6
	Overhaul	7
18 110 10	Clutch	7
	Removal	7
	Installation	15
18 110 30	Dual Disk Clutch 11"/11"	17
	Disassembly	17
	Assembly	20
18 110 30	11" Single Clutch (fitted with the power-shuttle gearbox)	21
	Disassembly	21
	Assembly	21
	Checks, Measurements and Repairs	22
	Dual Clutch	22
	Coplanarity Adjustment of 11"/11" Dual Clutch Release	23
	Coplanarity Adjustment of 11" Single Plate Clutch Release Levers	24
18 100 40	Main Clutch Control Linkage	25
	PTO Clutch Control	26

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87059382

Chapter 1 - Mechanical Transmission (8 x 8) and (16 x 16) Synchro-Command

CONTENTS

Section	Description	Page
	Specifications	2
	Shuttle Unit	2
	Gearbox and Range Gear	2
	Tightening Torques	2
	Special Tools	4
	Sectional Views	8
	Description and Operation	13
	Troubleshooting	13
	Overhaul	15
	Rear Transmission - Gearbox Casing	15
21 118 10	Removal	15
21 118 12	Installation	20
21 118 85	Disassembly	22
	Assembly	28
	Adjustment	30
21 130 10	Gearbox Control Lever	32
	Removal	32
	Installation	32
21 130 11	Range Gear Control Lever	33
	Removal	33
	Installation	33

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87059382

Chapter 2 - Power Shuttle Transmission (8 x 8 and 16 x 16 versions)

CONTENTS

Section	Description	Page
	Specifications	2
	Shuttle	2
	Gearbox	2
	Power Shuttle	2
	Tightening Torques	3
	Special Tools	4
	Sectional Views	7
	Clutches Control Pressure Test	10
	Description and Operation	12
	Troubleshooting	12
	Overhaul	13
21 118 85	Transmission - Gearbox	13
	Disassembly	13
	Assembly	14
21 134 46	Power Shuttle Control Valve	15
	Disassembly	15
	Assembly	17
21 134 70	A + B Clutch Valve Solenoids	18
	Removal	18
	Installation	18
21 154 60	Dump Valve Solenoid	19
	Removal	19
	Installation	19
21 154 34	Clutch Casing	20
	Disassembly	20
	Assembly	23

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87059382

Chapter 3 - Power Shuttle Transmission Calibration, Faults and Diagnostics

CONTENTS

Section	Description	Page
	Fault Codes Indication	3
	Description of Systems (ECM and Calibration and Diagnostic Unit - CDU)	4
	Automatic Self-Diagnosis (ECM)	5
	ECM First Start Up (Self Configuration)	6
	Transmission Disabled Indicator Light	7
	Diagnosis During Operation	9
	Calibration and Diagnostics Unit (CDU)	10
	Power Shuttle Fault Code Priority	11
	Calibration and Diagnostic Unit Use	14
	HH Menu Access	15
	H1 - Clutches A and B Calibration	18
	H2 - Clutches A and B Calibration Values Display	23
	H3 - System Configuration	24
	H4 - Power Shuttle Hardware and Software Revision Levels	26
	H5 - Control Switch Diagnosis	27
	H6 - Clutch A Fill Time Modification and Display	32
	H7 - Clutch B Fill Time	34
	H8 - Erasure of Data Stored in the Non-Volatile Memory (NVM)	36
	H9 - Voltmeter Functions	37
	HA - Clutch Pedal Potentiometer and Status Switch	41
	Clutch Pedal Potentiometer Replacement and Clutch Pedal Switch Adjustment	43
	HC - Transmission Oil Temperature Sender	44
	HD - HI/LO Synchronizer Operation	45
	HE - Gear Change Adjustments	47
	HF - Stored Error Codes	48
	Troubleshooting Fault Codes	50
	Description of Systems (ECM and Electronic Service Tool - EST)	51
	Automatic Self-Diagnosis (ECM)	52
	ECM First Start Up (Self Configuration)	53
	Transmission Disabled Indicator Light	54
	Diagnosis During Operation	56
	Power Shuttle Fault Code Priority	58

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87059382

Chapter 3 - Power Shuttle Transmission Calibration, Faults and Diagnostics (Continued)

CONTENTS

Section	Description	Page
	Electronic Service Tool (EST)	61
	Downloading the Latest Software into TN Series Tractor Power Shuttle Control Module with the Electronic Service Tool	62
	Connecting the Electronic Service Tool (EST) to the Tractor	66
	H1 - Clutches A and B Calibration	70
	H2 - Clutches A and B Calibration Values Display	75
	H3 - System Configuration	76
	H4 - Power Shuttle Hardware and Software Revision Levels	78
	H5 - Control Switch Diagnosis	79
	H6 - Clutch A Fill Time Modification and Display	84
	H7 - Clutch B Fill Time	86
	H8 - Erasure of Data Stored in the Non-Volatile Memory (NVM)	88
	H9 - Voltmeter Functions	89
	HA - Clutch Pedal Potentiometer and Status Switch	93
	Clutch Pedal Potentiometer Replacement and Clutch Pedal Switch Adjustment	95
	HC - Transmission Oil Temperature Sender	96
	HD - HI/LO Synchronizer Operation	97
	HE - Gear Change Adjustments	99
	HF - Stored Error Codes	100
	Troubleshooting Fault Codes	102
	Fault Codes	104
	Power Shuttle (8 x 8 and 16 x 16) Electronic Control Unit Input/Output Wiring Diagram	307

SECTION 23 - FWD TRANSFER BOX AND AUTO FWD

BOOK 3 - 87059383

Chapter 1 - FWD Transfer Box

CONTENTS

Section	Description	Page
	Specifications	2
	FWD Electrohydraulic Engagement	2
	Transmission Shaft	2
	Tightening Torques	3
	Special Tools	4
	Sectional Views	6
	Description and Operation	9
	FWD Drive Gear With Electrohydraulic Coupling	9
	Troubleshooting	10
	Overhaul	11
23 101 26	Transmission Shafts and Guard (TN55S, TN65S and TN75S)	11
	Removal	11
	Installation	12
23 101 26	Transmission Shafts and Guard (TN55D, TN65D and TN75D)	13
	Removal	13
	Installation	13
23 101 40	Drive Gear Housing	14
	Removal	14
	Installation	15
23 141 42	Disassembly (Mechanical Only)	16
	Assembly (Mechanical Only)	17
	Disassembly (Electrohydraulic Only)	18
	Assembly (Electrohydraulic Only)	19

SECTION 23 - FWD TRANSFER BOX AND AUTO FWD

BOOK 3 - 87059383

Chapter 2 - Auto FWD, Calibration and Diagnostics

CONTENTS

Section	Description	Page
	Description and Operation	2
	Automatic FWD Fault Codes Indication	2
	Faults Code Decoding	2
	Calibrations	3
	HH Menu Access	3
	H3 - System Configuration	4
	H4 - Software Revision Level	6
	H5 - Control Switches Diagnosis	6
	H8 - Deleting Data From the Non-Volatile Memory	7
	H9 - Voltmeter Functions	8
	HD - FWD Engagement Position	9
	HF - Errors Stored in the Non-Volatile Storage of the ECU	9
	First Start-Up	11
	Troubleshooting	12
	ECU Location	13
	Fault Codes	14
	PTO and FWD Electronic Control Unit Wiring Diagram	89

SECTION 25 - FRONT AXLE (FWD)

BOOK 3 - 87059383

Chapter 1 - Front Axle (Super Steer Axle)

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	5
	Special Tools	8
	Sectional Views	11
	Description and Operation	14
	Troubleshooting	16
	Overhaul	17
25 100 30	Front Axle Assembly	17
	Removal	17
	Installation	20
25 102 15	Bevel Drive and Front Axle Differential Housing	21
	Removal	21
	Installation	23
25 102 20	Disassembly	25
	Assembly	26
	Adjustments	27
25 102 24	Front Axle Differential	33
25 104 34	Front Differential Lock Clutch Assembly	34
	Disassembly	34
	Assembly	36
25 108 30	Front Epicyclic Final Drive with Brake	37
	Removal	37
	Installation	38
	Wheel Hub Seal	39
	Removal	39
	Installation	40
25 108 30	Front Epicyclic Final Drive	41
	Removal	41
	Installation	42

SECTION 25 - FRONT AXLE (FWD)

BOOK 3 - 87059383

Chapter 1 - Front Axle (Super Steer Axle) (Continued)

CONTENTS

Section	Description	Page
	Planetary Gears (TN55S)	43
	Disassembly	43
	Inspection	44
	Assembly	44
	Planetary Gears (TN65S, TN70S, TN75S)	44
	Disassembly	44
	Inspection	44
	Assembly	44
	Wheel Hub Seal	46
	Removal	46
	Installation	46
25 108 38	Wheel Hub and Steering Knuckle	47
	Removal	47
	Installation	47
25 108 46	Steering Knuckle Pins and Bearings	49
	Removal	49
	Installation	49
44 511 80	Front Drive Wheels Toe-In Check	50

SECTION 25 - FRONT AXLE (FWD)

BOOK 3 - 87059383

Chapter 2 - Front Axle (FWD)

CONTENT

Section	Description	Page
	Specifications	3
	Tightening Torques	5
	Special Tools	7
	Sectional Views	9
	Description and Operation	10
	Troubleshooting	12
	Front Axle Hydraulic Differential Lock	12
	Overhaul	13
25 100 30	Front Axle Assembly	13
	Removal	13
	Installation	16
	Disassembly	17
	Assembly	25
25 104 34	Front Differential Lock Clutch Unit	26
	Disassembly	26
	Assembly	27
25 108 46	Steering Knuckle Pins and Bearings	28
	Removal	28
	Installation	28
	Adjustments	29
	Stub Axle	29
	Bevel Drive	31
	Bevel Drive Shaft Bearing Preload	31
	Drive Pinion Position Adjustment Shim Thickness	32
	Differential Bearings and Backlash Between Pinion and Ring Gear	35
25 102 34	Front Axle Differential	38
	Limited Slip Self-Locking Differential Lock	39
25 102 27	Front Axle Differential with Limited Slip Unit	39
	Disassembly	39
	Assembly	40
44 511 80	Front Drive Wheels Toe-In Check	41

SECTION 25 - FRONT AXLE (FWD)

BOOK 3 - 87059383

Chapter 2 - Front Axle (FWD) (Continued)

CONTENT

Section	Description	Page
25 108 30	Front Epicyclic Final Drive	42
	Removal	42
	Installation	43
	Planetary Gears (TN55D)	44
	Disassembly	44
	Inspection	45
	Assembly	45
	Planetary Gears (TN65D, TN70D, TN75D)	45
	Disassembly	45
	Inspection	45
	Assembly	45
	25 108 30	Front Epicyclic Final Drive with Brake
Removal		47
Installation		48
Planetary Gears TN55D (with brake)		49
Disassembly		49
Inspection		50
Assembly		50
Planetary Gears TN65D, TN70D, TN75D (with brakes)		50
Disassembly		50
Inspection		50
Assembly		50

SECTION 27 - REAR MECHANICAL DRIVE

BOOK 3 - 87059383

Chapter 1 - Rear Mechanical Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Bevel Gear Pair and Differential	2
	Lateral Final Drives	3
	Tightening Torques	4
	Special Tools	6
	Sectional Views	10
	Description and Operation	13
	Troubleshooting	13
	Bevel Gear Pair and Differential	13
	Lateral Final Drives	13
	Hydraulically Controlled Differential Lock	14
	Overhaul	15
27 106 16	Rear Transmission Gearbox	15
	Removal	15
	Installation	18
27 110 10	Adjusting the Position of Differential Lock Engagement Sleeve	21
	Bevel Drive	22
	Adjustment	22
27 120 10	RH or LH Lateral Final Drive Box Assembly	27
	Removal	27
	Installation	29
27 120 34	Drive Wheel Shaft	30
	Removal	30
	Installation	31
27 120 32	Epicyclic Final Drive	32
	Removal	32
	Installation	32

SECTION 31 - MECHANICAL POWER TAKE-OFF

BOOK 3 - 87059383

Chapter 1 - Mechanical Power Take-off

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Tightening Torques	4
	Sectional Views	5
	Description and Operation	6
	PTO	6
	Mechanically Engaged PTO Control	6
	Servo Assist PTO Control	7
	Overhaul	8
31 112 20	Mechanical PTO	8
	Removal	8
	Installation	10
	PTO Brake	11
	Adjustments	12
	PTO Speed Sensor	12

SECTION 31 - MECHANICAL POWER TAKE-OFF

BOOK 3 - 87059383

Chapter 2 - PTO Servo-Assist Valve

CONTENTS

Section	Description	Page
	Description and Operation	2
	Adjustments	5
	PTO Clutch Servo Control	5
	Hydraulic PTO Servo Assist Cable	6
	PTO Engaged Switch	7

SECTION 33 - BRAKING SYSTEM

BOOK 3 - 87059383

Chapter 1 - Braking System

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Sectional Views	4
	Special Tools	6
	Description and Operation	7
	Troubleshooting	8
	Overhaul	10
33 202 60	Right or Left Hand Brake	10
	Removal	10
	Installation	10
33 202 46	Brake Hydraulic Pump	12
	Removal	12
	Installation	15
	Service Brakes Control Pedals Stroke (tractors with cabs)	16
	Adjustment	16
33 202 04	Brake Hydraulic System	17
	Air Bleeding	17
33 110 40	Parking Brake Disks	20
	Removal	20
	Installation	21
33 110 08	Hand Brake Control	21
	Stroke Adjustment	21

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87059384

Chapter 1 - High Pressure System Description and Operation

CONTENTS

Operation	Description	Page
	Precautionary Statements	3
	Description and Operation	4
35 104	High-Pressure System Hydraulic Pump	5
35 110	Mechanically Controlled Hydraulic Lift	7
	Principles of Draft Control	8
	Principles of Position Control	8
	Principles of Float	9
	Principles of Draft and Position Control Combined	9
	Lift-O-Matic	9
	Hydraulic Power Lift (HPL) Control Valve Oil Flow	10
	Lift Phase	10
	Neutral Phase	11
	Lower Phase	12
	Remote Control Valves	13
	Simple Self-Centering	13
	Simple Self-Centering with Float	13
	Detent with Auto-Release and Float	13
	Rear Remote Valve Arrangement	14
	Rear Remote Valve Stacking	15
	Rear Remote Valve Control Levers	15
	Quick-Fit Couplers	16
	Zero Pressure Return Port	16
	Mid-Mount Control Valves	17
	Mid-Mount Coupler Relocation Kit	17
	Joystick Control for Mid-Mount Valves	17
	Switching Between Single and Double-Acting Cylinders	17
	Double-Acting Valve with Automatic Detent Release and Float	18
	Float Phase	18
	Lift Phase	19
	Lower Phase	20

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87059384

Chapter 1 - High Pressure System Description and Operation (Continued)

CONTENTS

Operation	Description	Page
	Double-Acting Valve less Automatic Detent Release and Float	21
	Lift Phase	21
	Lower Phase	21
	Single-Acting Valve less Automatic Detent Release and Float	22
	Lift Phase	22
	Lower Phase	22
	Hydraulic System Diagram	23

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87059384

Chapter 2 - High Pressure System Overhaul and Adjustment

CONTENTS

Operation	Description	Page
	Specifications	2
	Tightening Torques	7
	Special Tools	9
	Sectional Views	11
	Troubleshooting	18
	Overhaul	20
35 110 40	Mechanically Controlled Lift Internal Controls	20
	Disassembly	20
	Assembly	23
	Mechanically Controlled Lift Adjustments	24
	Position Control	24
	Upper Stroke Limit	26
	Draft Control	27
	Position Control Rod	30
	Draft Control Rod	30
	Lift-O-Matic Device	31
	Lift Arm Descent Speed	32
	Lift-O-Matic Device Upper Stroke Limit	33
35 110 42	Arm Shaft and Lift Cylinder	34
	Disassembly	34
	Assembly	36
35 114 14	Mechanically Controlled Lift Control Valve	38
	Disassembly	38
	Assembly	41
35 114 30	Lift Pressure Relief Valve	42
35 114 32	Calibration	42
35 104 30	Hydraulic Pump	44
	Disassembly	44
	Inspection	44
	Assembly	44
35 204 46	Auxiliary Control Valves	45
	Disassembly - Assembly	45
	Testing	46

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**