



NEW HOLLAND TJ Series

Complete Contents

REPAIR MANUAL



TJ SERIES REPAIR MANUAL

COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINES	5
SECTION 21 - TRANSMISSIONS	93
SECTION 31 - POWER TAKE-OFF	101
SECTION 33 - BRAKES AND CONTROLS	105
SECTION 35 - HYDRAULIC SYSTEMS	107
SECTION 37 - TOWING HOOKS AND BALLASTING	122
SECTION 39 - FRAMES	123
SECTION 41 - STEERING	124
SECTION 44 - AXLES AND WHEELS	128
SECTION 50 - CAB CLIMATE CONTROL	136
SECTION 55 - ELECTRICAL SYSTEMS	146
SECTION 90 - PLATFORM AND CAB	178

The following pages are the collation of the contents pages from each section and chapter of the TJ Series Repair manual.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TJ Series Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 86642987

Chapter 1 - Standard Torque Specification

CONTENTS

Section	Description	Page
	Torque Specifications - Decimal Hardware	2
	Torque Specifications - Metric Hardware	3
	Torque Specifications - Steel Hydraulic Fittings	4

SECTION 00 - GENERAL INFORMATION

BOOK 86642987

Chapter 2 - Safety

CONTENTS

Section	Description	Page
	Safety	2
	Roll Over Protective Structure (ROPS)	3

SECTION 00 - GENERAL INFORMATION

BOOK 86642987

Chapter 3 - General Information and Specifications (All TJ Series Tractors)

CONTENTS

Section	Description	Page
	General Specifications	3
	Tractor Weights	6
	Approximate Travel Speeds (MPH) (TJ275 - TJ325 Wheel Tractors)	7
	Approximate Travel Speeds (KPH) (TJ275 - TJ325 Wheel Tractors)	8
	Approximate Travel Speeds (MPH) (TJ375 - TJ375HD, TJ450 Wheel Tractors)	9
	Approximate Travel Speeds (KPH) (TJ375 - TJ375HD, TJ450 Wheel Tractors)	10
	Approximate Travel Speeds (MPH) (TJ275 - TJ325 Wheel Tractors)	11
	Approximate Travel Speeds (MPH) (TJ375HD Wheel Tractors)	12
	Approximate Overall Measurements	13
	Electrical Specifications	14
	Fuse/Relay Identification - For Deluxe Cab and Powershift Transmission	15
	Fuse/Relay Identification - For Deluxe Cab and 24 Speed Transmission	16
	Fuse/Relay Identification - For Standard Cab and 24 Speed Transmission	17
	Programming the Display Monitor	18
	Instrument Panel Backlight Intensity	19
	Changing the Remote Valve Extend/Retract Values	19
	Changing Tire Radius	20
	Radar Sensor Calibration	20
	Radar Calibration Procedure	20
	Tire Average Rolling Radius Chart	21
	Dynamic Rolling Radius	22
	Critical Warning Displays	23
	Non-Critical Warning Displays	23
	Diagnostic Warning Displays	25
	Information Warning Displays	26
	Performance Monitor Display	27
	Wheel Bolt Torques	38
	Wheel Offset Direction Change	38
	Wheel Tread Settings	40
	Triple Wheel Tread Setting	48

SECTION 00 - GENERAL INFORMATION

BOOK 86642987

Chapter 4 - Maintenance Schedule - Fluids and Capacities (All TJ Series Tractors)

CONTENTS

Section	Description	Page
	Lubrication and Maintenance	3
	Plastic and Resin Parts	3
	Lubricants and Capacities	3
	Engine Lubrication	4
	Grille and Hood Access	7
	Access to Batteries and Hydraulic Filter	9
	Lubrication and Maintenance Chart	10
	10 Hours or Daily	12
	50 Hour Maintenance	16
	250 Hour Maintenance	20
	500 Hour Maintenance	22
	Air Induction System	33
	1500 Hour Maintenance	34
	6000 Hour Maintenance	45
	As Required Maintenance	48

SECTION 10 - ENGINES

BOOK 86642987

Chapter 1 - Engine Removal and Installation (TJ275 - TJ325)

CONTENTS

Section	Description	Page
	Special Torque Values	2
	Special Tools	2
	Engine Installation	10

SECTION 10 - ENGINES

BOOK 86642987

Chapter 2 - Air Induction System (TJ275 and TJ325)

CONTENTS

Section	Description	Page
	Special Torque Values	3
	Air Induction System	4
	Air Filter Elements	4
	Engine Air Induction System	5
	Primary and Secondary Filter Element Removal	5
	Primary Filter Element Service	7
	Restriction Indicator Switch Removal and Test	7
	Air Cleaner Housing Removal	8
	Aspirator Strata Tube Cleaning	10
	Aspirator Safety Check Valve Removal and Test	12
	Aspirator Safety Check Valve Installation	13
	Air Cleaner Housing Installation	14
	Restriction Indicator Switch Installation	15
	Secondary and Primary Filter Element Installation	16

SECTION 10 - ENGINES

BOOK 86642987

Chapter 3 - Fuel System and Filters (TJ275 and TJ325)

CONTENTS

Section	Description	Page
	Fuel Filter Drain	3
	Fuel Tank Drain	3
	Fuel Tank Vent	4
	Fuel Filter Replacement	4
	Inline Fuel Filter Replacement	7

SECTION 10 - ENGINES

BOOK 86642987

Chapter 4 - Radiator, Coolers and Condenser - Remove and Install (TJ275 - TJ325)

CONTENTS

Section	Description	Page
	Special Torque Values	2
	General Information	2
	Fuel Cooler Removal	2
	Fuel Cooler Installation	3
	Engine Air to Air Cooler Removal	3
	Engine Air to Air Cooler Installation	5
	A/C Condenser Removal	7
	A/C Condenser Installation	8
	Hydraulic/Transmission Oil Cooler Removal	9
	Hydraulic/Transmission Oil Cooler Installation	11
	Radiator and Cooler Assembly Removal	14
	Radiator and Cooler Assembly Installation	19

SECTION 10 - ENGINES

BOOK 86642988

Chapter 5 - 24 Valve, 8.3 Liter Engine - Introduction

CONTENTS

Section	Description	Page
	About the Manual	1
	How to Use the Manual	1
	Illustrations	2
	General Safety Instructions	3
	Important Safety Notice	3
	General Repair Instructions	4
	General Cleaning Instructions	5
	Solvent and Acid Cleaning	5
	Steam Cleaning	5
	Glass or Plastic Bead Cleaning	5

SECTION 10 - ENGINES

BOOK 86642988

Chapter 6 - 24 Valve, 8.3 Liter Engine - Identification

CONTENTS

Section	Description	Page
	Engine Identification	1
	Engine Dataplate	1
	Fuel Injection Pump Dataplate	2
	ECM Dataplate	2
	Specifications	3
	Air Intake System	3
	Cooling System	3
	Exhaust System	3
	General Specifications	3
	Lubricating Oil System	3
	Electrical System	4
	Fuel System	4
	Engine Views	5

SECTION 10 - ENGINES

BOOK 86642988

Chapter 7 - 24 Valve, 8.3 Liter Engine - Troubleshooting Symptoms

CONTENTS

Section	Description	Page
	Troubleshooting Procedures and Techniques	1
	Troubleshooting Symptoms Charts	1
	Communication Error Electronic Service Tool or Control Device	2
	Coolant Loss External	4
	Coolant Loss Internal	5
	Coolant Temperature Above Normal Gradual Overheat	6
	Coolant Temperature Is Above Normal - Sudden Overheat	9
	Coolant Temperature Is Below Normal	11
	Coolant in the Lubricating Oil	12
	Crankcase Gases (Blowby) Excessive	13
	Cranking Fuel Pressure Is Low	14
	Engine Acceleration or Response Poor	15
	Engine Decelerates Slowly	20
	Engine Difficult to Start or Will Not Start (Exhaust Smoke)	21
	Engine Difficult to Start or Will Not Start (No Exhaust Smoke)	26
	Engine Noise Excessive	30
	Engine Noise Excessive Combustion Knocks	33
	Engine Noise Excessive Connecting Rod	34
	Engine Noise Excessive Main Bearing	35
	Engine Noise Excessive Piston	36
	Engine Noise Excessive Turbocharger	37
	Engine Power Output Low	38
	Engine Runs Rough at Idle	45
	Engine Runs Rough or Misfires	49
	Engine Shuts Off Unexpectedly or Dies During Deceleration	53
	Engine Speed Surges at Low or High Idle	55
	Engine Speed Surges Under Load or in Operating Range	59
	Engine Speed Surges in PTO	64
	Engine Starts But Will Not Keep Running	65
	Engine Vibration Excessive	67
	Engine Will Not Crank or Cranks Slowly (Electric Starter)	69
	Engine Will Not Reach Rated Speed (RPM)	71

SECTION 10 - ENGINES

BOOK 86642988

Chapter 7 - 24 Valve, 8.3 Liter Engine - Troubleshooting Symptoms (Continued)

CONTENTS

Section	Description	Page
	Engine Will Not Shut Off	74
	Fault Code Warning Lamps Do Not Illuminate	75
	Fuel Consumption Excessive	76
	Fuel in Coolant	80
	Fuel in the Lubricating Oil	81
	Intake Manifold Air Temperature Above Specification	82
	Low Idle Adjust Switch Does Not Work	84
	Intake Manifold Pressure (Boost) is Below Normal	85
	Lubricating Oil Consumption Excessive	86
	Lubricating Oil Contaminated	88
	Lubricating Oil Pressure High	89
	Lubricating Oil Pressure Low	90
	Lubricating Oil Sludge in the Crankcase Excessive	92
	Lubricating Oil Temperature Above Specification	93
	Lubricating or Transmission Oil in the Coolant	94
	Smoke, White Excessive	95
	Smoke, Black Excessive	99
	Turbocharger Leaks Engine Oil or Fuel	103
	Engine Noise Diagnostic Procedures General Information	104
	Main Bearing Noise	104
	Connecting Rod Bearing Noise	104
	Piston Noise	104

SECTION 10 - ENGINES

BOOK 86642988

Chapter 8 - 24 Valve, 8.3 Liter Engine - Cylinder Block

CONTENTS

Section	Description	Page
	Service Tools	1
	Cylinder Block	1
	Bearings, Connecting Rod (001-005)	3
	Remove (001-005-002)	3
	Clean (001-005-006)	5
	Inspect for Reuse (001-005-007)	5
	Install (001-005-026)	6
	Bearings, Main (001-006)	9
	Initial Check (001-006-001)	9
	Remove (001-006-002)	10
	Clean (001-006-006)	11
	Inspect for Reuse (001-006-007)	12
	Install (001-006-026)	12
	Camshaft (001-008)	15
	Remove (001-008-002)	15
	Inspect for Reuse (001-008-007)	16
	Install (001-008-026)	19
	Camshaft Bushings (001-010)	21
	Initial Check (001-010-001)	21
	Install (001-010-026)	22
	Measure (001-010-010)	22
	Remove (001-010-002)	22
	Camshaft Gear (Camshaft Removed) (001-013)	23
	Remove (001-013-002)	23
	Inspect for Reuse (001-013-007)	24
	Install (001-013-026)	25
	Connecting Rod (001-014)	26
	Remove (001-014-002)	26
	Clean (001-014-006)	27
	Inspect for Reuse (001-014-007)	27
	Install (001-014-026)	29

SECTION 10 - ENGINES

BOOK 86642988

Chapter 8 - 24 Valve, 8.3 Liter Engine - Cylinder Block (Continued)

CONTENTS

Section	Description	Page
	Crankshaft (001-016)	30
	Rotation Check (001-016-052)	30
	Crankshaft Gear, Front (Crankshaft Installed) (001-018)	30
	General Information	30
	Crankshaft Seal, Front (001-023)	30
	Remove (001-023-002)	30
	Clean (001-023-006)	31
	Inspect for Reuse (001-023-007)	31
	Install (001-023-026)	32
	Crankshaft Seal, Rear (001-024)	33
	Remove (001-024-002)	33
	Clean (001-024-006)	34
	Inspect for Reuse (001-024-007)	34
	Install (001-024-026)	34
	Crankshaft Wear Sleeve, Front (001-025)	35
	Remove (001-025-002)	35
	Clean (001-025-006)	36
	Inspect for Reuse (001-025-007)	36
	Install (001-025-026)	36
	Cylinder Liner (001-028)	39
	Preparatory (001-028-000)	39
	Remove (001-028-002)	39
	Clean (001-028-006)	43
	Inspect for Reuse (001-028-007)	43
	Install (001-028-026)	46
	Gear Cover, Front (001-031)	52
	Remove (001-031-002)	52
	Clean (001-031-006)	53
	Inspect for Reuse (001-031-007)	53
	Install (001-031-026)	53

SECTION 10 - ENGINES

BOOK 86642988

Chapter 8 - 24 Valve, 8.3 Liter Engine - Cylinder Block (Continued)

CONTENTS

Section	Description	Page
	Gear Housing, Front (001-033)	55
	Remove (001-033-002)	55
	Clean (001-033-006)	56
	Inspect for Reuse (001-033-007)	57
	Install (001-033-026)	57
	Piston (001-043)	59
	General Information	59
	Disassemble (001-043-003)	60
	Remove (001-043-002)	60
	Clean (001-043-006)	61
	Inspect for Reuse (001-043-007)	62
	Assemble (001-043-025)	63
	Install (001-043-026)	63
	Piston and Connecting Rod Assembly (001-054)	70
	Remove (001-054-002)	70
	Disassemble (001-054-003)	73
	Assemble (001-054-025)	74
	Clean (001-054-006)	74
	Inspect for Reuse (001-054-007)	74
	Install (001-054-026)	75
	Piston Rings (001-047)	64
	Inspect for Reuse (001-047-007)	64
	Install (001-047-026)	65
	Vibration Damper (001-052)	68
	Remove (001-025-002)	68
	Inspect for Reuse (001-052-007)	68
	Install (001-052-026)	69
	Vibration Damper, Rubber (001-051)	66
	Remove (001-051-002)	66
	Inspect for Reuse (001-051-007)	67
	Install (001-051-026)	67

SECTION 10 - ENGINES

BOOK 86642988

Chapter 9 - 24 Valve, 8.3 Liter Engine - Cylinder Head

CONTENTS

Section	Description	Page
	Service Tools	1
	Cylinder Head	1
	Crosshead (002-001)	2
	Remove (002-001-002)	2
	Inspect for Reuse (002-001-007)	2
	Install (002-001-026)	2
	Cylinder Head (002-004)	2
	Preparatory (002-004-000)	2
	Remove (002-004-002)	3
	Clean (002-004-006)	4
	Inspect for Reuse (002-004-007)	6
	Install (002-004-026)	8
	Valve, Cylinder Head (002-020)	12
	Preparatory (002-020-000)	12
	Disassemble (002-020-003)	13
	Clean (002-020-006)	14
	Inspect for Reuse (002-020-007)	14
	Assemble (002-020-025)	17
	Install (002-020-026)	18
	Injector Protrusion (002-022)	19
	Measure (002-022-010)	19

SECTION 10 - ENGINES

BOOK 86642989

Chapter 10 - 24 Valve, 8.3 Liter Engine - Rocker Levers

CONTENTS

Section	Description	Page
	Overhead Set (003-004)	1
	Adjust (003-004-029)	1
	Rocker Lever (003-008)	3
	Disassemble (003-008-003)	3
	Remove (003-008-002)	3
	Clean (003-008-006)	4
	Inspect for Reuse (003-008-007)	5
	Assemble (003-008-025)	6
	Install (003-008-026)	7
	Rocker Lever Cover (003-011)	8
	Inspect for Reuse (003-011-007)	8
	Install (003-011-026)	8
	Remove (003-011-002)	8

SECTION 10 - ENGINES

BOOK 86642989

Chapter 11 - 24 Valve, 8.3 Liter Engine - Cam Followers

CONTENTS

Section	Description	Page
	Push Rods or Tubes (004-014)	1
	Clean (004-014-006)	1
	Inspect for Reuse (004-014-007)	1
	Preparatory (004-014-000)	1
	Remove (004-014-002)	1
	Install (004-014-026)	2
	Tappet (004-015)	3
	Preparatory (004-015-000)	3
	Remove (004-015-002)	3
	Inspect for Reuse (004-015-007)	5
	Install (004-015-026)	6

SECTION 10 - ENGINES

BOOK 86642989

Chapter 12 - 24 Valve, 8.3 Liter Engine - Fuel System

CONTENTS

Section	Description	Page
	Fuel System - General Information	1
	General Information	1
	Flow Diagram, Fuel System	4
	Specifications	5
	Fuel System	5
	Service Tools	6
	Fuel System	6
	Engine Fuel Heater, Electric (005-008)	7
	Initial Check (005-008-001)	7
	Remove (005-008-002)	7
	Fuel Flow (005-011)	9
	Pressure Test (005-011-013)	9
	Fuel Pump (005-016)	10
	Remove (005-016-002)	10
	Install (005-016-026)	11
	Fuel Pump Delivery Valve (005-020)	14
	Inspect for Reuse (005-020-007)	14
	Preparatory (005-020-000)	14
	Remove (005-020-002)	14
	Install (005-020-026)	15
	Leak Test (005-020-014)	16
	Fuel Pump Gear Pump (005-025)	16
	Measure (005-025-010)	16
	Preparatory (005-025-000)	16
	Fuel Pump Timing (005-037)	17
	Remove (005-037-002)	17
	Inspect for Reuse (005-037-007)	18
	Install (005-037-026)	18

SECTION 10 - ENGINES

BOOK 86642989

Chapter 12 - 24 Valve, 8.3 Liter Engine - Fuel System (Continued)

CONTENTS

Section	Description	Page
	Fuel Lift Pump (005-045)	19
	Initial Check (005-045-001)	19
	Install (005-045-026)	21
	Remove (005-045-002)	20
	Test (005-045-012)	20
	Rotor, CAPS Fuel Injection Pump (005-072)	22
	Preparatory (005-072-000)	22
	Remove (005-072-002)	22
	Inspect for Reuse	22
	Install (005-072-026)	23
	Leak Test (005-072-014)	23
	Fuel Pump Accumulator (005-077)	23
	Pressure Test (005-077-013)	23
	Injection Control Valve (005-078)	23
	Click Test (005-078-072)	23
	Pumping Control Valve (005-079)	24
	Click Test (005-079-072)	24
	Cutout Test (005-079-073)	24
	Fuel Pump Cam Housing (005-080)	25
	Inspect for Reuse (005-080-007)	25
	Snubber, Rate Shape (005-081)	25
	Preparatory (005-081-000)	25
	Leak Test (005-081-014)	26
	Inspect for Reuse (005-081-007)	26
	Remove (005-081-002)	26
	Install (005-081-026)	27
	Fuel Pump Distributor Inlet Fitting (005-084)	29
	Remove (005-084-002)	29
	Install (005-084-026)	30

SECTION 10 - ENGINES

BOOK 86642989

Chapter 12 - 24 Valve, 8.3 Liter Engine - Fuel System (Continued)

CONTENTS

Section	Description	Page
	Fuel Pump Accumulator Module (005-085)	32
	Remove (005-085-002)	32
	Install (005-085-026)	35
	Fuel Pump Distributor Module (005-086)	37
	Remove (005-086-002)	37
	Install (005-086-026)	38
	Fuel Pump Injection Control Valve (005-087)	42
	Fuel Pump Cam Housing Module (005-088)	43
	Remove (005-088-002)	43
	Install (005-088-026)	45
	Fuel Pump Gear Pump Module (005-089)	47
	Remove (005-089-002)	47
	Install (005-089-026)	48
	Fuel Pump Rate Shape Tube (005-090)	50
	Remove (005-090-002)	50
	Install (005-090-026)	51

SECTION 10 - ENGINES

BOOK 86642989

Chapter 13 - 24 Valve, 8.3 Liter Engine - Injectors and Fuel Lines

CONTENTS

Section	Description	Page
	Injectors and Fuel Lines - General Information	1
	General Information	1
	Air in Fuel (006-003)	3
	Measure (006-003-010)	3
	Test (006-003-012)	3
	Fuel Drain Line Restriction (006-012)	5
	Measure (006-012)	5
	Fuel Drain Lines (006-013)	6
	Remove (006-013-002)	6
	Initial Check (006-013-001)	6
	Inspect for Reuse (006-013-007)	7
	Install (006-013-026)	7
	Fuel Filter (Spin-On Type) (006-015)	8
	Remove (006-015-002)	8
	Install (006-015-026)	8
	Fuel Filter Head Bracket (006-018)	10
	Disassemble (006-018-003)	10
	Remove (006-018-002)	10
	Assemble (006-018-025)	11
	Inspect for Reuse (006-018-007)	11
	Install (006-018-026)	11
	Fuel Inlet Restriction (006-020)	12
	Initial Check (006-024-001)	12
	Fuel Supply Lines (006-024)	12
	Initial Check (006-024-001)	12
	Inspect for Reuse (006-024-007)	13
	Install (006-024-026)	13
	Remove (006-024-002)	13

SECTION 10 - ENGINES

BOOK 86642989

Chapter 13 - 24 Valve, 8.3 Liter Engine - Injectors and Fuel Lines (Continued)

CONTENTS

Section	Description	Page
	Injector (006-026)	13
	Remove (006-026-002)	13
	Disassemble (006-026-003)	14
	Clean (006-026-006)	15
	Inspect for Reuse (006-026-007)	15
	Measure (006-026-010)	15
	Test (006-026-012)	15
	Assemble (006-026-025)	17
	Inspect (006-026-062)	17
	Install (006-026-026)	18
	Injector Supply Lines (High Pressure) (006-051)	19
	Initial Check (006-051-001)	19
	Remove (006-051-002)	20
	Inspect for Reuse (006-051-007)	20
	Install (006-051-026)	21
	Fuel Connector (Head Mounted) (006-052)	22
	Inspect for Reuse (006-051-007)	22
	Install (006-052-026)	22
	Remove (006-052-002)	22
	Fuel Pump Air Bleed Line (006-056)	23
	Remove (006-056-002)	23
	Install (006-056-026)	24

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**