
TN75FA, TN85FA, TN95FA REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	2
SECTION 18 - CLUTCH	6
SECTION 21 - TRANSMISSIONS	7
SECTION 23 - FWD TRANSFER BOX AND AUTO FWD	10
SECTION 25 - FRONT AXLE (FWD)	11
SECTION 27 - REAR MECHANICAL DRIVE	12
SECTION 31 - MECHANICAL POWER TAKE-OFF	12
SECTION 33 - BRAKING SYSTEM	13
SECTION 35 - HYDRAULIC SYSTEM	14
SECTION 41 - STEERING	18
SECTION 44 - AXLE AND WHEELS	19
SECTION 50 - CAB CLIMATE CONTROL	20
SECTION 55 - ELECTRICAL SYSTEMS	20
SECTION 90 - CAB, PLATFORM, AND BODYWORK	24

The following pages are the collation of the contents pages from each section and chapter of the TNFA Series Repair manual. Complete Repair part # 87675643.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TNFA Series Tractors.

SECTION 00 - GENERAL

BOOK 1 - 87675644

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Health and Safety	5
	Precautionary Statements	15
	Safety	16
	Ecology and the Environment	19
	Minimum Hardware Tightening Torques	20
	Federal Emissions Warranty	22
	Consumables	25

SECTION 10 - ENGINE

BOOK 1 - 87675644

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	10
	Tightening Torques	12
	Sectional Views	14
	Troubleshooting	18
	Overhaul	19
10 001 10	Engine	19
	Removal	19
	Installation	19
	Compression Test	25
10 001 54	Disassembly	26
	Assembly	27
	Seal Installation	40

SECTION 10 - ENGINE

BOOK 1 - 87675644

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	Checks, Dimensions and Repairs	50
	Cylinder Block	50
	Crankshaft	52
	Main Bearings	54
	Flywheel	55
	Connecting Rods	56
	Pistons	57
	Valves	60
	Valve Timing	60
	Camshaft	61
	Tappets	62
	Cylinder Head	62
	Valve Seats	63
	Valve Guides	64
	Crankshaft Front Oil Seal	67
10 102 70	Rotating Counterweight Dynamic Balancer	72
	Valve/Rocker Arm	74

SECTION 10 - ENGINE

BOOK 1 - 87675644

Chapter 2 - Cooling System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	5
	Cooling System	4
	Radiator	4
	Thermometer	4
	Thermostat	4
	Thermostatic Switch	4
	Overhaul	6
10 406 10	Coolant Pump	6
	Removal	6
	Installation	10
	Disassembly	11
	Assembly	11
	Drive Belt Tension Adjustment	12
10 402 30	Cooling System Thermostat	13
	Removal	13
	Installation	14
10 402 28	Radiator	15
	Removal	15
	Installation	18

SECTION 10 - ENGINE

BOOK 1 - 87675644

Chapter 3 - Lubrication System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	3
	Sectional Views	4
	Description and Operation	5
	Oil Filter	5
	Low Oil Indicator	5
10 001 10	Oil Pump	6

SECTION 10 - ENGINE

BOOK 1 - 87675644

Chapter 4 - Fuel System

CONTENTS

Section	Description	Page
	Specifications	2
	Special Tools	4
	Tightening Torques	5
	Description and Operation	6
	Fuel Injection Pump (Bosch)	6
	Turbocharged Models	6
	All Models	8
	Overhaul	10
10 218 30	Fuel Injectors	10
	Removal	10
	Installation	11
10 246 14	Injection Pump	12
	Removal	12
	Installation	16
	Checking the Fuel Injection Pump Timing with the Pump on the Tractor	17
	Lock-time the Fuel Injection Pump with the Pump Removed from the Tractor ...	21
	Fuel Circuit Air Bleeding	26

SECTION 18 - CLUTCH

BOOK 1 - 87675644

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
18 000	General Specifications	1
	Tightening Torques	2
	Tools	2
	Cross-sectional Views	3
	Troubleshooting	5
18 110 10	Clutch - Removal-Installation	6
18 110 30	Dual Disk Clutch 11"/11" Test Bench Overhaul	11
18 110 30	Single Disk Clutch 11" (installed with Power-Shuttle) Test Bench Overhaul	15
	Checks, Measurements and Repairs - Dual Clutch	16
	Coplanarity Adjustment of 11"/11" Dual Clutch Release	17
	Coplanarity of 11" Single Plate Clutch Release Levers	18
	PTO Clutch Servo Assist	19
	PTO Clutch Control System	20
	PTO Clutch Control System Adjustment	22

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87051829

Chapter 1 - Mechanical Transmission (16 x 16) Synchro-Command

CONTENTS

Section	Description	Page
21 000	Main data	2
	Torque settings	2
	Tools	4
	Cross-sectional views	8
	Description and operation	12
	Troubleshooting	12
21 118 10	Rear transmission/gearbox casing. Removal - Installation	14
21 118 85	Gearbox transmission casing. Disassembly - Assembly	25
	Transmission-Gearbox Casing	33
21 130 10	Gearbox control lever. Removal - Installation	35
21 130 11	Range gear control lever. Removal - Installation	36

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87051829

Chapter 2 - 32 x 16 Dual Power with Electrohydraulic Power Shuttle

CONTENTS

Section	Description	Page
21 000	Main Data	2
	Torque Settings	3
	Tools	4
	Description and operation	10
21 118 85	Transmission-Gearbox. Disassembly - Assembly	11
21 154 34	Clutch Casing. Disassembly - Assembly	14
21 134 46	Power Shuttle Control Valve. Disassembly - Assembly	19
21 134 6	Accumulator. Disassembly - Assembly	22

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87051829

Chapter 3 - Power Shuttle Transmission Calibration, Faults and Diagnostics

CONTENTS

Section	Description	Page
	Fault Codes Indication	3
	Description of Systems (ECM and CDU)	4
	Automatic Self-Diagnosis (ECM)	5
	ECM First Start Up (Self Configuration)	6
	Transmission Disabled Indicators	7
	ECM Diagnosis During Operation	9
	Calibration and Diagnostics Unit (CDU)	10
	Power Shuttle Fault Code Priority	11
	Calibration and Diagnostic Unit Use	14
	HH Menu Access	15
	H1 - Clutches A and B Calibration	18
	H2 - Clutches A and B Calibration Values Display	23
	H3 - System Configuration	24
	H4 - Software Revision Level	26
	H5 - Control Switch Diagnosis	27
	H6 - Clutch A Fill Time Modification and Display	32
	H7 - Clutch B Fill Time Modification and Display	34
	H8 - Erasure of Data Stored in the Non-Volatile Memory (NVM)	36
	H9 - Voltmeter Functions	37
	HA - Clutch Pedal Potentiometer and Status Switch	41
	Clutch Pedal Potentiometer Replacement and Clutch Pedal Switch Adjustment	43
	HC - Transmission Oil Temperature Sender	44
	HD - Shuttle Synchronizer Operation	45
	HE - Gear Change Adjustments	47
	HF - Stored Error Codes	48
	Troubleshooting Fault Codes	51
	Description of Systems (ECM and EST)	52
	Automatic Self-Diagnosis (ECM)	53
	ECM First Start Up (Self Configuration)	54
	Transmission Disabled Indicators	55
	ECM Diagnosis During Operation	57
	Power Shuttle Fault Code Priority	59

SECTION 21 - TRANSMISSIONS

BOOK 2 - 87051829

Chapter 3 - Power Shuttle Transmission Calibration, Faults and Diagnostics (Continued)

CONTENTS

Section	Description	Page
	Electronic Service Tool (EST)	62
	Downloading the Latest Software into TNFA Series Tractor Power Shuttle Control Module with the Electronic Service Tool	63
	Connecting the Electronic Service Tool (EST) to the Tractor	67
	H1 - Clutches A and B Calibration	71
	H2 - Clutches A and B Calibration Values Display	76
	H3 - System Configuration	77
	H4 - Power Shuttle Hardware and Software Revision Levels	79
	H5 - Control Switch Diagnosis	80
	H6 - Clutch A Fill Time Modification and Display	85
	H7 - Clutch B Fill Time	87
	H8 - Erasure of Data Stored in the Non-Volatile Memory (NVM)	89
	H9 - Voltmeter Functions	90
	HA - Clutch Pedal Potentiometer and Status Switch	94
	Clutch Pedal Potentiometer Replacement and Clutch Pedal Switch Adjustment	96
	HC - Transmission Oil Temperature Sender	97
	HD - Shuttle Synchronizer Operation	98
	HE - Gear Change Adjustments	100
	HF - Stored Error Codes	101
	Troubleshooting Fault Codes	104
	Fault Codes	106

SECTION 23 - FWD TRANSFER BOX AND AUTO FWD

BOOK 3 - 87051830

Chapter 1 - FWD Transfer Box

CONTENTS

Section	Description	Page
23 000	Main Specifications	1
	Tightening Torques	2
	Tools	3
	Cross-Sectional Views	5
	Description and Operation of the FWD Drive Gear	7
	Troubleshooting	8
23 101 26	Transmission Shafts and Guard, Removal-Installation	9
23 101 40	Drive Gear Housing, Removal-Installation	10
23 202 52	Drive Gear Housing, Disassembly-Assembly	12

SECTION 23 - FWD TRANSFER BOX AND AUTO FWD

BOOK 3 - 87051830

Chapter 2 - Auto FWD, Calibration and Diagnostics

CONTENTS

Section	Description	Page
	Automatic FWD Fault Codes	2
	Calibration Using the CDU	3
	HH - Menu Access	3
	H3 - System Configuration	4
	H4 - Software Revision Level	7
	H5 - Control Switches Diagnosis	7
	H8 - Deleting Data from the Non-Volatile Memory	8
	H9 - Voltmeter Functions	9
	HD - FWD Engagement Position	10
	HF - Errors Stored in the Non-Volatile Memory of the ECM	10
	First Start-Up	12
	Electronic Service Tool (EST)	13
	Downloading the Latest Software	13
	Connecting the Electronic Service Tool (EST) to the Tractor	17

SECTION 23 - FWD TRANSFER BOX AND AUTO FWD

BOOK 3 - 87051830

Chapter 2 - Auto FWD, Calibration and Diagnostics (Continued)

CONTENTS

Section	Description	Page
	HH Menu Access	20
	H3 - System Configuration	21
	H4 - Software Revision Level	24
	H5 - Control Switches Diagnosis	24
	H8 - Deleting Data from the Non-Volatile Memory	25
	H9 - Voltmeter Functions	26
	HD - FWD Engagement Position	27
	HF - Errors Stored in the Non-Volatile Memory of the ECM	27
	First Start-Up	29
	Troubleshooting	30
	ECM Location	31

SECTION 25 - FRONT AXLE (FWD)

BOOK 3 - 87051830

Chapter 1 - Front Axle (Super Steer Axle)

CONTENTS

Section	Description	Page
25 000	Main Data	1
	Torque Settings	4
	Tools	7
	Cross-Sectional Views	10
	Description and Operation	13
	Troubleshooting	15
25 100 30	Front axle assembly. Removal-Installation	16
25 102 15	Bevel drive and front axle differential housing. Removal-Installation	25
25 102 20	Front axle bevel drive. Overhaul	29
25 102 24	Front axle differential. Overhaul	37
25 104 34	Front axle differential lock clutch assembly. Overhaul	38
25 108 30	Front epicyclic final drive. Removal-Installation	41
25 108 38	Wheel hub and steering knuckles. Removal-Installation	46
25 108 46	Steering knuckle pins and bearings. Replacement	49
44 511 80	Front wheels adjustment (Toe-in)	50

SECTION 27 - REAR MECHANICAL DRIVE

BOOK 3 - 87051830

Chapter 1 - Rear Mechanical Transmission

CONTENTS

Section	Description	Page
27 000	Main Data	1
	Tightening Torques	3
	Tools	5
	Cross-Sectional Views	9
	Description and Operation	12
	Troubleshooting	12
	27 106 16	Rear Transmission Gearbox Removal-Installation
27 110 10	Differential Lock Engagement Sleeve-Adjustment	20
27 120 10	Final Drive Box Assembly Removal-Installation	26
27 120 34	Drive Shaft Removal-Installation	28
27 120 32	Epicyclic Final Drive Removal-Installation	30

SECTION 31 - MECHANICAL POWER TAKE-OFF

BOOK 3 - 87051830

Chapter 1 - Servo-Assist PTO

CONTENTS

Section	Description	Page
31 000	Main Data	1
	Troubleshooting	2
	Tools	3
	Tightening Torques	4
	Independent Power Take-off Description and Operation	5
	PTO Servo-Assist Valve Description and Operation	7
	PTO Clutch Engagement/Oil Flow	8
	PTO Clutch Disengagement/Oil Flow	9
	PTO Clutch Servo Control Adjustment	10
	Hydraulic PTO Servo Assist Cable Adjustment	11
	PTO Engaged Switch Adjustment	12
	31 112 20	Mechanical PTO Removal-Installation
	PTO Brake	16

SECTION 33 - BRAKING SYSTEM

BOOK 3 - 87051830

Chapter 1 - Braking System

CONTENTS

Section	Description	Page
33 000	Main Data	1
	Torque Settings	2
	Cross-Sectional Views	3
	Tools	5
	Description and Operation	6
	Troubleshooting	7
33 202 60	Right or Left-Hand Brake, Removal-Installation	9
33 202 46	Brake Hydraulic Pump (Master Cylinders), Removal-Installation	11
33 202 04	Brake Hydraulic System, Air Bleeding	16
33 110 40	Parking Brake Disks, Removal-Installation	18
33 110 08	Handbrake Control, Stroke Adjustment	20

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87051831

Chapter 1 - High Pressure System Description and Operation

CONTENTS

Section	Description	Page
	Precautionary Statements	2
	Description and Operation	3
	High-pressure System Hydraulic pump	4
	Hydraulic System Configuration Table	5
	Mechanically Controlled Rear Hydraulic Lift	6
	HPL Lift-O-Matic (Fast Raise/Lower Control)	8
	Rear Mechanical Hydraulic Power Lift (HPL) Control Valve Oil Flow	9
	Remote Control Valves	12
	Rear Remote Valve Arrangement	13
	Rear Remote Valve Stacking	14
	Rear Remote Valve Control Levers	14
	Deluxe Quick-Release Couplers	15
	Zero-pressure Return Port	15
	Mid-mount Control Valves (Optional)	16
	Switching Between Single and Double Acting Cylinders	17
	Double-acting Valve with Automatic Detent Release and Float	18
	Double-acting Valve Less Automatic Detent Release and Float	21
	Single-acting Valve Less Automatic Release and Float	22
	TN75FA, TN85FA, TN95FA (without Front HPL and PTO) Models With Mechanical Shuttle Transmissions Hydraulic System Diagram	23
	TN85FA, TN95FA (with power Shuttle and Rear Mechanical HPL) Hydraulic System Diagram	25

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87051831

Chapter 2 - High Pressure System Overhaul and Adjustment

CONTENTS

Section	Description	Page
	Specifications	2
	Torque Settings	7
	Hydraulic Lift Tools	10
	Cross-sectional Views	12
	Rear Mechanical Hydraulic Power Lift Troubleshooting	20
35 110 30	Mechanically Controlled Rear Hydraulic Lift (HPL) Removal-Installation	22
35 110 40	Mechanically Controlled Rear Power Lift Internal Controls Disassembly-Assembly	25
	Mechanically Controlled Lift Adjustments	29
35 110 08	Mechanically Controlled Lift Rod Mechanism Adjustments	35
	Lift Arm Descent Speed Adjustments	37
	Upper Stroke Limit Adjustment	37
	Adjusting the Upper Stroke Limit of the Lift-O-Matic Device	38
35 110 42	Arm Shaft and Lift Cylinder Disassembly-Assembly	39
35 114 14	Mechanically Controlled Lift Control Valve Disassembly-Assembly	43
35 114 30	Lift Pressure Relief Valve Removal-installation	47
35 114 32	Lift Pressure Relief Valve (Calibration)	47
35 104 30	High Pressure (Lift) Pump Disassembly-Assembly	49
35 204 46	Remote Control Valves Disassembly-Assembly	50
	Flow Control Valve Testing	53
35 204 46	Flow Control Valve Disassembly-Assembly	55

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87051831

Chapter 3 - Low-Pressure System Description and Operation

CONTENTS

Section	Description	Page
	Low-pressure, steering and lubrication system - General Description	2
	Low-pressure system oil flow	5
	Transmission lubrication system	7
	Electro-hydraulic rear differential lock (FWD)	10
	Electro-hydraulic front differential lock (FWD)	12
	Electro-hydraulic four-wheel drive	14
	PTO servo-assist valve and Piston	16

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87051831

Chapter 4 - Low-Pressure System Test Fitting Locations

CONTENTS

Section	Description	Page
	System test fitting locations	2

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87051831

Chapter 5 - Front Electronic Lift and Front Power Take-off

CONTENTS

Operation	Description	Page
	Main Specifications	1
	Tightening Torques	3
	Cross-Sectional Views	6
	Description and Operation	11
	Troubleshooting	16
31 140 30	Front Power Take-off Transmission Shaft Removal-Installation	18
31 140 34	Front Power Take-off Drive Shaft Disassembly-Assembly	26
31 140 43	Front Power Take-off Electromagnetic Coupler Disassembly-Assembly	28
31 140 46	Front Power Take-off Electromagnetic Coupler Disassembly-Assembly	31
31 162 52	Front Lift Support Disassembly-Assembly	35
	Front Power Take-off	38
	Front Power Take-off Fault Code Signals	39
	Front Power Take-off Fault Codes	41
	Front Power Take-off Calibrations	42
	Troubleshooting Fault Codes	51
	Front Electronic Lift	85
	Front Electronic Lift Faults Diagnosis	85
	Front Electronic Lift Faults Code Signals	86
	Front Electronic Lift Faults Codes	88
	Front Electronic Lift Calibration	90
	Electronic Front Power Lift (Electronic Control Module) Wiring Diagram	197

SECTION 35 - HYDRAULIC SYSTEM

BOOK 4 - 87051831

Chapter 6 - Description and Operation of the Electronic Service Tool (EST) with the Front PTO and Hydraulic Power Lift (HPL)

CONTENTS

Section	Description	Page
	Description of The Electronic Control Module (ECM)	2
	ECM Self-diagnosis	3
	Connecting The Electronic Service Tool (EST) To The Tractor	4
	Downloading The Latest Software Into TNFA Series Tractor Electronic Control Modules With The Electronic Service Tool	7

SECTION 41 - STEERING

BOOK 5 - 87051832

Chapter 1 - Steering

CONTENTS

Section	Description	Page
	Main Data	2
	Torque Settings	2
	Tools	2
	Description and Operation	3
	Troubleshooting	10
41 204 30	Hydrostatic Steering Control Valve. Removal-Installation	12
41 204 34	Hydrostatic Steering Control Valve. Disassembly-Assembly	18
41 204 38	Hydrostatic Steering Control Valve. Bench Testing	34

SECTION 41 - STEERING

BOOK 5 - 87051832

Chapter 2 - Open Center Fixed-Displacement Steering Pump

CONTENTS

Operation	Description	Page
	Main Data	1
	Torque Settings	2
	Cross Sectional Views	3
	Description and Operation	4
41 206 20	Hydrostatic Steering Oil Pump - Disassembly-Assembly (with unit removed)	5

SECTION 44 - AXLES AND WHEELS

BOOK 5 - 87051832

Chapter 1 - Axles and Wheels

CONTENTS

Section	Description	Page
44 000	Main Data	1
	Cross-Sectional Views	3
	Tightening Torques	4
	Torque Settings	6
	Tools	7
	Troubleshooting	8
44 101 22	Front Axle Hub, Disassembly-Assembly	9
44 101 30	Front Axle, Removal-Installation	12
44 101 46	Stub Axle, Overhaul	15
44 511 80	Checking Front Wheel Alignment (Toe In)	19

SECTION 50 - CAB CLIMATE CONTROL

BOOK 5 - 87051832

Chapter 1 - Cab Climate Control

CONTENTS

Section	Description	Page
	Cab Air Conditioning System Safety	2
	Use of the Air Conditioning System	3
	Tools and General Characteristics	4
	Operating Principles	5
	Main Components of the Cab Air Conditioning System	6
	Cab Heating and Ventilation Controls	11
	Cab Air Conditioning and Temperature Controls	13
50 200 03	Function and Cooling Tests	14
	Maintenance of the Air Conditioning System	16
	Troubleshooting	18
	Refrigerant Recovery - Recycling and Evacuation - Charging Stations	22
50 200 04	Filter/Drying, Recharging and Refrigeration Check	24
50 200 06	Checks and Elimination of Gas Leaks	31
50 200 10	Compressor Drive Belt Tension Adjustment	33
50 206 14	Cab Air Infeed Vents Removal and Installation	34
50 206 51	Air Conditioning Unit Removal and Installation	35

SECTION 55 - ELECTRICAL SYSTEMS

BOOK 6 - 87051833

Chapter 1 - Instruments

CONTENTS

Section	Description	Page
55 100	Analog instruments	1
	Transmitters, sensors and switches	5
	Digital instruments	13
	Maintenance	16

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**