

PARTS MANUAL

**FORTIS®
S40-70FT, S55FTS
(F187)**

CUSTOMER EDITION

HYSTER

SECTIONS

1	FRAME
2	ENGINES
3	FUEL SYSTEM
4	ELECTRICAL SYSTEM
5	TRANSMISSION
6	DRIVE AXLE
7	STEERING SYSTEM
8	BRAKE SYSTEM
9	HYDRAULIC SYSTEM
10	MAST-TWO STAGE LIMITED FREE-LIFT
11	MAST-TWO STAGE FULL FREE-LIFT
12	MAST-THREE STAGE FULL FREE-LIFT
13	MAST-FOUR STAGE FULL FREE-LIFT
14	OPTIONS
15	FIELD CONVERSION KITS
16	NUMERICAL INDEX

This Parts Manual is divided into 16 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

TABLE OF CONTENTS

DESCRIPTION	PAGE
A	
ACCUMULATOR	14-90
ADD ON OPTIONS	
ADD ON TELEMETRY KITS	15-5
AIR INTAKE SYSTEM	
AIR FILTER ASSEMBLY	3-65
GASOLINE AND LPG - GM 2.4L (→ S/N F187V14024F)	3-4
GASOLINE AND LPG - GM 2.4L (S/N F187V14025F →)	3-6
MAZDA 2.0L AND 2.2L LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-34
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0 L))	3-48
MAZDA 2.0L AND 2.2L, GASOLINE - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08176E (2.2 L)) (→ S/N F187V09002E (2.0 L)) (→ S/N F187V08715E (2.2L)) (S/N F187V09003E → (2.0 L))	3-20
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	3-38
PRE-CLEANER AND DUCT	3-66
ALTERNATOR MOUNTING	
GASOLINE AND LPG - GM 2.4L	2-36
ARMREST ASSEMBLY	
MINI-LEVER MODULES - SEMI-SUSPENSION SEAT WITH HIP RESTRAINTS (S/N F187V15997H → INC. 15948)	1-60
MINI-LEVER MODULES - FULL SUSPENSION SEAT (S/N F187V15997H → INC. 15948)	1-62
ASSEMBLED ENGINE	
GASOLINE AND LPG - GM 2.4L (SHEET 1 OF 4)	2-26
GASOLINE AND LPG - GM 2.4L (SHEET 2 OF 4)	2-30
GASOLINE AND LPG - GM 2.4L (SHEET 3 OF 4)	2-32
GASOLINE AND LPG - GM 2.4L (SHEET 4 OF 4)	2-34
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0)) (S/N F187V08716E → (2.2L))	2-106
AUXILIARY QUICK DISCONNECT MANIFOLD AND HOSES	
DUAL AUXILIARY WITH E-HYDRAULICS - TWO STAGE LIMITED FREE-LIFT (F507/F562 SERIES MAST (THREE AND FOUR FUNCTION)	14-82
SINGLE AUXILIARY WITH E-HYDRAULICS - TWO STAGE LIMITED FREE-LIFT (F507/F562 SERIES MAST) (THREE FUNCTION)	14-78
SINGLE AUXILIARY WITH INTEGRAL SIDE-SHIFT AND E-HYDRAULICS - TWO STAGE LIMITED FREE-LIFT (F507/F562 SERIES MAST) (FOUR FUNCTION)	14-80
THREE STAGE FULL FREE-LIFT (F508/F563 SERIES MAST) (SINGLE AUXILIARY WITH E- HYDRAULICS) - THREE FUNCTION	14-84
THREE STAGE FULL FREE-LIFT (F508/F563 SERIES MAST (DUAL AUXILIARY WITH E- HYDRAULICS)) - THREE AND FOUR FUNCTION	14-88
THREE STAGE FULL FREE-LIFT (F508/F563 SERIES MAST) (SINGLE AUXILIARY WITH INTEGRAL SIDE-SHIFT AND E-HYDRAULICS) - FOUR FUNCTION	14-86
AUXILIARY SECTIONS, ONE AND TWO	
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION (→ S/N F187V10079E (3 FUNCTION LOW RELIEF)) (→ S/N F187V10197E (4 FUNCTION LOW RELIEF))	

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
(→ S/N F187V10354E (3 FUNCTION HIGH RELIEF)) (→ S/N F187V10696E (4 FUNCTION HIGH RELIEF))	9-52
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION (S/N F187V10080E → (3 FUNCTION LOW RELIEF)) (S/N F187V10198E → (4 FUNCTION LOW RELIEF)) (S/N F187V10354E → (3 FUNCTION HIGH RELIEF)) (S/N F187V10697E → (4 FUNCTION HIGH RELIEF))	9-54
AUXILIARY TUBE EXTENSION KIT	
AUXILIARY TUBE EXTENSIONS	
FOUR STAGE FULL FREE-LIFT (→ S/N D515V05514H)	14-64
FOUR STAGE FULL FREE-LIFT (S/N D515V05515H →)	14-66
FOUR STAGE FULL FREE-LIFT - E-HYDRAULICS WITH QUICK DISCONNECT FITTINGS (S/N D515V05515H →)	14-68
TWO AND THREE STAGE FULL FREE-LIFT (→ S/N D508V27242H) (→ S/N D509V02103H) (→ S/N D563V11350H) (→ S/N D564V02121H)	14-54
TWO AND THREE STAGE FULL FREE-LIFT (S/N D509V02104H →) (S/N D563V11351H →) (S/N D564V02122H →) (S/N D508V27243H →)	14-58
TWO AND THREE STAGE FULL FREE-LIFT - E-HYDRAULICS WITH QUICK DISCONNECT FITTINGS (S/N D508V27243H →) (S/N D509V02104H →) (S/N D563V11351H →) (S/N D564V02122H →)	14-60
TWO STAGE LIMITED FREE-LIFT (→ S/N D507V02972H) (→ S/N D562V02053H)	14-40
TWO STAGE LIMITED FREE-LIFT - WITHOUT QUICK DISCONNECT FITTINGS (S/N D507V02973H →) (S/N D562V02054H →)	14-42
TWO STAGE LIMITED FREE-LIFT - MANUAL HYDRAULICS WITH QUICK DISCONNECT FITTINGS (S/N D507V02973H →) (S/N D562V02054H →)	14-44
TWO STAGE LIMITED FREE-LIFT - E-HYDRAULICS WITH QUICK DISCONNECT FITTINGS (S/N D507V02973H →) (S/N D562V02054H →)	14-46
TWO STAGE LIMITED FREE-LIFT - WITH ISS CARRIAGE AND WITHOUT QUICK DISCONNECT FITTINGS (S/N D507V02973H →) (S/N D562V02054H →)	14-48
TWO STAGE LIMITED FREE-LIFT - WITH ISS CARRIAGE AND MANUAL HYDRAULICS WITH QUICK DISCONNECT FITTINGS (S/N D507V02973H →) (S/N D562V02054H →)	14-50
TWO STAGE LIMITED FREE-LIFT - WITH ISS CARRIAGE AND E-HYDRAULICS WITH QUICK DISCONNECT FITTINGS (S/N D507V02973H →) (S/N D562V02054H →)	14-52
AUXILIARY TUBES	
THREE STAGE FULL FREE-LIFT (F508/F563 SERIES MAST) - MANUAL AND E-HYDRAULICS VALVE WITH QUICK DISCONNECT	14-74
THREE STAGE FULL FREE-LIFT (F508/F563 SERIES MAST) - MANUAL AND E-HYDRAULICS VALVE WITHOUT QUICK DISCONNECT	14-76
TWO STAGE LIMITED FREE LIFT (F507/F562 SERIES MAST - WITH MANUAL AND E-HYDRAULICS VALVE WITHOUT QUICK DISCONNECT	14-70
TWO STAGE LIMITED FREE LIFT (F507/F562 SERIES MAST - MANUAL AND E-HYDRAULIC VALVE WITH QUICK DISCONNECT	14-72
AUXILLIARY HOSES	
THREE STAGE FULL FREE LIFT - TWO STAGE LIMITED FREE-LIFT	9-26
B	
BACK-UP ALARM	14-8
BRAKE ASSEMBLY	8-18

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
BRAKE LINKAGE	
DUAL PEDAL (→ S/N F187V16129H)	8-6
DUAL PEDAL (S/N F187V16130H →)	8-10
SINGLE PEDAL (→ S/N F187V16129H)	8-2
SINGLE PEDAL (S/N F187V16130H →)	8-4
C	
CAM POSITION SENSOR	
GM 2.4L GASOLINE AND LPG - 2010 SERIES	2-51
CAMSHAFT AND VALVES	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT	
ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-80
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT	
ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	2-112
CAMSHAFT, CYLINDER HEAD AND MANIFOLDS	
GM 2.4L (→ S/N F187V06059D)	2-44
GM 2.4L ENGINE (S/N F187V06060D →)	2-48
CARBURETOR	
MAZDA 2.0L AND 2.2L LPG - 2005 AND 2006 EMISSION COMPLIANT	
ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-102
MAZDA 2.0L AND 2.2L LPG - 2005 AND 2006 EMISSION COMPLIANT	
ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-36
CARRIAGE	
FOUR STAGE FULL FREE-LIFT	13-20
HEAVY DUTY - TWO STAGE FULL FREE-LIFT	11-46
HEAVY DUTY - THREE STAGE FULL FREE-LIFT (D508/D563)	12-28
HEAVY DUTY - THREE STAGE FULL FREE-LIFT (F508/F563)	12-68
HEAVY DUTY - FOUR STAGE FULL FREE-LIFT	13-22
THREE STAGE FULL FREE-LIFT - D508/D563	12-26
THREE STAGE FULL FREE-LIFT - F508/F563	12-66
TWO STAGE FULL FREE-LIFT	11-44
TWO STAGE LIMITED FREE-LIFT - D507/D562	10-12
TWO STAGE LIMITED FREE-LIFT - F507-F562	10-32
CHARGE PUMP	
→ S/N F187V25052L	5-68
CHARGE PUMP ASSEMBLY	
S/N F187V25053L →	5-70
CONTROL VALVE	
TRANSMISSION (→ 9/2007)	5-64
CONTROL VALVE ASSEMBLY	
9/2007 →	5-66
MANUAL CONTROL - THREE AND FOUR FUNCTION	9-40
CONTROL VALVE LOCKOUT GROUP	
MANUAL CONTROL VALVE	9-44
COOLING MANIFOLD AND ATTACHING PARTS	
GASOLINE AND LPG - GM 2.4L	2-16
COOLING SYSTEM	
GASOLINE AND LPG - GM 2.4L (→ S/N F187V08135D)	2-6
GASOLINE AND LPG - GM 2.4L (S/N F187V08136D →)	2-10

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
GASOLINE AND LPG - MAZDA 2.0L AND 2.2L (→ S/N F187V08135D)	2-58
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (S/N F187V08135D ↔ S/N F187V09002E 2.0L) (S/N F187V08136D ↔ S/N F187V08715E 2.2L)	2-62
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-66
COUNTERWEIGHT	
→ 4/2007	1-20
4/2007 →	1-22
COWL ELECTRICAL	4-40
MANUAL HYDRAULIC - WITH OPERATOR PRESENCE SYSTEM	4-42
COWL MOUNT	1-18
CRANKSHAFT AND PISTONS	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-82
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V18716E → (2.2 L))	2-114
CRANKSHAFT, PISTONS AND OIL PAN	
GM 2.4L ENGINE	2-40
CYLINDER BLOCK	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-78
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0L))	2-110
CYLINDER HEAD	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V09002E) (→ S/N F187V08715E 2.2L)	2-76
CYLINDER HEAD AND COVER	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0L))	2-108
D	
DELAY VALVE	
MAZDA 2.0L AND 2.2L LPG - 2005-2006 SERIES ENGINE (S/N F187V07282D ↔ S/N F187V08715E)	2-104
DISTRIBUTOR	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG	4-33
DRIVE AXLE	6-2
DRIVE TIRES AND WHEELS	
S40-50FT	6-5
S55-60FT	6-6
S70FT	6-7
E	
E-HYDRAULIC CONTROL CONVERSION KITS	
E-HYDRAULIC CONVERSION KITS	
ELECTRICAL SYSTEM	
CHASSIS	4-4

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
ELECTRONIC CONTROL LEVERS	
MINI-LEVER MODULE (FOUR FUNCTION) - DATE CODE 0725 THRU 0743	4-54
MINI-LEVER MODULE (FOUR FUNCTION) - DATE CODE 0744	4-60
MINI-LEVER MODULES - DATE CODE 0724	4-50
MINI-LEVER MODULES (THREE FUNCTION) - DATE CODE 0725 THRU 0743	4-52
MINI-LEVER MODULES (THREE FUNCTION) - DATE CODE 0744	4-56
ELECTRONIC LEVER LABELS	
AUXILIARY DUAL FUNCTION	1-70
AUXILIARY SINGLE FUNCTION	1-68
ELECTRONIC PRESSURE REGULATOR ASSEMBLY	
MAZDA 2.0L AND 2.2L LPG - 2007 EMISSION COMPLIANT ENGINES (S/N F187V08716E ↔ 2/2008 (2.2L)) (S/N F187V09003E ↔ 2/2008 (2.0 L))	3-58
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (2/2008 ↔ 2/2012)	3-60
MAZDA 2.0L AND 2.2L LPG (2/2012 →)	3-62
ELECTRONIC PRESSURE REGULATOR KIT	
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0 L))	3-64
EMISSION CONTROL SYSTEM	
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-134
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E →) (S/N F187V08716E → (2.2L))	2-132
EMISSION LINES	
MAZDA 2.0L AND 2.2L, GASOLINE - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-98
MAZDA 2.0L AND 2.2L, GASOLINE - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-26
ENGINE CONTROL MODULE	
MAZDA 2.0L AND 2.2L LPG	4-32
MAZDA 2.0L AND 2.2L, GASOLINE	4-31
ENGINE COOLING	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-86
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0L))	2-118
ENGINE ELECTRICAL COMPONENTS	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	4-18
ENGINE ELECTRICAL COMPONENTS	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	4-14
ENGINE ELECTRICAL SYSTEM	
MAZDA 2.0L AND 2.2L LPG, SHEET 1 OF 2	4-24
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG, SHEET 2 OF 2 - 2007 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → 2.2L)	4-28
MAZDA 2.0L AND 2.2L, GASOLINE, SHEET 1 OF 2	4-20
ENGINE FUEL SYSTEM	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-136

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
ENGINE FUEL SYSTEM AND EMISSION CONTROL	
MAZDA 2.0L AND 2.2L LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-100
MAZDA 2.0L AND 2.2L LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-28
ENGINE FUEL SYSTEM AND INTAKE MANIFOLD	
MAZDA 2.0L AND 2.2L, GASOLINE - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-96
MAZDA 2.0L AND 2.2L, GASOLINE - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-24
ENGINE MOUNT	
GASOLINE AND LPG - GM 2.4L	2-4
GASOLINE AND LPG - MAZDA 2.0L AND 2.2L	2-52
ENGINE SAFETY ELECTRICAL	
MAZDA 2.0L AND 2.2L	4-36
EXHAUST	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V09002E (2.0L)) (→ S/N F187V08715E (2.2L))	2-72
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-74
EXHAUST MANIFOLD	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-126
EXHAUST SYSTEM	
GM 2.4L GASOLINE AND LPG	2-18
GM 2.4L GASOLINE AND LPG - 2010 SERIES	2-20
F	
FENDERS	1-17
FIELD KITS	
FIRE EXTINGUISHER	14-12
FLOORPLATES AND COVERS	
→ S/N F187V11309F EXC. 01315, 01317, 01229	1-10
S/N F187V11310F → INC. 01310, 01024, 01079, 01151, 01164, 01221, 01230	1-14
FLYWHEEL AND HOUSING	
GASOLINE AND LPG - MAZDA 2.0 L AND 2.2 L (→ S/N F187V07304D)	2-54
GASOLINE AND LPG - MAZDA 2.0 L AND 2.2 L (S/N F187V07305D →)	2-56
GM 2.4L, GASOLINE AND LPG (→ S/N F187V13502F)	2-22
GM 2.4L, GASOLINE AND LPG (S/N F187V13502F →)	2-24
FORK	
OPTIONAL	1-76
FORK ASSEMBLY KITS	15-15
FORK POSITIONER ASSEMBLY	14-30
FORKS	
OPTIONAL	1-74
OPTIONAL	1-78
FORWARD CLUTCH	
SINGLE SPEED TRANSMISSION (→ S/N F187V08503E)	5-52
SINGLE SPEED TRANSMISSION (S/N F187V08504E → (T133M))	5-54
SINGLE SPEED TRANSMISSION (S/N T141M001501 →) (S/N T148M001501 →)	5-56

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
FREE-LIFT	
FOUR STAGE FULL FREE-LIFT	13-16
THREE STAGE FULL FREE-LIFT - D508/D563	12-18
TWO STAGE FULL FREE- LIFT - E509-E564	11-34
TWO STAGE FULL FREE-LIFT - D509-D564	11-12
FREE-LIFT CYLINDER	
THREE STAGE FULL FREE-LIFT - F508-F563	12-58
TWO STAGE FULL FREE- LIFT - E509-E564	11-37
FREE-LIFT CYLINDER AND ATTACHING PARTS	
THREE STAGE FULL FREE-LIFT - F508-F563	12-50
FREE-LIFT CYLINDERS	
FOUR STAGE FULL FREE-LIFT	13-18
THREE STAGE FULL FREE-LIFT - D508/D563	12-22
TWO STAGE FULL FREE-LIFT - D509-D564	11-16
FUEL PUMP AND SENDER	
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	3-44
FUEL REGULATOR	
LPG - GM 2.4L	3-14
FUEL SUPPLY SYSTEM	
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0 L))	3-42
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	3-40
FUEL SYSTEM	
GASOLINE - GM 2.4L	3-8
LPG - GM 2.4L	3-10
MAZDA 2.0L AND 2.2L LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-30
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0 L))	3-50
MAZDA 2.0L AND 2.2L, GASOLINE - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	3-22
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0 L))	3-46
FUEL SYSTEM HOSES AND ATTACHING PARTS	
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES	3-52
FUEL SYSTEM SENSORS	
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	4-35
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	4-34
FULL SUSPENSION SEAT	
MANUAL AND ELECTRO-HYDRAULIC — SWIVEL AND NON SWIVEL - SHEET 1 OF 4 (S/N F187V15997H → INC. 15948)	1-52
RECLINER AND DAMPER KITS - SHEET 3 OF 4 (S/N F187V15997H → INC. 15948)	1-56
SERVICE KITS FOR NON SWIVEL AND SWIVEL - SHEET 2 OF 4 (S/N F187V15997H →)	1-54
WITH AND WITHOUT ELECTRONIC CONTROLS (→ 7/2005)	1-40
WITH AND WITHOUT ELECTRONIC CONTROLS (7/2005 ↔ S/N F187V05858D)	1-42

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
WITH AND WITHOUT ELECTRONIC CONTROLS - WITH LIMITED BACK TILT (S/N F187V05859D ↔ S/N F187V15996H EXC. 15948)	1-44
FULL SUSPENSION SWIVEL SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS (→ 7/2006)	1-46
WITH AND WITHOUT ELECTRONIC CONTROLS (7/2006 ↔ S/N F187V15996H)	1-48
WITH LIMITED BACK TILT (S/N F187V05859D ↔ S/N F187V15996H EXC. 15948)	1-50
G	
GEAR PUMP ASSEMBLY	
HIGH PRESSURE	9-16
LOW PRESSURE - GEAR DRIVE OPTION	9-12
LOW PRESSURE - CHAIN DRIVE OPTION	9-14
GM ENGINE ELECTRICAL	
GASOLINE AND LPG/GS AND LPS 2.4L (→ S/N F187V13146F EXC. 04157)	4-10
GASOLINE AND LPG/GS AND LPS 2.4L (S/N F187V13147F → INC. 04157)	4-12
H	
HAND LEVERS	
FOUR FUNCTION - WITHOUT DETENTED LEVERS	9-34
FOUR FUNCTION - WITH DETENTED LEVERS	9-36
THREE FUNCTION - WITHOUT DETENTED LEVERS	9-28
THREE FUNCTION - WITH DETENTED LEVERS	9-30
HEADER HOSE	
FOUR STAGE FULL FREE-LIFT - WITH FLOATING SHEAVE	13-24
FOUR STAGE FULL FREE-LIFT - WITH HOSE CHANNELS	13-28
TWO STAGE FULL FREE-LIFT - D509-D564	11-20
TWO STAGE LIMITED FREE-LIFT - D507/D562	10-14
HEADER HOSE AND ATTACHING PARTS	
TWO STAGE LIMITED FREE-LIFT - F507-F562	10-28
HEADER HOSE CONVERSION KIT	
HEADER HOSE CONVERSION KITS	
HEADER HOSES	
THREE STAGE FULL FREE-LIFT - D508/D563 (→ S/N D508V27872H) (→ S/N D563V11658H)	12-30
THREE STAGE FULL FREE-LIFT - D508/D563 (S/N D508V27873H →) (S/N D563V11659H →)	12-34
TWO STAGE FULL FREE-LIFT - E509-E564	11-40
HEADER HOSES AND ATTACHING PARTS	
THREE STAGE FULL FREE-LIFT - F508/F563	12-62
HOOD	
→ S/N F187V15865H	1-4
S/N F187V15877H →	1-6
HOSE CHANNELS	
HEADER HOSE - FOUR STAGE FULL FREE-LIFT	13-32
HYDRAULIC CONTROL VALVE	
ELECTRO HYDRAULIC POPPET VALVES - LIFT AND LOWER	9-66
ELECTRONIC VALVE ASSEMBLY - THREE AND FOUR FUNCTION (→ S/N F187V09717E 4 FUNCTION, LOW RELIEF) (→ S/N F187V10074E 4 FUNCTION, HIGH RELIEF) (→ S/N F187V09787E 3 FUNCTION, LOW RELIEF) (→ S/N F187V10402E 3 FUNCTION, HIGHT RELIEF3 FUNCTION, HEIGHT RELIEF)	9-58

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
ELECTRONIC VALVE ASSEMBLY - THREE AND FOUR FUNCTION (S/N F187V09718E → 4 FUNCTION, LOW RELIEF) (S/N F187V10075E → 4 FUNCTION, HIGH RELIEF) (S/N F187V09788E → 3 FUNCTION, LOW RELIEF) (S/N F187V10403E → 3 FUNCTION, HIGH RELIEF)	9-60
ELECTRONIC VALVE AUXILIARY ONE SECTION - THREE AND FOUR FUNCTION	9-70
ELECTRONIC VALVE AUXILIARY TWO SECTION - FOUR FUNCTION	9-72
ELECTRONIC VALVE INLET SECTION - THREE AND FOUR FUNCTION (→ S/N F187V09787E (3 FUNCTION LOW RELIEF)) (→ S/N F187V09717E (4 FUNCTION LOW RELIEF)) (→ S/N F187V10074E (4 FUNCTION HIGH RELIEF)) (→ S/N F187V10402E (3 FUNCTION LOW RELIEF))	9-62
ELECTRONIC VALVE INLET SECTION - THREE AND FOUR FUNCTION (S/N F187V10403E → (3 FUNCTION HIGH RELIEF)) (S/N F187V09718E → (4 FUNCTION LOW RELIEF)) (S/N F187V09788E → (3 FUNCTION LOW RELIEF)) (S/N F187V10075E → (4 FUNCTION HIGH RELIEF))	9-64
ELECTRONIC VALVE OUTLET SECTION - THREE AND FOUR FUNCTION	9-74
ELECTRONIC VALVE OUTLET SECTION (7/2009 →)	9-76
ELECTRONIC VALVE TILT SECTION - THREE AND FOUR FUNCTION	9-68
HYDRAULIC CONTROLS	
HYDRAULIC FILTER	
→ S/N F187V15585G	9-18
S/N F187V15586G →	9-20
HYDRAULIC OIL COOLER KITS	15-15
HYDRAULIC SUPPLY AND RETURN	
WITH ALUMINUM TRANSMISSION - WITH GEAR DRIVE	9-8
WITH ALUMINUM TRANSMISSION - WITH CHAIN DRIVE	9-10
WITH IRON TRANSMISSION	9-4
I	
IMPACT SENSOR	
9/2005 →	4-8
INNER MAST	
FOUR STAGE FULL FREE-LIFT	13-8
THREE STAGE FULL FREE-LIFT - F508-F563	12-42
THREE STAGE FULL FREE-LIFT - D508/D563	12-8
TWO STAGE FULL FREE- LIFT - E509-E564	11-26
TWO STAGE FULL FREE-LIFT - D509-D564	11-4
TWO STAGE LIMITED FREE LIFT - F507-F562	10-20
TWO STAGE LIMITED FREE-LIFT - D507/D562	10-4
INSTRUMENT CLUSTER	4-48
INTAKE AND EXHAUST MANIFOLDS	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V09002E (2.0L)) (→ S/N F187V08715E (2.2L))	2-90
INTAKE MANIFOLD	
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-130

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
MAZDA 2.0L AND 2.2L, GASOLINE - 2007 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0L)) (S/N F187V08716E → (2.2L))	2-128
INTEGRAL SIDE-SHIFT	
FORK POSITIONER - THREE STAGE FULL FREE-LIFT (D508/D563)	14-24
FORK POSITIONER (F507-F562) - TWO STAGE LIMITED FREE-LIFT	14-26
FORK POSITIONER (F508-F563) - THREE STAGE FULL FREE-LIFT	14-28
HYDRAULIC HOSES - TWO STAGE LIMITED FREE-LIFT (D507, D562)	14-34
HYDRAULIC HOSES - THREE STAGE FULL FREE-LIFT (D508/D563)	14-36
INTEGRAL SIDE-SHIFT CARRIAGE	
THREE AND FOUR STAGE FULL FREE-LIFT - D508, D563, D515	14-20
THREE STAGE FULL FREE-LIFT - F508/F563	14-22
TWO STAGE FULL FREE-LIFT - D509/E509 AND D564/E564	14-18
TWO STAGE LIMITED FREE-LIFT - D507/D562	14-14
TWO STAGE LIMITED FREE-LIFT - F507/F562	14-16
INTEGRAL SIDE-SHIFT CYLINDER	14-32
INTEGRAL SIDE-SHIFT HYDRAULIC HOSES	
FOUR STAGE FULL FREE-LIFT	14-39
THREE STAGE FULL FREE LIFT - F508/F563	14-37
TWO STAGE FULL FREE LIFT - D509/E509 AND D564/E564	14-38
TWO STAGE LIMITED FREE-LIFT - F507/F562	14-35
INTERMEDIATE 1 MAST	
FOUR STAGE FULL FREE-LIFT	13-4
INTERMEDIATE 2 MAST	
FOUR STAGE FULL FREE-LIFT	13-6
INTERMEDIATE MAST	
THREE STAGE FULL FREE-LIFT - F508-F563	12-44
THREE STAGE FULL FREE-LIFT - D508/D563	12-4
L	
LABELS	
HYDRAULIC CONTROL LABELS - CONTROL LEVER	1-82
LOAD BACKREST EXTENSION	1-80
LOAD WEIGH ELECTRICAL	4-70
LPG TANK BRACKET	
SWING OUT	3-68
SWING OUT, DROP DOWN - ALTERNATE PART	3-78
SWING OUT/DROP DOWN	3-74
LPG TANK SHORT BRACKET	
SWING OUT	3-70
M	
MAIN LIFT	
FOUR STAGE FULL FREE-LIFT	13-10
THREE STAGE FULL FREE-LIFT - D508/D563	12-10
TWO STAGE FULL FREE- LIFT - E509-E564	11-28
TWO STAGE FULL FREE-LIFT - D509-D564	11-6
TWO STAGE LIMITED FREE LIFT - F507-F562	10-22
TWO STAGE LIMITED FREE-LIFT - D507/D562	10-6

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
MAIN LIFT CYLINDER	
LEFT HAND - TWO STAGE FULL FREE-LIFT (D509-D564)	11-10
LEFT HAND - FOUR STAGE FULL FREE-LIFT	13-12
RIGHT HAND - TWO STAGE FULL FREE-LIFT (D509-D564)	11-8
RIGHT HAND - FOUR STAGE FULL FREE-LIFT	13-14
THREE STAGE FULL FREE-LIFT - F508-F563	12-54
TWO STAGE LIMITED FREE LIFT - F507-F562	10-24
MAIN LIFT CYLINDER - LH	
TWO STAGE FULL FREE- LIFT - E509-E564	11-32
MAIN LIFT CYLINDER - RH	
TWO STAGE FULL FREE- LIFT - E509-E564	11-30
MAIN LIFT CYLINDER AND ATTACHING PARTS	
THREE STAGE FULL FREE-LIFT - F508-F563	12-46
MAIN LIFT CYLINDERS	
THREE STAGE FULL FREE-LIFT - D508/D563	12-14
TWO STAGE LIMITED FREE-LIFT - D507/D562	10-8
MAST ELECTRICAL	4-69
MASTER CYLINDER	8-17
MINI LEVER MODULE LABELS	
HYDRAULIC CONTROL FUNCTIONS	1-72
MINI-LEVER CONTROLS	
WITH ARMREST - THREE FUNCTION (S/N F187V15997H →)	4-62
WITH ARMREST - FOUR FUNCTION (S/N F187V15997H →)	4-64
MIRRORS	14-11
MISCELLANEOUS CONVERSION KITS	15-3
MISCELLANEOUS KITS	15-2
MIXER AND THROTTLE BODY ASSEMBLY	
MAZDA 2.0L AND 2.2L LPG - 2007 EMISSION COMPLIANT	
ENGINES (S/N F187V08716E ↔ 2/2008 (2.2L)) (S/N F187V09003E ↔ 2/2008 (2.0 L))	3-54
MAZDA 2.0L AND 2.2L LPG - 2007-2010 EMISSION COMPLIANT ENGINES (2/2008 → (2.2L)) (2/2008 → (2.0 L))	3-56
MONOTROL PEDAL ASSEMBLY	
→ S/N F187V21728K	3-88
N	
NON SUSPENSION SEAT	
WITHOUT ELECTRONIC CONTROLS (→ S/N F187V15997H)	1-26
WITHOUT ELECTRONIC CONTROLS (S/N F187V15997H → INC. 15948)	1-28
WITHOUT ELECTRONIC CONTROLS - OPTIONAL	1-30
O	
OIL PUMP AND FILTER	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT	
ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-94
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT	
ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	2-122
OUTER MAST	
FOUR STAGE FULL FREE-LIFT	13-2
THREE STAGE FULL FREE LIFT - F508-F563	12-38

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
THREE STAGE FULL FREE-LIFT - D508/D563	12-2
TWO STAGE FULL FREE LIFT - E509-E564	11-24
TWO STAGE FULL FREE-LIFT - D509-D564	11-2
TWO STAGE LIMITED FREE-LIFT - D507/D562	10-2
TWO STAGE LIMITED FREE-LIFT - F507-F562	10-18
OUTLET SECTION	
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION	9-56
OVERHEAD GUARD	1-24
P	
PARK BRAKE	
→ S/N F187V16129H	8-14
S/N F187V16130H →	8-16
PLATES AND LABELS	1-64
POWER DISTRIBUTION MODULE	
→ S/N F187V07458D	4-44
S/N F187V07459D →	4-46
R	
RADIATOR ASSEMBLY	
GM 2.4L GASOLINE AND LPG	2-14
MAZDA 2.0L AND 2.2L	2-70
RED SEAT BELT RETRACTOR AND BUCKLE	14-13
REMOTE OIL FILTER	
GASOLINE AND LPG - GM 2.4L	2-37
REPLACEMENT KITS	15-15
RETURN TO SET TILT KITS	15-5
REVERSE CLUTCH	
SINGLE SPEED TRANSMISSION (→ S/N F187V08503E)	5-58
SINGLE SPEED TRANSMISSION (S/N F187V08504E → (T133M))	5-60
SINGLE SPEED TRANSMISSION (S/N T141M001501 →) (S/N T148M001501 →)	5-62
S	
SEAT ATTACHING PARTS	
NOT INCLUDED WITH SEAT - SHEET 4 OF 4 (S/N F187V15997H → INC. 15948)	1-58
SEAT CONVERSION KITS	15-2
SEMI SUSPENSION SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS (→ 7/2006)	1-32
SEMI-SUSPENSION SEAT	
WITH AND WITHOUT ELECTRONIC CONTROLS (7/2006 ↔ S/N F187V15996H)	1-34
WITH AND WITHOUT ELECTRONIC CONTROLS (S/N F187V15997H → INC. 15948)	1-38
STATOR SUPPORT HOUSING	5-50
STEER TIRES AND WHEELS	7-13
STEERING AXLE	7-10
STEERING COLUMN ASSEMBLY	7-4
ISOLATED, DIESEL	7-6
STEERING CONTROL UNIT	7-8
STEERING CYLINDER	7-12
STEERING SYSTEM	7-2

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
STROBE LIGHT	
→ S/N F187V09896E	14-4
LED (S/N F187V09897E →)	14-6
T	
THROTTLE BODY AND ATTACHING PARTS	
GM 2.4L GASOLINE AND LPG	3-16
GM 2.4L GASOLINE AND LPG - 2010 SERIES	3-18
MAZDA 2.0L AND 2.2L, GASOLINE - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → (2.2L)) (S/N F187V09003E → (2.0 L))	3-47
THROTTLE LINKAGE	
GASOLINE	3-81
LPG	3-83
THROTTLE PEDAL AND ATTACHING PARTS	
MONOTROL PEDAL (→ S/N F187V21728K)	3-86
THROTTLE PEDAL ASSEMBLY AND ATTACHING PARTS	
MONOTROL (S/N F187V21729K →)	3-92
STANDARD PEDAL	3-90
TILT CYLINDER AND MAST INSTALLATION	9-78
TILT CYLINDERS	
S40-55FT	9-80
S60-70FT	9-82
TILT/HOIST AND AUXILIARY HOSES	9-22
TIMING GEAR COVER AND OIL PAN	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2005 AND 2006 EMISSION COMPLIANT ENGINES (→ S/N F187V08715E (2.2L)) (→ S/N F187V09002E (2.0L))	2-92
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	2-124
TORQUE CONVERTER	
GASOLINE AND LPG - MAZDA (2.0L AND 2.2L)	5-9
GASOLINE AND LPG - GM 2.4L	5-10
TORQUE CONVERTER HOUSING AND ATTACHING PARTS	
SINGLE SPEED - ALUMINUM CHAIN DRIVE (2/2011 →)	5-48
SINGLE SPEED GEAR DRIVE (S/N T141M001501 →)	5-42
TRANSMISSION	
SINGLE SPEED - SHEET 1 OF 2 (→ S/N F187V06785D INC. 6830-6831) (→ T117M016844)	5-20
SINGLE SPEED - SHEET 2 OF 2 (→ S/N F187V06785D INC. 6830-6831) (→ T117M016844)	5-24
SINGLE SPEED - SHEET 1 OF 2 (S/N F187V06786D ↔ S/N F187V08503E) (T117M016845 →)	5-26
SINGLE SPEED - SHEET 2 OF 2 (S/N F187V06786D ↔ S/N F187V08503E) (T117M016845 →)	5-30
SINGLE SPEED - SHEET 1 OF 2 (S/N T133M0001501 → (DRY BRAKE)) (S/N F187V08504E →)	5-32
SINGLE SPEED - SHEET 2 OF 2 (S/N T133M0001501 → (DRY BRAKE)) (S/N F187V08504E →)	5-34
TRANSMISSION COOLING	
WITH AIR OIL COOLER - MAZDA 2.0L, 2.2L, AND GM 2.4L (→ S/N F187V14228F)	5-16
WITH AIR OIL COOLER - MAZDA 2.0L, 2.2L, AND GM 2.4L (S/N F187V14229F →)	5-18
WITHOUT AIR OIL COOLER - MAZDA 2.0L, 2.2L (→ S/N F187V14228F)	5-11
WITHOUT AIR OIL COOLER - MAZDA 2.0L AND 2.2L (S/N F187V14229F →)	5-14
TRANSMISSION ELECTRICAL SYSTEM	
→ S/N F187V07304D	4-66
S/N F187V07305D →	4-68

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
TRANSMISSION HOUSING AND ASSEMBLY	
SINGLE SPEED - ALUMINUM CHAIN DRIVE (2/2011 →)	5-44
SINGLE SPEED GEAR DRIVE (S/N T141M001501 →)	5-38
TRANSMISSION MOUNT	
→ S/N F187V06785D	5-2
S/N F187V06786D → EXC. 6830-6831	5-3
S/N T141M001501 →	5-6
SINGLE SPEED - ALUMINUM CHAIN DRIVE (2/2011 →)	5-8
V	
VALVE ASSEMBLY, LIFT AND TILT	
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION (→ S/N F187V10079E (3 FUNCTION LOW RELIEF))	
(→ S/N F187V10197E (4 FUNCTION LOW RELIEF))	
(→ S/N F187V10696E (4 FUNCTION HIGH RELIEF))	
(→ S/N F187V10354E (3 FUNCTION HIGH RELIEF))	9-46
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION (S/N F187V10080E ↔ S/N F187V15456G (3 FUNCTION LOW RELIEF))	
(S/N F187V10198E ↔ S/N F187V15350G (4 FUNCTION LOW RELIEF))	
(S/N F187V10697E ↔ S/N F187V15314G (4 FUNCTION HIGH RELIEF))	
(S/N F187V10354E ↔ S/N F187V15293G (3 FUNCTION HIGH RELIEF))	9-48
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION (S/N F187V15457G → (3 FUNCTION LOW RELIEF))	
(S/N F187V15351G → (4 FUNCTION LOW RELIEF))	
(S/N F187V15315G → (4 FUNCTION HIGH RELIEF))	
(S/N F187V15294G → (3 FUNCTION HIGH RELIEF))	9-50
W	
WIRE HARNESS	
BACK-UP ALARM	14-10
CHASSIS - MAZDA 2.0L AND 2.2L (→ S/N F187V07304D)	4-74
CHASSIS - MAZDA, WITH ANTI-STALL (→ S/N F187V15996H EXC. 15948)	4-92
CHASSIS - MAZDA (S/N F187V15997H → INC. 15948)	4-98
CHASSIS - MAZDA-WITHOUT SEAT BELT SEQUENCE MODULE (1/2013 →)	4-104
CHASSIS - MAZDA-WITH SEAT BELT SEQUENCE MODULE	4-110
CHASSIS - GM 2.4L (→ S/N F187V07304D)	4-116
CHASSIS - GM 2.4L (S/N F187V07305D ↔ S/N F187V08649D)	4-122
CHASSIS - GM 2.4L (S/N F187V08650D → EXC. 7239-7240, 8630)	4-128
CHASSIS - GM, WITH ANTI-STALL (→ S/N F187V15996H EXC. 15948)	4-134
CHASSIS - GM 2.4L (S/N F187V15997H → INC. 15948)	4-140
CHASSIS - GM 2.4L-WITHOUT SEAT BELT SEQUENCE MODULE (1/2013 →)	4-146
CHASSIS - GM 2.4L-WITH SEAT BELT SEQUENCE MODULE	4-152
COWL WITH FORWARD/REVERSE LEVER - WITHOUT RETURN TO SET TILT (→ S/N F187V16129H)	4-168
COWL WITH FORWARD/REVERSE LEVER - WITHOUT RETURN TO SET TILT (S/N F187V16130H →)	4-172
COWL WITH FORWARD/REVERSE LEVER - WITH HYDRAULIC PUMP SOLENOID (→ S/N F187V16129H)	4-176

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
COWL WITH FORWARD/REVERSE LEVER - WITH HYDRAULIC PUMP SOLENOID (S/N F187V16130H →)	4-180
COWL WITH MONOTROL PEDAL - WITH RETURN TO SET TILT (→ S/N F187V16129H)	4-160
COWL WITH MONOTROL PEDAL - WITH RETURN TO SET TILT (S/N F187V16130H →)	4-164
COWL WITH MONOTROL PEDAL - WITH HYDRAULIC PUMP SOLENOID (→ S/N F187V16129H)	4-184
COWL WITH MONOTROL PEDAL - WITH HYDRAULIC PUMP SOLENOID (S/N F187V16130H →)	4-188
ELECTRONIC CONTROL VALVE - 3 FUNCTION	4-258
ELECTRONIC CONTROL VALVE - 4 FUNCTION	4-260
FUSED STARTER - GM 2.4L 2010 SERIES	4-277
GM 2.4L ENGINE - LPG (→ S/N F187V08649E INC. 8630 EXC. 7239-7240)	4-230
GM 2.4L ENGINE - LPG (S/N F187V08650E → INC. 7239-7240 EXC. 8630)	4-234
GM 2.4L ENGINE, GASOLINE (→ S/N F187V08649E INC. 8630 EXC. 7239-7240)	4-246
GM 2.4L ENGINE, GASOLINE (S/N F187V08650E → INC. 7239-7240 EXC. 8630)	4-250
GM 2.4L ENGINE, GASOLINE - 2010 SERIES	4-254
GM 2.4L ENGINE, LPG - 2010 SERIES	4-238
GM 2.4L ENGINE, LPG - WITH LOW FUEL SENSOR	4-242
HYDRAULIC OIL COOLER - THREE OR FOUR FUNCTION (OPTIONAL)	4-274
LIGHTS (→ S/N F187V07342D)	4-268
LIGHTS (S/N F187V07343D ↔ 6/2007)	4-270
LIGHTS (6/2007 →)	4-272
SEALED ALTERNATOR - GM 2,4L	4-228
SEAT JUMPER (→ S/N F187V15996H EXC. 15948)	4-158
TRANSMISSION - SINGLE SPEED (→ S/N F187V07304D)	4-262
TRANSMISSION - SINGLE SPEED (GM) (S/N F187V07305D →)	4-264
TRANSMISSION - SINGLE SPEED (MAZDA)	4-266
WIRE HARNESS (CHASSIS)	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG (S/N F187V07305D ↔ S/N F187V09002E 2.0L) (S/N F187V07305D ↔ S/N F187V08715E 2.2L)	4-80
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007-2010 EMISSION COMPLIANT ENGINES (S/N F187V08716E → 2.2L) (S/N F187V09003E → 2.0L)	4-86
WIRE HARNESS (ENGINE)	
MAZDA 2.0L AND 2.2L LPG (→ S/N F187V07304D)	4-210
MAZDA 2.0L AND 2.2L LPG (S/N F187V07305D ↔ S/N F187V8715E 2.2L) (S/N F187V07305D ↔ S/N F187V09002E 2.0L)	4-212
MAZDA 2.0L AND 2.2L LPG - 2007-2009 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	4-214
MAZDA 2.0L AND 2.2L LPG - 2010 SERIES	4-220
MAZDA 2.0L AND 2.2L, GASOLINE (→ S/N F187V07304D)	4-192
MAZDA 2.0L AND 2.2L, GASOLINE (S/N F187V07305D ↔ S/N F187V08715E 2.2L) (S/N F187V07305D ↔ S/N F187V09002E 2.0L)	4-196
MAZDA 2.0L AND 2.2L, GASOLINE - 2007 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	4-200
MAZDA 2.0L AND 2.2L, GASOLINE - 2010 SERIES	4-206
WIRE HARNESS (SEALED ALTERNATOR)	
MAZDA 2.0L AND 2.2L, GASOLINE AND LPG - 2007 EMISSION COMPLIANT ENGINES (S/N F187V09003E → (2.0 L)) (S/N F187V08716E → (2.2L))	4-226
WIRE HARNESS ADAPTER	
LOW FUEL PRESSURE	4-276
WORK, REAR DRIVE, AND BRAKE/TAIL LIGHTS	4-72