

PARTS MANUAL

**H40-70FT
(N177)**

CUSTOMER EDITION

HYSTER

SECTIONS

1	FRAME
2	ENGINE ASSEMBLY - MAZDA
3	ENGINE ASSEMBLY - YANMAR
4	ENGINE ASSEMBLY-KUBOTA
5	FUEL SYSTEM - DIESEL
6	FUEL SYSTEM - GAS/LPG
7	ELECTRICAL SYSTEM
8	TRANSMISSION
9	DRIVE AXLE
10	STEERING SYSTEM
11	BRAKE SYSTEM
12	HYDRAULIC SYSTEM
13	MAST-TWO STAGE LIMITED FREE-LIFT
14	MAST-TWO STAGE FULL FREE-LIFT
15	MAST-THREE STAGE FULL FREE-LIFT
16	OPTIONS
17	FIELD CONVERSION KITS

This Parts Manual is divided into 18 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

18

NUMERICAL INDEX

This Parts Manual is divided into 18 major sections which are listed above. Quick reference to these sections can be made by placing the right thumb on the tab of the desired section, bending the book back and thumbing the pages to the corresponding tab.

TABLE OF CONTENTS

DESCRIPTION	PAGE
A	
ACCUMULATOR AND ATTACHING PARTS	16-10
ADD ON FORK POSITIONER KITS	17-5
ADD ON OPTION KITS	17-4
ADD ON TELEMETRY KITS	17-5
AIR CONDITIONER COMPRESSOR	
KUBOTA 2.5 LPG	1-50
AIR FILTER ASSEMBLY	
MAZDA 2.2L, GASOLINE AND LPG	6-8
YANMAR 2.6L AND 3.3L DIESEL	5-4
AIR INTAKE AND FILTER SYSTEM	
KUBOTA 2.5L LPG	6-6
MAZDA 2.2L LPG	6-4
MAZDA 2.2L, GASOLINE	6-2
YANMAR 2.6L AND 3.3L DIESEL - WITHOUT AUXILIARY INTAKE SILENCER	5-2
AIR INTAKE SYSTEM	
PRE-CLEANER AND DUCT	5-5
ALTERNATOR AND MOUNTING	
YANMAR 2.6L AND 3.3L - DIESEL	7-20
ALTERNATOR AND PULLEY ASSEMBLY	
KUBOTA 2.5L	4-42
ARMREST ASSEMBLY	
MINI-LEVER MODULES - SEMI-SUSPENSION SEAT WITH HIP RESTRAINTS	1-40
MINI-LEVER MODULES - FULL SUSPENSION SEAT	1-42
ASSEMBLED ENGINE	
MAZDA 2.2L, GASOLINE AND LPG	2-16
AUXILIARY ONE AND TWO	
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION	12-32
AUXILIARY QUICK DISCONNECT MANIFOLD AND HOSES	
THREE STAGE FULL FREE-LIFT (DUAL AUXILIARY WITH E-HYDRAULICS - THREE AND FOUR FUNCTION)	16-30
THREE STAGE FULL FREE-LIFT (SINGLE AUXILIARY WITH E-HYDRAULICS - THREE FUNCTION)	16-26
THREE STAGE FULL FREE-LIFT (SINGLE AUXILIARY WITH INTEGRAL SIDE-SHIFT AND E-HYDRAULICS) - FOUR FUNCTION	16-28
TWO STAGE LIMITED FREE-LIFT (DUAL AUXILIARY WITH E-HYDRAULICS) - THREE AND FOUR FUNCTION	16-24
TWO STAGE LIMITED FREE-LIFT (SINGLE AUXILIARY WITH E-HYDRAULICS) - THREE FUNCTION	16-20
TWO STAGE LIMITED FREE-LIFT (SINGLE AUXILIARY WITH INTEGRAL SIDE-SHIFT AND E-HYDRAULICS) - FOUR FUNCTION	16-22
AUXILIARY TUBES	
THREE STAGE FULL FREE-LIFT - MANUAL AND E-HYDRAULICS VALVE WITH QUICK DISCONNECT	16-16
THREE STAGE FULL FREE-LIFT - MANUAL AND E-HYDRAULICS VALVE WITHOUT QUICK DISCONNECT	16-18
TWO STAGE LIMITED FREE LIFT - WITH MANUAL AND E-HYDRAULICS VALVE WITHOUT QUICK DISCONNECT	16-12

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
TWO STAGE LIMITED FREE LIFT - MANUAL AND E-HYDRAULIC VALVE WITH QUICK DISCONNECT	16-14
AUXILLIARY HOSES	
THREE STAGE FULL FREE LIFT - TWO STAGE LIMITED FREE-LIFT	12-14
AXLE HOUSING	
WET BRAKE (→ S/N N177V03520M)	9-6
WET BRAKE (S/N N177V03521M →)	9-18
B	
BACK-UP ALARM	16-4
BATTERY CABLES	
2.5L LPG	7-26
BEVEL GEAR	
WET BRAKE (→ S/N N177V03520M)	9-4
WET BRAKE (S/N N177V03521M →)	9-20
BRAKE ASSEMBLY	
DRY BRAKE	11-6
BRAKE COOLING SYSTEM	
SINGLE AND DUAL PEDAL WET BRAKE - WITH SINGLE SPEED TRANSMISSION	11-10
BRAKE LINKAGE	
DUAL PEDAL - DRY BRAKE	11-4
DUAL PEDAL - WET BRAKE	11-14
SINGLE PEDAL - DRY BRAKE	11-2
SINGLE PEDAL - WET BRAKE	11-12
BRAKE MASTER CYLINDER ASSEMBLY	
DRY BRAKE	11-9
WET BRAKE	11-16
BRAKE PEDAL CONVERSION KITS	17-2
C	
CAB	
AIR CONDITIONER	1-64
CONDENSER ASSEMBLY - CAB (WITH A/C)	1-82
FRAME AND ATTACHING PARTS - WITHOUT A/C	1-84
FRAME AND ATTACHING PARTS - CAB WITH A/C	1-86
HEATER	1-66
INTERIOR PANELS	1-80
LH DOOR	1-58
RH DOOR AND HEATER ASSEMBLY	1-60
SLIDING REAR WINDOW	1-78
WINDOW - LEFT HAND DOOR	1-74
WINDOW - RIGHT HAND DOOR	1-76
WINDOWS AND WINDOW WIPER SYSTEM	1-70
WITH A/C	1-54
WITHOUT A/C	1-52
CAB ATTACHING PARTS	
WITH A/C	1-56
CAB DOORS	
PVC	1-68

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
CAB WITH STEEL DOORS	
HEATER - WITHOUT A/C	1-63
CAMSHAFT AND DRIVE GEAR	
YANMAR 2.6L AND 3.3L - DIESEL	3-18
CAMSHAFT AND VALVES	
MAZDA 2.2L, GASOLINE AND LPG	2-22
CAMSHAFT ASSEMBLY	
KUBOTA 2.5L	4-50
CARRIAGE	
THREE STAGE FULL FREE-LIFT	15-30
TWO STAGE FULL FREE-LIFT	14-22
TWO STAGE LIMITED FREE-LIFT	13-16
CHARGE PUMP ASSEMBLY	8-31
CONTROL VALVE ASSEMBLY	
LOW PRESSURE	8-30
MANUAL CONTROL - THREE AND FOUR FUNCTION	12-24
CONTROL VALVE LOCKOUT GROUP	
MANUAL CONTROL VALVE	12-26
COOLING REPAIR KITS	17-2
COOLING SYSTEM	
KUBOTA 2.5L - WITHOUT AIR OIL COOLER	4-8
KUBOTA 2.5L - WITH AIR OIL COOLER	4-10
MAZDA 2.2L, GASOLINE AND LPG, SQUARE WAVE RADIATOR - BASIC POWERSHIFT TRANSMISSION	2-2
MAZDA 2.2L, GASOLINE AND LPG, SQUARE WAVE RADIATOR - ELECTRONIC TRANSMISSION, EXTERNAL OIL COOLER, OR WET BRAKE	2-6
MAZDA 2.2L, GASOLINE SERPENTINE RADIATOR - BASIC POWERSHIFT TRANSMISSION	2-4
YANMAR 2.6L AND 3.3L, DIESEL, SQUARE WAVE RADIATOR - WITH INTERNAL OIL COOLER	3-2
YANMAR 2.6L AND 3.3L, DIESEL, SQUARE WAVE RADIATOR - WITH EXTERNAL OIL COOLER	3-4
COUNTER/REVERSE CLUTCH	
SINGLE SPEED TRANSMISSION	8-28
COUNTERWEIGHT	1-3
COVER ASSEMBLY	
KUBOTA 2.5L	4-34
COWL ELECTRICAL	
ELECTRO-HYDRAULIC	7-8
MANUAL HYDRAULIC - WITH OPERATOR PRESENCE SYSTEM	7-6
COWL MOUNT	1-18
CRANKSHAFT AND PISTON ASSEMBLY	
KUBOTA 2.5L	4-30
CRANKSHAFT AND PISTONS	
MAZDA 2.2L, GASOLINE AND LPG	2-24
YANMAR 2.6L AND 3.3L - DIESEL	3-20
CRANKSHAFT BEARING ASSEMBLY	
KUBOTA 2.5L	4-28
CYLINDER BLOCK	
MAZDA 2.2L, GASOLINE AND LPG	2-20
YANMAR 2.6 AND 3.3L - DIESEL	3-12

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
CYLINDER BLOCK ASSEMBLY	
KUBOTA 2.5L	4-16
CYLINDER HEAD	
MAZDA 2.2L, GASOLINE AND LPG	2-18
YANMAR 2.6L AND 3.3L - DIESEL	3-14
CYLINDER HEAD ASSEMBLY	
KUBOTA 2.5L	4-20
CYLINDER HEAD COVER ASSEMBLY	
KUBOTA 2.5L	4-22
D	
DASH PANEL AND STEERING COLUMN COVER	1-14
DIFFERENTIAL	
DRY BRAKE	9-36
WET BRAKE (→ S/N N177V03520M)	9-8
WET BRAKE (S/N N177V03521M →)	9-22
DIPSTICK TUBE ASSEMBLY	
KUBOTA 2.5L	4-25
DIRECTIONAL CONTROL CONVERSION	17-2
DRIVE AXLE	
DRY BRAKE - SHEET 1 OF 3	9-30
DRY BRAKE - SHEET 2 OF 3	9-32
DRY BRAKE - SHEET 3 OF 3	9-34
DRIVE AXLE AND ATTACHING PARTS	
DRY BRAKE	9-28
WET BRAKE (→ S/N N177V03520M)	9-2
WET BRAKE (S/N N177V03521M →)	9-16
DRIVE TIRE AND WHEEL	
PNEUMATIC RADIAL	9-42
SINGLE	9-38
WIDE TREAD	9-40
DUAL DRIVE WHEELS AND TIRES	9-44
E	
ECU ASSEMBLY	
KUBOTA 2.5L	4-48
E-HYDRAULIC CONTROL CONVERSION KITS	17-2
ELECTRICAL SYSTEM	
RH CHASSIS	7-4
ELECTRONIC PRESSURE REGULATOR ASSEMBLY	
MAZDA 2.2L LPG	6-24
ELECTRONIC PRESSURE REGULATOR KIT	
MAZDA 2.2L LPG	6-26
EMISSION CONTROL SYSTEM	
MAZDA 2.2L, GASOLINE	2-26
ENGINE COOLING	
YANMAR 2.6L AND 3.3L - DIESEL	3-28
ENGINE COOLING SYSTEM	
MAZDA 2.2L, GASOLINE AND LPG	2-42

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
ENGINE ELECTRICAL COMPONENTS	
MAZDA 2.2L, GASOLINE AND LPG	7-10
ENGINE ELECTRICAL SYSTEM	
YANMAR DIESEL	7-14
ENGINE FUEL SYSTEM	
MAZDA 2.2L, GASOLINE	2-30
ENGINE MOUNT	
KUBOTA 2.5L LPG	4-14
ENGINE MOUNTING	2-12
YANMAR 2.6 AND 3.3L	3-8
ENGINE WIRE HARNESS AND ATTACHING PARTS	
2.5L KUBOTA LPG - SINGLE SPEED TRANSMISSION	7-18
EXHAUST	
YANMAR 2.6 AND 3.3L DIESEL - WITHOUT CATALYTIC CONVERTER	3-6
EXHAUST MANIFOLD	
MAZDA 2.2L, GASOLINE AND LPG	2-32
EXHAUST MANIFOLD ASSEMBLY	
KUBOTA 2.5L	4-40
EXHAUST SYSTEM	
WITH CATALYTIC CONVERTER - KUBOTA 2.5L	4-4
EXHAUST SYSTEM WITH CATALYTIC CONVERTER	
MAZDA 2.2L, GASOLINE AND LPG	2-8
EXHAUST WRAPS	
KUBOTA 2.5L LPG	4-6
F	
FAN ASSEMBLY	
MAZDA	2-10
YANMAR 2.6 AND 3.3L	3-9
FAN PULLEY ASSEMBLY	
KUBOTA 2.5L	4-47
FENDER EXTENSIONS	1-16
FIRE EXTINGUISHER	16-8
FLANGE BREATHER ASSEMBLY	
KUBOTA 2.5L	4-32
FLOORPLATES AND COVERS	1-10
FLYWHEEL AND HOUSING	
2.2 L - GASOLINE AND LPG	2-14
YANMAR 2.6L AND 3.3L - DIESEL	3-10
FLYWHEEL HOUSING AND STARTER	
KUBOTA 2.5L LPG	4-12
FORK POSITIONER ASSEMBLY	16-50
FORKS	1-46
OPTIONAL	1-48
FREE-LIFT	
TWO STAGE FULL FREE- LIFT	14-12
FREE-LIFT CYLINDER	
THREE STAGE FULL FREE-LIFT	15-22
TWO STAGE FULL FREE- LIFT	14-15

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
FREE-LIFT CYLINDER AND ATTACHING PARTS	
THREE STAGE FULL FREE-LIFT	15-18
FUEL FILTER AND WATER SEPARATOR	
YANMAR 2.6L AND 3.3L - DIESEL	5-10
FUEL INJECTION SYSTEM	
YANMAR 2.6L AND 3.3L - DIESEL	5-8
FUEL PUMP AND SENDER	
MAZDA 2.2L, GASOLINE	6-14
FUEL SUPPLY SYSTEM	
MAZDA 2.2L LPG	6-16
MAZDA 2.2L, GASOLINE	6-12
FUEL SYSTEM	
KUBOTA 2.5L LPG	6-27
MAZDA 2.2L LPG	6-10
MAZDA 2.2L, GASOLINE	6-9
YANMAR 2.6L AND 3.3L - DIESEL	5-6
FUEL SYSTEM HOSES AND ATTACHING PARTS	
MAZDA 2.2L LPG	6-18
FUEL SYSTEM SENSORS	
MAZDA 2.2L LPG	7-12
FULL SUSPENSION SEAT	
RECLINER AND DAMPER KITS - SHEET 2 OF 3	1-36
SERVICE KITS FOR NON SWIVEL AND SWIVEL - SHEET 3 OF 3	1-38
WITH ELECTRO-HYDRAULIC CONTROLS - SHEET 1 OF 3	1-28
WITH MANUAL HYDRAULIC CONTROLS - SHEET 1 OF 3	1-32
G	
GEAR CASE ASSEMBLY	
KUBOTA 2.5L - 280 MM FAN HEIGHT	4-54
GEAR HOUSING	
YANMAR 2.6L AND 3.3L - DIESEL	3-24
GEAR PUMP ASSEMBLY	
HIGH PRESSURE	12-6
LOW PRESSURE - CHAIN DRIVE OPTION	12-4
H	
HAND LEVERS	
FOUR FUNCTION - WITH DETENTED LEVERS	12-20
FOUR FUNCTION - WITHOUT DETENTED LEVERS	12-22
THREE FUNCTION - WITH DETENTED LEVERS	12-16
THREE FUNCTION - WITHOUT DETENTED LEVERS	12-18
HEADER HOSE AND ATTACHING PARTS	
TWO STAGE LIMITED FREE-LIFT	13-12
HEADER HOSE CONVERSION KITS	
HEADER HOSES	
TWO STAGE FULL FREE-LIFT	14-18
HEADER HOSES AND ATTACHING PARTS	
THREE STAGE FULL FREE-LIFT - THREE AND FOUR FUNCTION	15-26

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
HEATER HOSE 2.5L KUBOTA LPG	1-22
HEATER HOSES MAZDA, GASOLINE	1-19
MAZDA, LPG	1-20
YANMAR DIESEL	1-21
HOOD ASSEMBLY	1-6
HYDRAULIC CONTROL CONVERSIONS	
HYDRAULIC CONTROL VALVE ELECTRONIC VALVE ASSEMBLY - THREE AND FOUR FUNCTION	12-35
ELECTRONIC VALVE AUXILIARY ONE SECTION - THREE AND FOUR FUNCTION	12-44
ELECTRONIC VALVE AUXILIARY TWO SECTION - FOUR FUNCTION	12-46
ELECTRONIC VALVE INLET SECTION - THREE AND FOUR FUNCTION	12-37
ELECTRONIC VALVE TILT SECTION - THREE AND FOUR FUNCTION	12-42
HYDRAULIC CONTROL VALVE (ELECTRO-HYDRAULIC) THREE AND FOUR FUNCTION - POPPET VALVES	12-40
HYDRAULIC FILTER	12-8
HYDRAULIC HOSES LIFT, TILT, AND AUXILIARY	12-10
HYDRAULIC SUPPLY AND RETURN WITH ALUMINUM TRANSMISSION - WITH CHAIN DRIVE	12-2
I	
IGNITION COIL ASSEMBLY KUBOTA 2.5L	4-33
IMPACT SENSOR	7-34
INNER MAST THREE STAGE FULL FREE-LIFT	15-8
TWO STAGE FULL FREE- LIFT	14-4
TWO STAGE LIMITED FREE LIFT	13-4
INPUT/FORWARD CLUTCH SINGLE SPEED TRANSMISSION	8-26
INSTRUMENT CLUSTER	7-36
INTAKE AND EXHAUST MANIFOLD YANMAR 2.6L AND 3.3L - DIESEL	3-22
INTAKE MANIFOLD MAZDA 2.2L, GASOLINE	2-34
MAZDA 2.2L LPG	2-36
INTAKE MANIFOLD ASSEMBLY KUBOTA 2.5L	4-38
INTEGRAL SIDE-SHIFT FORK POSITIONER - TWO STAGE LIMITED FREE-LIFT	16-46
FORK POSITIONER - THREE STAGE FULL FREE-LIFT	16-48
INTEGRAL SIDE-SHIFT CARRIAGE THREE STAGE FULL FREE-LIFT	16-34
TWO STAGE FULL FREE-LIFT	16-38
TWO STAGE LIMITED FREE-LIFT	16-32
INTEGRAL SIDE-SHIFT CYLINDER	16-44

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
INTEGRAL SIDE-SHIFT HYDRAULIC HOSES	
THREE STAGE FULL FREE LIFT	16-41
TWO STAGE FULL FREE- LIFT	16-42
TWO STAGE LIMITED FREE-LIFT	16-40
INTERMEDIATE MAST	
THREE STAGE FULL FREE-LIFT	15-6
L	
LABELS	
EXTERIOR	1-90
HYDRAULIC CONTROL LABELS - MANUAL HYDRAULIC	1-94
INTERIOR	1-92
LIGHT KITS	17-3
LIGHTS	
STOP, TAIL, TURN, BACKUP, AND STROBE - WITH CAB	7-44
STOP, TAIL, TURN, BACKUP, AND STROBE - WITH OVERHEAD GUARD	7-46
LOAD BACKREST EXTENSION	1-44
LOAD WEIGH ELECTRICAL	7-32
LPG FUEL GROUP KUBOTA	
PREMIUM LOW FUEL SENSOR - SECTION 1 OF 2	6-33
PREMIUM LOW FUEL SENSOR - SECTION 2 OF 2	6-34
STANDARD LOW FUEL SENSOR - SECTION 1 OF 2	6-36
STANDARD LOW FUEL SENSOR - SECTION 2 OF 2	6-38
LPG TANK BRACKET	
SWING OUT	6-28
SWING OUT, DROP DOWN	6-30
LUBRICATION SYSTEM	
YANMAR 2.6L AND 3.3L - DIESEL	3-30
M	
MAIN LIFT	
TWO STAGE FULL FREE- LIFT	14-6
TWO STAGE LIMITED FREE LIFT	13-6
MAIN LIFT CYLINDER	
THREE STAGE FULL FREE-LIFT	15-14
TWO STAGE LIMITED FREE LIFT	13-8
MAIN LIFT CYLINDER - LH	
TWO STAGE FULL FREE- LIFT	14-10
MAIN LIFT CYLINDER - RH	
TWO STAGE FULL FREE- LIFT	14-8
MAIN LIFT CYLINDER AND ATTACHING PARTS	
THREE STAGE FULL FREE-LIFT	15-10
MANUAL VALVE ANTI STALL GROUP	
SINGLE SPEED TRANSMISSION	12-28
MAP SENSOR	
MAZDA 2.2L, LPG	2-28
MAST ELECTRICAL	7-30
MINI LEVER MODULE LABELS	
HYDRAULIC CONTROL FUNCTIONS	1-96

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
MINI-LEVER CONTROLS	
WITH ARMREST - THREE FUNCTION	7-38
WITH ARMREST - FOUR FUNCTION	7-40
MIRRORS	
WITH CAB	16-6
WITH OVERHEAD GUARD	16-7
MIXER AND THROTTLE BODY ASSEMBLY	
MAZDA 2.2L LPG	6-22
O	
OIL COOLER ASSEMBLY	
KUBOTA 2.5L - 280 MM FAN HEIGHT	4-41
OIL FILTER ASSEMBLY	
KUBOTA 2.5L	4-24
OIL PAN	
YANMAR 2.6L AND 3.3L - DIESEL	3-26
OIL PAN ASSEMBLY	
KUBOTA 2.5L	4-18
OIL PUMP AND FILTER	
MAZDA 2.2L, GASOLINE AND LPG	2-40
OIL PUMP ASSEMBLY	
KUBOTA 2.5L	4-26
OUTER MAST	
THREE STAGE FULL FREE LIFT	15-2
TWO STAGE FULL FREE LIFT	14-2
TWO STAGE LIMITED FREE-LIFT	13-2
OUTLET SECTION	
ELECTRONIC CONTROL VALVE - THREE AND FOUR FUNCTION	12-48
MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION	12-34
OVERHEAD GUARD	1-4
P	
PARK BRAKE ASSEMBLY	11-18
PARKING BRAKE	
WET BRAKE (→ S/N N177V03520M)	9-10
WET BRAKE (S/N N177V03521M →)	9-24
POWER DISTRIBUTION MODULE	7-24
R	
RAIN TOP	1-88
S	
SEALED ALTERNATOR AND MOUNTING	
YANMAR 2.6 AND 3.3L	7-22
SEAT	
NON SUSPENSION - WITH MANUAL HYDRAULIC CONTROLS	1-24
SEMI SUSPENSION - WITH MANUAL AND ELECTRO-HYDRAULIC CONTROLS	1-26
SEAT BELT SWITCH ADAPTER	7-42
SEAT CONVERSION KITS	17-2
STATOR SUPPORT HOUSING	8-24

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
STEER AXLE	10-12
STEER CYLINDER	10-14
STEER TIRES AND WHEELS	
H40-50FT	10-16
H40-70FT	10-18
STEERING COLUMN AND ATTACHING PARTS	
ISOLATED - DIESEL	10-3
NON-ISOLATED - GASOLINE AND LPG	10-2
STEERING COLUMN ASSEMBLY	
ISOLATED, DIESEL	10-6
NON-ISOLATED - GASOLINE AND LPG	10-4
STEERING CONTROL UNIT	10-8
STEERING LINES	10-10
STROBE LIGHT	
LED	16-2
T	
THROTTLE BODY AND ATTACHING PARTS	
MAZDA 2.2L, GASOLINE	6-20
THROTTLE CABLE ASSEMBLY	
YANMAR 2.6L AND 3.3L - DIESEL	5-12
THROTTLE PEDAL ASSEMBLY AND ATTACHING PARTS	
MONOTROL	5-18
MONOTROL	6-42
STANDARD PEDAL	5-16
STANDARD PEDAL	6-40
THROTTLE POSITION SENSOR AND ATTACHING PARTS	
YANMAR 2.6L AND 3.3L DIESEL	5-14
TILT CYLINDER AND MAST INSTALLATION	12-50
TILT CYLINDERS	
H40-50FT	12-52
H60-70FT	12-54
TIMING GEAR COVER AND OIL PAN	
MAZDA 2.2L, GASOLINE AND LPG	2-38
TORQUE CONVERTER	
MAZDA	8-14
YANMAR AND KUBOTA ENGINES	8-16
TORQUE CONVERTER HOUSING AND ATTACHING PARTS	
SINGLE SPEED - ALUMINUM CHAIN DRIVE	8-22
TRANSMISSION COOLING	
KUBOTA 2.5L LPG - SQUARE WAVE WITHOUT OIL COOLER WITH SINGLE SPEED TRANSMISSION	8-10
KUBOTA 2.5L LPG - SQUARE WAVE WITH OIL COOLER WITH SINGLE SPEED TRANSMISSION	8-12
MAZDA 2.2L, GASOLINE AND LPG - SERPENTINE AND SQUARE WAVE	8-2
MAZDA 2.2L, GASOLINE AND LPG - WITH AIR COOLER	8-4
YANMAR 2.6L AND 3.3L DIESEL - SQUARE WAVE WITH INTERNAL AIR COOLER	8-6
YANMAR 2.6L AND 3.3L DIESEL - SQUARE WAVE WITH EXTERNAL OIL COOLER	8-8
TRANSMISSION ELECTRICAL	
SINGLE SPEED	7-28

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
TRANSMISSION HOUSING AND ASSEMBLY SINGLE SPEED - ALUMINUM CHAIN DRIVE	8-20
TRANSMISSION MOUNT SINGLE SPEED - ALUMINUM CHAIN DRIVE	8-18
TREAD CONVERSION KITS	17-4
V	
VALVE AND ROCKER ARM ASSEMBLY KUBOTA 2.5L	4-36
VALVE ASSEMBLY, LIFT AND TILT MANUAL CONTROL VALVE - THREE AND FOUR FUNCTION	12-30
W	
WATER FLANGE AND THERMOSTAT ASSEMBLY KUBOTA 2.5L	4-44
WATER PUMP ASSEMBLY KUBOTA 2.5L	4-46
WEATHER PROTECTION KITS	17-2
WET BRAKES → S/N N177V03520M	9-12
S/N N177V03521M →	9-25
WHEEL HUB WET BRAKE (→ S/N N177V03520M)	9-14
WET BRAKE (S/N N177V03521M →)	9-26
WIRE HARNESS ADAPTER - LOW FUEL PRESSURE	7-120
AIR CONDITIONER	7-122
AIR CONDITIONING JUMPER	7-121
ALTERNATOR - DIESEL	7-124
ALTERNATOR TO BATTERY DISCONNECT SWITCH - KUBOTA 2.5L	7-130
COWL WITH FORWARD/REVERSE LEVER - WITHOUT RETURN TO SET TILT	7-104
COWL WITH FORWARD/REVERSE LEVER - WITH HYDRAULIC PUMP SOLENOID	7-108
COWL WITH MONOTROL PEDAL - WITH RETURN TO SET TILT	7-100
COWL WITH MONOTROL PEDAL - WITH HYDRAULIC PUMP SOLENOID	7-112
ELECTRONIC CONTROL VALVE - THREE FUNCTION	7-116
ELECTRONIC CONTROL VALVE - FOUR FUNCTION	7-118
ENGINE - YANMAR 2.6L AND 3.3L, DIESEL	7-96
LIGHTS WITH OVERHEAD GUARD	7-132
RH CHASSIS - MAZDA 2.2L	7-48
RH CHASSIS - KUBOTA 2.5L	7-60
RH CHASSIS - YANMAR 2.6L AND 3.3L, DIESEL	7-72
RH CHASSIS WITH SEAT BELT SEQUENCE MODULE - MAZDA 2.2L	7-54
RH CHASSIS WITH SEAT BELT SEQUENCE MODULE - KUBOTA 2.5L LPG	7-66
RH CHASSIS WITH SEAT BELT SEQUENCE MODULE - YANMAR 2.6L AND 3.3L, DIESEL	7-78
SEALED ALTERNATOR - YANMAR 2.6L AND 3.3L, DIESEL	7-126
TRANSMISSION - SINGLE SPEED	7-128
WIRE HARNESS (ENGINE) KUBOTA 2.5L LPG	7-92
MAZDA 2.2L LPG	7-88

TABLE OF CONTENTS (continued)

DESCRIPTION	PAGE
MAZDA 2.2L, GASOLINE	7-84
WIRE HARNESS ASSEMBLY	
KUBOTA 2.5L	4-52

ABBREVIATIONS QUICK REFERENCE SHEET

Listed below are abbreviations used in parts manuals to denote the following expressions:

TERM	DEFINITION	TERM	DEFINITION
Amp	Amperes	FRE	Freezer Environment
AR	As Required	in.	inches
BDI	Battery Discharge Indicators	LPG	Liquefied Petroleum Gas
BWI	Brush Wear Indicator	MAP	Manifold Absolute Pressure
CE	Communicator End	mm	millimeters
CRE	Corrosive Environment	MSTS	Microprocessor Spark Timing System
D/B	Date Break	NPT	National Pipe Threads
dbA	Decibel "A" Scale	O/S	Oversize
DE	Drive End	PTO	Power Take Off
ECH	Empty Container Handler	RPM	Revolutions per Minute
ECH-3	Empty Container Handler - 3 High Stacking	S/N	Serial Number
ECH-4	Empty Container Handler - 4 High Stacking	TMM	Truck Management Module
ECH-5	Empty Container Handler - 5 High Stacking	UL Type D	Diesel-Powered Safety Rating
ECH-6	Empty Container Handler - 6 High Stacking	UL Type DS	Diesel-Powered Safety Rating
ECH-7	Empty Container Handler - 7 High Stacking	UL Type E	Battery-Powered Safety Rating
ECM	Electronic Control Module	UL Type EE	Battery-Powered Safety Rating
ECN	Engineering Change Notice	UL Type ES	Battery-Powered Safety Rating
EEPROM	Electrically Erasable Programmable Read Only Memory	UL Type G	Gasoline-Powered Safety Rating
EPA	US Environmental Protection Agency	UL Type GS	Gasoline-Powered Safety Rating
EPROM	Electrically Programmable Read Only Memory	UL Type LP	Gas-Powered Safety Rating
		UL Type LPS	LP Gas-Powered Safety Rating
		U/S	Undersize
		UL	Underwriters Laboratory
		V	Volts