

HP8587

-UN-18MAY99



*JOHN DEERE 9550 SELF-PROPELLED COMBINE™ WITH 90 SERIES CORN HEAD
MANUFACTURED (1999-)*

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS, USA. ALL RIGHTS RESERVED.

NOTE

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC1223.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2210.

FOR 918 AND 920 DRAPER PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2212.

FOR 90 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2404.

FOR 900R & F SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2771.

FOR 914P BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2772.

IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 9550 AND 9550 SIDEHILL SELF-PROPELLED COMBINE.

VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE

RGP5307

-UN-21JUN99



RGP5307

FIRST LINE

RG - WATERLOO ENGINE WORKS

6

081 (8.1 LITERS)

H - AIR-TO-AIR

H

XXXXXX

SECOND LINE

6081HH008

6081HH009

DEFINES

DESIGNATES ENGINE MANUFACTURER.

DESIGNATES NUMBER OF CYLINDERS.

DESIGNATES LITER DISPLACEMENT.

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

DESIGNATES HARVESTER VEHICLE.

DESIGNATES ENGINE SERIAL NUMBER.


APPLICATION

9550

9550 SIDEHILL

SHORT BLOCK SERIAL NUMBER IDENTIFICATION

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490995

- | | |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED | 09 |
| 3. DESIGNATES YEAR ASSEMBLED | 95 |

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

PRODUCT INFORMATION NUMBER (PIN) PLATE

THE PRODUCT IDENTIFICATION NUMBER (PIN) PLATE IS LOCATED NEAR THE RIGHT-HAND SIDE OF THE TOOL BOX. AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

HO9550X685000
COMBINE

(FIRST LINE)

HO - MANUFACTURING UNIT (HARVESTER WORKS)

9550 - MODEL IDENTIFIER

X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX

900000 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

COMBINE - TYPE OF PRODUCT

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

KITS

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™
DIAL-A-MATIC™
HARVESTRAK™
CONTOUR MASTER™

POSI-TORQ™
TORQ-GARD SUPREME®
QUIK-TATCH™

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

FUNCTION CODE

(EXAMPLE - FC: 5000)

FUNCTION CODES ARE LOCATED ON EACH PAGE IN THE UPPER RIGHT-HAND CORNER IN THE BOX. THE CODE LISTED IS A GROUPING CODE THAT CAN BE USED FOR WARRANTIES AND FOR DTAC TO IDENTIFY CERTAIN AREAS.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SECTION INDEX

SECTION 10 - GENERAL INFORMATION

SECTION 20 - ENGINE ACCESSORIES

SECTION 25 - ENGINE

SECTION 30 - FUEL AND AIR

SECTION 40 - ELECTRICAL

SECTION 50 - POWER TRAIN

SECTION 60 - STEERING AND BRAKES

SECTION 70 - HYDRAULICS

SECTION 80 - BODY AND SHIELDS

SECTION 90 - OPERATOR'S STATION

SECTION 95 - AIR CONDITIONING AND HEATING

SECTION 100 - FEEDER HOUSE

SECTION 110 - THRESHING AND SEPARTION

SECTION 120 - CLEANING SHOE

SECTION 125 - ELEVATORS

SECTION 130 - RESIDUE DISPOSAL

SECTION 135 - SIDEHILL LEVELING

SECTION 140 - DRIVES

SECTION 150 - GRAIN TANK AND UNLOADING AUGER

SECTION 155 - GREENSTAR YIELD MAPPING AND MONITOR SYSTEMS

SECTION 160 - RUBBER TRACK SYSTEM

SECTION 170 - DECALS

SECTION 180 - NUMERICAL INDEX

ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
	A				
3D11	A/C COMPRESSOR MANIFOLD.....	95 - 11	3B21	ARMREST, OPERATOR'S SEAT	90 - 20
3D11	A/C COMPRESSOR R134A	95 - 11	3B13	ASHTRAY.....	90 - 12
1H5	ACCESS COVER FUEL INJECTION PUMP	40 - 58	2F23	ASSEMBLY, SIX STACK SOLENOID VALVE	70 - 14
2J18	ACCESS PLATFORM, ENGINE	80 - 38	2E16	ATTENUATOR, STEERING HOSES.....	60 - 16
2G18	ACCUMULATOR AND MOUNTING, ONE GALLON	70 - 34	4F9	AUGER DRIVE, UPPER TAILINGS AND SHIELD.....	140 - 54
2G20	ACCUMULATOR PRESSURE GAUGE AND WIRING HARNESS	70 - 36	3I23	AUGER HOUSING, LOADING, UPPER CLEAN GRAIN	125 - 8
2G16	ACCUMULATOR, ONE HALF GALLON	70 - 32	1G17	AUGER LIGHT, UNLOADING	40 - 44
4I19	ACCUMULATOR, TENSION CYLINDER	160 - 26	4G5	AUGER MOUNTING, UNLOADING, SWING	150 - 16
3C11	ACTIVE HEADER HEIGHT CONTROL DISPLAY, R.H. CORNERPOST PANEL.....	90 - 36	4G9	AUGER SWIVEL SUPPORT AND BRACES	150 - 20
2G7	ACTIVE HEADER HEIGHT CONTROL HYDRAULIC LINE AND VALVE BLOCK	70 - 22	3J9	AUGER TROUGH, LOWER TAILINGS.....	125 - 18
1H19	ACTUATOR, STRAW WALKING SENSING SWITCH	40 - 73	3I19	AUGER, CLEAN GRAIN LOWER	125 - 4
1D10	ADAPTER, OIL COOLER	25 - 30	4G23	AUGER, CROSS, COVERS AND CHANNEL.....	150 - 34
1D9	ADAPTER, OIL COOLER BYPASS	25 - 29	4G21	AUGER, GRAIN TANK CROSS	150 - 32
2B6	ADAPTER, TRANSMISSION.....	50 - 2	4G1	AUGER, GRAIN TANK, VERTICAL UNLOADING	150 - 12
1D4	ADHESIVE, ROCKER ARM COVER GASKET	25 - 23	4G17	AUGER, HORIZONTAL UNLOADING.....	150 - 28
4I1	ADJUSTABLE IDLER ASSEMBLY AND FRONT ARM ..	160 - 6	3J1	AUGER, LOADING, CLEAN GRAIN	125 - 10
2B8	ADJUSTABLE REAR AXLE.....	50 - 4	3J15	AUGER, LOWER TAILINGS	125 - 24
2F7	ADJUSTABLE REAR AXLE STEERING TIE RODS	60 - 33	3H17	AUGER, SHOE GRAIN SUPPLY AND HOUSING	120 - 2
4E11	ADJUSTING BRACKET, CYLINDER DRIVE, DUAL-RANGE	140 - 32	3J17	AUGER, TIGHTENER, LOWER DRIVE ELEVATOR	125 - 26
1H13	ADJUSTING MOTOR, CONCAVE.....	40 - 66	4F9	AUGER, UPPER TAILINGS.....	140 - 54
1H18	ADJUSTING MOTOR, SEPARATOR FAN DRIVE	40 - 72	2B9	AXLE SPACERS	50 - 5
1E22	AIR CLEANER AND INTAKE TUBES.....	30 - 18	2B10	AXLE SPACERS	50 - 6
3D12	AIR CONDITIONER COMPRESSOR HOSE	95 - 12	4J17	AXLE STOP AND TIRE CLEARANCE LABEL.....	170 - 20
1B19	AIR CONDITIONER COMPRESSOR PULLEY.....	20 - 17	2B5	AXLE SUPPORT, REAR	50 - 1
1B19	AIR CONDITIONER COMPRESSOR SUPPORT	20 - 17	4I8	AXLE, BOGEY WHEEL	160 - 14
3D7	AIR CONDITIONING AND HEATER DUCTS	95 - 7	2B7	AXLE, FIXED REAR	50 - 3
3D4	AIR CONDITIONING AND HEATER HOUSING, LOWER	95 - 4	2B6	AXLE, FRONT (SIDEHILL)	50 - 2
3D2	AIR CONDITIONING AND HEATER HOUSING, UPPER.....	95 - 2	4I5	AXLE, IDLER	160 - 10
3D14	AIR CONDITIONING COMPRESSOR HARDWARE.....	95 - 14	2B8	AXLE, REAR, ADJUSTABLE.....	50 - 4
2F18	AIR CONDITIONING CONDENSER	70 - 8	2F4	AXLE, REAR, SPINDLES (HEAVY DUTY).....	60 - 30
3D9	AIR CONDITIONING SYSTEM - RECEIVER-DRYER	95 - 9	2F2	AXLE, REAR, SPINDLES (REGULAR DUTY)	60 - 28
3D10	AIR CONDITIONING SYSTEM, EVAPORATOR HEATER.....	95 - 10	2C6	AXLE, SUPPORT, FRONT	50 - 28
3D8	AIR CONDITIONING SYSTEM, WATER VALVE	95 - 8		B	
1G9	AIR CONDITIONING WIRING HARNESS	40 - 36	1H9	BACKSHAFT SPEED SENSOR, FEEDER HOUSE.....	40 - 62
3H19	AIR DUCT, CLEANOUT FAN	120 - 4	1E14	BASE, FUEL FILTER.....	30 - 10
3D2	AIR DUCT, INTAKE	95 - 2	4F18	BASE, GRAIN TANK	150 - 4
3B19	AIR SEAT SUSPENSION	90 - 18	1D11	BASE, OIL FILTER	25 - 32
3B21	AIR SEAT SWITCH	90 - 20	1H22	BATTERIES AND CABLES	40 - 76
4I3	AIR SUSPENSION.....	160 - 8	2C10	BEARING CAP AND HOUSING, FINAL DRIVE (SIDEHILL).....	50 - 32
1H5	ALTERNATOR ADJUSTING STRAP.....	40 - 58	3H11	BEARING KIT, STRAW WALKERS	110 - 24
1H5	ALTERNATOR SUPPORT AND BRACKET	40 - 58	1C20	BEARING KIT, UNDERSIZED MAIN BEARING CRANKSHAFT	25 - 13
1H3	ALTERNATOR, SHEAVE AND BELT (185 AMP)	40 - 56	4I10	BEARING, BOGEY WHEEL	160 - 16
1H1	ALTERNATOR, SHEAVE AND BELT - (95 AMP)	40 - 54	4I8	BEARING, BOGEY WHEEL AXLE	160 - 14
3C15	ANTENNA, SPEAKERS AND RADIO	90 - 40	2C24	BEARING, CAM LOBE MOTOR	50 - 48
3I1	ARM, FRAME, PRECLEANER CHAFFER	120 - 10	3I19	BEARING, CLEAN GRAIN, LOWER.....	125 - 4
4I1	ARM, FRONT AND ADJUSTABLE IDLER ASSEMBLY..	160 - 6	2C8	BEARING, FINAL DRIVE, SINGLE REDUCTION	50 - 30
4I5	ARM, REAR	160 - 10	3E1	BEARING, GEAR BOX (STANDARD).....	100 - 10
1D3	ARM, ROCKER	25 - 22	4I7	BEARING, IDLER WHEEL.....	160 - 12
2D6	ARM, STEERING, CAM LOBE MOTOR (STEERABLE MOTOR).....	50 - 56	1C21	BEARING, MAIN (8400).....	25 - 14
4B18	ARM, TAILBOARD, CHOP-TO-BALE	130 - 16	4D13	BEARING, MAIN GEARCASE	140 - 6
1G13	ARM, WINDSHIELD WIPER	40 - 40	3D23	BEARING, REVERSE GEAR BOX, HIGH CAPACITY	100 - 6
3B24	ARMREST PANEL, OPERATOR'S	90 - 24	3H17	BEARING, SHOE GRAIN AUGER	120 - 2
3C1	ARMREST PANEL, OPERATOR'S	90 - 26	3J14	BEARING, TAILINGS ELEVATOR CONVEYOR	125 - 23
3B24	ARMREST ROCKER SWITCHES	90 - 24	1C21	BEARING, THRUST (8400).....	25 - 14
3C1	ARMREST ROCKER SWITCHES	90 - 26	2B19	BEARING, TRANSMISSION	50 - 16
1G5	ARMREST WIRING HARNESS.....	40 - 32	2B21	BEARING, TRANSMISSION PINION SHAFT.....	50 - 18
			4E19	BEATER DRIVE SHEAVES AND TIGHTENER	140 - 40
			3H1	BEATER GRATE (NARROW)	110 - 14
			3H6	BEATER GRATE CURTAIN	110 - 19
			3H7	BEATER, SHAFT AND DRIVE BELT	110 - 20

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4I17	BELT AND DRIVE WHEEL	160 - 24	1G13	BLADE, WIPER	40 - 40
4H3	BELT GUIDE, UNLOADING AUGER DRIVE	150 - 40	4B7	BLADES, TRI-ROD CHOPPER	130 - 4
2H1	BELT PICKUP / REEL DRIVE, PUMP MOUNTING SHEAVE	70 - 42	1B20	BLOCK, ENGINE COOLANT HEATER	20 - 18
4K3	BELT, AIR CONDITIONING COMPRESSOR	170 - 30	1C13	BLOCK, SHORT	25 - 6
4K5	BELT, AIR FLOW DRIVE	170 - 32	2C23	BLOCK, VALVE	50 - 46
1H3	BELT, ALTERNATOR (185 AMP)	40 - 56	4I10	BOGEY WHEEL ASSEMBLY	160 - 16
4K1	BELT, ALTERNATOR (185 AMP)	170 - 28	4I8	BOGEY WHEEL AXLES	160 - 14
1H1	BELT, ALTERNATOR (95 AMP)	40 - 54	3C9	BOOT, GEARSHIFT	90 - 34
4K1	BELT, ALTERNATOR (95 AMP)	170 - 28	1H3	BOSCH ALTERNATOR, SHEAVE AND BELT (185 AMP)	40 - 56
3B24	BELT, ARMREST CONTROL PANEL	90 - 24	1H1	BOSCH ALTERNATOR, SHEAVE AND BELT (95 AMP)	40 - 54
3H7	BELT, BEATER	110 - 20	4I11	BOX, GEAR, TRANSFER	160 - 18
4K7	BELT, BEATER	170 - 34	2J20	BOX, TOOL	80 - 40
4E19	BELT, BEATER DRIVE AND TIGHTENER	140 - 40	2G16	BRACKET, ACCUMULATOR MOUNTING ONE HALF GALLON	70 - 32
4F3	BELT, CHOPPER DRIVE, FRONT	140 - 48	1H5	BRACKET, ALTERNATOR	40 - 58
4F12	BELT, CLEAN GRAIN ELEVATOR	140 - 58	2E11	BRACKET, BRAKE CABLE SUPPORT	60 - 11
4K3	BELT, CLEAN GRAIN ELEVATOR	170 - 30	4B18	BRACKET, CHOP-TO-BALE	130 - 16
4E21	BELT, CLEANING FAN	140 - 42	1H14	BRACKET, CONCAVE INDICATOR	40 - 68
4K5	BELT, CLEANING FAN	170 - 32	4H8	BRACKET, DISPLAY, YIELD MAPPING	155 - 4
4K3	BELT, COOLING FAN	170 - 30	3G3	BRACKET, FEEDER HOUSE, SIDEHILL, UPPER	100 - 62
1B14	BELT, COOLING FAN, ENGINE	20 - 12	2J16	BRACKET, FUEL TANK	80 - 36
4D24	BELT, COUNTERSHAFT DRIVE AND VARIABLE SHEAVE	140 - 18	4C21	BRACKET, LEVELING CABLES AND SHEAVES SIDEHILL (LOWER FRONT)	135 - 12
4E2	BELT, CYLINDER DRIVE	140 - 22	1H21	BRACKET, LOW SHAFT SPEED SENSORS	40 - 75
4K3	BELT, CYLINDER DRIVE	170 - 30	4H10	BRACKET, MASS FLOW SENSOR, YIELD MAPPING ..	155 - 6
4K3	BELT, CYLINDER INTERMEDIATE DRIVE	170 - 30	4H12	BRACKET, MOISTURE SENSOR, YIELD MAPPING ...	155 - 8
4E9	BELT, DUAL RANGE CYLINDER DRIVE	140 - 30	4H6	BRACKET, POSITION RECEIVER YIELD MAPPING ...	155 - 2
4D23	BELT, ELECTROMAGNETIC CLUTCH	140 - 16	2F22	BRACKET, SOLENOID CONTROL VALVE	70 - 12
4K1	BELT, FEEDER CONVEYOR	170 - 28	4H10	BRACKET, TRANSDUCER MOUNTING YIELD MAPPING	155 - 6
3E7	BELT, FEEDER HOUSE DRIVE TIGHTENER	100 - 16	2E11	BRAKE CABLE SUPPORT BRACKET	60 - 11
3G1	BELT, FEEDER HOUSE DUST PAN, L.H.	100 - 60	2E8	BRAKE CYLINDER, MASTER	60 - 8
3E3	BELT, FIXED SPEED FEEDERHOUSE WITH REVERSER	100 - 12	2E6	BRAKE LINES, MASTER CYLINDER AND RESERVOIR	60 - 6
4K5	BELT, FIXED SPEED FEEDERHOUSE W/REVERSER	170 - 32	2E4	BRAKE PEDAL AND MASTER CYLINDER	60 - 4
3G7	BELT, FRONT DRIVE SHAFT, FEEDER HOUSE (FIXED SPEED WITH REVERSER)	100 - 66	2E2	BRAKE PEDAL AND SEAL, PARKING	60 - 2
3D19	BELT, HEADER AND REEL PUMP	100 - 2	2E12	BRAKE SHOES AND DRUM	60 - 12
4K5	BELT, HEADER AND REEL PUMP	170 - 32	4I15	BRAKE SHOES AND DRUM	160 - 22
3J15	BELT, LOWER TAILINGS AUGER AND ELEVATOR ...	125 - 24	2E10	BRAKE SLAVE CYLINDER	60 - 10
4K3	BELT, LOWER TAILINGS AUGER AND ELEVATOR ...	170 - 30	2E4	BRAKE, MASTER CYLINDER	60 - 4
3J17	BELT, LOWER TAILINGS DRIVE AUGER	125 - 26	2G20	BULB, ACCUMULATOR PRESSURE GAUGE	70 - 36
3B21	BELT, OPERATOR'S SEAT	90 - 20	3C1	BULB, ARMREST CONTROL PANEL	90 - 26
4K3	BELT, ROTARY SCREEN	170 - 30	3B11	BULB, CAB LIGHT, ROOF	90 - 10
1B4	BELT, ROTARY SCREEN DRIVE	20 - 2	1H23	BULB, CAB ROOF LIGHT	40 - 77
4K3	BELT, ROTARY SCREEN DRIVE	170 - 30	2I23	BULB, FLOODLAMP, LEFT REAR CORNER PANEL ...	80 - 18
3B23	BELT, SEAT ASSEMBLY	90 - 22	1H24	BULB, FRONT AND REAR	40 - 78
4K1	BELT, SECONDARY COUNTERSHAFT	170 - 28	3C13	BULB, OVERHEAD CONSOLE	90 - 38
4E13	BELT, SECONDARY COUNTERSHAFT DRIVE	140 - 34	3C11	BULB, R.H. CORNERPOST DISPLAY PANEL	90 - 36
4E17	BELT, SHOE, WALKER AND CONVEYOR AUGERS ...	140 - 38	2J18	BULB, REAR LAMP, ENGINE ACCESS PLATFORM ...	80 - 38
4E1	BELT, SINGLE RANGE CYLINDER DRIVE	140 - 20	2I19	BULB, SERVICE LIGHT, GULLWING DOOR, L.H.	80 - 14
4F5	BELT, STRAW CHOPPER	140 - 50	2J3	BULB, SERVICE LIGHT, GULLWING DOOR, R.H.	80 - 22
4K5	BELT, STRAW CHOPPER	170 - 32	2J5	BULB, SERVICE, REAR DOOR, R.H.	80 - 24
3H13	BELT, STRAW SPREADER	110 - 26	1I3	BULB, SIDE FINDER LIGHT	40 - 82
4B24	BELT, STRAW SPREADER	130 - 22	3C5	BULB, STEERING WHEEL CONTROL HOUSING	90 - 30
4K5	BELT, STRAW SPREADER	170 - 32	3B4	BULB, STUBBLE LAMP, CAB SUPPORT	90 - 2
1H5	BELT, TENSIONER ALTERNATOR	40 - 58	1I4	BULB, TRANSPORT LIGHTS	40 - 83
4H1	BELT, UNLOADING AUGER COUNTERSHAFT	150 - 38	1I2	BULB, TURN AND TAIL LIGHTS	40 - 81
4K5	BELT, UNLOADING AUGERS	170 - 32	1G17	BULB, UNLOADING AUGER LIGHT	40 - 44
4K7	BELT, UNLOADING SYSTEM	170 - 34	1C25	BUSHING, CAMSHAFT	25 - 18
3G5	BELT, UPPER DRIVE SHAFT, FEEDER HOUSE	100 - 64	1C11	BUSHING, CAMSHAFT, CYLINDER BLOCK	25 - 4
3F20	BELT, UPPER, VARIABLE DRIVE COUNTERSHAFT ...	100 - 54	4H24	BUSHING, MAIN FRAME PIVOT	160 - 4
3E5	BELT, VARIABLE SPEED DRIVE TIGHTENER	100 - 14	1D9	BYPASS TUBES, OIL COOLER	25 - 29
3D19	BELT, VARIABLE SPEED FEEDERHOUSE	100 - 2	1D11	BYPASS VALVE, OIL FILTER	25 - 32
4K5	BELT, VARIABLE SPEED FEEDERHOUSE	170 - 32			
2G10	BI-DIRECTIONAL MODULE, SOLENOID CONTROL VALVE, REEL LIFT AND CYLINDER SPEED	70 - 26			
4B11	BLADE, FINE CUT CHOPPER - PADDLED	130 - 8			

ALPHABETICAL INDEX - CONTINUED

GRID	C	PAGE	GRID	PAGE	
3D6	CAB AIR FILTER AND HOUSING	95 - 6	3J15	CHAIN, ROLLER, LOWER TAILINGS AUGER	125 - 24
3B13	CAB DOOR AND GLASS	90 - 12	4F9	CHAIN, ROLLER, UPPER TAILINGS AUGER DRIVE	140 - 54
3B15	CAB DOOR LATCH	90 - 14	4K7	CHAIN, TAILINGS AUGER	170 - 34
3B11	CAB INTERIOR ROOF	90 - 10	3J14	CHAIN, TAILINGS ELEVATOR CONVEYOR	125 - 23
3B9	CAB INTERIOR TRIM PANELS	90 - 8	3J19	CHAIN, UPPER TAILINGS AUGER	125 - 28
3C20	CAB LANDING AND MIRROR (L.H.)	90 - 46	4G23	CHANNEL, CROSS AUGER	150 - 34
3C22	CAB LANDING AND MIRROR (R.H.)	90 - 48	4G1	CHARGE HOUSING, VERTICAL UNLOADING AUGER	150 - 12
1G3	CAB MAIN WIRING HARNESS	40 - 30	1E22	CHECK VALVE, AIR CLEANER	30 - 18
3B21	CAB OPERATOR'S SEAT AND ARMREST	90 - 20	2H22	CHECK VALVE, CHAFF SPREADER CONTROL	70 - 64
3B7	CAB REAR AND SIDE SEALS	90 - 6	3D4	CHECK VALVE, HEATING AND AIR CONDITIONER ...	95 - 4
1H23	CAB ROOF LIGHTS	40 - 77	2C16	CHECK VALVE, HYDROSTATIC PUMP	50 - 38
3B4	CAB SUPPORTS	90 - 2	2H3	CHECK VALVE, REEL DRIVE FLOW CONTROL	70 - 44
1H22	CABLE, BATTERY	40 - 76	4B20	CHOP-TO-DROP DECLUTCHING LEVER	130 - 18
4H18	CABLE, DATASTORE/COMPUTER	155 - 14	4B21	CHOPPER COVER AND BRACKETS, CHOP-TO-BALE	130 - 19
3C7	CABLE, FEEDER HOUSE REVERSE CONTROL	90 - 32	4B4	CHOPPER DOOR	130 - 1
2C12	CABLE, HYDROSTATIC DRIVE CONTROL	50 - 34	4F3	CHOPPER DRIVES (FRONT)	140 - 48
3G3	CABLE, LEVELING, FEEDER HOUSE, SIDEHILL	100 - 62	4B13	CHOPPER HOUSING AND KNIFEBANK	130 - 10
1F10	CABLE, WIRING	40 - 8	4B11	CHOPPER ROTOR, FINE CUT PADDLED BLADE	130 - 8
2D3	CAM, CARRIER, AND PISTON (STEERABLE MOTOR)	50 - 52	4B15	CHOPPER SENSOR	130 - 12
3D19	CAM, VARIABLE DRIVE SHEAVE, FRONT	100 - 2	4B15	CHOPPER TRANSPORT SPROCKETS	130 - 12
1C25	CAMSHAFT	25 - 18	4B9	CHOPPER, FINE CUT STRAIGHT BLADE	130 - 6
1C11	CAMSHAFT BUSHING, CYLINDER BLOCK	25 - 4	4B7	CHOPPER, TRI-ROD	130 - 4
1C25	CAMSHAFT FOLLOWER	25 - 18	4F24	CHUTE, GRAIN TANK CLEAN OUT	150 - 10
1D3	CAMSHAFT FOLLOWER	25 - 22	3C13	CIRCUIT BOARD, OVERHEAD CONSOLE	90 - 38
1C25	CAMSHAFT GEAR AND BUSHING	25 - 18	1G20	CIRCUIT BOARDS, CENTRAL ELECTRONICS MODULE	40 - 48
4F24	CAP, GRAIN TANK CLEAN OUT CHUTE	150 - 10	3D2	CIRCUIT BOX, HEATER AND AIR CONDITIONER	95 - 2
1C11	CAP, MAIN BEARING, CYLINDER BLOCK	25 - 4	1G22	CIRCUIT BREAKER	40 - 50
1B12	CAP, RADIATOR	20 - 10	3I21	CLEAN GRAIN CONVEYOR CHAIN	125 - 6
1D4	CAP, ROCKER ARM COVER	25 - 23	3J3	CLEAN GRAIN ELEVATOR GEARCASE	125 - 12
2D4	CAPS, YOKE AND PIVOTS (STEERABLE MOTOR) ...	50 - 54	3I17	CLEAN GRAIN ELEVATOR UPPER SHEAVE	125 - 2
2D3	CARRIER, PISTON, AND CAM (STEERABLE MOTOR)	50 - 52	3I17	CLEAN GRAIN ELEVATOR UPPER SPROCKET	125 - 2
2D23	CASE DRAIN, 4-WHEEL DRIVE, HYDRAULIC LINES	50 - 74	3J1	CLEAN GRAIN LOADING AUGER	125 - 10
4I11	CASE, GEAR, TRANSFER	160 - 18	3I23	CLEAN GRAIN LOADING AUGER HOUSING, UPPER	125 - 8
4F24	CASE, VERTICAL AUGER LOWER GEAR	150 - 10	3I19	CLEAN GRAIN LOWER AUGER AND HINGED DOOR	125 - 4
1G20	CENTRAL ELECTRONICS MODULE AND CIRCUIT BOARDS	40 - 48	3I21	CLEAN GRAIN LOWER ELEVATOR	125 - 6
2H22	CHAFF SPREADER CONTROL, CHECK VALVE, ROD AND KNOB	70 - 64	4F24	CLEAN OUT CHUTE, GRAIN TANK	150 - 10
4C3	CHAFF SPREADER DISC	130 - 26	1E22	CLEANER, AIR AND INTAKE TUBES	30 - 18
2H24	CHAFF SPREADER LINES AND FITTINGS	70 - 66	4E21	CLEANING FAN DRIVE, SEPARATOR	140 - 42
2I1	CHAFF SPREADER LINES, HOSES, VALVE AND PUMP	70 - 68	3H19	CLEANING FAN INTAKE SHIELDS	120 - 4
4C9	CHAFF SPREADER MOUNTING SUPPORT	130 - 32	3H19	CLEANING FANS AND SHROUDS	120 - 4
4C7	CHAFF SPREADER PAN AND SEALS	130 - 30	1I5	CLEANING SHOE INSPECTION LIGHT	40 - 84
2G24	CHAFF SPREADER PUMP	70 - 40	1H7	CLUTCH ASSEMBLY (STARTER)	40 - 60
4C5	CHAFF SPREADER SHIELDS AND HANDLES	130 - 28	3D13	CLUTCH, COMPRESSOR (REFRIGERANT)	95 - 13
2I3	CHAFF SPREADER, HOSES, LINES	70 - 70	4D23	CLUTCH, HEADER ELECTROMAGNETIC	140 - 16
3I3	CHAFFER ELEMENT	120 - 12	3F3	CLUTCH, SLIP, FEEDER HOUSE FRONT SHAFT	100 - 36
3I5	CHAFFER EXTENSION ELEMENT	120 - 14	3J15	CLUTCH, SLIP, LOWER TAILINGS AUGER	125 - 24
3I7	CHAFFER FRAME	120 - 16	4E17	CLUTCH, SLIP, STRAW WALKER AND CONVEYOR AUGER	140 - 38
3I1	CHAFFER FRAME ARMS, PRE-CLEANER	120 - 10	3C5	COLD WEATHER START BUTTON	90 - 30
3H23	CHAFFER FRAME, PRE-CLEANER	120 - 8	1E16	COLD WEATHER STARTING AID	30 - 12
3H21	CHAFFER, PRE-CLEANING	120 - 6	3C3	COLUMN, STEERING, LOWER	90 - 28
3F15	CHAIN IDLERS AND SHIELD BRACKETS, DRIVE (SIDEHILL)	100 - 48	3D15	COMPRESSOR PARTS (REFRIGERANT)	95 - 15
4F11	CHAIN TIGHTENER, UPPER TAILINGS DRIVE	140 - 56	3D12	COMPRESSOR, AIR CONDITION, HOSE	95 - 12
3I21	CHAIN, CONVEYOR, CLEAN GRAIN LOWER ELEVATOR	125 - 6	3D11	COMPRESSOR, AIR CONDITIONING, R134A	95 - 11
3F13	CHAIN, FEEDER CONVEYOR	100 - 46	3D13	COMPRESSOR, CLUTCH (REFRIGERANT)	95 - 13
3F7	CHAIN, FEEDER CONVEYOR IDLER SHAFT	100 - 40	1H13	CONCAVE ADJUSTING MOTOR	40 - 66
3C1	CHAIN, LINK, ARMREST CONTROL PANEL	90 - 26	3H1	CONCAVE ASSEMBLY AND BEATER GRATE	110 - 14
4G21	CHAIN, LINK, GRAIN TANK CROSS AUGERS	150 - 32	1H14	CONCAVE INDICATOR	40 - 68
			3F24	CONCAVE INDICATOR	100 - 58
			3H1	CONCAVE, SPIKE-TOOTH	110 - 14
			3H3	CONCAVE, SPIKE-TOOTH	110 - 16
			2F18	CONDENSER, AIR CONDITIONING AND OIL COOLER	70 - 8
			1C10	CONDITIONER, COOLANT	25 - 3

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1C17	CONNECTING RODS	25 - 10	1C19	CRANKSHAFT KIT, UNDERSIZE (CONNECTING ROD JOURNAL)	25 - 12
1F4	CONNECTORS, ELECTRICAL, WEATHERPACK	40 - 2	1C20	CRANKSHAFT KIT, UNDERSIZED MAIN BEARING.....	25 - 13
1C2	CONNECTORS, ENGINE HEATER HOSE.....	20 - 25	1E3	CRANKSHAFT PULLEY AND DAMPERS	25 - 50
1E10	CONNECTORS, FUEL INJECTION PUMP HOUSING ..	30 - 6	4G19	CROSS AUGER BEARING PLATE, L.H.	150 - 30
1F12	CONNECTORS, SUPPLEMENTARY TERMINALS	40 - 10	4G23	CROSS AUGER COVERS AND CHANNEL.....	150 - 34
3C13	CONSOLE, OVERHEAD	90 - 38	4G21	CROSS AUGERS, GRAIN TANK	150 - 32
2H17	CONTOUR MASTER HYDRAULIC HOSES, L.H SIDE ..	70 - 58	3H6	CURTAIN, BEATER GRATE	110 - 19
2G5	CONTOUR MASTER SOLENOID CONTROL RELIEF VALVE	70 - 20	4F20	CURTAIN, GRAIN TANK	150 - 6
2H20	CONTOUR MASTER TILT CYLINDER.....	70 - 61	3G20	CURTAIN, SEPARATOR, RASP BAR CYLINDER.....	110 - 9
2H21	CONTOUR MASTER TILT CYLINDER HOSES AND FITTINGS	70 - 62	4C1	CURTAIN, SPREADER	130 - 24
3E21	CONTOUR MASTER, FEEDER HOUSE SHELL, WEAR PLATES AND SEALS	100 - 30	3B17	CUSHION, SEAT	90 - 16
4D6	CONTROL ASSEMBLY, LEVELING (SIDEHILL).....	135 - 21	1C11	CYLINDER BLOCK FITTINGS	25 - 4
2C12	CONTROL CABLES, HYDROSTATIC DRIVE	50 - 34	3G12	CYLINDER COVER, THRESHING	110 - 1
3B24	CONTROL PANEL, OPERATOR'S ARMREST	90 - 24	3G17	CYLINDER DOOR (CORN)	110 - 6
3C1	CONTROL PANEL, OPERATOR'S ARMREST	90 - 26	3G15	CYLINDER DOOR (GRAIN AND RICE)	110 - 4
1E8	CONTROL UNIT, ELECTRONIC.....	30 - 4	4E11	CYLINDER DRIVE ADJUSTING BRACKET, DUAL-RANGE	140 - 32
1G24	CONTROL UNIT, ELECTRONIC (ECU)	40 - 52	4E2	CYLINDER DRIVE GEARCASE, DUAL-RANGE	140 - 22
2F23	CONTROL VALVE MODULE, SIX STACK SOLENOID..	70 - 14	4E7	CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING, DUAL-RANGE	140 - 28
2D7	CONTROL VALVE, CAM LOBE MOTOR.....	50 - 58	4E9	CYLINDER DRIVE INTERMEDIATE SHEAVE, DUAL-RANGE	140 - 30
2C19	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT	50 - 42	4E5	CYLINDER DRIVE TIGHTENER, DUAL-RANGE	140 - 26
2G12	CONTROL VALVE, SOLENOID, AUGER SWING	70 - 28	4E1	CYLINDER DRIVE, SINGLE RANGE	140 - 20
1E8	CONTROLLER, ENGINE	30 - 4	1D1	CYLINDER HEAD AND BOLT KIT	25 - 20
1F13	CONVENIENCE OUTLET KIT.....	40 - 12	1E1	CYLINDER HEAD GASKET KIT	25 - 48
4E17	CONVEYOR AUGERS, STRAW WALKER, SIEVE AND CHAFFER DRIVE	140 - 38	1C17	CYLINDER LINERS	25 - 10
3I21	CONVEYOR CHAIN, CLEAN GRAIN	125 - 6	4C17	CYLINDER PINS, LEVELING, SIDEHILL (SIDEHILL).....	135 - 8
3F13	CONVEYOR, FEEDER DRIVE CHAIN	100 - 46	3G19	CYLINDER SHEAR BAR	110 - 8
1C10	COOLANT CONDITIONER, ENGINE	25 - 3	2G10	CYLINDER SPEED AND REEL LIFT, SOLENOID CONTROL VALVE.....	70 - 26
1B20	COOLANT HEATER, ENGINE BLOCK.....	20 - 18	2G22	CYLINDER SPEED HYDRAULIC LINES AND HOSES ..	70 - 38
1B12	COOLANT RECOVERY TANK (RADIATOR)	20 - 10	2E10	CYLINDER, BRAKE SLAVE	60 - 10
1C10	COOLANT SCAN TEST KIT	25 - 3	2E8	CYLINDER, BRAKE, MASTER	60 - 8
1D10	COOLER, ENGINE OIL	25 - 30	4G24	CYLINDER, DRIVE, GRAIN TANK UNLOADING.....	150 - 36
3D21	COOLER, OIL, FEEDER HOUSE GEARCASE	100 - 4	2I19	CYLINDER, GAS, GULLWING DOOR, L.H.....	80 - 14
4B17	CORN DEFLECTOR	130 - 14	2G13	CYLINDER, HEADER LIFT, HYDRAULIC	70 - 29
2I23	CORNER PANEL, REAR, L H	80 - 18	4G3	CYLINDER, HYDRAULIC, UNLOADING AUGER SWING, LINES AND HOSES	150 - 14
3C11	CORNERPOST DISPLAY PANEL, R.H.....	90 - 36	4D2	CYLINDER, LEVELING	135 - 17
4E13	COUNTERSHAFT DRIVE, SECONDARY.....	140 - 34	4D1	CYLINDER, LEVELING, SIDEHILL	135 - 16
4H1	COUNTERSHAFT DRIVE, UNLOADING AUGER	150 - 38	2E4	CYLINDER, MASTER, BRAKE	60 - 4
4D21	COUNTERSHAFT GEARCASE, PRIMARY	140 - 14	2F1	CYLINDER, STEERING.....	60 - 26
1B17	COUPLING WITH HUB, ENGINE-TRANSMISSION.....	20 - 15	4I21	CYLINDER, TENSION INDIVIDUAL REPAIR PARTS	160 - 28
2B10	COUPLINGS, AXLE	50 - 6	4I5	CYLINDER, TENSION AND ATTACHING HARDWARE	160 - 10
4G23	COVER AND CHANNEL, CROSS AUGER	150 - 34	3G21	CYLINDER, THRESHING, RASP BAR	110 - 10
4B21	COVER, CHOPPER, CHOP-TO-BALE	130 - 19	3G23	CYLINDER, THRESHING, SPIKE TOOTH	110 - 12
1E20	COVER, ENGINE.....	30 - 16	2H20	CYLINDER, TILT, CONTOUR MASTER.....	70 - 61
1H5	COVER, FUEL INJECTION PUMP ACCESS.....	40 - 58	2H21	CYLINDER, TILT, HOSES AND FITTINGS, CONTOUR MASTER.....	70 - 62
2C14	COVER, HYDROSTATIC PUMP	50 - 36	4G5	CYLINDER, UNLOADING AUGER SWING	150 - 16
2D1	COVER, INNER	50 - 50	4D24	CYLINDER, VARIABLE SHEAVE COUNTER DRIVE SHAFT	140 - 18
3J13	COVER, MATERIAL SENSOR TAILING ELEVATOR	125 - 22			
4H12	COVER, MOISTURE SENSOR, YIELD MAPPING	155 - 8		D	
1D10	COVER, OIL COOLER	25 - 30	1C18	DAMPER KEY, CRANKSHAFT	25 - 11
4H6	COVER, POSITION RECEIVER YIELD MAPPING	155 - 2	1E3	DAMPER, CRANKSHAFT	25 - 50
1D4	COVER, ROCKER ARM	25 - 23	4H18	DATASTORE	155 - 14
1D18	COVER, THERMOSTAT	25 - 40	4H16	DATASTORE MODULE	155 - 12
3G12	COVER, THRESHING CYLINDER	110 - 1	4H18	DATASTORE MODULE	155 - 14
1C24	COVER, TIMING GEAR.....	25 - 17	4H16	DATASTORE WITH DISPLAY.....	155 - 12
4H14	COVER, WITH MOISTURE SENSOR.....	155 - 10	4H19	DECALS, DISPLAY, YIELD MONITOR.....	155 - 15
4H14	COVER, WITHOUT MOISTURE SENSOR	155 - 10			
1B22	CRANKCASE, ENGINE, OIL DRAIN.....	20 - 20			
3H13	CRANKS, STRAW WALKER AND SPREADER DRIVE	110 - 26			
1C18	CRANKSHAFT	25 - 11			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4J19	DECALS, FRENCH CANADIAN	170 - 22	2C21	DRAIN PLUG, HYDROSTATIC DRIVE MOTOR	50 - 44
4J17	DECALS, FRONT AND REAR TIRE.....	170 - 20	2C23	DRAIN PLUG, HYDROSTATIC MOTOR VALVE	50 - 46
4H19	DECALS, MOISTURE SENSOR, YIELD MONITOR	155 - 15	1B24	DRAIN PLUG, INTERCOOLER	20 - 22
4J20	DECALS, PORTUGUESE	170 - 23	4D13	DRAIN PLUG, MAIN GEARCASE.....	140 - 6
4J21	DECALS, ROMANIAN	170 - 24	2G5	DRAIN PLUG, RELIEF VALVE	70 - 20
4J22	DECALS, RUSSIAN	170 - 25	1D18	DRAIN VALVE, CYLINDER HEAD	25 - 40
4J15	DECALS, SAFETY (RUBBER TRACK).....	170 - 18	1E13	DRAIN VALVE, FUEL COOLER	30 - 9
4I23	DECALS, SAFETY AND LOCATIONS	170 - 2	1E18	DRAIN VALVE, FUEL TANK.....	30 - 14
4J1	DECALS, SAFETY AND LOCATIONS	170 - 4	1D13	DRAIN VALVE, OIL PAN.....	25 - 34
4J3	DECALS, SAFETY AND LOCATIONS	170 - 6	4H3	DRIVE BELT GUIDE, UNLOADING AUGER	150 - 40
4J5	DECALS, SAFETY AND LOCATIONS	170 - 8	3F15	DRIVE CHAIN IDLERS AND SHIELD BRACKETS (SIDEHILL).....	100 - 48
4J7	DECALS, SAFETY AND LOCATIONS	170 - 10	4F11	DRIVE CHAIN TIGHTENER, UPPER TAILINGS	140 - 56
4J23	DECALS, SPANISH	170 - 26	3F13	DRIVE CHAIN, FEEDER CONVEYOR	100 - 46
4J24	DECALS, UKRAINIAN	170 - 27	2C12	DRIVE CONTROL CABLES, HYDROSTATIC	50 - 34
4H19	DECALS, YIELD MONITOR	155 - 15	1C18	DRIVE GEAR, OIL PUMP, CRANKSHAFT.....	25 - 11
4B20	DECLUTCHING LEVER, CHOP-TO-DROP	130 - 18	4F12	DRIVE IDLER, CLEAN GRAIN ELEVATOR	140 - 58
4H10	DEFLECTOR DOOR, MASS FLOW SENSOR YIELD MAPPING	155 - 6	2B9	DRIVE SHAFT	50 - 5
4B17	DEFLECTOR, CORN	130 - 14	3G7	DRIVE SHAFT (FIXED SPEED WITH REVERSER)	100 - 66
3G15	DEFLECTOR, CYLINDER DOOR (GRAIN AND RICE).....	110 - 4	3G5	DRIVE SHAFT, FEEDER HOUSE, UPPER (FIXED SPEED WITH REVERSER).....	100 - 64
2B23	DIFFERENTIAL GEARS AND SHAFTS	50 - 20	2C4	DRIVE SHAFT, FINAL (SIDEHILL)	50 - 26
2C1	DIFFERENTIAL GEARS AND SHAFTS (SIDEHILL)	50 - 22	4D19	DRIVE SHAFT, GEARCASE AND PRIMARY COUNTERSHAFT	140 - 12
1C11	DIPSTICK TUBE, CYLINDER BLOCK	25 - 4	3G9	DRIVE SHAFT, HEADER, SIDEHILL	100 - 68
4D19	DIPSTICK, COUNTERSHAFT GEARCASE	140 - 12	2C18	DRIVE SHAFT, HYDROSTATIC CHARGE PUMP	50 - 40
1D15	DIPSTICK, ENGINE OIL	25 - 36	2B10	DRIVE SHAFTS	50 - 6
4D17	DIPSTICK, MAIN GEARCASE.....	140 - 10	3E13	DRIVE SHIELD, FEEDHOUSE, L.H. WITH AIRFLOW	100 - 22
3D23	DIPSTICK, REVERSER GEAR BOX, HIGH CAPACITY	100 - 6	3E11	DRIVE SHIELD, FEEDHOUSE, L.H. WITHOUT AIRFLOW.....	100 - 20
4C3	DISC, CHAFF SPREADER	130 - 26	2J7	DRIVE SHIELD, R.H. REAR	80 - 26
2C19	DISPLACEMENT CONTROL VALVE, HYDROSTATIC DRIVE	50 - 42	3E15	DRIVE SHIELD, R.H., FEEDER HOUSE	100 - 24
4H8	DISPLAY BRACKET, YIELD MAPPING	155 - 4	3E9	DRIVE SHIELDS, SAFETY STOP, FEEDER HOUSE (SIDEHILL).....	100 - 18
4H19	DISPLAY DECALS, YIELD MONITOR	155 - 15	4F7	DRIVE SHIELDS, STRAW CHOPPER	140 - 52
3C11	DISPLAY PANEL, R.H. CORNERPOST	90 - 36	2C7	DRIVE SUPPORT SHIELD, FINAL (SIDEHILL)	50 - 29
4H16	DISPLAY WITH DATASTORE.....	155 - 12	4F12	DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR	140 - 58
4H8	DISPLAY, YIELD MAPPING	155 - 4	3E7	DRIVE TIGHTENER, FEEDER HOUSE	100 - 16
4D3	DIVIDER MOUNTING, FLOW (SIDEHILL)	135 - 18	3E3	DRIVE TIGHTENER, FIXED SPEED FEEDER HOUSE.....	100 - 12
4D3	DIVIDER VALVE, FLOW (SIDEHILL)	135 - 18	3E5	DRIVE TIGHTENER, VARIABLE SPEED	100 - 14
3B15	DOOR LATCH, CAB	90 - 14	4I13	DRIVE TRANSFER, FINAL, SINGLE REDUCTION	160 - 20
3B13	DOOR, CAB	90 - 12	4I17	DRIVE WHEEL AND BELT	160 - 24
4B4	DOOR, CHOPPER	130 - 1	2B11	DRIVE WHEELS	50 - 7
3I19	DOOR, CLEAN GRAIN LOWER AUGER	125 - 4	2B12	DRIVE WHEELS, HIGH FLOATATION.....	50 - 8
2I17	DOOR, CORNER PANEL, L.H., FRONT	80 - 12	4E19	DRIVE, BEATER AND TIGHTENER.....	140 - 40
3G17	DOOR, CYLINDER (CORN)	110 - 6	2H1	DRIVE, BELT PICKUP / REEL PUMP MOUNTING SHEAVE	70 - 42
3G15	DOOR, CYLINDER (GRAIN AND RICE)	110 - 4	4F3	DRIVE, CHOPPER (FRONT).....	140 - 48
2J18	DOOR, ENGINE ACCESS PLATFORM	80 - 38	4H1	DRIVE, COUNTERSHAFT, UNLOADING AUGER	150 - 38
2J14	DOOR, ENGINE COMPARTMENT	80 - 34	1C3	DRIVE, ENGINE.....	20 - 26
1E20	DOOR, ENGINE PLATFORM	30 - 16	1B14	DRIVE, ENGINE FAN	20 - 12
3E17	DOOR, FEEDER HOUSE FRAME	100 - 26	4F1	DRIVE, FAN, SPEED CONTROL SHEAVE LINKAGE....	140 - 46
4F16	DOOR, GRAIN TANK TOP	150 - 2	2C3	DRIVE, FINAL DRIVE SHAFT.....	50 - 24
2I21	DOOR, GULLWING, LEFT REAR.....	80 - 16	4E15	DRIVE, GEARCASE, STRAW WALKER.....	140 - 36
4G7	DOOR, HORIZONTAL UNLOADING AUGER.....	150 - 18	2C21	DRIVE, HYDROSTATIC MOTOR, FIXED.....	50 - 44
4G13	DOOR, HORIZONTAL UNLOADING AUGER HOUSING	150 - 24	2D11	DRIVE, HYDROSTATIC OIL HOSE, UPPER	50 - 62
4G15	DOOR, HORIZONTAL UNLOADING AUGER HOUSING (EXPORT)	150 - 26	2D9	DRIVE, HYDROSTATIC, LOWER OIL LINES (2-WHEEL DRIVE).....	50 - 60
2I19	DOOR, L.H. GULLWING	80 - 14	2D17	DRIVE, HYDROSTATIC, LOWER OIL LINES (4-WHEEL DRIVE).....	50 - 68
4H10	DOOR, MASS FLOW SENSOR DEFLECTOR YIELD MAPPING	155 - 6	2H3	DRIVE, REEL, FLOW CONTROL VALVE	70 - 44
2J3	DOOR, R.H. GULLWING	80 - 22	2H7	DRIVE, REEL, HYDRAULIC LINES AND HOSES, L.H. SIDE	70 - 48
2J5	DOOR, R.H., REAR	80 - 24	2H9	DRIVE, REEL, HYDRAULIC, FRONT LINES AND HOSES	70 - 50
1B10	DOOR, RADIATOR SHELL	20 - 8			
1B6	DOOR, ROTARY SCREEN	20 - 4			
3G13	DOOR, STONE TRAP, FEEDER HOUSE	110 - 2			
3J11	DOOR, TAILINGS, ELEVATOR HOUSING.....	125 - 20			
2E8	DRAIN PLUG, BRAKE MASTER CYLINDER.....	60 - 8			
1C11	DRAIN PLUG, CYLINDER BLOCK	25 - 4			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE
1C4	DRIVE, ROTARY SCREEN	20 - 27
1C5	DRIVE, ROTARY SCREEN	20 - 28
4E13	DRIVE, SECONDARY COUNTERSHAFT	140 - 34
4F5	DRIVE, STRAW CHOPPER (REAR)	140 - 50
4I15	DRUM AND SHOES, BRAKE	160 - 22
2E12	DRUM, BRAKE	60 - 12
3F7	DRUM, FEEDER CONVEYOR IDLER SHAFT	100 - 40
4E4	DUAL RANGE LOCKOUT ARM	140 - 24
4E11	DUAL-RANGE CYLINDER DRIVE ADJUSTING BRACKET	140 - 32
4E2	DUAL-RANGE CYLINDER DRIVE GEARCASE	140 - 22
4E7	DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING	140 - 28
4E9	DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHEAVE	140 - 30
4E5	DUAL-RANGE CYLINDER DRIVE TIGHTENER	140 - 26
3D7	DUCTS, HEATER AND AIR CONDITIONING	95 - 7
2B13	DUEL WHEELS, WIDE SPACED	50 - 9
3F9	DUST FAN, FEEDER HOUSE	100 - 42
3G1	DUST FAN, L.H. SIDE FEEDER HOUSE	100 - 60
4F18	DUST SHIELD, GRAIN TANK BASE	150 - 4

E

1E8	ECU	30 - 4
1G24	ECU, ELECTRONIC CONTROL UNIT	40 - 52
1B20	ELECTRICAL CORD, COOLANT HEATER	20 - 18
2D7	ELECTRICAL CONNECTION, CONTROL VALVE	50 - 58
1F6	ELECTRICAL CONNECTOR SERVICE KIT	40 - 4
1F8	ELECTRICAL CONNECTOR SERVICE KIT	40 - 6
1F13	ELECTRICAL CONVENIENCE OUTLET	40 - 12
1F4	ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK	40 - 2
1F12	ELECTRICAL TERMINALS WITH LEAD WIRES	40 - 10
1G3	ELECTRICAL WIRING, CAB	40 - 30
1F15	ELECTRICAL, ENGINE SYSTEM	40 - 14
4D23	ELECTROMAGNETIC HEADER CLUTCH	140 - 16
1E8	ELECTRONIC CONTROL UNIT	30 - 4
1G24	ELECTRONIC CONTROL UNIT (ECU)	40 - 52
1E8	ELECTRONIC FUEL INJECTION PUMP	30 - 4
1G20	ELECTRONICS MODULE, CENTRAL AND CIRCUIT BOARDS	40 - 48
3I3	ELEMENT, CHAFFER	120 - 12
3I5	ELEMENT, CHAFFER EXTENSION	120 - 14
3I9	ELEMENT, SIEVE	120 - 18
4F12	ELEVATOR DRIVE IDLER, CLEAN GRAIN	140 - 58
4F12	ELEVATOR DRIVE TIGHTENER, CLEAN GRAIN	140 - 58
3I21	ELEVATOR, LOWER, CLEAN GRAIN	125 - 6
3J11	ELEVATOR, TAILINGS ELEVATOR	125 - 20
3J11	ELEVATOR, TAILINGS HOUSING	125 - 20
2J14	ENGINE COMPARTMENT	80 - 34
1E8	ENGINE CONTROLLER	30 - 4
1G24	ENGINE CONTROLLER (ECU)	40 - 52
1C3	ENGINE DRIVE	20 - 26
1B14	ENGINE FAN AND DRIVES	20 - 12
1C23	ENGINE FLYWHEEL	25 - 16
1B17	ENGINE GEARCASE COUPLING WITH HUB	20 - 15
4D9	ENGINE GEARCASE OIL FILTER ASSEMBLY	140 - 2
4D11	ENGINE GEARCASE PRESSURE REGULATOR	140 - 4
4D17	ENGINE GEARCASE, SEPARATOR AND PUMP DRIVE	140 - 10
4D15	ENGINE GEARCASE, SEPARATOR DRIVE WET- CLUTCH AND PUMP DRIVE SHAFT	140 - 8
1B24	ENGINE INTERCOOLER	20 - 22
1C1	ENGINE MOUNTS AND REAR SUPPORT	20 - 24
1C9	ENGINE OIL (TORQ-GARD PLUS-50)	25 - 2

GRID		PAGE
1D10	ENGINE OIL COOLER	25 - 30
1D15	ENGINE OIL DIPSTICK AND TUBE	25 - 36
1D11	ENGINE OIL FILTER	25 - 32
1D6	ENGINE OIL PUMP	25 - 26
1D8	ENGINE OIL PUMP INTAKE	25 - 28
1C15	ENGINE OVERHAUL KIT	25 - 8
1E20	ENGINE PLATFORM	30 - 16
1E1	ENGINE REBUILD GASKET KIT	25 - 48
1C13	ENGINE SHORT BLOCK	25 - 6
1H20	ENGINE SPEED SENSOR	40 - 74
1F15	ENGINE WIRING HARNESS	40 - 14
1B17	ENGINE, TRANSMISSION COUPLING WITH HUB	20 - 15
3C5	ETHER START BUTTON	90 - 30
1E17	ETHER STARTING FITTINGS	30 - 13
3D10	EVAPORATOR HEATER, AIR CONDITIONER	95 - 10
1D24	EXHAUST MANIFOLD HEAT SHIELD	25 - 46
1D24	EXHAUST MANIFOLDS AND GASKETS	25 - 46
1E24	EXHAUST PIPE AND MUFFLER	30 - 20
1D1	EXHAUST VALVE SHIELD	25 - 20
1D1	EXHAUST VALVES	25 - 20
1B20	EXTENSION CORD, ENGINE BLOCK COOLANT HEATER	20 - 18
3I5	EXTENSION ELEMENT, CHAFFER	120 - 14
4F22	EXTENSIONS, GRAIN TANK	150 - 8

F

4E23	FAN DRIVE SPEED CONTROL LINKAGE	140 - 44
4F1	FAN DRIVE SPEED CONTROL SHEAVE LINKAGE	140 - 46
4E21	FAN DRIVE, CLEANING, SEPARATOR	140 - 42
1B16	FAN DRIVE, FIXED (RADIATOR)	20 - 14
1B16	FAN PULLEY HUB (RADIATOR)	20 - 14
1B19	FAN PULLEY, AIR CONDITIONER COMPRESSOR	20 - 17
3D4	FAN, BLOWER, HEATER AND AIR CONDITIONER	95 - 4
3H19	FAN, CLEANING	120 - 4
3F9	FAN, DUST, FEEDER HOUSE	100 - 42
3G1	FAN, DUST, L.H. SIDE FEEDER HOUSE	100 - 60
1B14	FAN, ENGINE	20 - 12
3D2	FAN, HEATER AND AIR CONDITIONER	95 - 2
3F9	FEEDER CONVEYOR DRIVE CHAIN & TIGHTENER ..	100 - 42
3F11	FEEDER CONVEYOR DRIVE CHAIN, TIGHTENER AND GUIDES (SIDEHILL)	100 - 44
3F7	FEEDER CONVEYOR IDLER SHAFT, DRUM AND CHAIN	100 - 40
1H9	FEEDER HOUSE BACKSHAFT SPEED SENSOR	40 - 62
3E9	FEEDER HOUSE DRIVE SHIELDS AND SAFETY STOP (SIDEHILL)	100 - 18
3E7	FEEDER HOUSE DRIVE TIGHTENER	100 - 16
3E3	FEEDER HOUSE DRIVE TIGHTENER (FIXED SPEED)	100 - 12
3G1	FEEDER HOUSE DUST FAN, L.H. SIDE	100 - 60
3F5	FEEDER HOUSE FLOOR	100 - 38
3E17	FEEDER HOUSE FRAME	100 - 26
3E19	FEEDER HOUSE FRAME, SIDEHILL	100 - 28
3G7	FEEDER HOUSE FRONT DRIVE SHAFT, SHEAVE (FIXED SPEED WITH REVERSER)	100 - 66
3D21	FEEDER HOUSE GEARCASE OIL COOLER	100 - 4
3G3	FEEDER HOUSE LEVELING CABLES, SHEAVES AND BRACKETS, SIDEHILL (UPPER REAR)	100 - 62
3F17	FEEDER HOUSE LOWER SHAFT, PADDLES AND SPROCKET (SIDEHILL)	100 - 50
3E23	FEEDER HOUSE OUTER CLOSURE FRAME (SIDEHILL)	100 - 32
3F24	FEEDER HOUSE POSITION SENSOR	100 - 58
3C7	FEEDER HOUSE REVERSER FOOT CONTROL	90 - 32
3E21	FEEDER HOUSE SHELL, CONTOUR MASTER	100 - 30

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3F1	FEEDER HOUSE SLIP CLUTCH	100 - 34	4H22	FRAME MOUNTING, TRACK	160 - 2
3G5	FEEDER HOUSE UPPER DRIVE SHAFT, SHEAVE (FIXED SPEED WITH REVERSER)	100 - 64	3I7	FRAME, CHAFFER	120 - 16
3F1	FEEDER HOUSE UPPER SHAFT	100 - 34	3E17	FRAME, FEEDER HOUSE	100 - 26
3F19	FEEDER HOUSE VARIABLE DRIVE HYDRAULIC HOSE	100 - 52	3E21	FRAME, FEEDER HOUSE, CONTOUR MASTER	100 - 30
3E21	FEEDER HOUSE WEAR PLATES, CONTOUR MASTER	100 - 30	3E19	FRAME, FEEDER HOUSE, SIDEHILL	100 - 28
3G13	FEEDER HOUSE/SEPARATOR SEAL, STONE TRAP AND DOOR	110 - 2	4H24	FRAME, MAIN, PIVOT BUSHINGS	160 - 4
3F20	FEEDER HOUSE, UPPER COUNTERSHAFT VARIABLE DRIVE	100 - 54	3E23	FRAME, OUTER CLOSURE, FEEDER HOUSE (SIDEHILL)	100 - 32
3E11	FEEDHOUSE DRIVE SHIELD, LH WITHOUT AIRFLOW	100 - 20	2I7	FRAME, SEPARATOR	80 - 2
3H1	FILLER STRIPS, CONCAVE	110 - 14	4H22	FRAME, SHIPPING	160 - 2
1E22	FILTER, AIR AND INTAKE TUBES	30 - 18	3I11	FRAME, SIEVE	120 - 20
3D4	FILTER, AIR, RECIRCULATION	95 - 4	4J19	FRENCH CANADIAN DECALS AND LABELS	170 - 22
3D6	FILTER, CAB AIR	95 - 6	4I1	FRONT ARM AND ADJUSTABLE IDLER ASSEMBLY ..	160 - 6
1D11	FILTER, ENGINE OIL	25 - 32	2B6	FRONT AXLE (SIDEHILL)	50 - 2
3D10	FILTER, EVAPORATOR HEATER	95 - 10	1C24	FRONT OIL SEAL, TIMING GEAR	25 - 17
1E14	FILTER, FUEL	30 - 10	3F3	FRONT SHAFT SLIP CLUTCH, FEEDER HOUSE (SIDEHILL)	100 - 36
1E18	FILTER, FUEL TANK	30 - 14	2I13	FRONT SHIELD ASSEMBLY, RIGHT SIDE	80 - 8
2H19	FILTER, MAIN HYDRAULIC	70 - 60	1E14	FUEL CHECK VALVE	30 - 10
4D9	FILTER, OIL, ENGINE GEARCASE	140 - 2	1E13	FUEL COOLER	30 - 9
1C24	FILTER, WATER PUMP (WEEP HOLE)	25 - 17	1E14	FUEL FILTER AND LINES	30 - 10
1G11	FILTER, WINDSHIELD WASHER	40 - 38	1E18	FUEL GUAGE	30 - 14
2C10	FINAL DRIVE HOUSING AND BEARING CAP (SIDEHILL)	50 - 32	1E6	FUEL INJECTION LINES AND NOZZLES	30 - 2
2C6	FINAL DRIVE INNER CASTING AND PIVOT TUBE (SIDEHILL)	50 - 28	1E12	FUEL INJECTION NOZZLE	30 - 8
4I13	FINAL DRIVE MOUNTING, SINGLE REDUCTION	160 - 20	1E8	FUEL INJECTION PUMP	30 - 4
2C8	FINAL DRIVE PINION, SHAFTS AND BEARINGS	50 - 30	1E10	FUEL INJECTION PUMP HOUSING CONNECTORS ...	30 - 6
2D24	FINAL DRIVE SHAFT SHIELDS - SINGLE REDUCTION (RICE ONLY)	50 - 75	1E6	FUEL LEAK-OFF LINES	30 - 2
2C4	FINAL DRIVE SHAFTS (SIDEHILL)	50 - 26	1E8	FUEL LEAK-OFF LINES (FUEL PUMP)	30 - 4
2C7	FINAL DRIVE SUPPORT SHIELD (SIDEHILL)	50 - 29	1E8	FUEL PUMP	30 - 4
1I3	FINDER, SIDE LIGHT	40 - 82	1E18	FUEL SENDER	30 - 14
4B9	FINE CUT ROTOR CHOPPER (STRAIGHT BLADE) ...	130 - 6	1E8	FUEL SHUT-OFF SOLENOID	30 - 4
3H5	FINGER GRATE, SPIKE-TOOTH	110 - 18	1E18	FUEL TANK GAUGE	30 - 14
3F9	FINGER, FEEDER HOUSE DUST FAN	100 - 42	2J16	FUEL TANK STEPS	80 - 36
3G1	FINGER, FEEDER HOUSE DUST PAN, L.H.	100 - 60	1E18	FUEL TANK, SUPPORTS, AND FITTINGS	30 - 14
3H23	FINGER, PRECLEANER CHAFFER	120 - 8	1E11	FUEL TRANSFER PUMP	30 - 7
3I5	FINGERS, PLASTIC, CHAFFER	120 - 14	1E11	FUEL TRANSFER PUMP HAND PRIMER	30 - 7
2H24	FITTINGS, CHAFF SPREADER	70 - 66	G		
1C11	FITTINGS, CYLINDER BLOCK	25 - 4	1E1	GASKET KIT, CYLINDER HEAD	25 - 48
1E17	FITTINGS, ETHER STARTING	30 - 13	1E1	GASKET KIT, ENGINE REBUILD	25 - 48
1E18	FITTINGS, FUEL TANK	30 - 14	1E1	GASKET KIT, SHORT BLOCK	25 - 48
2H21	FITTINGS, TILT CYLINDER, CONTOUR MASTER	70 - 62	1D1	GASKET, CYLINDER HEAD	25 - 20
2B7	FIXED REAR AXLE	50 - 3	1D24	GASKET, EXHAUST MANIFOLD	25 - 46
2F6	FIXED REAR AXLE STEERING TIE RODS	60 - 32	1D20	GASKET, INTAKE MANIFOLD	25 - 42
3E3	FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER ..	100 - 12	1D11	GASKET, OIL FILTER HOUSING	25 - 32
2I23	FLOODLAMP, LEFT REAR CORNER PANEL	80 - 18	1D13	GASKET, OIL PAN	25 - 34
3B9	FLOOR MAT	90 - 8	1D8	GASKET, OIL PUMP INTAKE, ENGINE	25 - 28
3B7	FLOOR PANELS, CAB	90 - 6	1D6	GASKET, OIL PUMP, ENGINE	25 - 26
3F5	FLOOR, FEEDER HOUSE	100 - 38	1C22	GASKET, REAR CRANKSHAFT OIL SEAL	25 - 15
2H3	FLOW CONTROL VALVE, REEL DRIVE	70 - 44	1D4	GASKET, ROCKER ARM COVER	25 - 23
4D3	FLOW DIVIDER VALVE AND MOUNTING (SIDEHILL)	135 - 18	1D18	GASKET, THERMOSTAT	25 - 40
4C11	FLOW DIVIDER, LEVELING SYSYEM (SIDEHILL)	135 - 2	1C24	GASKET, TIMING GEAR COVER	25 - 17
4H10	FLOW SENSOR, MASS, YIELD MAPPING	155 - 6	1D22	GASKET, TURBOCHARGER	25 - 44
1C23	FLYWHEEL	25 - 16	1D18	GASKET, WATER MANIFOLD	25 - 40
1C25	FOLLOWER, CAMSHAFT	25 - 18	1D16	GASKET, WATER PUMP	25 - 38
1D3	FOLLOWER, ROCKER ARM	25 - 22	2G20	GAUGE, PRESSURE, ACCUMULATOR	70 - 36
3C7	FOOT PEDAL, FEEDER HOUSE REVERSER	90 - 32	2C1	GEAR AND SHAFTS, DIFFERENTIAL (SIDEHILL)	50 - 22
2D19	FOUR WHEEL DRIVE HYDRAULIC LINES AND HOSES, L.H.	50 - 70	3E1	GEAR BOX, REVERSER (STANDARD)	100 - 10
2I7	FRAME	80 - 2	3D23	GEAR BOX, REVERSER, HIGH CAPACITY	100 - 6
			3D25	GEAR BOX, REVERSER, HIGH CAPACITY	100 - 8
			1C25	GEAR, CAMSHAFT	25 - 18
			2B23	GEAR, DIFFERENTIAL	50 - 20
			2C8	GEAR, FINAL DRIVE, SINGLE REDUCTION	50 - 30
			1E8	GEAR, INJECTION PUMP	30 - 4

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1C18	GEAR, OIL PUMP DRIVE, CRANKSHAFT.....	25 - 11	2I19	HANDLE, GULLWING DOOR, L.H.....	80 - 14
1D6	GEAR, OIL PUMP, ENGINE	25 - 26	3B24	HANDLE, HYDROSTATIC CONTROL	90 - 24
3H17	GEAR, SHOE GRAIN AUGER	120 - 2	2I9	HANDLE, LEFT SIDE FRONT SHIELD	80 - 4
4B24	GEAR, STRAW SPREADER	130 - 22	2I15	HANDLE, RIGHT SIDE SHIELD	80 - 10
2B19	GEAR, TRANSMISSION	50 - 16	3H16	HANDLE, SHOE GRAIN AUGER CLEANOUT DOOR....	120 - 1
4E15	GEARCASE DRIVE, STRAW WALKER	140 - 36	3I9	HANDLE, SIEVE ELEMENT	120 - 18
3J3	GEARCASE, CLEAN GRAIN ELEVATOR	125 - 12	2J14	HANDRAIL, ENGINE COMPARTMENT	80 - 34
4D19	GEARCASE, DRIVE SHAFT AND PRIMARY COUNTERSHAFT	140 - 12	3C20	HANDRAIL, L.H.....	90 - 46
4E2	GEARCASE, DUAL-RANGE CYLINDER DRIVE	140 - 22	3C22	HANDRAIL, R.H.	90 - 48
4D15	GEARCASE, ENGINE	140 - 8	2J5	HANDRAIL, REAR DOOR, R.H.	80 - 24
4D17	GEARCASE, ENGINE	140 - 10	3C17	HANDRAILS	90 - 42
3D25	GEARCASE, HIGH CAPACITY	100 - 8	3C24	HARDWARE KIT, CAB	90 - 50
4G12	GEARCASE, HORIZONTAL UNLOADING AUGER DRIVE	150 - 23	4H16	HARNES, DATASTORE	155 - 12
4D13	GEARCASE, MAIN.....	140 - 6	4H12	HARNES, MOISTURE SENSOR MOTOR YIELD MAPPING	155 - 8
4D21	GEARCASE, PRIMARY COUNTERSHAFT	140 - 14	1H7	HARNES, STARTER, WIRING	40 - 60
4I11	GEARCASE, TRANSFER	160 - 18	4D5	HARNES, WIRING, LEVELING (SIDEHILL).....	135 - 20
4F24	GEARCASE, VERTICAL AUGER LOWER	150 - 10	1G15	HARVESTRAK WIRING HARNES	40 - 42
2F16	GEARS, MAIN HYDRAULIC PUMP	70 - 6	1D1	HEAD BOLT KIT, CYLINDER	25 - 20
2B21	GEARS, TRANSMISSION PINION	50 - 18	1D1	HEAD, CYLINDER	25 - 20
3C9	GEARSHIFT LEVER AND LINKAGE	90 - 34	3G9	HEADER DRIVE SHAFT, SIDEHILL	100 - 68
3B13	GLASS, CAB AND DOOR.....	90 - 12	4D23	HEADER ELECTROMAGNETIC CLUTCH	140 - 16
3C11	GRAIN LOSS DISPLAY, R.H. CORNERPOST.....	90 - 36	2G7	HEADER HEIGHT CONTROL HYDRAULIC LINE AND VALVE BLOCK	70 - 22
1G16	GRAIN LOSS MONITOR WIRING HARNES	40 - 43	2G6	HEADER HEIGHT CONTROL VALVE	70 - 21
3I13	GRAIN PAN, SHAKER.....	120 - 22	2G13	HEADER LIFT CYLINDER, HYDRAULIC	70 - 29
4F20	GRAIN TANK AND CURTAINS.....	150 - 6	4C23	HEADER LIFT HYDRAULIC LINES AND HOSES (SIDEHILL).....	135 - 14
4F18	GRAIN TANK BASE.....	150 - 4	2G14	HEADER LIFT LINES AND HOSES	70 - 30
4G21	GRAIN TANK CROSS AUGERS.....	150 - 32	2G8	HEADER LIFT MODULE, SOLENOID CONTROL VALVE	70 - 24
1G17	GRAIN TANK DUAL LEVEL MONITOR HARNES.....	40 - 44	4C19	HEADER LIFT SUPPORT (SIDEHILL)	135 - 10
4F22	GRAIN TANK EXTENSIONS.....	150 - 8	1D24	HEAT SHIELD, EXHAUST MANIFOLD.....	25 - 46
1G19	GRAIN TANK FULL BIN SENSOR	40 - 46	3D7	HEATER AND AIR CONDITIONING DUCTS	95 - 7
4H4	GRAIN TANK SAMPLING TROUGH.....	150 - 41	3D4	HEATER AND AIR CONDITIONING HOUSING, LOWER	95 - 4
4F16	GRAIN TANK TOP.....	150 - 2	3D2	HEATER AND AIR CONDITIONING HOUSING, UPPER	95 - 2
4G24	GRAIN TANK UNLOADING DRIVE CYLINDER AND MOUNTING	150 - 36	1C2	HEATER HOSE CONNECTORS.....	20 - 25
4G1	GRAIN TANK VERTICAL UNLOADING AUGER AND MOUNTING	150 - 12	1B20	HEATER, COOLANT, ENGINE BLOCK	20 - 18
1G18	GRAIN TANK WIRING HARNES	40 - 45	2B12	HIGH FLOATATION DRIVE WHEELS	50 - 8
3H6	GRATE CURTAIN, BEATER	110 - 19	3I19	HINGE, DOOR, CLEAN GRAIN LOWER AUGER	125 - 4
3H1	GRATE, BEATER (NARROW).....	110 - 14	3E17	HINGE, DOOR, FEEDER HOUSE FRAME	100 - 26
3H5	GRATE, FINGER, SPIKE-TOOTH.....	110 - 18	4F16	HINGE, DOOR, GRAIN TANK TOP	150 - 2
3H3	GRATE, SPIKE-TOOTH CONCAVE	110 - 16	2J14	HINGE, ENGINE COMPARTMENT DOOR.....	80 - 34
2J8	GRIP, LADDER, REAR	80 - 28	4F22	HINGE, GRAIN TANK EXTENSIONS	150 - 8
2J10	GRIP, LATCH ARM, REAR LADDER	80 - 30	2I19	HINGE, GULLWING DOOR, L.H.	80 - 14
2B23	GROUND SPEED SENSOR	50 - 20	2I21	HINGE, LEFT REAR GULLWING	80 - 16
2C1	GROUND SPEED SENSOR (SIDEHILL)	50 - 22	2J3	HINGE, R.H. GULLWING DOOR	80 - 22
4B22	GUARD AND STRAW SPREADER MOUNTING	130 - 20	2J5	HINGE, REAR DOOR, R.H.	80 - 24
3F9	GUIDES, FEEDER CONVEYOR DRIVE CHAIN	100 - 42	3I19	HINGED DOOR, LOWER AUGER, CLEAN GRAIN.....	125 - 4
3F11	GUIDES, TIGHTENER AND FEEDER CONVEYOR DRIVE CHAIN (SIDEHILL)	100 - 44	2J12	HOOD, REAR.....	80 - 32
2I19	GULLWING DOOR, L.H.	80 - 14	1E20	HOOK, ENGINE PLATFORM	30 - 16
2I21	GULLWING DOOR, LEFT REAR	80 - 16	4G17	HORIZONTAL UNLOADING AUGER	150 - 28
2J3	GULLWING DOOR, R.H.	80 - 22	4G12	HORIZONTAL UNLOADING AUGER DRIVE GEARCASE	150 - 23
H			4G13	HORIZONTAL UNLOADING AUGER HOUSING	150 - 24
1E11	HAND PRIMER, FUEL TRANSFER PUMP	30 - 7	4G15	HORIZONTAL UNLOADING AUGER HOUSING (EXPORT)	150 - 26
4C5	HANDLE AND SHIELDS, CHAFF SPREADER	130 - 28	4G11	HORIZONTAL UNLOADING AUGER HUB SUPPORT AND SWITCH	150 - 22
3B15	HANDLE, CAB DOOR	90 - 14	4G7	HORIZONTAL UNLOADING AUGER SWIVEL.....	150 - 18
3B7	HANDLE, CAB REAR	90 - 6	3B6	HORN ASSEMBLY.....	90 - 4
3I3	HANDLE, CHAFFER ELEMENT	120 - 12	3C5	HORN BUTTON.....	90 - 30
3I5	HANDLE, CHAFFER EXTENSION	120 - 14	3D12	HOSE, AIR CONDITIONER COMPRESSOR	95 - 12
3G17	HANDLE, CYLINDER DOOR (CORN)	110 - 6	2H5	HOSE, HYDRAULIC, REEL PUMP	70 - 46
3G15	HANDLE, CYLINDER DOOR, GRAIN AND RICE	110 - 4			
3F5	HANDLE, FEEDER HOUSE LATCH.....	100 - 38			

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
3F19	HOSE, HYDRAULIC, VARIABLE DRIVE, FEEDER HOUSE.....	2H19	HYDRAULIC FILTER ASSEMBLY, MAIN.....
	100 - 52	2H17	HYDRAULIC HOSE, CONTOUR MASTER (L.H.)
2D15	HOSE, HYDROSTATIC OIL COOLER	3F19	HYDRAULIC HOSE, VARIABLE DRIVE, FEEDER HOUSE.....
2F18	HOSE, OIL AND AIR CONDITIONER CONDENSER		100 - 52
2D11	HOSE, OIL, HYDROSTATIC DRIVE, UPPER	2H5	HYDRAULIC HOSES, REEL PUMP
2D19	HOSE, 4-WHEEL DRIVE HYDRAULIC, L.H.	2G22	HYDRAULIC LINES AND HOSES, CYLINDER SPEED
2G14	HOSES AND LINES, HEADER LIFT		70 - 38
4C23	HOSES AND LINES, HYDRAULIC, HEADER LIFT (SIDEHILL).....	2G14	HYDRAULIC LINES AND HOSES, HEADER LIFT
	135 - 14	4C23	HYDRAULIC LINES AND HOSES, HEADER LIFT (SIDEHILL).....
2H9	HOSES AND LINES, REEL DRIVE, FRONT		135 - 14
2H15	HOSES AND LINES, REEL LIFT	2D19	HYDRAULIC LINES AND HOSES, L.H., 4-WHEEL DRIVE
2E18	HOSES AND LINES, STEERING, FRONT		50 - 70
2E24	HOSES AND LINES, STEERING, REAR	2H13	HYDRAULIC LINES AND HOSES, REEL FORE-AND-AFT, FRONT
4G3	HOSES AND LINES, UNLOADING AUGER SWING HYDRAULIC CYLINDER		70 - 54
	150 - 14	2F20	HYDRAULIC LINES AND HOSES, WET CLUTCH OIL COOLER.....
2F20	HOSES AND LINES, WET CLUTCH OIL COOLER		70 - 10
3D21	HOSES, FEEDER HOUSE GEARCASE COOLER	2D23	HYDRAULIC LINES, CASE DRAIN, 4-WHEEL DRIVE
4G24	HOSES, GRAIN TANK UNLOADING DRIVE CYLINDER		50 - 74
	150 - 36	2H11	HYDRAULIC LINES, REEL FORE-AND-AFT, L.H. SIDE
2H17	HOSES, HYDRAULIC, CONTOUR MASTER (L.H.).....		70 - 52
2G22	HOSES, HYDRAULIC, CYLINDER SPEED	4G5	HYDRAULIC MOUNTING, UNLOADING AUGER SWING
4C15	HOSES, LEVELING CYLINDER (SIDEHILL)		150 - 16
2I3	HOSES, LINES, CHAFF SPREADER	2F12	HYDRAULIC PRESSURE LINES AND HOSES
2D13	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (SIDEHILL 2 WHEEL DRIVE).....	2F16	HYDRAULIC PUMP, MAIN
	50 - 64	2F14	HYDRAULIC RETURN LINES, UPPER
2D9	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (2-WHEEL DRIVE).....	2F11	HYDRAULIC/HYDROSTATIC OIL RESERVOIR.....
	50 - 60	4I19	HYDRAULICS, TENSION CYLINDER.....
2D17	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE).....	2C18	HYDROSTATIC DRIVE CHARGE PUMP
	50 - 68	2C12	HYDROSTATIC DRIVE CONTROL CABLES
2F12	HOSES, PRESSURE, HYDRAULIC	2C19	HYDROSTATIC DRIVE DISPLACEMENT CONTROL VALVE.....
1B12	HOSES, RADIATOR		50 - 42
2H7	HOSES, REEL DRIVE, HYDRAULIC, L.H. SIDE	2C21	HYDROSTATIC DRIVE MOTOR, FIXED
2E20	HOSES, STEERING, L.H. SIDE	2D11	HYDROSTATIC DRIVE OIL HOSE, UPPER
2E16	HOSES, STEERING, UPPER	2D13	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (SIDEHILL 2 WHEEL DRIVE).....
2H21	HOSES, TILT CYLINDER, CONTOUR MASTER.....		50 - 64
2F14	HOSES, UPPER RETURN, HYDRAULIC.....	2D9	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (2-WHEEL DRIVE)
2D21	HOSES, 4-WHEEL DRIVE, FLOW CONTROL TO CAM LOBE MOTOR		50 - 60
	50 - 72	2D17	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (4-WHEEL DRIVE)
2C10	HOUSING AND BEARING CAP, FINAL DRIVE (SIDEHILL).....		50 - 68
3H17	HOUSING AND SHOE GRAIN SUPPLY AUGERS	2C14	HYDROSTATIC DRIVE PUMP SHAFT AND COVER ...
1E10	HOUSING CONNECTORS, FUEL INJECTION PUMP ..	2D15	HYDROSTATIC OIL COOLER LINES AND HOSES
2B18	HOUSING COVER, TRANSMISSION AND DIFFERENTIAL	2F11	HYDROSTATIC/HYDRAULIC RESERVOIR
	50 - 14		70 - 1
3D4	HOUSING, AIR CONDITIONER/HEATER, LOWER		
3D2	HOUSING, AIR CONDITIONER/HEATER, UPPER		
3D6	HOUSING, CAB AIR FILTER		
4G1	HOUSING, CHARGE, VERTICAL UNLOADING AUGER.....		
	150 - 12		
4G13	HOUSING, HORIZONTAL UNLOADING AUGER.....		
4G15	HOUSING, HORIZONTAL UNLOADING AUGER (EXPORT)		
	150 - 26		
2C16	HOUSING, HYDROSTATIC PUMP		
1D11	HOUSING, OIL FILTER		
1C22	HOUSING, REAR CRANKSHAFT OIL SEAL		
2B7	HOUSING, SPINDLE, REAR AXLE (REGULAR DUTY)		
	50 - 3		
3J11	HOUSING, TAILINGS ELEVATOR		
1D18	HOUSING, THERMOSTAT, FRONT		
2B17	HOUSING, TRANSMISSION AND DIFFERENTIAL		
3J19	HOUSING, UPPER TAILINGS AUGER		
4G11	HUB SUPPORT, HORIZONTAL AUGER		
4I10	HUB, BOGEY WHEEL		
1B16	HUB, FAN PULLEY (RADIATOR)		
4I7	HUB, IDLER WHEEL		
1C4	HUB, ROTARY SCREEN DRIVE		
1C5	HUB, ROTARY SCREEN DRIVE		
	20 - 27		
	20 - 28		
		1B4	IDLER ARMS, ROTARY SCREEN DRIVE
		4I1	IDLER ASSEMBLY, ADJUSTABLE AND FRONT ARM..
		4I5	IDLER AXLE.....
		3F13	IDLER BRACKET, FEEDER CONVEYOR
		1B19	IDLER PULLEY, AIR CONDITIONER COMPRESSOR ..
		4I7	IDLER WHEEL ASSEMBLY
		3F15	IDLER, DRIVE CHAIN (SIDEHILL)
		4F12	IDLER, DRIVE, CLEAN GRAIN ELEVATOR
		3F7	IDLER, FEEDER HOUSE CONVEYOR
		3G1	IDLER, FEEDER HOUSE DUST PAN, L.H.
		4B24	IDLER, STRAW SPREADER.....
		3C5	IGNITION SWITCH
		3F24	INDICATOR, FEEDER HOUSE POSITION
		1H14	INDICATOR, SPIKE TOOTH.....
		1E8	INJECTION PUMP GEAR
		1E8	INJECTION PUMP LUBE LINE
		1E8	INJECTION PUMP, ELECTRONIC FUEL.....
		2C6	INNER CASTING, PIVOT TUBE, FINAL DRIVE (SIDEHILL).....
			50 - 28
		2D1	INNER COVER.....
			50 - 50
		2B19	INPUT SHAFT, TRANSMISSION
			50 - 16

I

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3H1	INSERTS, CONCAVE	110 - 14			
1D1	INSERTS, VALVE SEAT	25 - 20			
1I5	INSPECTION LIGHT, CLEANING SHOE	40 - 84			
1D20	INTAKE MANIFOLD AND GASKET	25 - 42			
3H19	INTAKE SHIELDS, CLEANING FAN	120 - 4			
1E22	INTAKE TUBES AND AIR CLEANER	30 - 18			
1D1	INTAKE VALVES, CYLINDER HEAD	25 - 20			
1D8	INTAKE, ENGINE OIL PUMP	25 - 28			
1B24	INTERCOOLER	20 - 22			
3B11	INTERIOR CAB ROOF	90 - 10			
4E7	INTERMEDIATE SHAFT MOUNTING, CYLINDER DRIVE, DUAL-RANGE	140 - 28			
4E9	INTERMEDIATE SHEAVE, CYLINDER DRIVE, DUAL-RANGE	140 - 30			
J					
4D19	JACKSHAFT, PRIMARY COUNTERSHAFT	140 - 12			
4E21	JACKSHAFT, SEPARATOR FAN DRIVE	140 - 42			
4F5	JACKSHAFT, STRAW CHOPPER DIVE, REAR	140 - 50			
4I11	JACKSHAFT, TRANSFER GEARCASE	160 - 18			
4H1	JACKSHIFT, UNLOADING AUGER COUNTERSHAFT ..	150 - 38			
K					
1C18	KEY, DAMPER, CRANKSHAFT	25 - 11			
3D14	KIT, AIR CONDITIONING COMPRESSOR	95 - 14			
1F13	KIT, CONVENIENCE OUTLET	40 - 12			
1E1	KIT, CYLINDER HEAD	25 - 48			
1D1	KIT, CYLINDER HEAD BOLT	25 - 20			
1F6	KIT, ELECTRICAL CONNECTOR SERVICE	40 - 4			
1F8	KIT, ELECTRICAL CONNECTOR SERVICE	40 - 6			
1C15	KIT, ENGINE OVERHAUL	25 - 8			
1E1	KIT, ENGINE REBUILD	25 - 48			
3C24	KIT, HARDWARE, CAB	90 - 50			
2C23	KIT, HYDROSTATIC MOTOR VALVE	50 - 46			
4D2	KIT, LEVELING CYLINDER (SIDEHILL)	135 - 17			
4D1	KIT, LEVELING CYLINDER, SIDEHILL	135 - 16			
3B21	KIT, LUMBAR	90 - 20			
4B11	KIT, PADDLE BLADE, FINE CUT CHOPPER	130 - 8			
1C17	KIT, PISTON/LINER	25 - 10			
3G21	KIT, RASP BAR THRESHING CYLINDER	110 - 10			
3D15	KIT, SEAL, COMPRESSOR, REFRIGERANT	95 - 15			
3H11	KIT, STRAW WALKER BEARING	110 - 24			
1F10	KIT, TERMINAL AND WIRING	40 - 8			
1C19	KIT, UNDERSIZE CRANKSHAFT (CONNECTING ROD JOURNAL)	25 - 12			
1C20	KIT, UNDERSIZED MAIN BEARING CRANKSHAFT	25 - 13			
1D16	KIT, WATER PUMP	25 - 38			
4B13	KNIFE, CHOPPER HOUSING	130 - 10			
4B13	KNIFEBANK AND HOUSING, CHOPPER	130 - 10			
3B24	KNOB, ARMREST CONTROL PANEL	90 - 24			
3C1	KNOB, ARMREST CONTROL PANEL	90 - 26			
3D6	KNOB, CAB AIR FILTER DOOR	95 - 6			
2H22	KNOB, CHAFF SPREADER CONTROL	70 - 64			
4F16	KNOB, DOOR, GRAIN TANK TOP	150 - 2			
2I17	KNOB, DOOR, LEFT FRONT PANEL	80 - 12			
3C9	KNOB, GEARSHIFT LEVER	90 - 34			
3B21	KNOB, LUMBAR	90 - 20			
3C13	KNOB, POTENTIOMETER	90 - 38			
				L	
1F17	L.H. MAIN WIRING HARNESS	40 - 16			
1F18	L.H. MAIN WIRING HARNESS	40 - 18			
4J17	LABEL, AXLE STOP AND TIRE CLEARANCE	170 - 20			
4J17	LABEL, TIRE CLEARANCE	170 - 20			
4J17	LABEL, TIRE PRESSURE	170 - 20			
4J17	LABEL, WHEEL BOLT TORQUE	170 - 20			
4J19	LABELS, FRENCH CANADIAN	170 - 22			
4J20	LABELS, PORTUGUESE	170 - 23			
4J21	LABELS, ROMANIAN	170 - 24			
4J22	LABELS, RUSSIAN	170 - 25			
4J15	LABELS, SAFETY (RUBBER TRACK)	170 - 18			
4J23	LABELS, SPANISH	170 - 26			
4J24	LABELS, UKRAINIAN	170 - 27			
3C19	LADDER AND LATCH, OPERATOR'S PLATFORM	90 - 44			
3C17	LADDER EXTENSION	80 - 42			
2J14	LADDER, ENGINE COMPARTMENT	80 - 34			
4F16	LADDER, GRAIN TANK	150 - 2			
3C17	LADDER, HANDRAILS AND EXTENSION	90 - 42			
2J8	LADDER, REAR	80 - 28			
2J5	LAMP, SERVICE, R.H. REAR DOOR	80 - 24			
1I4	LAMP, TRANSPORT WARNING LIGHTS	40 - 83			
2J8	LANDING AND LADDER, REAR	80 - 28			
3C20	LANDING, L.H.	90 - 46			
3C22	LANDING, R.H.	90 - 48			
2J10	LANDING, REAR LADDER	80 - 30			
3C19	LATCH AND LADDER, OPERATOR'S PLATFORM	90 - 44			
2J10	LATCH ARM, REAR LADDER LANDING	80 - 30			
3F5	LATCH HANDLE, FEEDER HOUSE	100 - 38			
1E22	LATCH, AIR CLEANER	30 - 18			
3B15	LATCH, CAB DOOR	90 - 14			
4B18	LATCH, CHOP-TO-BALE	130 - 16			
2I17	LATCH, DOOR, LEFT FRONT PANEL	80 - 12			
3E11	LATCH, DRIVE SHIELD	100 - 20			
4F24	LATCH, GRAIN TANK CLEAN OUT CHUTE	150 - 10			
4F16	LATCH, GRAIN TANK TOP	150 - 2			
3H16	LATCH, SHOE GRAIN AUGER CLEANOUT DOOR	120 - 1			
3J11	LATCH, TAILINGS, ELEVATOR HOUSING	125 - 20			
2I11	LEFT SIDE SHIELD ASSEMBLY	80 - 6			
1H25	LENS, FRONT (AMBER)	40 - 79			
1H24	LENS, FRONT, AMBER	40 - 78			
3G3	LEVELING CABLES, FEEDER HOUSE, SIDEHILL, (UPPER REAR)	100 - 62			
4C21	LEVELING CABLES, SHEAVES AND BRACKETS SIDEHILL (LOWER FRONT)	135 - 12			
4D6	LEVELING CONTROL ASSEMBLY (SIDEHILL)	135 - 21			
4C15	LEVELING CYLINDER HOSES AND OIL LINES (SIDEHILL)	135 - 6			
4C17	LEVELING CYLINDER MOUNTING BRACKETS (SIDEHILL)	135 - 8			
4C13	LEVELING CYLINDER OIL LINES (SIDEHILL)	135 - 4			
4C17	LEVELING CYLINDER PINS (SIDEHILL)	135 - 8			
4D1	LEVELING CYLINDER, SIDEHILL	135 - 16			
4C11	LEVELING SOLENOID VALVE AND FLOW DIVIDER (SIDEHILL)	135 - 2			
4D4	LEVELING VALVE	135 - 19			
4D5	LEVELING WIRING HARNESS (SIDEHILL)	135 - 20			
4B20	LEVER, DECLUTCHING, CHOP-TO-DROP	130 - 18			
3C9	LEVER, GEARSHIFT	90 - 34			
3B21	LEVER, LUMBAR ADJUSTMENT	90 - 20			
2G13	LIFT CYLINDER, HEADER, HYDRAULIC	70 - 29			
1D5	LIFT STRAPS, ENGINE	25 - 24			
4C19	LIFT SUPPORT, HEADER (SIDEHILL)	135 - 10			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1H24	LIGHT ASSEMBLY, L.H. FRONT	40 - 78	4E4	LOCKOUT ARM, DUAL RANGE	140 - 24
111	LIGHT ASSEMBLY, REAR, AMBER	40 - 80	3B17	LOUVER, CAB	90 - 16
3J11	LIGHT SWITCH, TAILINGS ELEVATOR	125 - 20	1H21	LOW SHAFT SPEED SENSORS AND BRACKETS	40 - 75
1H23	LIGHT, CAB ROOF	40 - 77	3I19	LOWER AUGER, CLEAN GRAIN	125 - 4
3B11	LIGHT, CAB ROOF	90 - 10	3I21	LOWER ELEVATOR, CLEAN GRAIN	125 - 6
115	LIGHT, CLEANING SHOE INSPECTION	40 - 84	2D13	LOWER HYDROSTATIC DRIVE OIL LINES AND HOSES (SIDEHILL 2 WHEEL DRIVE)	50 - 64
1H25	LIGHT, R.H. FRONT	40 - 79	2D9	LOWER HYDROSTATIC DRIVE OIL LINES AND HOSES (2-WHEEL DRIVE)	50 - 60
112	LIGHT, REAR TURN AND TAIL	40 - 81	2D17	LOWER HYDROSTATIC DRIVE OIL LINES AND HOSES (4-WHEEL DRIVE)	50 - 68
2J18	LIGHT, REAR, ENGINE ACCESS PLATFORM	80 - 38	3J15	LOWER TAILINGS AUGER AND SHAFT	125 - 24
2J14	LIGHT, SERVICE, ENGINE COMPARTMENT	80 - 34	3J17	LOWER TAILINGS AUGER DRIVE TIGHTENER	125 - 26
2I19	LIGHT, SERVICE, L.H. GULLWING	80 - 14	3J15	LOWER TAILINGS AUGER SHAFT TIGHTENER	125 - 24
2J3	LIGHT, SERVICE, R.H. GULLWING	80 - 22	3J9	LOWER TAILINGS AUGER TROUGH	125 - 18
2J5	LIGHT, SERVICE, R.H. REAR DOOR	80 - 24	1C10	LUBRICANT, ELECTRICAL CONNECTOR, ENGINE	25 - 3
113	LIGHT, SIDE FINDER	40 - 82	1C10	LUBRICANT, VALVE STEM	25 - 3
3B4	LIGHT, STUBBLE LIGHT, CAB SUPPORT	90 - 2			
114	LIGHT, TRANSPORT WARNING	40 - 83		M	
1G17	LIGHT, UNLOADING AUGER	40 - 44	1H21	MAGNET, LOW SPEED SENSORS AND BRACKETS ..	40 - 75
2G7	LINE, HYDRAULIC, HEADER HEIGHT CONTROL	70 - 22	1H20	MAGNETIC PICK-UP (ENGINE)	40 - 74
1E8	LINE, INJECTION PUMP LUBE	30 - 4	1C11	MAIN BEARING CAPS, CYLINDER BLOCK	25 - 4
2C10	LINE, OIL - FINAL DRIVE HOUSING (SIDEHILL)	50 - 32	1C21	MAIN BEARINGS (8400)	25 - 14
1C17	LINER SHIM	25 - 10	4H24	MAIN FRAME PIVOT BUSHINGS	160 - 4
1C17	LINERS, CYLINDER	25 - 10	4D13	MAIN GEARCASE	140 - 6
2H24	LINES AND FITTINGS, CHAFF SPREADER	70 - 66	2F16	MAIN HYDRAULIC PUMP	70 - 6
2G14	LINES AND HOSES, HEADER LIFT	70 - 30	2G6	MAIN VALVE BLOCK SOLENOID ACTIVE HEADER HEIGHT CONTROL	70 - 21
4C23	LINES AND HOSES, HYDRAULIC, HEADER LIFT (SIDEHILL)	135 - 14	1F20	MAIN WIRING HARNESS, L.H.	40 - 20
2H9	LINES AND HOSES, REEL DRIVE, FRONT	70 - 50	2D1	MANIFOLD	50 - 50
2H15	LINES AND HOSES, REEL LIFT	70 - 56	3D11	MANIFOLD, A/C COMPRESSOR, R134A	95 - 11
2E18	LINES AND HOSES, STEERING, FRONT	60 - 18	2D23	MANIFOLD, CASE DRAIN	50 - 74
2E24	LINES AND HOSES, STEERING, REAR	60 - 24	1D24	MANIFOLD, EXHAUST	25 - 46
4G3	LINES AND HOSES, UNLOADING AUGER SWING HYDRAULIC CYLINDER	150 - 14	1D20	MANIFOLD, INTAKE	25 - 42
2F20	LINES AND HOSES, WET CLUTCH OIL COOLER	70 - 10	1D18	MANIFOLD, WATER, FRONT	25 - 40
2D21	LINES AND HOSES, 4-WHEEL DRIVE FLOW CONTROL TO CAM LOBE MOTOR	50 - 72	4H10	MASS FLOW SENSOR BRACKET, YIELD MAPPING ..	155 - 6
2E6	LINES, BRAKE, RESERVOIR, MASTER CYLINDER	60 - 6	4H10	MASS FLOW SENSOR DOOR, YIELD MAPPING	155 - 6
1E14	LINES, FUEL FILTER	30 - 10	4H10	MASS FLOW SENSOR, YIELD MAPPING	155 - 6
1E6	LINES, FUEL INJECTION	30 - 2	2E8	MASTER BRAKE CYLINDER	60 - 8
1E6	LINES, FUEL LEAK-OFF	30 - 2	2E6	MASTER CYLINDER, RESERVOIR, BRAKE LINES	60 - 6
1E8	LINES, FUEL LEAK-OFF, FUEL PUMP	30 - 4	3B9	MAT, CAB FLOOR	90 - 8
211	LINES, HOSES, VALVE AND PUMP, CHAFF SPREADER	70 - 68	1E20	MAT, ENGINE PLATFORM	30 - 16
2G22	LINES, HYDRAULIC, CYLINDER SPEED	70 - 38	3E17	MAT, FEEDER HOUSE FRAME	100 - 26
2H5	LINES, HYDRAULIC, REEL PUMP	70 - 46	3J13	MATERIAL MODULE, TAILINGS ELEVATOR	125 - 22
2D15	LINES, HYDROSTATIC OIL COOLER	50 - 66	3C20	MIRROR, L.H.	90 - 46
2D13	LINES, OIL, HYDROSTATIC DRIVE, LOWER (SIDEHILL 2 WHEEL DRIVE)	50 - 64	3C22	MIRROR, R.H.	90 - 48
2D9	LINES, OIL, HYDROSTATIC DRIVE, LOWER (2-WHEEL DRIVE)	50 - 60	4H8	MOBILE PROCESSOR, YIELD MAPPING	155 - 4
2D17	LINES, OIL, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE)	50 - 68	1G20	MODULE, CENTRAL ELECTRONICS AND CIRCUIT BOARDS	40 - 48
4C15	LINES, OIL, LEVELING CYLINDER (SIDEHILL)	135 - 6	4H16	MODULE, DATASTORE	155 - 12
2F12	LINES, PRESSURE, HYDRAULIC	70 - 2	4H18	MODULE, DATASTORE	155 - 14
2H7	LINES, REEL DRIVE, HYDRAULIC, L.H. SIDE	70 - 48	2F23	MODULE, SIX STACK SOLENOID VALVE	70 - 14
2F14	LINES, RETURN, HYDRAULIC RESERVOIR	70 - 4	3J13	MODULE, TAILINGS ELEVATOR SENSOR	125 - 22
2E22	LINES, STEERING R.H. SIDE	60 - 22	1H16	MOISTURE SENSOR	40 - 70
2E20	LINES, STEERING, L.H. SIDE	60 - 20	4H12	MOISTURE SENSOR BRACKET, YIELD MAPPING	155 - 8
1D22	LINES, TURBOCHARGER OIL	25 - 44	4H12	MOISTURE SENSOR COVER, YIELD MAPPING	155 - 8
2D19	LINES, 4-WHEEL DRIVE HYDRAULIC, L.H.	50 - 70	4H14	MOISTURE SENSOR COVERS, YIELD MAPPING	155 - 10
1H14	LINKAGE, CONCAVE INDICATOR	40 - 68	4H19	MOISTURE SENSOR DECALS, YIELD MONITOR	155 - 15
3F24	LINKAGE, CONCAVE SENSOR	100 - 58	4H12	MOISTURE SENSOR MOTOR HARNESS YIELD MAPPING	155 - 8
3C9	LINKAGE, GEARSHIFT	90 - 34	4H12	MOISTURE SENSOR MOTOR, YIELD MAPPING	155 - 8
4F1	LINKAGE, SHEAVE, FAN DRIVE SPEED CONTROL	140 - 46	4H12	MOISTURE SENSOR, YIELD MAPPING	155 - 8
4E23	LINKAGE, SPEED CONTROL, FAN DRIVE	140 - 44	1G16	MONITOR WIRING HARNESS, GRAIN LOSS	40 - 43
3J1	LOADING AUGER, CLEAN GRAIN	125 - 10	4C3	MOTOR AND DISC, CHAFF SPREADER	130 - 26
			1H18	MOTOR, ADJUSTING, SEPARATOR FAN DRIVE	40 - 72

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1H13	MOTOR, CONCAVE ADJUSTING.....	40-66	2D13	OIL LINES, HYDROSTATIC DRIVE, LOWER (SIDEHILL 2 WHEEL DRIVE).....	50-64
3D2	MOTOR, HEATER AND AIR CONDITIONER.....	95-2	4C13	OIL LINES, LEVELING CYLINDER (SIDEHILL).....	135-4
2C21	MOTOR, HYDROSTATIC DRIVE, FIXED.....	50-44	2E6	OIL LINES, MASTER CYLINDER AND RESERVOIR	60-6
4H12	MOTOR, MOISTURE SENSOR, YIELD MAPPING	155-8	1D22	OIL LINES, TURBOCHARGER	25-44
3D2	MOTOR, PRESSURE BLOWER	95-2	1D13	OIL PAN	25-34
3D4	MOTOR, RECIRCULATION BLOWER, HEATER AND AIR CONDITIONER.....	95-4	1D13	OIL PAN DRAIN VALVE	25-34
1H11	MOTOR, REEL SPEED, AND BRACKET.....	40-64	1D13	OIL PAN GASKET	25-34
1G13	MOTOR, WINDSHIELD WIPER	40-40	1D11	OIL PRESSURE REGULATING VALVE	25-32
4C17	MOUNTING BRACKETS, LEVELING CYLINDER (SIDEHILL).....	135-8	1B18	OIL PRESSURE SENSOR (ENGINE).....	20-16
4D3	MOUNTING, FLOW DIVIDER (SIDEHILL)	135-18	1D6	OIL PUMP AND GASKET, ENGINE	25-26
4G24	MOUNTING, GRAIN TANK UNLOADING DRIVE CYLINDER	150-36	1C18	OIL PUMP DRIVE GEAR, CRANKSHAFT	25-11
2F11	MOUNTING, HYDRAULIC/HYDROSTATIC OIL RESERVOIR	70-1	1D8	OIL PUMP INTAKE AND GASKET, ENGINE.....	25-28
2G18	MOUNTING, ONE GALLON ACCUMULATOR.....	70-34	1D6	OIL PUMP, ENGINE	25-26
4B22	MOUNTING, STRAW SPREADER AND GUARD	130-20	2C18	OIL PUMP, HYDROSTATIC DRIVE CHARGE PUMP ...	50-40
4H22	MOUNTING, TRACK FRAME	160-2	1C24	OIL SEAL, CRANKSHAFT FRONT.....	25-17
4G5	MOUNTING, UNLOADING AUGER SWING HYDRAULIC CYLINDER.....	150-16	1C22	OIL SEAL, CRANKSHAFT REAR	25-15
2F23	MOUNTINGS, SIX STACK SOLENOID VALVE	70-14	3D11	OIL, A/C COMPRESSOR	95-11
2G3	MOUNTINGS, SOLENOID CONTROL VALVE MODULE ASSEMBLY, FOUR STACK.....	70-18	1C9	OIL, ENGINE (TORQ-GARD, PLUS-50).....	25-2
2G1	MOUNTINGS, SOLENOID CONTROL VALVE MODULE, FIVE STACK	70-16	1C10	OIL, VALVE STEM LUBRICANT.....	25-3
2D25	MUD SHIELDS (POWERED REAR WHEELS).....	50-76	2G18	ONE GALLON ACCUMULATOR AND MOUNTING.....	70-34
1E24	MUFFLER AND EXHAUST PIPE	30-20	3B24	OPERATOR'S ARMREST PANEL	90-24
	N		3C1	OPERATOR'S ARMREST PANEL	90-26
1E12	NOZZLE, FUEL INJECTION	30-8	3C19	OPERATOR'S PLATFORM LADDER AND LATCH	90-44
1E6	NOZZLES, FUEL INJECTION	30-2	3B21	OPERATOR'S SEAT AND ARMREST	90-20
	O		3B23	OPERATOR'S SEATBELT.....	90-22
1D16	O-RING, WATER PUMP	25-38	1F13	OUTLET, CONVENIENCE, KIT	40-12
1C10	OFF-SEASON STORAGE KIT.....	25-3	1C15	OVERHAUL KIT, ENGINE.....	25-8
2F18	OIL COOLER	70-8	3C13	OVERHEAD CONSOLE.....	90-38
1D9	OIL COOLER BYPASS ADAPTER AND TUBES.....	25-29		P	
2D15	OIL COOLER LINES AND HOSES, HYDROSTATIC.....	50-66	3F17	PADDLE SHAFT, FEEDER HOUSE (SIDEHILL)	100-50
1D10	OIL COOLER VALVE, TUBES AND COVER.....	25-30	3I21	PADDLE, CLEAN GRAIN CONVEYOR CHAIN	125-6
1D10	OIL COOLER, ENGINE	25-30	3F17	PADDLE, LOWER SHAFT, FEEDER HOUSE (SIDEHILL).....	100-50
3D21	OIL COOLER, FEEDER HOUSE GEARCASE.....	100-4	4H12	PADDLE, MOISTURE SENSOR, YIELD MAPPING.....	155-8
1B22	OIL DRAIN, ENGINE CRANKCASE	20-20	3J14	PADDLE, TAILINGS ELEVATOR CONVEYOR	125-23
4D9	OIL FILTER ASSEMBLY, ENGINE GEARCASE	140-2	4B11	PADDLED BLADE, FINE CUT CHOPPER	130-8
1D11	OIL FILTER BASE	25-32	3J19	PADDLES, UPPER TAILINGS AUGER	125-28
1D11	OIL FILTER BYPASS VALVE	25-32	1D13	PAN, OIL	25-34
1D11	OIL FILTER HOUSING AND GASKET	25-32	3I13	PAN, SHAKER	120-22
1D11	OIL FILTER, ENGINE	25-32	3B24	PANEL, ARMREST	90-24
2D11	OIL HOSE, UPPER, HYDROSTATIC DRIVE	50-62	3C1	PANEL, ARMREST	90-26
2D9	OIL HOSES, HYDROSTATIC DRIVE, LOWER (2-WHEEL DRIVE).....	50-60	3B9	PANEL, CAB INTERIOR TRIM	90-8
2D17	OIL HOSES, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE).....	50-68	2J1	PANEL, RIGHT FRONT.....	80-20
2D23	OIL LINE, CASE DRAIN	50-74	2E2	PARKING BRAKE PEDAL AND SEAL	60-2
2C8	OIL LINE, FINAL DRIVE	50-30	3B24	PAWL, ARMREST PANEL.....	90-24
2C10	OIL LINE, FINAL DRIVE HOUSING (SIDEHILL).....	50-32	3C3	PAWL, LOWER STEERING COLUMN	90-28
4C15	OIL LINES AND HOSES, LEVELING CYLINDER (SIDEHILL).....	135-6	2E4	PEDAL, BRAKE	60-4
2D9	OIL LINES HYDROSTATIC DRIVE, LOWER (2-WHEEL DRIVE).....	50-60	2E2	PEDAL, PARKING BRAKE	60-2
2D17	OIL LINES HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE).....	50-68	3C7	PEDAL, REVERSER FOOT CONTROL, FEEDER HOUSE.....	90-32
			3C3	PEDAL, STEERING WHEEL ADJUSTER.....	90-28
			1H20	PICK-UP, MAGNETIC (ENGINE)	40-74
			2C8	PINION, FINAL DRIVE.....	50-30
			1C17	PISTON & LINER KIT	25-10
			1C17	PISTON RINGS	25-10
			2D3	PISTON, CAM, AND CARRIER (STEERABLE MOTOR).....	50-52
			1C17	PISTON, ENGINE	25-10
			1B4	PITMAN ARM.....	20-2
			4H24	PIVOT BUSHINGS, MAIN FRAME	160-4
			2C6	PIVOT TUBE, INNER CASTING, FINAL DRIVE (SIDEHILL).....	50-28