

H51903

-UN-04FEB99



*JOHN DEERE 9650 SELF-PROPELLED COMBINE™ WITH 90 SERIES CORN HEAD*

*MANUFACTURED (1999- )*

*(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)*

*COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS, USA. ALL RIGHTS RESERVED.*

## NOTE

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC1223.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2210.

FOR 918 AND 920 DRAPER PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2212.

FOR 90 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2404.

FOR 900R & F SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2771.

FOR 914P BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE PARTS CATALOG - PC2772.

## IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 9650 SELF-PROPELLED COMBINE. VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

## PRODUCT INFORMATION NUMBER (PIN) PLATE

THE PRODUCT IDENTIFICATION NUMBER (PIN) PLATE IS LOCATED NEAR THE RIGHT-HAND SIDE OF THE TOOL BOX. AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

HO9650X685000  
COMBINE

(FIRST LINE)

HO - MANUFACTURING UNIT (HARVESTER WORKS)

9650 - MODEL IDENTIFIER

X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX

900000 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

COMBINE - TYPE OF PRODUCT

## TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE

RGP5229

-UN-21JUN99



RGP5229

### FIRST LINE

RG - WATERLOO ENGINE WORKS

6

081 (8.1 LITERS)

H - AIR-TO-AIR

H

XXXXXX

### SECOND LINE

6081HH010

### DEFINES

DESIGNATES ENGINE MANUFACTURER.

DESIGNATES NUMBER OF CYLINDERS.

DESIGNATES LITER DISPLACEMENT.

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

DESIGNATES HARVESTER VEHICLE.


DESIGNATES ENGINE SERIAL NUMBER.

### APPLICATION

9650

## SHORT BLOCK SERIAL NUMBER IDENTIFICATION

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490995

- |                                   |         |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED     | 09      |
| 3. DESIGNATES YEAR ASSEMBLED      | 95      |

**Thanks very much for your reading,  
Want to get more information,  
Please click here, Then get the complete  
manual**

**JustClickHere** 

**NOTE:**

**If there is no response to click on the link above,  
please download the PDF document first, and then  
click on it.**

**Have any questions please write to me:  
[admin@servicemanualperfect.com](mailto:admin@servicemanualperfect.com)**

## PARTS LISTING INFORMATION

SERIAL NUMBER OR PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION SHOWS ON WHICH MACHINES THE PART MAY BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE, BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRINTED.

## DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

## BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

## KITS

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

## JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

## BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

## SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

## TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™  
DIAL-A-MATIC™  
HARVESTRAK™  
CONTOUR MASTER™

POSI-TORQ™  
TORQ-GARD SUPREME®  
QUIK-TATCH™

## CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

## FUNCTION CODE

(EXAMPLE - FC: 5000)

FUNCTION CODES ARE LOCATED ON EACH PAGE IN THE UPPER RIGHT-HAND CORNER IN THE BOX. THE CODE LISTED IS A GROUPING CODE THAT CAN BE USED FOR WARRANTIES AND FOR DTAC TO IDENTIFY CERTAIN AREAS.

## COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SECTION INDEX

SECTION 10 - GENERAL INFORMATION

SECTION 20 - ENGINE ACCESSORIES

SECTION 25 - ENGINE

SECTION 30 - FUEL AND AIR

SECTION 40 - ELECTRICAL

SECTION 50 - POWER TRAIN

SECTION 60 - STEERING AND BRAKES

SECTION 70 - HYDRAULICS

SECTION 80 - BODY AND SHIELDS

SECTION 90 - OPERATOR'S STATION

SECTION 95 - AIR CONDITIONING AND HEATING

SECTION 100 - FEEDER HOUSE

SECTION 110 - THRESHING AND SEPARATION

SECTION 120 - CLEANING SHOE

SECTION 125 - ELEVATORS

SECTION 130 - RESIDUE DISPOSAL

SECTION 140 - DRIVES

SECTION 150 - GRAIN TANK AND UNLOADING AUGER

SECTION 155 - GREENSTAR YIELD MAPPING AND MONITOR SYSTEMS

SECTION 160 - RUBBER TRACK SYSTEM

SECTION 170 - DECALS

SECTION 180 - NUMERICAL INDEX



## ALPHABETICAL INDEX

GRID		PAGE	GRID		PAGE
	A				
1H5	ACCESS COVER FUEL INJECTION PUMP .....	40 - 58	3B23	ARMREST ROCKER SWITCHES .....	90 - 24
1B10	ACCESS DOOR, RADIATOR .....	20 - 8	3C1	ARMREST ROCKER SWITCHES .....	90 - 26
2G11	ACCUMULATOR AND MOUNTING, ONE GALLON .....	70 - 34	1G5	ARMREST WIRING HARNESS .....	40 - 32
2G13	ACCUMULATOR PRESSURE GAUGE .....	70 - 36	3B12	ASHTRAY .....	90 - 12
2G9	ACCUMULATOR, SINGLE MOUNTING BRACKET ONE HALF GALLON .....	70 - 32	3B23	ASHTRAY .....	90 - 24
2G9	ACCUMULATOR, SINGLE, ONE HALF GALLON .....	70 - 32	1H7	ASSEMBLY, CLUTCH (STARTER) .....	40 - 60
2F24	ACTIVE HEADER HEIGHT CONTROL HYDRAULIC LINE AND VALVE BLOCK .....	70 - 22	2E9	ATTENUATOR, HYDRAULIC STEERING .....	60 - 16
1H19	ACTUATOR, STRAW WALKER SENSOR SWITCH .....	40 - 73	4E17	AUGER COVERS AND CHANNEL, CROSS .....	150 - 34
1D8	ADAPTER, OIL COOLER .....	25 - 28	4D3	AUGER DRIVE SHIELD, UPPER TAILINGS .....	140 - 54
1D7	ADAPTER, OIL COOLER BYPASS .....	25 - 27	4D3	AUGER DRIVE, UPPER TAILINGS .....	140 - 54
4F22	ADJUSTABLE IDLER ASSEMBLY AND FRONT ARM ..	160 - 6	3I9	AUGER HOUSING, LOADING, UPPER CLEAN GRAIN .....	125 - 8
2B6	ADJUSTABLE REAR AXLE .....	50 - 3	4D22	AUGER SWING, HOSES AND LINES .....	150 - 14
2E24	ADJUSTABLE REAR AXLE STEERING TIE RODS .....	60 - 32	4E3	AUGER SWIVEL SUPPORT AND BRACES .....	150 - 20
4C5	ADJUSTING BRACKET, CYLINDER DRIVE, DUAL-RANGE .....	140 - 32	3I9	AUGER TROUGH, LOWER TAILINGS .....	125 - 18
1H13	ADJUSTING MOTOR, CONCAVE .....	40 - 66	4E15	AUGER, GRAIN TANK CROSS .....	150 - 32
1H18	ADJUSTING MOTOR, SEPARATOR FAN DRIVE .....	40 - 72	4D20	AUGER, GRAIN TANK, VERTICAL UNLOADING .....	150 - 12
1E19	AIR CLEANER AND INTAKE TUBES .....	30 - 18	4E1	AUGER, HORIZONTAL UNLOADING .....	150 - 18
3D11	AIR CONDITIONER COMPRESSOR .....	95 - 11	4E11	AUGER, HORIZONTAL UNLOADING (17- AND 20-FT.) .....	150 - 28
1B20	AIR CONDITIONER COMPRESSOR FAN PULLEY .....	20 - 18	3I11	AUGER, LOADING, CLEAN GRAIN .....	125 - 10
3D14	AIR CONDITIONER COMPRESSOR HARDWARE .....	95 - 14	3J1	AUGER, LOWER TAILINGS .....	125 - 24
3D12	AIR CONDITIONER COMPRESSOR HOSE .....	95 - 12	3J3	AUGER, LOWER TAILINGS DRIVE TIGHTENER .....	125 - 26
3D11	AIR CONDITIONER COMPRESSOR MANIFOLD .....	95 - 11	3I5	AUGER, LOWER, CLEAN GRAIN .....	125 - 4
1B20	AIR CONDITIONER COMPRESSOR SUPPORT .....	20 - 18	3G23	AUGER, SHOE GRAIN SUPPLY .....	120 - 2
3D7	AIR CONDITIONING AND HEATER DUCTS .....	95 - 7	4D3	AUGER, UPPER TAILINGS .....	140 - 54
3D4	AIR CONDITIONING AND HEATER HOUSING, LOWER .....	95 - 4	2B7	AXLE EXTENSIONS .....	50 - 4
3D2	AIR CONDITIONING AND HEATER HOUSING, UPPER .....	95 - 2	2B7	AXLE SHAFTS .....	50 - 4
2F11	AIR CONDITIONING CONDENSER AND OIL COOLER .....	70 - 8	2B7	AXLE SPACERS .....	50 - 4
3D10	AIR CONDITIONING SYSTEM, EVAPORATOR HEATER .....	95 - 10	2B8	AXLE SPACERS .....	50 - 5
3D9	AIR CONDITIONING SYSTEM, RECEIVER-DRYER .....	95 - 9	4H13	AXLE STOP AND TIRE CLEARANCE LABEL .....	170 - 20
3D8	AIR CONDITIONING SYSTEM, WATER VALVE .....	95 - 8	4G4	AXLE, BOGEY WHEEL .....	160 - 14
1G9	AIR CONDITIONING WIRING HARNESS .....	40 - 36	4G1	AXLE, IDLER .....	160 - 10
1C1	AIR COOLER .....	20 - 24	2B6	AXLE, REAR, ADJUSTABLE .....	50 - 3
3D7	AIR DUCT, AIR CONDITIONER AND HEATER .....	95 - 7	2E22	AXLE, REAR, SPINDLES (HEAVY DUTY) .....	60 - 30
3H1	AIR DUCT, CLEANING FANS .....	120 - 4	2E20	AXLE, REAR, SPINDLES (REGULAR DUTY) .....	60 - 28
3D2	AIR DUCT, INTAKE .....	95 - 2			
1B8	AIR DUCT, RADIATOR .....	20 - 6		B	
1B6	AIR DUCT, ROTARY SCREEN .....	20 - 4	1H9	BACKSHAFT SPEED SENSOR, FEEDER HOUSE .....	40 - 62
1E19	AIR FILTER .....	30 - 18	3G5	BAR, SPIKE TOOTH THRESHING CYLINDER .....	110 - 12
3D6	AIR FILTER, CAB .....	95 - 6	4D12	BASE, GRAIN TANK .....	150 - 4
3B18	AIR SEAT SUSPENSION .....	90 - 18	1H22	BATTERY AND CABLES .....	40 - 76
3B20	AIR SEAT SWITCH .....	90 - 20	3G17	BEARING KIT, STRAW WALKERS .....	110 - 24
4F24	AIR SUSPENSION .....	160 - 8	1C18	BEARING KIT, UNDERSIZED MAIN BEARING CRANKSHAFT .....	25 - 11
3B18	AIR SUSPENSION, SEAT .....	90 - 18	4G6	BEARING, BOGEY WHEEL .....	160 - 16
1H5	ALTERNATOR ADJUSTING STRAP .....	40 - 58	4G4	BEARING, BOGEY WHEEL AXLE .....	160 - 14
1H5	ALTERNATOR BRACKET .....	40 - 58	2C15	BEARING, CAM LOBE MOTOR .....	50 - 40
1H3	ALTERNATOR, SHEAVE AND BELT (185 AMP) .....	40 - 56	1C15	BEARING, CONNECTING ROD .....	25 - 8
1H1	ALTERNATOR, SHEAVE AND BELT (95 AMP) .....	40 - 54	2C1	BEARING, FINAL DRIVE .....	50 - 24
1I1	AMBER LAMP ASSEMBLY, REAR .....	40 - 80	1B4	BEARING, IDLER ARM, ROTARY SCREEN .....	20 - 2
3C15	ANTENNA, SPEAKERS AND RADIO .....	90 - 40	4G3	BEARING, IDLER WHEEL .....	160 - 12
3B20	ARM REST, OPERATOR'S SEAT .....	90 - 20	1C19	BEARING, MAIN .....	25 - 12
4B23	ARM, DUAL RANGE LOCKOUT .....	140 - 25	3I24	BEARING, TAILINGS ELEVATOR CONVEYOR .....	125 - 23
3H7	ARM, FRAME, PRECLEANER CHAFFER .....	120 - 10	1C19	BEARING, THRUST .....	25 - 12
4F22	ARM, FRONT AND ADJUSTABLE IDLER ASSEMBLY ..	160 - 6	2B18	BEARING, TRANSMISSION .....	50 - 16
4G1	ARM, REAR .....	160 - 10	2B20	BEARING, TRANSMISSION PINION SHAFT .....	50 - 18
1D1	ARM, ROCKER .....	25 - 20	4C13	BEATER DRIVE SHEAVES AND TIGHTENER .....	140 - 40
3J23	ARM, TAILBOARD, CHOP-TO-BALE .....	130 - 16	3G7	BEATER GRATE (WIDE) .....	110 - 14
3B23	ARMREST PANEL, OPERATOR'S .....	90 - 24	3G12	BEATER GRATE CURTAIN .....	110 - 19
3C1	ARMREST PANEL, OPERATOR'S .....	90 - 26	3G13	BEATER, SHAFT AND DRIVE BELT .....	110 - 20
			4G13	BELT AND DRIVE WHEEL .....	160 - 24
			4E22	BELT GUIDE, UNLOADING AUGER DRIVE .....	150 - 40
			2G19	BELT PICKUP / REEL DRIVE, PUMP MOUNTING SHEAVE .....	70 - 42

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3G13	BELT SET, BEATER SHAFT.....	110-20	3F6	BELT, UPPER VARIABLE DRIVE COUNTERSHAFT ....	100-40
1H5	BELT TENSIONER, ALTERNATOR .....	40-58	3D18	BELT, VARIABLE SPEED FEEDERHOUSE.....	100-2
4H23	BELT, AIR CONDITIONING COMPRESSOR .....	170-30	4I1	BELT, VARIABLE SPEED FEEDERHOUSE.....	170-32
4I1	BELT, AIR FLOW DRIVE .....	170-32	4I1	BELT, VARIABLE SPEED FEEDERHOUSE (HI-CAPACITY) .....	170-32
1H3	BELT, ALTERNATOR (185 AMP) .....	40-56	3E5	BELT, VARIABLE SPEED TIGHTENER DRIVE.....	100-14
4H21	BELT, ALTERNATOR (185 AMP) .....	170-28	2G3	BI-DIRECTIONAL MODULE, SOLENOID CONTROL VALVE, REEL LIFT AND CYLINDER SPEED .....	70-26
1H1	BELT, ALTERNATOR (95 AMP) .....	40-54	3G13	BLADE, BEATER .....	110-20
4H21	BELT, ALTERNATOR (95 AMP) .....	170-28	3J16	BLADE, FINE CUT CHOPPER - PADDLED.....	130-8
4I3	BELT, BEATER .....	170-34	3J14	BLADE, FINE CUT ROTOR CHOPPER .....	130-6
4C13	BELT, BEATER DRIVE AND TIGHTENER.....	140-40	3J12	BLADE, TRI-ROD CHOPPER .....	130-4
4C21	BELT, CHOPPER DRIVES (FRONT) .....	140-48	1G13	BLADE, WIPER .....	40-40
4H23	BELT, CLEAN GRAIN ELEVATOR .....	170-30	1B22	BLOCK, ENGINE COOLANT HEATER.....	20-20
4D6	BELT, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER.....	140-58	1C11	BLOCK, SHORT.....	25-4
4C15	BELT, CLEANING FAN (490 - 980 RPM) .....	140-42	4G6	BOGEY WHEEL ASSEMBLY .....	160-16
4I1	BELT, CLEANING FAN (490 - 980 RPM) .....	170-32	4G4	BOGEY WHEEL AXLES .....	160-14
4C15	BELT, CLEANING FAN (750 - 1350 RPM) .....	140-42	4G7	BOX, GEAR, TRANSFER .....	160-18
4I1	BELT, CLEANING FAN (750 - 1350 RPM) .....	170-32	2J16	BOX, TOOL .....	80-40
1B16	BELT, COOLING FAN .....	20-14	1H5	BRACKET, ALTERNATOR .....	40-58
4H23	BELT, COOLING FAN .....	170-30	2E4	BRACKET, BRAKE CABLE SUPPORT .....	60-11
4B21	BELT, CYLINDER DRIVE (150 - 500 RPM) .....	140-22	3J23	BRACKET, CHOP-TO-BALE .....	130-16
4H23	BELT, CYLINDER DRIVE (150 - 500 RPM) .....	170-30	4F4	BRACKET, DISPLAY, YIELD MAPPING.....	155-4
4B21	BELT, CYLINDER DRIVE (240 - 960 RPM).....	140-22	1H21	BRACKET, LOW SHAFT SPEED SENSORS.....	40-75
4H23	BELT, CYLINDER DRIVE (240 - 960 RPM).....	170-30	4F6	BRACKET, MASS FLOW SENSOR YIELD MAPPING .....	155-6
4H23	BELT, CYLINDER INTERMEDIATE DRIVE .....	170-30	4F8	BRACKET, MOISTURE SENSOR, YIELD MAPPING ....	155-8
4C3	BELT, DUAL RANGE CYLINDER DRIVE, INTERMEDIATE SHEAVE.....	140-30	4F2	BRACKET, POSITION RECEIVER YIELD MAPPING .....	155-2
4B17	BELT, ELECTROMAGNETIC CLUTCH.....	140-17	1B10	BRACKET, RADITOR MOUNTING .....	20-8
1B14	BELT, ENGINE FAN DRIVE .....	20-12	2G9	BRACKET, SINGLE ACCUMULATOR MOUNTING ONE HALF GALLON .....	70-32
4H21	BELT, FEEDER CONVEYOR .....	170-28	2F15	BRACKET, SOLENOID CONTROL VALVE .....	70-12
3E7	BELT, FEEDER HOUSE DRIVE TIGHTENER .....	100-16	4F6	BRACKET, TRANSDUCER MOUNTING YIELD MAPPING .....	155-6
3E3	BELT, FEEDER HOUSE DRIVE TIGHTENER (FIXED SPEED).....	100-12	2E4	BRAKE CABLE SUPPORT BRACKET .....	60-11
4I1	BELT, FIXED SPEED FEEDERHOUSE W/REVERSER	170-32	2E1	BRAKE CYLINDER, MASTER.....	60-8
3D18	BELT, HEADER AND REEL PUMP .....	100-2	2D23	BRAKE LINES, MASTER CYLINDER AND RESERVOIR .....	60-6
4I1	BELT, HEADER AND REEL PUMP .....	170-32	2D19	BRAKE PEDAL AND SEAL, PARKING .....	60-2
3J1	BELT, LOWER TAILINGS AUGER .....	125-24	2D21	BRAKE PEDALS AND MASTER CYLINDER .....	60-4
4H23	BELT, LOWER TAILINGS AUGER AND ELEVATOR ....	170-30	2E5	BRAKE SHOES AND DRUM.....	60-12
3B22	BELT, OPERATOR'S SEAT .....	90-23	4G11	BRAKE SHOES AND DRUM.....	160-22
4H23	BELT, ROTARY SCREEN.....	170-30	2E3	BRAKE SLAVE CYLINDER.....	60-10
1B4	BELT, ROTARY SCREEN DRIVE.....	20-2	2G13	BULB, ACCUMULATOR PRESSURE GAUGE.....	70-36
4H23	BELT, ROTARY SCREEN DRIVE.....	170-30	1H23	BULB, CAB ROOF LIGHT .....	40-77
4B18	BELT, SECONDARY COUNTERSHAFT.....	140-18	2J10	BULB, ENGINE COMPARTMENT.....	80-34
4H21	BELT, SECONDARY COUNTERSHAFT.....	170-28	3C13	BULB, OVERHEAD CONSOLE .....	90-38
4C7	BELT, SECONDARY COUNTERSHAFT DRIVE .....	140-34	3C5	BULB, STEERING COLUMN CONTROLS .....	90-30
4C15	BELT, SEPARATOR FAN DRIVE .....	140-42	1C9	BUSHING, CAMSHAFT .....	25-2
4H21	BELT, SHOE, WALKER AND CONVEYOR AUGERS ....	170-28	1C23	BUSHING, CAMSHAFT .....	25-16
4B20	BELT, SINGLE RANGE CYLINDER DRIVE .....	140-21	4F20	BUSHING, MAIN FRAME PIVOT .....	160-4
4C23	BELT, STRAW CHOPPER (FINE CUT BALING).....	140-50	1D7	BYPASS TUBES, OIL COOLER .....	25-27
4I1	BELT, STRAW CHOPPER (FINE CUT BALING).....	170-32	1D9	BYPASS VALVE, OIL FILTER.....	25-30
4C23	BELT, STRAW CHOPPER (FINE CUT) .....	140-50	<b>C</b>		
4I1	BELT, STRAW CHOPPER (FINE CUT) .....	170-32	3D6	CAB AIR FILTER AND HOUSING .....	95-6
4C23	BELT, STRAW CHOPPER (STANDARD BALING) .....	140-50	3B12	CAB DOOR AND GLASS .....	90-12
4I1	BELT, STRAW CHOPPER (STANDARD BALING) .....	170-32	3B14	CAB DOOR LATCH .....	90-14
4C23	BELT, STRAW CHOPPER (STANDARD).....	140-50	3B8	CAB INTERIOR TRIM PANELS .....	90-8
4I1	BELT, STRAW CHOPPER (STANDARD).....	170-32	3C20	CAB LANDING AND MIRROR (L.H.) .....	90-46
3K4	BELT, STRAW SPREADER .....	130-22	3C22	CAB LANDING AND MIRROR (R.H.) .....	90-48
4I1	BELT, STRAW SPREADER .....	170-32	1G3	CAB MAIN WIRING HARNESS.....	40-30
3G19	BELT, STRAW WALKER.....	110-26	3B20	CAB OPERATOR'S SEAT AND BACKREST .....	90-20
4C11	BELT, STRAW WALKER, CONVEYOR AUGERS, SIEVE AND CHAFFER DRIVE .....	140-38	3B6	CAB REAR AND SIDE SEALS .....	90-6
4E20	BELT, UNLOADING AUGER COUNTERSHAFT .....	150-38			
4I1	BELT, UNLOADING AUGERS.....	170-32			
4I3	BELT, UNLOADING SYSTEM.....	170-34			
3F14	BELT, UPPER DRIVE SHAFT (FIXED SPEED WITH REVERSER).....	100-48			
3I23	BELT, UPPER TAILINGS AUGER .....	125-22			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3B6	CAB REAR, SIDE AND FLOOR PANELS .....	90 - 6	3K1	CHOPPER COVER AND BRACKETS, CHOP-TO-BALE	130 - 19
3B10	CAB ROOF .....	90 - 10	3J9	CHOPPER DOOR .....	130 - 1
1H23	CAB ROOF LIGHTS .....	40 - 77	4C21	CHOPPER DRIVES (FRONT) .....	140 - 48
3B3	CAB SUPPORT .....	90 - 2	3J18	CHOPPER HOUSING AND KNIFEBANK .....	130 - 10
1H22	CABLE, BATTERY .....	40 - 76	3J16	CHOPPER ROTOR, FINE CUT PADDLED BLADE .....	130 - 8
2E5	CABLE, BRAKE .....	60 - 12	3J20	CHOPPER TRANSPORT SPROCKETS .....	130 - 12
4F14	CABLE, DATASTORE/COMPUTER .....	155 - 14	3J14	CHOPPER, FINE CUT STRAIGHT BLADE .....	130 - 6
2C3	CABLE, HYDROSTATIC DRIVE CONTROL .....	50 - 26	3J12	CHOPPER, TRI-ROD .....	130 - 4
2C15	CAM LOBE MOTOR .....	50 - 40	3B23	CIGARETTE LIGHTER .....	90 - 24
2C19	CAM, CARRIER AND PISTON .....	50 - 44	3B23	CIRCUIT BOARD, ARMREST CONTROL PANEL .....	90 - 24
3G9	CAM, SPIKE TOOTH CONCAVE .....	110 - 16	1G20	CIRCUIT BOARD, CENTRAL ELECTRONICS .....	40 - 48
2B17	CAM, TRANSMISSION SHIFTER .....	50 - 14	3C13	CIRCUIT BOARD, OVERHEAD CONSOLE .....	90 - 38
1C23	CAMSHAFT .....	25 - 16	1G22	CIRCUIT BREAKER AND RELAY PANEL .....	40 - 50
1C9	CAMSHAFT BUSHING .....	25 - 2	3I7	CLEAN GRAIN CONVEYOR CHAIN .....	125 - 6
1D1	CAMSHAFT FOLLOWERS .....	25 - 20	4D6	CLEAN GRAIN ELEVATOR DRIVE TIGHTENER .....	140 - 58
1C23	CAMSHAFT GEAR AND FOLLOWER .....	25 - 16	3I13	CLEAN GRAIN ELEVATOR GEARCASE .....	125 - 12
1E21	CAP, EXHAUST PIPE .....	30 - 20	3I3	CLEAN GRAIN ELEVATOR UPPER SHAFT .....	125 - 2
4D18	CAP, GRAIN TANK CLEAN OUT CHUTE .....	150 - 10	3I11	CLEAN GRAIN LOADING AUGER .....	125 - 10
1C9	CAP, MAIN BEARING .....	25 - 2	3I9	CLEAN GRAIN LOADING AUGER HOUSING, UPPER	125 - 8
1B12	CAP, RADIATOR .....	20 - 10	3I5	CLEAN GRAIN LOWER AUGER AND HINGED DOOR	125 - 4
1G11	CAP, WINDSHIELD SIPER RESERVOIR .....	40 - 38	3I7	CLEAN GRAIN LOWER ELEVATOR .....	125 - 6
2C20	CAP, YOKE AND PIVOTS (STEERABLE MOTOR) .....	50 - 46	4D18	CLEAN OUT CHUTE, GRAIN TANK .....	150 - 10
2C19	CARRIER, PISTON AND CAM .....	50 - 44	1E19	CLEANER, AIR AND INTAKE TUBES .....	30 - 18
2D13	CASE DRAIN, 4-WHEEL DRIVE, HYDRAULIC LINES .....	50 - 64	4C15	CLEANING FAN DRIVE, SEPARATOR .....	140 - 42
4G7	CASE, GEAR, TRANSFER .....	160 - 18	3H1	CLEANING FAN INTAKE SHIELDS .....	120 - 4
4D18	CASE, VERTICAL AUGER LOWER GEAR .....	150 - 10	3H1	CLEANING FANS AND SHROUDS .....	120 - 4
2J4	CATCH, REAR LANDING LADDER .....	80 - 28	1I5	CLEANING SHOE INSPECTION LIGHT .....	40 - 84
1G20	CENTRAL ELECTRONICS MODULE AND CIRCUIT BOARDS .....	40 - 48	3G22	CLEANOUT DOOR, SUPPLY AUGER .....	120 - 1
2H16	CHAFF SPREADER CONTROL, CHECK VALVE, ROD AND KNOB .....	70 - 64	1H7	CLUTCH ASSEMBLY (STARTER) .....	40 - 60
3K8	CHAFF SPREADER DISC .....	130 - 26	3D13	CLUTCH, COMPRESSOR .....	95 - 13
2H18	CHAFF SPREADER LINES AND FITTINGS .....	70 - 66	3E19	CLUTCH, FEEDER HOUSE SHAFT .....	100 - 28
3K14	CHAFF SPREADER MOUNTING SUPPORT .....	130 - 32	4B17	CLUTCH, HEADER ELECTROMAGNETIC .....	140 - 17
2G17	CHAFF SPREADER PUMP .....	70 - 40	3C5	COLD WEATHER START BUTTON .....	90 - 30
3K10	CHAFF SPREADER SHIELDS AND HANDLES .....	130 - 28	1E13	COLD WEATHER STARTING AID .....	30 - 12
2H22	CHAFF SPREADER, HOSES, LINES (DUAL MOTOR) .....	70 - 70	3B12	COMPLETE CAB .....	90 - 12
2H20	CHAFF SPREADER, LINES, HOSES, VALVE AND PUMP .....	70 - 68	3D15	COMPRESSOR PARTS (650301- ) .....	95 - 15
3K12	CHAFF SPREADER, PAN AND SEALS .....	130 - 30	3D11	COMPRESSOR, AIR CONDITIONING .....	95 - 11
3H9	CHAFFER ELEMENT .....	120 - 12	3D13	COMPRESSOR, CLUTCH .....	95 - 13
3H11	CHAFFER EXTENSION ELEMENT .....	120 - 14	1H13	CONCAVE ADJUSTING MOTOR .....	40 - 66
3H13	CHAFFER FRAME .....	120 - 16	1H14	CONCAVE INDICATOR .....	40 - 68
3H7	CHAFFER FRAME ARMS, PRECLEANER .....	120 - 10	3G7	CONCAVE, SPIKE-TOOTH .....	110 - 14
3H5	CHAFFER FRAME, PRE-CLEANER .....	120 - 8	3G9	CONCAVE, SPIKE-TOOTH .....	110 - 16
3H3	CHAFFER, PRECLEANING .....	120 - 6	2F11	CONDENSER, AIR CONDITIONING .....	70 - 8
1E15	CHAIN LINK, FUEL TANK .....	30 - 14	1C15	CONNECTING ROD .....	25 - 8
4D5	CHAIN TIGHTENER, UPPER TAILINGS DRIVE .....	140 - 57	1C15	CONNECTING ROD BEARINGS .....	25 - 8
3C1	CHAIN, ARMREST CONTROL PANEL .....	90 - 26	1F4	CONNECTOR, ELECTRICAL, WEATHERPACK .....	40 - 2
3C17	CHAIN, CAB PLATFORM SAFETY .....	90 - 42	1C4	CONNECTOR, ENGINE HEATER HOSE .....	20 - 27
3I7	CHAIN, CONVEYOR, CLEAN GRAIN LOWER ELEVATOR .....	125 - 6	1E7	CONNECTOR, FUEL INJECTION PUMP HOUSING .....	30 - 6
3F3	CHAIN, FEEDER CONVEYOR .....	100 - 36	1F12	CONNECTOR, SUPPLEMENTARY TERMINALS .....	40 - 10
3E23	CHAIN, FEEDER CONVEYOR IDLER .....	100 - 32	3C13	CONSOLE, OVERHEAD .....	90 - 38
3J1	CHAIN, LOWER TAILINGS AUGER .....	125 - 24	3B8	CONTAINER, TRASH .....	90 - 8
4I3	CHAIN, LOWER TAILINGS AUGER .....	170 - 34	2H11	CONTOUR MASTER HYDRAULIC HOSES, L.H. ....	70 - 58
3E23	CHAIN, ROLLER, FEEDER CONVEYOR .....	100 - 32	2F22	CONTOUR MASTER SOLENOID RELIEF VALVE .....	70 - 20
3C17	CHAIN, SAFETY, CAB PLATFORM .....	90 - 42	2H14	CONTOUR MASTER TILT CYLINDER .....	70 - 61
3I24	CHAIN, TAILINGS ELEVATOR CONVEYOR .....	125 - 23	2H15	CONTOUR MASTER TILT CYLINDER HOSES .....	70 - 63
4I3	CHAIN, UPPER TAILINGS AUGER .....	170 - 34	3E17	CONTOUR MASTER, FEEDER HOUSE SHELL, WEAR PLATES AND SEALS .....	100 - 26
4E17	CHANNEL, CROSS AUGER .....	150 - 34	2C3	CONTROL CABLES, HYDROSTATIC DRIVE .....	50 - 26
4D20	CHARGE HOUSING, VERTICAL UNLOADING AUGER	150 - 12	3B23	CONTROL PANEL, OPERATOR'S ARMREST .....	90 - 24
2C9	CHARGE PUMP, HYDROSTATIC .....	50 - 32	3C1	CONTROL PANEL, OPERATOR'S ARMREST .....	90 - 26
2H16	CHECK VALVE, CHAFF SPREADER CONTROL .....	70 - 64	1E5	CONTROL UNIT, ELECTRONIC .....	30 - 4
3J25	CHOP-TO-BALE DECLUTCHING LEVER .....	130 - 18	1G24	CONTROL UNIT, ELECTRONIC (ECU) .....	40 - 52
			2C23	CONTROL VALVE .....	50 - 50
			2F16	CONTROL VALVE MODULE, 6-STACK SOLENOID .....	70 - 14
			2C24	CONTROL VALVE SOLENOID .....	50 - 51
			2C10	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT .....	50 - 34

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2G5	CONTROL VALVE, SOLENOID, AUGER SWING .....	70 - 28	4C3	CYLINDER DRIVE INTERMEDIATE SHEAVE, DUAL-RANGE .....	140 - 30
2G5	CONTROL VALVE, SOLENOID, REEL FORE/AFT .....	70 - 28	4B24	CYLINDER DRIVE TIGHTENER, DUAL-RANGE .....	140 - 26
1E5	CONTROLLER, ENGINE .....	30 - 4	1C24	CYLINDER HEAD .....	25 - 18
1F13	CONVENIENCE OUTLET,KIT .....	40 - 12	1C24	CYLINDER HEAD GASKET .....	25 - 18
4C11	CONVEYOR AUGERS, STRAW WALKER, SIEVE AND CHAFFER DRIVE .....	140 - 38	1D22	CYLINDER HEAD GASKET KIT .....	25 - 46
3I7	CONVEYOR CHAIN, CLEAN GRAIN .....	125 - 6	1C15	CYLINDER LINER O-RING KIT .....	25 - 8
3E23	CONVEYOR, LEVEL LAND IDLER .....	100 - 32	3G1	CYLINDER SHEAR BAR, SEPARATOR.....	110 - 8
1B22	COOLANT HEATER, ENGINE BLOCK.....	20 - 20	2G15	CYLINDER SPEED HYDRAULIC HOSES .....	70 - 38
1B12	COOLANT RECOVERY TANK .....	20 - 10	2G3	CYLINDER SPEED, SOLENOID CONTROL VALVE .....	70 - 26
1D8	COOLER, ENGINE OIL .....	25 - 28	3G5	CYLINDER THRESHING, SPIKE TOOTH .....	110 - 12
3D20	COOLER, OIL, FEEDER HOUSE GEARCASE .....	100 - 4	2D21	CYLINDER, BRAKE PEDAL .....	60 - 4
3J22	CORN DEFLECTOR .....	130 - 15	2E3	CYLINDER, BRAKE SLAVE .....	60 - 10
2I19	CORNER PANEL, REAR, L.H. ....	80 - 18	2D23	CYLINDER, BRAKE, MASTER .....	60 - 6
3C11	CORNERPOST DISPLAY PANEL, R.H. ....	90 - 36	2E1	CYLINDER, BRAKE, MASTER .....	60 - 8
4C7	COUNTERSHAFT DRIVE, SECONDARY.....	140 - 34	4E18	CYLINDER, GRAIN TANK UNLOADING DRIVE .....	150 - 36
4E20	COUNTERSHAFT DRIVE, UNLOADING AUGER .....	150 - 38	2G6	CYLINDER, HEADER LIFT, HYDRAULIC .....	70 - 29
4B15	COUNTERSHAFT, PRIMARY GEARCASE .....	140 - 14	2C7	CYLINDER, HYDROSTATIC PUMP .....	50 - 30
4B13	COUNTERSHAFT, PRIMARY, SEPARATOR.....	140 - 12	2D21	CYLINDER, MASTER BRAKE.....	60 - 4
1B19	COUPLING WITH HUB, ENGINE-TRANSMISSION.....	20 - 17	2E19	CYLINDER, STEERING.....	60 - 26
2B8	COUPLINGS, AXLE .....	50 - 5	4G17	CYLINDER, TENSION INDIVIDUAL REPAIR PARTS.....	160 - 28
4E17	COVER AND CHANNEL, CROSS AUGER .....	150 - 34	4G1	CYLINDER, TENSION AND ATTACHING HARDWARE	160 - 10
3K1	COVER, CHOPPER, CHOP-TO-BALE .....	130 - 19	3G3	CYLINDER, THRESHING, RASP BAR .....	110 - 10
1E17	COVER, ENGINE.....	30 - 16	2H14	CYLINDER, TILT - CONTOUR MASTER .....	70 - 61
1H5	COVER, FUEL INJECTION PUMP ACCESS .....	40 - 58	2H15	CYLINDER, TILT, HOSES, CONTOUR MASTER .....	70 - 63
2C5	COVER, HYDROSTATIC PUMP .....	50 - 28	4D24	CYLINDER, UNLOADING AUGER SWING .....	150 - 16
2C17	COVER, INNER, CAM LOBE MOTOR .....	50 - 42			
4F8	COVER, MOISTURE SENSOR, YIELD MAPPING .....	155 - 8		<b>D</b>	
4F10	COVER, MOISTURE SENSOR, YIELD MAPPING .....	155 - 10	1C16	DAMPER KEY .....	25 - 9
4F2	COVER, POSITION RECEIVER YIELD MAPPING.....	155 - 2	1D24	DAMPER, CRANKSHAFT .....	25 - 48
1D2	COVER, ROCKER ARM .....	25 - 21	4F14	DATASTORE .....	155 - 14
1B21	COVER, STARTER RELAY.....	20 - 19	4F12	DATASTORE MODULE .....	155 - 12
1D16	COVER, THERMOSTAT .....	25 - 38	4F14	DATASTORE MODULE .....	155 - 14
3F19	COVER, THRESHING CYLINDER .....	110 - 1	4F12	DATASTORE W/DISPLAY.....	155 - 12
1C22	COVER, TIMING GEAR.....	25 - 15	4F16	DECALS, DISPLA, YIELD MAPPING .....	155 - 17
4F10	COVER, WHEN MOISTURE SENSOR IS NOT USED YIELD MAPPING.....	155 - 10	4F15	DECALS, DISPLAY, YIELD MAPPING .....	155 - 15
3G19	CRANK, STRAW WALKER .....	110 - 26	4H15	DECALS, FRENCH CANADIAN .....	170 - 22
1B24	CRANKCASE, ENGINE OIL DRAIN .....	20 - 22	4H9	DECALS, FRONT AND REAR .....	170 - 16
1C16	CRANKSHAFT .....	25 - 9	4H13	DECALS, FRONT AND REAR TIRE.....	170 - 20
1C22	CRANKSHAFT FRONT OIL SEAL .....	25 - 15	4H7	DECALS, L.H.....	170 - 14
1C17	CRANKSHAFT KIT, UNDERSIZE .....	25 - 10	4F15	DECALS, MOISTURE SENSOR, YIELD MAPPING.....	155 - 15
1C18	CRANKSHAFT KIT, UNDERSIZED MAIN BEARING.....	25 - 11	4F16	DECALS, MOISTURE SENSOR, YIELD MAPPING.....	155 - 17
1C20	CRANKSHAFT OIL SEAL .....	25 - 13	4H16	DECALS, PORTUGESE.....	170 - 23
1D24	CRANKSHAFT PULLEY AND DAMPER.....	25 - 48	4H5	DECALS, R.H. ....	170 - 12
3G19	CRANKSHAFT, STRAW WALKER .....	110 - 26	4H17	DECALS, ROMANIAN .....	170 - 24
4E13	CROSS AUGER BEARING PLATE, L.H. ....	150 - 30	4H18	DECALS, RUSSIAN .....	170 - 25
4E17	CROSS AUGER COVERS AND CHANNEL.....	150 - 34	4H11	DECALS, SAFETY (RUBBER TRACK).....	170 - 18
4E15	CROSS AUGER, GRAIN TANK .....	150 - 32	4G20	DECALS, SAFETY AND LOCATIONS .....	170 - 2
3G12	CURTAIN, BEATER GRATE .....	110 - 19	4G22	DECALS, SAFETY AND LOCATIONS .....	170 - 4
4D14	CURTAIN, GRAIN TANK .....	150 - 6	4G24	DECALS, SAFETY AND LOCATIONS .....	170 - 6
3G2	CURTAIN, SEPARATOR, RASP BAR CYLINDER.....	110 - 9	4H1	DECALS, SAFETY AND LOCATIONS .....	170 - 8
3K6	CURTAIN, SPREADER .....	130 - 24	4H3	DECALS, SAFETY AND LOCATIONS .....	170 - 10
3C11	CURUIT BOARD, CORNERPOST DISPLAY, R.H. ....	90 - 36	4H19	DECALS, SPANISH .....	170 - 26
3B16	CUSHION, SEAT, PASSENGER.....	90 - 16	4H20	DECALS, UKRAINIAN .....	170 - 27
1C9	CYLINDER BLOCK FITTINGS .....	25 - 2	4F15	DECALS, YIELD MAPPING.....	155 - 15
3F19	CYLINDER COVER, THRESHING .....	110 - 1	4F16	DECALS, YIELD MAPPING.....	155 - 17
3F24	CYLINDER DOOR (CORN).....	110 - 6	3J25	DECLUTCHING LEVER, CHOP-TO-BALE .....	130 - 18
3F22	CYLINDER DOOR, SEPARATOR (GRAIN AND RICE).....	110 - 4	4F6	DEFLECTOR DOOR, MASS FLOW SENSOR YIELD MAPPING .....	155 - 6
4C5	CYLINDER DRIVE ADJUSTING BRACKET, DUAL-RANGE .....	140 - 32	3K12	DEFLECTOR, CHAFF SPREADER.....	130 - 30
4B21	CYLINDER DRIVE GEAR CASE, DUAL-RANGE.....	140 - 22	3J22	DEFLECTOR, CORN .....	130 - 15
4C1	CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING, DUAL-RANGE .....	140 - 28	3F22	DEFLECTOR, CYLINDER DOOR, SEPARATOR (GRAIN AND RICE).....	110 - 4
			2B22	DIFFERENTIAL GEARS .....	50 - 20

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2B22	DIFFERENTIAL SHAFTS.....	50 - 20	2G19	DRIVE, BELT PICKUP AND REEL PUMP MOUNTING SHEAVE .....	70 - 42
1C9	DIPSTICK TUBE, CYLINDER BLOCK .....	25 - 2	4E20	DRIVE, COUNTERSHAFT, UNLOADING AUGER .....	150 - 38
1D13	DIPSTICK, ENGINE OIL .....	25 - 34	1B14	DRIVE, ENGINE FAN .....	20 - 12
3K8	DISC, CHAFF SPREADER .....	130 - 26	1B16	DRIVE, ENGINE FAN .....	20 - 14
2C10	DISPLACEMENT CONTROL VALVE .....	50 - 34	4C19	DRIVE, FAN, SPEED CONTROL SHEAVE LINKAGE....	140 - 46
4F4	DISPLAY BRACKET, YIELD MAPPING .....	155 - 4	4C9	DRIVE, GEARCASE, STRAW WALKER.....	140 - 36
4F16	DISPLAY DECALS, YEILD MAPPING .....	155 - 17	2C12	DRIVE, HYDROSTATIC MOTOR .....	50 - 36
4F15	DISPLAY DECALS, YIELD MAPPING .....	155 - 15	2D3	DRIVE, HYDROSTATIC OIL HOSES, UPPER (FOUR WHEEL DRIVE) .....	50 - 54
3C11	DISPLAY PANEL, R.H. CORNERPOST .....	90 - 36	2D1	DRIVE, HYDROSTATIC, LOWER OIL LINES (TWO WHEEL DRIVE) .....	50 - 52
4F12	DISPLAY W/DATASTORE.....	155 - 12	2H1	DRIVE, REEL, HYDRAULIC LINES, L.H.....	70 - 48
4F4	DISPLAY, YIELD MAPPING .....	155 - 4	4C7	DRIVE, SECONDARY COUNTERSHAFT.....	140 - 34
3B14	DOOR LATCH, CAB .....	90 - 14	4B20	DRIVE, SINGLE RANGE CYLINDER .....	140 - 21
3B12	DOOR, CAB AND GLASS.....	90 - 12	4C23	DRIVE, STRAW CHOPPER (REAR).....	140 - 50
3J9	DOOR, CHOPPER.....	130 - 1	4C11	DRIVE, STRAW WALKER, CONVEYOR AUGERS, SIEVE AND CHAFFER DRIVE.....	140 - 38
3I7	DOOR, CLEAN GRAIN ELEVATOR .....	125 - 6	4G11	DRUM AND SHOES, BRAKE .....	160 - 22
3I5	DOOR, CLEAN GRAIN LOWER AUGER .....	125 - 4	2E5	DRUM, BRAKE.....	60 - 12
2I13	DOOR, CORNER SHEET, LEFT FRONT.....	80 - 12	3E23	DRUM, FEEDER CONVEYOR IDLER .....	100 - 32
3F24	DOOR, CYLINDER (CORN) .....	110 - 6	3D9	DRYER, AIR CONDITIONER .....	95 - 9
3F22	DOOR, CYLINDER, SEPARATOR (GRAIN AND RICE).....	110 - 4	4B23	DUAL RANGE LOCKOUT ARM .....	140 - 25
2J14	DOOR, ENGINE ACCESS PLATFORM .....	80 - 38	4C5	DUAL-RANGE CYLINDER DRIVE ADJUSTING BRACKET.....	140 - 32
1E17	DOOR, ENGINE COMPARTMENT .....	30 - 16	4B21	DUAL-RANGE CYLINDER DRIVE GEAR CASE .....	140 - 22
2J10	DOOR, ENGINE COMPARTMENT .....	80 - 34	4C1	DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHAFT MOUNTING.....	140 - 28
3E15	DOOR, FEEDER HOUSE FRAME .....	100 - 24	4C3	DUAL-RANGE CYLINDER DRIVE INTERMEDIATE SHEAVE.....	140 - 30
4D10	DOOR, GRAIN TANK .....	150 - 2	4B24	DUAL-RANGE CYLINDER DRIVE TIGHTENER .....	140 - 26
2I15	DOOR, GULLWING, L.H.....	80 - 14	3F1	DUST FAN, FEEDER HOUSE - R.H. ....	100 - 34
2I23	DOOR, GULLWING, R.H. ....	80 - 22	3F12	DUST FAN, LH SIDE FEEDER HOUSE.....	100 - 46
2I17	DOOR, LEFT REAR GULLWING .....	80 - 16			
4F6	DOOR, MASS FLOW SENSOR DEFLECTOR YIELD MAPPING .....	155 - 6		<b>E</b>	
3I23	DOOR, MATERIAL SENSOR REPLACEMENT TAILING ELEVATOR.....	125 - 22	1E5	E.C.U. ....	30 - 4
2J1	DOOR, RADIATOR .....	80 - 24	1G20	ECU MODULE .....	40 - 48
1B10	DOOR, RADIATOR ACCESS .....	20 - 8	1G24	ECU, ELECTRONIC CONTROL UNIT .....	40 - 52
1B6	DOOR, ROTARY SCREEN .....	20 - 4	1F6	ELECTRICAL CONNECTOR SERVICE KIT.....	40 - 4
2I3	DOOR, SEPARATOR FRAME.....	80 - 2	1F8	ELECTRICAL CONNECTOR SERVICE KIT.....	40 - 6
3G22	DOOR, SHOE GRAIN SUPPLY AUGER CLEANOUT....	120 - 1	1F4	ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK .....	40 - 2
3F20	DOOR, STONE TRAP, FEEDER HOUSE .....	110 - 2	4B17	ELECTROMAGNETIC HEADER CLUTCH .....	140 - 17
3I21	DOOR, TAILINGS ELEVATOR .....	125 - 20	1E5	ELECTRONIC CONTROL UNIT .....	30 - 4
1C9	DRAIN PLUG, CYLINDER BLOCK .....	25 - 2	1G24	ELECTRONIC CONTROL UNIT (ECU).....	40 - 52
2C12	DRAIN PLUG, DRIVE MOTOR .....	50 - 36	1E5	ELECTRONIC FUEL INJECTION PUMP .....	30 - 4
1B22	DRAIN PLUG, ENGINE COOLANT.....	20 - 20	1G20	ELECTRONICS MODULE, CENTRAL .....	40 - 48
2C14	DRAIN PLUG, HYDROSTATIC MOTOR VALVE .....	50 - 38	3H9	ELEMENT, CHAFFER .....	120 - 12
1C9	DRAIN VALVE, CYLINDER BLOCK .....	25 - 2	3H11	ELEMENT, CHAFFER EXTENSION .....	120 - 14
1D16	DRAIN VALVE, CYLINDER HEAD .....	25 - 38	3H15	ELEMENT, SIEVE .....	120 - 18
1E15	DRAIN VALVE, FUEL .....	30 - 14	4D6	ELEVATOR DRIVE IDLER, CLEAN GRAIN .....	140 - 58
1E10	DRAIN VALVE, FUEL COOLER .....	30 - 9	4D6	ELEVATOR DRIVE TIGHTENER, CLEAN GRAIN .....	140 - 58
1D11	DRAIN VALVE, OIL PAN.....	25 - 32	3I7	ELEVATOR, LOWER, CLEAN GRAIN .....	125 - 6
1B12	DRAIN VALVE, RADIATOR.....	20 - 10	3I21	ELEVATOR, TAILINGS .....	125 - 20
4E22	DRIVE BELT GUIDE, UNLOADING AUGER .....	150 - 40	3I3	ELEVATOR, UPPER CLEAN GRAIN .....	125 - 2
4D5	DRIVE CHAIN TIGHTENER, UPPER TAILINGS .....	140 - 57	2J14	ENGINE ACCESS PLATFORM.....	80 - 38
4C21	DRIVE CHOPPER (FRONT) .....	140 - 48	1E17	ENGINE COMPARTMENT.....	30 - 16
1C16	DRIVE GEAR, OIL PUMP .....	25 - 9	2J10	ENGINE COMPARTMENT.....	80 - 34
4D6	DRIVE IDLER, CLEAN GRAIN ELEVATOR .....	140 - 58	1E5	ENGINE CONTROLLER .....	30 - 4
2B24	DRIVE SHAFT, FINAL DRIVE.....	50 - 22	1B14	ENGINE FAN DRIVE .....	20 - 12
2B8	DRIVE SHAFTS .....	50 - 5	1B16	ENGINE FAN DRIVE .....	20 - 14
2J3	DRIVE SHIELD, R.H. REAR .....	80 - 27	1C21	ENGINE FLYWHEEL .....	25 - 14
4D1	DRIVE SHIELDS, STRAW CHOPPER .....	140 - 52	1B19	ENGINE GEARCASE HUB .....	20 - 17
4D6	DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR.....	140 - 58	4B3	ENGINE GEARCASE OIL FILTER ASSEMBLY .....	140 - 2
3E7	DRIVE TIGHTENER, FEEDER HOUSE .....	100 - 16	4B5	ENGINE GEARCASE PRESSURE REGULATOR .....	140 - 4
3E3	DRIVE TIGHTENER, FIXED SPEED FEEDER HOUSE.....	100 - 12			
3E5	DRIVE TIGHTENER, VARIABLE SPEED .....	100 - 14			
4G13	DRIVE WHEEL AND BELT .....	160 - 24			
2B9	DRIVE WHEELS .....	50 - 6			
2B10	DRIVE WHEELS, HIGH FLOATATION.....	50 - 7			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4B11	ENGINE GEARCASE, SEPARATOR AND PUMP DRIVE .....	140 - 10	3F14	FEEDER HOUSE UPPER DRIVE SHAFT, (FIXED SPEED WITH REVERSER) .....	100 - 48
4B9	ENGINE GEARCASE, SEPARATOR DRIVE WET-CLUTCH AND PUMP DRIVE SHAFT .....	140 - 8	3E19	FEEDER HOUSE UPPER SHAFT .....	100 - 28
1C1	ENGINE INTERCOOLER .....	20 - 24	3F5	FEEDER HOUSE VARIABLE DRIVE HOSE .....	100 - 39
1C3	ENGINE MOUNTS AND REAR SUPPORT .....	20 - 26	3E17	FEEDER HOUSE WEAR PLATES - CONTOUR MASTER .....	100 - 26
1C8	ENGINE OIL (TORQ-GARD PLUS-50) .....	25 - 1	3F20	FEEDER HOUSE/SEPARATOR SEAL, STONE TRAP AND DOOR .....	110 - 2
1D8	ENGINE OIL COOLER .....	25 - 28	3F6	FEEDER HOUSE, UPPER COUNTERSHAFT VARIABLE DRIVE .....	100 - 40
1D13	ENGINE OIL DIPSTICK .....	25 - 34	3B16	FIELD OFFICE .....	90 - 16
1D9	ENGINE OIL FILTER .....	25 - 30	1E19	FILTER, AIR CLEANER .....	30 - 18
1D4	ENGINE OIL PUMP .....	25 - 24	3D4	FILTER, AIR, RECIRCULATION .....	95 - 4
1D6	ENGINE OIL PUMP INTAKE .....	25 - 26	3D6	FILTER, CAB AIR .....	95 - 6
1C13	ENGINE OVERHAUL KIT .....	25 - 6	1D9	FILTER, ENGINE OIL .....	25 - 30
1C15	ENGINE PISTON .....	25 - 8	3D10	FILTER, EVAPORATOR HEATER .....	95 - 10
1D22	ENGINE REBUILD GASKET KIT .....	25 - 46	1E11	FILTER, FUEL .....	30 - 10
1C11	ENGINE SHORT BLOCK .....	25 - 4	1E15	FILTER, FUEL PUMP .....	30 - 14
1H20	ENGINE SPEED SENSOR .....	40 - 74	2C9	FILTER, HYDROSTATIC CHARGE PUMP .....	50 - 32
1F15	ENGINE WIRING HARNESS .....	40 - 14	2H13	FILTER, MAIN HYDRAULIC .....	70 - 60
1B19	ENGINE-TRANSMISSION COUPLING WITH HUB .....	20 - 17	4B3	FILTER, OIL, ENGINE GEARCASE .....	140 - 2
1E14	ETHER AID FITTINGS .....	30 - 13	1C22	FILTER, WATER PUMP .....	25 - 15
3C5	ETHER START BUTTON .....	90 - 30	1G11	FILTER, WINDSHIELD WASHER .....	40 - 38
3D10	EVAPORATOR HEATER, AIR CONDITIONER .....	95 - 10	2C1	FINAL DRIVE .....	50 - 24
1D21	EXHAUST MANIFOLD .....	25 - 44	2B24	FINAL DRIVE SHAFT .....	50 - 22
1D21	EXHAUST MANIFOLD HEAT SHIELD .....	25 - 44	2D15	FINAL DRIVE SHAFT SHIELDS .....	50 - 66
1E21	EXHAUST PIPE AND MUFFLER .....	30 - 20	2D14	FINAL DRIVE SHAFT SHIELDS - SINGLE REDUCTION .....	50 - 65
1C24	EXHAUST VALVES .....	25 - 18	3J14	FINE CUT ROTOR CHOPPER (STRAIGHT BLADE) .....	130 - 6
3H11	EXTENSION ELEMENT, CHAFFER .....	120 - 14	3G11	FINGER GRATE, SPIKE-TOOTH .....	110 - 18
2B7	EXTENSION, AXLE .....	50 - 4	3F1	FINGER, FEEDER HOUSE DUST FAN - R.H. .....	100 - 34
3J9	EXTENSION, CHOPPER DOOR .....	130 - 1	3F12	FINGER, FEEDER HOUSE DUST FAN, L.H. .....	100 - 46
4D16	EXTENSION, GRAIN TANK .....	150 - 8	3H5	FINGER, PRECLEANER CHAFFER .....	120 - 8
3C19	EXTENSION, LADDER ASSEMBLY .....	90 - 45	3H11	FINGERS, PLASTIC, CHAFFER .....	120 - 14
<b>F</b>					
4C17	FAN DRIVE SPEED CONTROL LINKAGE .....	140 - 44	1C9	FITTINGS, CYLINDER BLOCK .....	25 - 2
4C19	FAN DRIVE SPEED CONTROL SHEAVE LINKAGE .....	140 - 46	1E14	FITTINGS, ETHER STARTING .....	30 - 13
4C15	FAN DRIVE, CLEANING, SEPARATOR .....	140 - 42	1E15	FITTINGS, FUEL TANK .....	30 - 14
1B14	FAN DRIVE, ENGINE .....	20 - 12	1B18	FIXED FAN DRIVE .....	20 - 16
1B18	FAN DRIVE, FIXED .....	20 - 16	2B5	FIXED REAR AXLE .....	50 - 2
1B18	FAN PULLEY HUB .....	20 - 16	2E25	FIXED REAR AXLE STEERING TIE RODS .....	60 - 33
1B20	FAN PULLEY, AIR CONDITIONER COMPRESSOR .....	20 - 18	3E3	FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER .....	100 - 12
3D2	FAN, AIR CONDITIONER AND HEATER .....	95 - 2	1I5	FLOODLIGHT, CLEANING SHOE INSPECTION .....	40 - 84
1H3	FAN, ALTERNATOR (185 AMP) .....	40 - 56	2I19	FLOODLIGHT, LEFT REAR CORNER PANEL .....	80 - 18
1H1	FAN, ALTERNATOR (95 AMP) .....	40 - 54	1I3	FLOODLIGHT, SIDE FINDER .....	40 - 82
3D4	FAN, BLOWER, AIR CONDITIONER AND HEATER .....	95 - 4	3B8	FLOOR MAT .....	90 - 8
3H1	FAN, CLEANING .....	120 - 4	3B6	FLOOR PANELS .....	90 - 6
3F1	FAN, DUST, FEEDER HOUSE, R.H. .....	100 - 34	3E21	FLOOR, FEEDER HOUSE .....	100 - 30
3F12	FAN, DUST, LH SIDE FEEDER HOUSE .....	100 - 46	3F8	FLOOR, FEEDER HOUSE RETURN .....	100 - 42
1B16	FAN, ENGINE .....	20 - 14	2G21	FLOW CONTROL VALVE, REEL DRIVE .....	70 - 44
3F3	FEEDER CONVEYOR DRIVE CHAIN AND IDLER BRACKET .....	100 - 36	4F6	FLOW SENSOR, MASS, YIELD MAPPING .....	155 - 6
3E23	FEEDER CONVEYOR IDLER SHAFT AND DRUM .....	100 - 32	1C21	FLYWHEEL RING GEAR .....	25 - 14
1H9	FEEDER HOUSE BACKSHAFT SPEED SENSOR .....	40 - 62	1C21	FLYWHEEL, ENGINE .....	25 - 14
3E7	FEEDER HOUSE DRIVE TIGHTENER .....	100 - 16	1C23	FOLLOWER, CAMSHAFT .....	25 - 16
3E3	FEEDER HOUSE DRIVE TIGHTENER (FIXED SPEED) .....	100 - 12	1D1	FOLLOWER, CAMSHAFT .....	25 - 20
3F1	FEEDER HOUSE DUST FAN - R.H. .....	100 - 34	3C7	FOOT PEDAL, FEEDER HOUSE REVERSER .....	90 - 32
3F12	FEEDER HOUSE DUST FAN, LH SIDE .....	100 - 46	2D7	FOUR WHEEL DRIVE HYDRAULIC HOSES, L.H. .....	50 - 58
3E21	FEEDER HOUSE FLOOR .....	100 - 30	3H7	FRAME ARMS, PRECLEANER CHAFFER .....	120 - 10
3E15	FEEDER HOUSE FRAME .....	100 - 24	4F18	FRAME MOUNTING, TRACK .....	160 - 2
3F16	FEEDER HOUSE FRONT DRIVE SHAFT, SHEAVE AND MOUNTINGS (FIXED SPEED WITH .....	100 - 50	3H13	FRAME, CHAFFER .....	120 - 16
3D20	FEEDER HOUSE GEARCASE OIL COOLER .....	100 - 4	1E17	FRAME, ENGINE COMPARTMENT .....	30 - 16
3F10	FEEDER HOUSE POSITION SENSOR .....	100 - 44	3E15	FRAME, FEEDER HOUSE .....	100 - 24
3C7	FEEDER HOUSE REVERSER FOOT CONTROL .....	90 - 32	4F20	FRAME, MAIN, PIVOT BUSHINGS .....	160 - 4
3E17	FEEDER HOUSE SHELL - CONTOUR MASTER .....	100 - 26	2I3	FRAME, SEPARATOR .....	80 - 2
			4F18	FRAME, SHIPPING .....	160 - 2
			3H17	FRAME, SIEVE .....	120 - 20
			4H15	FRENCH CANADIAN DECALS AND LABELS .....	170 - 22
			4F22	FRONT ARM AND ADJUSTABLE IDLER ASSEMBLY ..	160 - 6

## ALPHABETICAL INDEX - CONTINUED

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
2I21	FRONT PANEL, RIGHT.....	80 - 20	4B15	GEARCASE, PRIMARY COUNTERSHAFT .....	140 - 14
2I9	FRONT SHIELD ASSEMBLY, RIGHT SIDE.....	80 - 8	3E1	GEARCASE, STANDARD .....	100 - 10
2E11	FRONT STEERING HOSES AND LINES.....	60 - 18	3C9	GEARSHIFT LEVER AND LINKAGE .....	90 - 34
3D18	FRONT VARIABLE DRIVE SHEAVE .....	100 - 2	3B12	GLASS, CAB AND DOOR .....	90 - 12
1E11	FUEL CHECK VALVE .....	30 - 10	1G16	GRAIN LOSS MONITOR.....	40 - 43
1E10	FUEL COOLER .....	30 - 9	3H19	GRAIN PAN, SHAKER.....	120 - 22
1E11	FUEL FILTER.....	30 - 10	4D14	GRAIN TANK AND CURTAINS.....	150 - 6
1E11	FUEL FILTER LINES.....	30 - 10	4D12	GRAIN TANK BASE.....	150 - 4
1E3	FUEL INJECTION LINES.....	30 - 2	4E15	GRAIN TANK CROSS AUGERS.....	150 - 32
1E3	FUEL INJECTION NOZZLE.....	30 - 2	4D16	GRAIN TANK EXTENSIONS.....	150 - 8
1E9	FUEL INJECTION NOZZLE.....	30 - 8	1G19	GRAIN TANK FULL BIN SENSOR .....	40 - 46
1H5	FUEL INJECTION PUMP ACCESS COVER .....	40 - 58	4D10	GRAIN TANK TOP.....	150 - 2
1E7	FUEL INJECTION PUMP HOUSING CONNECTORS .....	30 - 6	4E18	GRAIN TANK UNLOADING DRIVE CYLINDER.....	150 - 36
1E3	FUEL LEAK-OFF LINES .....	30 - 2	4D20	GRAIN TANK VERTICAL UNLOADING AUGER .....	150 - 12
1E5	FUEL LEAK-OFF LINES .....	30 - 4	1G18	GRAIN TANK WIRING HARNESS .....	40 - 45
1E5	FUEL PUMP.....	30 - 4	3G12	GRATE CURTAIN, BEATER.....	110 - 19
1E15	FUEL PUMP.....	30 - 14	3G11	GRATE, FINGER, SPIKE-TOOTH.....	110 - 18
1E15	FUEL SENDER .....	30 - 14	3G9	GRATE, SPIKE TOOTH CONCAVE .....	110 - 16
1E15	FUEL TANK AND FITTINGS.....	30 - 14	3B10	GRILLE, SPEAKER .....	90 - 10
2J12	FUEL TANK STEPS AND MOUNTING BRACKETS .....	80 - 36	3J25	GRIP, DECLUTCHING LEVER .....	130 - 18
1E8	FUEL TRANSFER PUMP .....	30 - 7	2J4	GRIP, REAR LANDING LADDER .....	80 - 28
			3K2	GUARD AND STRAW SPREADER MOUNTING .....	130 - 20
			3F3	GUIDE, CHAIN SUPPORT, FEEDER CONVEYOR .....	100 - 36
	<b>G</b>		2I15	GULLWING DOOR, L.H. ....	80 - 14
1D22	GASKET KIT, CYLINDER HEAD .....	25 - 46	2I17	GULLWING DOOR, LEFT REAR .....	80 - 16
1D22	GASKET KIT, ENGINE REBUILD .....	25 - 46	2I23	GULLWING DOOR, R.H.....	80 - 22
1D22	GASKET KIT, SHORT BLOCK .....	25 - 46			
1C24	GASKET, CYLINDER HEAD .....	25 - 18		<b>H</b>	
1D21	GASKET, EXHAUST MANIFOLD .....	25 - 44	3K10	HANDLE AND SHIELDS, CHAFF SPREADER .....	130 - 28
1D18	GASKET, INTAKE MANIFOLD .....	25 - 40	3B23	HANDLE, ARMREST CONTROL PANEL.....	90 - 24
1D9	GASKET, OIL FILTER HOUSING .....	25 - 30	3B6	HANDLE, CAB .....	90 - 6
1D11	GASKET, OIL PAN .....	25 - 32	3B14	HANDLE, CAB DOOR .....	90 - 14
1D4	GASKET, OIL PUMP.....	25 - 24	3H9	HANDLE, CHAFFER ELEMENT .....	120 - 12
1D6	GASKET, OIL PUMP INTAKE.....	25 - 26	3H11	HANDLE, CHAFFER EXTENSION ELEMENT .....	120 - 14
1C20	GASKET, REAR OIL SEAL.....	25 - 13	3F24	HANDLE, CYLINDER DOOR (CORN) .....	110 - 6
1D2	GASKET, ROCKER ARM COVER .....	25 - 21	3F22	HANDLE, CYLINDER DOOR, SEPARATOR (GRAIN AND RICE).....	110 - 4
1D16	GASKET, THERMOSTAT .....	25 - 38	3E21	HANDLE, FEEDER HOUSE LATCH.....	100 - 30
1C22	GASKET, TIMING GEAR COVER.....	25 - 15	2I15	HANDLE, GULLWING DOOR, L.H.....	80 - 14
1D19	GASKET, TURBOCHARGER .....	25 - 42	2I23	HANDLE, GULLWING DOOR, R.H. ....	80 - 22
1D16	GASKET, WATER MANIFOLD .....	25 - 38	2I5	HANDLE, LEFT SIDE FRONT SHIELD .....	80 - 4
1D14	GASKET, WATER PUMP .....	25 - 36	2I11	HANDLE, RIGHT SIDE SHIELD .....	80 - 10
2G13	GAUGE, ACCUMULATOR PRESSURE .....	70 - 36	3G22	HANDLE, SHOE GRAIN SUPPLY AUGER DOOR .....	120 - 1
3D22	GEAR BOX, REVERSER - (HIGH CAPACITY) .....	100 - 6	3H15	HANDLE, SIEVE ELEMENT .....	120 - 18
3E1	GEAR BOX, REVERSER, STANDARD .....	100 - 10	2J14	HANDRAIL, ENGINE ACCESS PLATFORM .....	80 - 38
4B21	GEAR CASE, DUAL-RANGE CYLINDER DRIVE.....	140 - 22	2J10	HANDRAIL, ENGINE COMPARTMENT .....	80 - 34
4G7	GEAR CASE, TRANSFER.....	160 - 18	3C20	HANDRAIL, L.H.....	90 - 46
4D18	GEAR CASE, VERTICAL AUGER LOWER .....	150 - 10	3C17	HANDRAIL, PLATFORM EXTENSIONS .....	90 - 42
1C23	GEAR, CAMSHAFT .....	25 - 16	3C22	HANDRAIL, R.H. ....	90 - 48
2B22	GEAR, DIFFERENTIAL .....	50 - 20	2J1	HANDRAIL, RADIATOR DOOR.....	80 - 24
2C1	GEAR, FINAL DRIVE.....	50 - 24	3C24	HARDWARE KIT, CAB .....	90 - 50
1E5	GEAR, INJECTION PUMP.....	30 - 4	1G9	HARNESS, AIR CONDITIONING WIRING .....	40 - 36
1C16	GEAR, OIL PUMP DRIVE .....	25 - 9	1G5	HARNESS, ARMREST WIRING .....	40 - 32
1D4	GEAR, OIL PUMP DRIVE .....	25 - 24	1G3	HARNESS, CAB WIRING .....	40 - 30
3E1	GEAR, REVERSER, STANDARD .....	100 - 10	4F12	HARNESS, DATASTORE .....	155 - 12
3G23	GEAR, SHOE GRAIN SUPPLY AUGER.....	120 - 2	1G19	HARNESS, FULL BIN SENSOR .....	40 - 46
2B18	GEAR, TRANSMISSION .....	50 - 16	1F17	HARNESS, MAIN WIRING, L.H. ....	40 - 17
2B20	GEAR, TRANSMISSION PINION .....	50 - 18	1F20	HARNESS, MAIN WIRING, L.H. ....	40 - 20
1C17	GEAR, UNDERSIZE CRANKSHAFT.....	25 - 10	4F8	HARNESS, MOISTURE SENSOR MOTOR YIELD MAPPING .....	155 - 8
4C9	GEARCASE DRIVE, STRAW WALKER .....	140 - 36	1F25	HARNESS, R.H. MAIN W/GREENSTAR.....	40 - 27
4B13	GEARCASE MOUNTING.....	140 - 12	1F22	HARNESS, R.H. MAIN WIRING W/O GREENSTAR .....	40 - 23
3I13	GEARCASE, CLEAN GRAIN ELEVATOR .....	125 - 12	1H7	HARNESS, STARTER, WIRING .....	40 - 60
4B9	GEARCASE, ENGINE .....	140 - 8			
4B11	GEARCASE, ENGINE .....	140 - 10			
4E6	GEARCASE, HORIZONTAL UNLOADING AUGER DRIVE .....	150 - 23			
4B7	GEARCASE, MAIN.....	140 - 6			

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1G7	HARNESS, STEERING COLUMN WIRING .....	40 - 34	2D1	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE) .....	50 - 52
1G17	HARNESS, UNLOADING AUGER.....	40 - 44	2D9	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE).....	50 - 60
1G15	HARVESTRAK WIRING HARNESS .....	40 - 42	2D3	HOSES, OIL, HYDROSTATIC DRIVE, UPPER (FOUR WHEEL DRIVE) .....	50 - 54
1C24	HEAD, CYLINDER .....	25 - 18	2F5	HOSES, PRESSURE, HYDRAULIC .....	70 - 2
4B17	HEADER ELECTROMAGNETIC CLUTCH .....	140 - 17	2H3	HOSES, REEL DRIVE, HYDRAULIC, FRONT .....	70 - 50
2F23	HEADER HEIGHT CONTROL VALVE .....	70 - 21	2F7	HOSES, RETURN, HYDRAULIC.....	70 - 4
2F24	HEADER HEIGHT CONTROL, HYDRAULIC LINE AND VALVE BLOCK .....	70 - 22	2E9	HOSES, STEERING, UPPER .....	60 - 16
2G6	HEADER LIFT CYLINDER, HYDRAULIC .....	70 - 29	2H15	HOSES, TILT CYLINDER - CONTOUR MASTER .....	70 - 63
2G7	HEADER LIFT LINES AND HOSES .....	70 - 30	4D22	HOSES, UNLOADING AUGER SWING .....	150 - 14
2G1	HEADER LIFT MODULE, SOLENOID VALVE .....	70 - 24	3F5	HOSES, VARIABLE DRIVE, FEEDER HOUSE .....	100 - 39
3B10	HEADLINER, CAB .....	90 - 10	2F13	HOSES, WET CLUTCH OIL COOLER, HYDRAULIC ....	70 - 10
1D21	HEAT SHIELD, EXHAUST MANIFOLD.....	25 - 44	1G11	HOSES, WINDSHIELD WIPER .....	40 - 38
3D7	HEATER AND AIR CONDITIONING DUCTS .....	95 - 7	3G23	HOUSING AND SHOE GRAIN SUPPLY AUGERS .....	120 - 2
3D2	HEATER AND AIR CONDITIONING HOUSING.....	95 - 2	1E7	HOUSING CONNECTORS, FUEL INJECTION PUMP ..	30 - 6
3D4	HEATER AND AIR CONDITIONING HOUSING, LOWER .....	95 - 4	2B17	HOUSING COVER, TRANSMISSION AND DIFFERENTIAL .....	50 - 14
1C4	HEATER HOSE CONNECTORS.....	20 - 27	3D4	HOUSING, AIR CONDITIONER/HEATER, LOWER .....	95 - 4
1B22	HEATER, COOLANT, ENGINE BLOCK .....	20 - 20	3D2	HOUSING, AIR CONDITIONER/HEATER, UPPER .....	95 - 2
3D10	HEATER, EVAPORATOR, AIR CONDITIONER.....	95 - 10	3D6	HOUSING, CAB AIR FILTER .....	95 - 6
3D22	HIGH CAPACITY REVERSE GEAR BOX .....	100 - 6	4D20	HOUSING, CHARGE, VERTICAL UNLOADING AUGER.....	150 - 12
2B10	HIGH FLOATATION DRIVE WHEELS .....	50 - 7	2C1	HOUSING, FINAL DRIVE .....	50 - 24
3F22	HINGE, CYLINDER DOOR (GRAIN AND RICE).....	110 - 4	4E9	HOUSING, HORIZONTAL UNLOADING AUGER (EXPORT) .....	150 - 26
3I5	HINGE, DOOR, LOWER AUGER, CLEAN GRAIN .....	125 - 4	4E7	HOUSING, HORIZONTAL UNLOADING AUGER (17 AND 20 FT.) .....	150 - 24
3F20	HINGE, DOOR, STONE TRAP .....	110 - 2	2C7	HOUSING, HYDROSTATIC PUMP .....	50 - 30
2J10	HINGE, ENGINE COMPARTMENT.....	80 - 34	1C20	HOUSING, REAR OIL SEAL.....	25 - 13
1E17	HINGE, ENGINE PLATFORM DOOR.....	30 - 16	2B5	HOUSING, SPINDLE, REAR AXLE .....	50 - 2
3E15	HINGE, FEEDER HOUSE FRAME DOOR .....	100 - 24	3I21	HOUSING, TAILINGS ELEVATOR .....	125 - 20
2I23	HINGE, GULLWING DOOR, R.H.....	80 - 22	1D16	HOUSING, THERMOSTAT, FRONT .....	25 - 38
2I15	HINGE, L.H. GULLWING.....	80 - 14	2B16	HOUSING, TRANSMISSION AND DIFFERENTIAL .....	50 - 13
1B10	HINGE, RADIATOR ACCESS DOOR .....	20 - 8	3J5	HOUSING, UPPER TAILINGS AUGER .....	125 - 28
2J1	HINGE, RADIATOR DOOR .....	80 - 24	4E5	HUB SUPPORT, HORIZONTAL UNLOADING AUGER..	150 - 22
2J8	HOOD, REAR.....	80 - 32	4G6	HUB, BOGEY WHEEL.....	160 - 16
4E11	HORIZONTAL UNLOADING AUGER (17- AND 20-FT.).....	150 - 28	1B16	HUB, FAN.....	20 - 14
4E6	HORIZONTAL UNLOADING AUGER DRIVE GEARCASE .....	150 - 23	1B18	HUB, FAN PULLEY .....	20 - 16
4E9	HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) .....	150 - 26	4G3	HUB, IDLER WHEEL .....	160 - 12
4E7	HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.) .....	150 - 24	2H13	HYDRAULIC FILTER, MAIN .....	70 - 60
4E1	HORIZONTAL UNLOADING AUGER SWIVEL.....	150 - 18	2H11	HYDRAULIC HOSES, CONTOUR MASTER (L.H.) .....	70 - 58
3B5	HORN ASSEMBLY.....	90 - 5	2G15	HYDRAULIC HOSES, CYLINDER SPEED .....	70 - 38
3C5	HORN BUTTON .....	90 - 30	2D7	HYDRAULIC HOSES, L.H., 4-WHEEL DRIVE .....	50 - 58
2G7	HOSES AND LINES, HEADER LIFT .....	70 - 30	2G23	HYDRAULIC HOSES, REEL PUMP .....	70 - 46
2D5	HOSES AND LINES, HYDROSTATIC OIL COOLER.....	50 - 56	2F13	HYDRAULIC HOSES, WET CLUTCH OIL COOLER.....	70 - 10
2H9	HOSES AND LINES, REEL LIFT .....	70 - 56	2H7	HYDRAULIC LINES AND HOSES, REEL FORE-AND-AFT, FRONT .....	70 - 54
2E11	HOSES AND LINES, STEERING, FRONT.....	60 - 18	2D13	HYDRAULIC LINES, CASE DRAIN, 4-WHEEL DRIVE .....	50 - 64
2E17	HOSES AND LINES, STEERING, REAR .....	60 - 24	2H5	HYDRAULIC LINES, REEL FORE-AND-AFT, L.H. ....	70 - 52
1B12	HOSES RADIATOR .....	20 - 10	2C19	HYDRAULIC MOTOR PISTON CARRIER .....	50 - 44
3D12	HOSES, AIR CONDITIONER COMPRESSOR .....	95 - 12	2F5	HYDRAULIC PRESSURE HOSES .....	70 - 2
2H20	HOSES, CHAFF SPREADER .....	70 - 68	2G17	HYDRAULIC PUMP REEL / FEEDER HOUSE DRIVE ..	70 - 40
2D11	HOSES, CONTROL VALVE TO CAM LOBE MOTOR (4-WHEEL DRIVE).....	50 - 62	2F9	HYDRAULIC PUMP, MAIN .....	70 - 6
2D7	HOSES, FOUR WHEEL DRIVE HYDRAULIC, L.H. ....	50 - 58	2F7	HYDRAULIC RETURN LINES.....	70 - 4
4E18	HOSES, GRAIN TANK UNLOADING DRIVE CYLINDER .....	150 - 36	2F4	HYDRAULIC/HYDROSTATIC OIL RESERVOIR.....	70 - 1
2H11	HOSES, HYDRAULIC, CONTOUR MASTER (L.H.).....	70 - 58	4G15	HYDRAULICS, TENSION CYLINDER.....	160 - 26
2G15	HOSES, HYDRAULIC, CYLINDER SPEED .....	70 - 38	2C10	HYDROSTASTIC DRIVE DISPLACEMENT CONTROL VALVE.....	50 - 34
2G23	HOSES, HYDRAULIC, REEL PUMP.....	70 - 46	2C9	HYDROSTATIC DRIVE CHARGE PUMP .....	50 - 32
1C1	HOSES, INTERCOOLER .....	20 - 24	2C3	HYDROSTATIC DRIVE CONTROL CABLES .....	50 - 26
2H22	HOSES, LINES, CHAFF SPREADER (DUAL MOTOR).....	70 - 70	2C12	HYDROSTATIC DRIVE MOTOR.....	50 - 36
4E1	HOSES, LUBRICATION, HORIZONTAL UNLOADING AUGER.....	150 - 18	2D3	HYDROSTATIC DRIVE OIL HOSES, UPPER (FOUR WHEEL DRIVE) .....	50 - 54



## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2D1	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (TWO WHEEL DRIVE) .....	50 - 52	4D24	KIT, UNLOADING AUGER SWING CYLINDER REPAIR .....	150 - 16
2D9	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (4-WHEEL DRIVE) .....	50 - 60	1D14	KIT, WATER PUMP SEAL .....	25 - 36
2C5	HYDROSTATIC DRIVE PUMP COVER .....	50 - 28	1C18	KIT, UNDERSIZED MAIN BEARING CRANKSHAFT .....	25 - 11
2C5	HYDROSTATIC DRIVE PUMP SHAFT .....	50 - 28	3J18	KNIFEBANK AND HOUSING, CHOPPER .....	130 - 10
2D5	HYDROSTATIC OIL COOLER LINES .....	50 - 56	3C9	KNOB GEARSHIFT .....	90 - 34
2F4	HYDROSTATIC/HYDRAULIC RESERVOIR .....	70 - 1	3B23	KNOB, ARMREST CONTROL PANEL .....	90 - 24
<b>I</b>			3C1	KNOB, ARMREST CONTROL PANEL .....	90 - 26
1B4	IDLER ARMS, ROTARY SCREEN DRIVE .....	20 - 2	3D6	KNOB, CAB AIR FILTER .....	95 - 6
4F22	IDLER ASSEMBLY, ADJUSTABLE AND FRONT ARM..	160 - 6	2H16	KNOB, CHAFF SPREADER ADJUSTER .....	70 - 64
4G1	IDLER AXLE .....	160 - 10	2I13	KNOB, DOOR, LEFT FRONT .....	80 - 12
1B20	IDLER PULLEY, AIR CONDITIONER COMPRESSOR ..	20 - 18	3B20	KNOB, LUMBAR .....	90 - 20
4G3	IDLER WHEEL ASSEMBLY .....	160 - 12	3C13	KNOB, OVERHEAD CONSOLE .....	90 - 38
4D6	IDLER, DRIVE, CLEAN GRAIN ELEVATOR .....	140 - 58	<b>L</b>		
3C5	IGNITION SWITCH .....	90 - 30	1F18	L.H. MAIN WIRING HARNESS .....	40 - 18
1H14	INDICATOR, SPIKE TOOTH .....	40 - 68	1F20	L.H. MAIN WIRING HARNESS .....	40 - 20
1E5	INJECTION PUMP GEAR .....	30 - 4	2E13	L.H. SIDE LINES, STEERING .....	60 - 20
1E5	INJECTION PUMP, ELECTRONIC FUEL .....	30 - 4	4H13	LABEL, AXLE STOP AND TIRE CLEARANCE .....	170 - 20
2C17	INNER COVER, CAM LOBE MOTOR .....	50 - 42	4H15	LABEL, FRENCH CANADIAN .....	170 - 22
2B18	INPUT SHAFT, TRANSMISSION .....	50 - 16	4H16	LABEL, PORTUGUESE .....	170 - 23
1I5	INSPECTION LIGHT, CLEANING SHOE .....	40 - 84	4H17	LABEL, ROMANIAN .....	170 - 24
1D18	INTAKE MANIFOLD .....	25 - 40	4H18	LABEL, RUSSIAN .....	170 - 25
3G23	INTAKE SHIELD, SHOE GRAIN SUPPLY AUGER .....	120 - 2	4H11	LABEL, SAFETY (RUBBER TRACK) .....	170 - 18
3H1	INTAKE SHIELDS, CLEANING FAN .....	120 - 4	4H19	LABEL, SPANISH .....	170 - 26
1E19	INTAKE TUBES AND AIR CLEANER .....	30 - 18	4H13	LABEL, TIRE CLEARANCE .....	170 - 20
1C24	INTAKE VALVES .....	25 - 18	4H13	LABEL, TIRE PRESSURE .....	170 - 20
1D6	INTAKE, ENGINE OIL PUMP .....	25 - 26	4H20	LABEL, UKRAINIAN .....	170 - 27
1C1	INTERCOOLER .....	20 - 24	4H13	LABEL, WHEEL BOLT TORQUE .....	170 - 20
4C1	INTERMEDIATE SHAFT MOUNTING, CYLINDER DRIVE, DUAL-RANGE .....	140 - 28	3C19	LADDER EXTENSION ASSEMBLY .....	90 - 45
4C3	INTERMEDIATE SHEAVE, CYLINDER DRIVE, DUAL-RANGE .....	140 - 30	3C17	LADDER, CAB PLATFORM .....	90 - 42
<b>K</b>			2J10	LADDER, ENGINE COMPARTMENT .....	80 - 34
1C16	KEY, DAMPER, CRANKSHAFT .....	25 - 9	4D10	LADDER, GRAIN TANK .....	150 - 2
1F13	KIT-CONVENIENCE, OUTLET .....	40 - 12	2J4	LADDER, REAR LANDING .....	80 - 28
1H11	KIT, ALIGNMENT BRACKET REEL SPEED .....	40 - 64	1H24	LAMP ASSEMBLY - L.H. FRONT (AMBER) .....	40 - 78
2H14	KIT, CONTOUR MASTER CYLINDER REPAIR .....	70 - 61	1H25	LAMP ASSEMBLY, R.H. FRONT (AMBER) .....	40 - 79
2G5	KIT, CONTROL VALVE, AUGER SWING .....	70 - 28	1I1	LAMP ASSEMBLY, REAR (AMBER) .....	40 - 80
2G5	KIT, CONTROL VALVE, REEL FORE/AFT .....	70 - 28	1H24	LAMP, TURN SIGNAL, L.H. FRONT (AMBER) .....	40 - 78
1D22	KIT, CYLINDER HEAD .....	25 - 46	3C20	LANDING, L.H. .....	90 - 46
1C15	KIT, CYLINDER LINER O-RING .....	25 - 8	3C22	LANDING, R.H. .....	90 - 48
1F6	KIT, ELECTRICAL CONNECTOR SERVICE .....	40 - 4	2J4	LANDING, REAR .....	80 - 28
1F8	KIT, ELECTRICAL CONNECTOR SERVICE .....	40 - 6	2J6	LATCH ARM, REAR LADDER LANDING .....	80 - 30
1C13	KIT, ENGINE OVERHAUL .....	25 - 6	3B14	LATCH, CAB DOOR .....	90 - 14
1D22	KIT, ENGINE REBUILD .....	25 - 46	3J23	LATCH, CHOP-TO-BALE .....	130 - 16
2G1	KIT, HEADER LIFT CONTROL VALVE REPAIR .....	70 - 24	3J25	LATCH, DECLUTCHING LEVER, CHOP-TO-BALE .....	130 - 18
2C12	KIT, HYDROSTATIC DRIVE MOTOR .....	50 - 36	2I13	LATCH, DOOR, LEFT FRONT .....	80 - 12
2F9	KIT, MAIN HYDRAULIC PUMP REPAIR .....	70 - 6	3G22	LATCH, DOOR, SHOE GRAIN SUPPLY CLEANOUT ...	120 - 1
2E1	KIT, MASTER BRAKE CYLINDER .....	60 - 8	1G20	LATCH, ELECTRONICS MODULE .....	40 - 48
3J16	KIT, PADDLE BLADE, FINE CUT CHOPPER .....	130 - 8	1E17	LATCH, ENGINE PLATFORM DOOR .....	30 - 16
2G21	KIT, REEL DRIVE FLOW CONTROL REPAIR .....	70 - 44	4D18	LATCH, GRAIN TANK CLEAN OUT CHUTE .....	150 - 10
2G3	KIT, REEL LIFT/VARIABLE .....	70 - 26	3E11	LATCH, L.H. DRIVE SHIELD - W/AIRFLOW .....	100 - 20
1H11	KIT, REEL SPEED BRACKET .....	40 - 64	3E9	LATCH, L.H. DRIVE SHIELD - W/O AIRFLOW .....	100 - 18
2E19	KIT, STEERING CYLINDER REPAIR .....	60 - 26	3C19	LATCH, LADDER EXTENSION .....	90 - 45
2E7	KIT, STEERING PUMP SEALS .....	60 - 14	3E13	LATCH, R.H. DRIVE SHIELD .....	100 - 22
3G17	KIT, STRAW WALKER BEARING .....	110 - 24	1B10	LATCH, RADIATOR FRAME .....	20 - 8
1F10	KIT, TERMINAL AND WIRING .....	40 - 8	3I21	LATCH, TAILINGS ELEVATOR .....	125 - 20
2H15	KIT, TILT CYLINDER REPAIR, CONTOUR MASTER .....	70 - 63	2I7	LEFT SIDE SHIELD ASSEMBLY .....	80 - 6
1C17	KIT, UNDERSIZE CRANKSHAFT .....	25 - 10	3J25	LEVER, DECLUTCHING, CHOP-TO-BALE .....	130 - 18
			3C9	LEVER, GEARSHIFT .....	90 - 34
			2G6	LIFT CYLINDER, HEADER, HYDRAULIC .....	70 - 29
			1D3	LIFT STRAPS, ENGINE .....	25 - 22
			1H25	LIGHT ASSEMBLY - R.H. FRONT (AMBER) .....	40 - 79
			3I21	LIGHT SWITCH, TAILINGS ELEVATOR .....	125 - 20
			3C1	LIGHT, ARMREST CONTROL PANEL .....	90 - 26
			1H23	LIGHT, CAB ROOF .....	40 - 77

## ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
115	LIGHT, CLEANING SHOE INSPECTION .....	40-84		M	
2J14	LIGHT, ENGINE ACCESS PLATFORM .....	80-38			
2119	LIGHT, FLOOD, LEFT REAR CORNER PANEL .....	80-18	2117	MAGNET, GULLWING, LEFT REAR .....	80-16
1H24	LIGHT, L.H. FRONT (AMBER) .....	40-78	1H20	MAGNETIC PICK-UP (ENGINE) .....	40-74
112	LIGHT, REAR TURN AND TAIL (RED) .....	40-81	1C9	MAIN BEARING CAPS .....	25-2
2J10	LIGHT, SERVICE, ENGINE COMPARTMENT .....	80-34	1C19	MAIN BEARINGS .....	25-12
2115	LIGHT, SERVICE, L.H. GULLWING .....	80-14	4F20	MAIN FRAME PIVOT BUSHINGS .....	160-4
2123	LIGHT, SERVICE, R.H. GULLWING .....	80-22	4B7	MAIN GEARCASE .....	140-6
2J1	LIGHT, SERVICE, RADIATOR DOOR .....	80-24	2F9	MAIN HYDRAULIC PUMP .....	70-6
113	LIGHT, SIDE FINDER .....	40-82	2F23	MAIN VALVE BLOCK SOLENOID ACTIVE HEADER HEIGHT CONTROL .....	70-21
3B3	LIGHT, STUBBLE .....	90-2	1F25	MAIN WIRING HARNESS, R.H. W/GREENSTAR .....	40-27
114	LIGHT, TRANSPORT WARNING .....	40-83	1F22	MAIN WIRING HARNESS, R.H. W/O GREENSTAR .....	40-23
1G17	LIGHT, UNLOADING AUGER .....	40-44	3D11	MANIFOLD, AIR CONDITIONER COMPRESSOR .....	95-11
3B23	LIGHTER, CIGARETTE .....	90-24	2C17	MANIFOLD, CAM LOBE MOTOR .....	50-42
3F12	LIMIT CURTAIN, FEEDER HOUSE DUST FAN .....	100-46	2D13	MANIFOLD, CASE DRAIN .....	50-64
1C15	LINER, CYLINDER .....	25-8	1D21	MANIFOLD, EXHAUST .....	25-44
2G7	LINES AND HOSES, HEADER LIFT .....	70-30	1D18	MANIFOLD, INTAKE .....	25-40
2D5	LINES AND HOSES, HYDROSTATIC OIL COOLER .....	50-56	1D16	MANIFOLD, WATER, FRONT .....	25-38
2H9	LINES AND HOSES, REEL LIFT .....	70-56	4F6	MASS FLOW SENSOR BRACKET YIELD MAPPING .....	155-6
2E11	LINES AND HOSES, STEERING, FRONT .....	60-18	4F6	MASS FLOW SENSOR DOOR, YIELD MAPPING .....	155-6
2E17	LINES AND HOSES, STEERING, REAR .....	60-24	4F6	MASS FLOW SENSOR, YIELD MAPPING .....	155-6
2D23	LINES, BRAKE .....	60-6	2E1	MASTER BRAKE CYLINDER .....	60-8
2H18	LINES, CHAFF SPREADER .....	70-66	2D23	MASTER CYLINDER, RESERVOIR, BRAKE LINES .....	60-6
2D11	LINES, CONTROL VALVE TO CAM LOBE MOTOR (4-WHEEL DRIVE) .....	50-62	2D21	MASTER CYLINDERS .....	60-4
2D7	LINES, FOUR WHEEL DRIVE HYDRAULIC, L.H. ....	50-58	3B8	MAT, CAB FLOOR .....	90-8
1E5	LINES, FUEL .....	30-4	1E17	MAT, ENGINE PLATFORM .....	30-16
1E11	LINES, FUEL FILTER .....	30-10	3E15	MAT, FEEDER HOUSE FRAME .....	100-24
1E3	LINES, FUEL INJECTION .....	30-2	1B10	MAT, RADIATOR FRAME .....	20-8
1E3	LINES, FUEL LEAK-OFF .....	30-2	3I23	MATERIAL SENSOR, TAILINGS ELEVATOR .....	125-22
2H20	LINES, HOSES, VALVE AND PUMP, CHAFF SPREADER .....	70-68	3C20	MIRROR, L.H. ....	90-46
2G23	LINES, HYDRAULIC, REEL PUMP .....	70-46	3C22	MIRROR, R.H. ....	90-48
1E5	LINES, INJECTION PUMP LUBE .....	30-4	4F4	MOBILE PROCESSOR, YIELD MAPPING .....	155-4
2D1	LINES, OIL, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE) .....	50-52	3C11	MODULE, ACTIVE HEADER HEIGHT CONTROL DISPLAY, R.H. CORNERPOST .....	90-36
2D9	LINES, OIL, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE) .....	50-60	1G20	MODULE, CENTRAL ELECTRONICS .....	40-48
2H3	LINES, REEL DRIVE, HYDRAULIC, FRONT .....	70-50	4F12	MODULE, DATASTORE .....	155-12
2H1	LINES, REEL DRIVE, HYDRAULIC, L.H. ....	70-48	4F14	MODULE, DATASTORE .....	155-14
2F7	LINES, RETURN, HYDRAULIC RESERVOIR .....	70-4	3C11	MODULE, GRAIN LOSS DISPLAY R.H. CORNERPOST .....	90-36
2E15	LINES, STEERING R.H. SIDE .....	60-22	3C11	MODULE, TACHOMETER DISPLAY R.H. CORNERPOST .....	90-36
2E13	LINES, STEERING, L.H. SIDE .....	60-20	3I23	MODULE, TAILINGS ELEVATOR SENSOR .....	125-22
1D19	LINES, TURBOCHARGER OIL .....	25-42	2F16	MODULE, 6-STACK SOLENOID CONTROL VALVE .....	70-14
4D22	LINES, UNLOADING AUGER SWING .....	150-14	1H16	MOISTURE SENSOR .....	40-70
1H14	LINKAGE, CONCAVE INDICATOR .....	40-68	4F8	MOISTURE SENSOR BRACKET, YIELD MAPPING .....	155-8
1H14	LINKAGE, CORN AND SMALL GRAIN CONCAVE .....	40-68	4F8	MOISTURE SENSOR COVER, YIELD MAPPING .....	155-8
4C19	LINKAGE, FAN DRIVE SPEED CONTROL .....	140-46	4F10	MOISTURE SENSOR COVERS - YIELD MAPPING W/O MOISTURE SENSOR .....	155-10
3F10	LINKAGE, FEEDER HOUSE POSITION SENSOR .....	100-44	4F10	MOISTURE SENSOR COVERS, YIELD MAPPING .....	155-10
3C9	LINKAGE, GEARSHIFT .....	90-34	4F15	MOISTURE SENSOR DECALS, YIELD MAPPING .....	155-15
4C17	LINKAGE, SPEED CONTROL, FAN DRIVE .....	140-44	4F16	MOISTURE SENSOR DECALS, YIELD MAPPING .....	155-17
3I11	LOADING AUGER, CLEAN GRAIN .....	125-10	4F8	MOISTURE SENSOR MOTOR HARNESS YIELD MAPPING .....	155-8
3H9	LOUVER, CHAFFER ELEMENT .....	120-12	4F8	MOISTURE SENSOR MOTOR, YIELD MAPPING .....	155-8
3H11	LOUVER, CHAFFER EXTENSION ELEMENT .....	120-14	4F8	MOISTURE SENSOR, YIELD MAPPING .....	155-8
3H3	LOUVER, PRECLEANING CHAFFER .....	120-6	3K8	MOTOR AND DISC, CHAFF SPREADER .....	130-26
3H15	LOUVER, SIEVE ELEMENT .....	120-18	2C19	MOTOR PISTON CARRIER .....	50-44
1H21	LOW SHAFT SPEED SENSORS AND BRACKETS .....	40-75	1H13	MOTOR, ADJUSTING, CONCAVE .....	40-66
3I5	LOWER AUGER, CLEAN GRAIN .....	125-4	1H18	MOTOR, ADJUSTING, SEPARATOR FAN DRIVE .....	40-72
3I7	LOWER ELEVATOR, CLEAN GRAIN .....	125-6	3D2	MOTOR, BLOWING .....	95-2
2D1	LOWER HYDROSTATIC DRIVE OIL LINES AND HOSES (TWO WHEEL DRIVE) .....	50-52	2C15	MOTOR, CAM LOBE .....	50-40
3J1	LOWER TAILINGS AUGER AND SHAFT .....	125-24	2C12	MOTOR, HYDROSTATIC DRIVE .....	50-36
3J3	LOWER TAILINGS AUGER DRIVE TIGHTENER .....	125-26	4F8	MOTOR, MOISTURE SENSOR, YIELD MAPPING .....	155-8
3J1	LOWER TAILINGS AUGER TIGHTENER .....	125-24			
3I19	LOWER TAILINGS AUGER TROUGH .....	125-18			
3B20	LUMBAR ASSEMBLY .....	90-20			

**ALPHABETICAL INDEX - CONTINUED**

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
3D4	MOTOR, RECIRCULATION BLOWER .....	95 - 4	3B22	OPERATOR'S SEATBELT .....	90 - 23
1H11	MOTOR, REEL SPEED .....	40 - 64	1F13	OUTLET, CONVENIENCE, KIT .....	40 - 12
2C14	MOTOR, VALVE, HYDROSTATIC .....	50 - 38	1C13	OVERHAUL KIT, ENGINE .....	25 - 6
1G13	MOTOR, WINDSHIELD WIPER .....	40 - 40	3C13	OVERHEAD CONSOLE .....	90 - 38
2J12	MOUNTING BRACKETS, FUEL TANK .....	80 - 36			
3K14	MOUNTING SUPPORT, CHAFF SPREADER .....	130 - 32		<b>P</b>	
4E18	MOUNTING, GRAIN TANK UNLOADING DRIVE CYLINDER .....	150 - 36	4F8	PADDLE, MOISTURE SENSOR, YIELD MAPPING .....	155 - 8
2F4	MOUNTING, HYDRAULIC OIL RESERVOIR .....	70 - 1	3I24	PADDLE, TAILINGS ELEVATOR CONVEYOR .....	125 - 23
2G11	MOUNTING, ONE GALLON ACCUMULATOR .....	70 - 34	3J5	PADDLE, UPPER TAILINGS AUGER .....	125 - 28
2F20	MOUNTING, SOLENOID CONTROL VALVE MODULE, 4-STACK .....	70 - 18	3J16	PADDLED BLADE, FINE CUT CHOPPER .....	130 - 8
2F18	MOUNTING, SOLENOID CONTROL VALVE, 5-STACK .....	70 - 16	3K12	PAN, CHAFF SPREADER .....	130 - 30
3K2	MOUNTING, STRAW SPREADER AND GUARD .....	130 - 20	1D11	PAN, OIL .....	25 - 32
4F18	MOUNTING, TRACK FRAME .....	160 - 2	3H19	PAN, SHAKER .....	120 - 22
4D24	MOUNTING, UNLOADING AUGER SWING CYLINDER .....	150 - 16	3B23	PANEL, ARMREST .....	90 - 24
2D16	MUD SHIELDS, POWERED REAR WHEELS .....	50 - 67	3C1	PANEL, ARMREST .....	90 - 26
1E21	MUFFLER AND EXHAUST PIPE .....	30 - 20	3B8	PANEL, CAB INTERIOR .....	90 - 8
	<b>N</b>		3B6	PANEL, FLOOR .....	90 - 6
1E3	NOZZLE, FUEL INJECTION .....	30 - 2	2I17	PANEL, GULLWING, LEFT REAR .....	80 - 16
1E9	NOZZLE, FUEL INJECTION .....	30 - 8	2I13	PANEL, LEFT FRONT AND DOOR .....	80 - 12
	<b>O</b>		2I21	PANEL, RIGHT FRONT .....	80 - 20
1D14	O-RING KIT, WATER PUMP .....	25 - 36	2D19	PARKING BRAKE PEDAL AND SEAL .....	60 - 2
3D12	O-RING, AIR CONDITIONER HOSE .....	95 - 12	2D21	PEDAL, BRAKE .....	60 - 4
1D8	OIL COOLER ADAPTER AND COVER .....	25 - 28	3C7	PEDAL, REVERSER FOOT CONTROL, FEEDER HOUSE .....	90 - 32
2F11	OIL COOLER AND AIR CONDITIONING .....	70 - 8	1H20	PICK-UP, MAGNETIC (ENGINE) .....	40 - 74
1D7	OIL COOLER BYPASS ADAPTER .....	25 - 27	2G17	PICKUP DRIVE, REEL AND BELT .....	70 - 40
1D7	OIL COOLER BYPASS TUBES .....	25 - 27	1C15	PISTON RINGS .....	25 - 8
2D5	OIL COOLER LINES AND HOSES, HYDROSTATIC .....	50 - 56	2C19	PISTON, CAM AND CARRIER .....	50 - 44
1D8	OIL COOLER, ENGINE .....	25 - 28	1C15	PISTON, ENGINE .....	25 - 8
3D20	OIL COOLER, FEEDER HOUSE GEARCASE .....	100 - 4	4F20	PIVOT BUSHINGS, MAIN FRAME .....	160 - 4
1B24	OIL DRAIN, ENGINE CRANKCASE .....	20 - 22	2C20	PIVOT, CAPS AND YOKE (STEERABLE MOTOR) .....	50 - 46
4B3	OIL FILTER ASSEMBLY, ENGINE GEARCASE .....	140 - 2	4E13	PLATE, CROSS AUGER BEARING, L.H. ....	150 - 30
1D9	OIL FILTER, ENGINE .....	25 - 30	1E17	PLATFORM, ENGINE .....	30 - 16
2D1	OIL HOSES, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE) .....	50 - 52	2J14	PLATFORM, ENGINE ACCESS .....	80 - 38
2D9	OIL HOSES, HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE) .....	50 - 60	4H16	PORTUGESE DECALS AND LABELS .....	170 - 23
2D3	OIL HOSES, UPPER, HYDROSTATIC DRIVE (FOUR WHEEL DRIVE) .....	50 - 54	4F2	POSITION RECEIVER BRACKET YIELD MAPPING .....	155 - 2
2D1	OIL LINES HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE) .....	50 - 52	4F2	POSITION RECEIVER COVER YIELD MAPPING .....	155 - 2
2D9	OIL LINES HYDROSTATIC DRIVE, LOWER (4-WHEEL DRIVE) .....	50 - 60	4F2	POSITION RECEIVER, YIELD MAPPING .....	155 - 2
1D11	OIL PAN DRAIN VALVE .....	25 - 32	3C13	POTENTIOMETER .....	90 - 38
1D11	OIL PAN DRAIN VALVE AND GASKET .....	25 - 32	1B22	POWER CORD, ENGINE BLOCK COOLANT HEATER .....	20 - 20
1D8	OIL PRESSURE REGULATING VALVE .....	25 - 28	3H5	PRE-CLEANER CHAFFER FRAME .....	120 - 8
1D9	OIL PRESSURE REGULATING VALVE .....	25 - 30	3H7	PRECLEANER CHAFFER FRAME ARMS .....	120 - 10
1B21	OIL PRESSURE SENSOR .....	20 - 19	3H3	PRECLEANING CHAFFER .....	120 - 6
1C16	OIL PUMP DRIVE GEAR .....	25 - 9	2G13	PRESSURE GAUGE, ACCUMULATOR .....	70 - 36
1D4	OIL PUMP DRIVE GEAR .....	25 - 24	4B5	PRESSURE REGULATOR, ENGINE GEARCASE .....	140 - 4
1D6	OIL PUMP INTAKE GASKET .....	25 - 26	4B3	PRESSURE SWITCH, ENGINE GEARCASE OIL FILTER ASSEMBLY .....	140 - 2
1D4	OIL PUMP, ENGINE .....	25 - 24	2F5	PRESSURE, HYDRAULIC HOSES .....	70 - 2
1C22	OIL SEAL, CRANKSHAFT FRONT .....	25 - 15	4B18	PRIMARY COUNTERSHAFT, SUPPORTS AND VARI- ABLE SHEAVE .....	140 - 18
1C20	OIL SEAL, REAR .....	25 - 13	1E8	PRIMER, FUEL TRANSFER .....	30 - 7
3D11	OIL, AIR CONDITIONER COMPRESSOR .....	95 - 11	4F4	PROCESSOR, MOBILE, YIELD MAPPING .....	155 - 4
1C8	OIL, ENGINE (TORQ-GARD, PLUS-50) .....	25 - 1	1B20	PULLEY, AIR CONDITIONER COMPRESSOR FAN .....	20 - 18
3B23	OPERATOR'S ARMREST PANEL .....	90 - 24	1D24	PULLEY, CRANKSHAFT .....	25 - 48
3C1	OPERATOR'S ARMREST PANEL .....	90 - 26	3J3	PULLEY, LOWER TAILINGS AUGER TIGHTENER .....	125 - 26
3B20	OPERATOR'S SEAT AND BACKREST .....	90 - 20	4C7	PULLEY, SECONDARY COUNTERSHAFT DRIVE .....	140 - 34
			3E5	PULLEY, VARIABLE SPEED DRIVE TIGHTENER .....	100 - 14
			4B11	PUMP DRIVE AND SEPARATOR, GEARCASE .....	140 - 10
			4B9	PUMP DRIVE SHAFT AND SEPARATOR DRIVE WET-CLUTCH, GEARCASE .....	140 - 8
			2G19	PUMP MOUNTING SHEAVE, REEL AND BELT PICKUP DRIVE .....	70 - 42
			2H20	PUMP, CHAFF SPREADER .....	70 - 68

## ALPHABETICAL INDEX - CONTINUED

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
2G17	PUMP, FEEDER HOUSE AND REEL DRIVE .....	70 - 40	2D23	RESERVOIR, BRAKE LINES, MASTER CYLINDER .....	60 - 6
1E5	PUMP, FUEL .....	30 - 4	2F4	RESERVOIR, HYDRAULIC/HYDROSTATIC .....	70 - 1
1E15	PUMP, FUEL .....	30 - 14	1G11	RESERVOIR, WINDSHIELD WASHER.....	40 - 38
1E8	PUMP, FUEL TRANSFER .....	30 - 7	3F8	RETURN FLOOR, FEEDER HOUSE .....	100 - 42
2C5	PUMP, HYDROSTATIC DRIVE.....	50 - 28	2F7	RETURN LINES, HYDRAULIC .....	70 - 4
2C9	PUMP, HYDROSTATIC DRIVE CHARGE .....	50 - 32	3C7	REVERSER FOOT CONTROL, FEEDER HOUSE.....	90 - 32
2F9	PUMP, MAIN HYDRAULIC .....	70 - 6	3D22	REVERSER GEAR BOX (HIGH CAPACITY) .....	100 - 6
1D4	PUMP, OIL ENGINE .....	25 - 24	3D24	REVERSER GEAR BOX, HI CAPACITY .....	100 - 8
2G17	PUMP, REEL/FEEDER HOUSE DRIVE .....	70 - 40	3E1	REVERSER GEAR BOX, STANDARD .....	100 - 10
2E7	PUMP, STEERING.....	60 - 14	2I11	RIGHT SIDE SHIELD ASSEMBLY .....	80 - 10
2B18	PUMP, TRANSMISSION .....	50 - 16	1C21	RING GEAR, FLYWHEEL .....	25 - 14
1D14	PUMP, WATER .....	25 - 36	1C15	RING, PISTON.....	25 - 8
1G11	PUMP, WINDSHIELD WASHER .....	40 - 38	1D1	ROCKER ARM AND SHAFT.....	25 - 20
1D1	PUSH RODS .....	25 - 20	1D2	ROCKER ARM COVER.....	25 - 21
			1C15	ROD, CONNECTING .....	25 - 8
			1D1	ROD, PUSH .....	25 - 20
	<b>R</b>		4H17	ROMANIAN DECALS AND LABELS.....	170 - 24
1F23	R.H. MAIN WIRING HARNESS		1H23	ROOF, CAB LIGHTS .....	40 - 77
	W/O GREENSTAR .....	40 - 24	3B10	ROOF, INTERIOR CAB.....	90 - 10
1G1	R.H. MAIN WIRING HARNESS W/GREENSTAR.....	40 - 28	1B6	ROTARY SCREEN DOOR AND SCREEN.....	20 - 4
2E15	R.H. SIDE STEERING LINES .....	60 - 22	1B4	ROTARY SCREEN DRIVE AND IDLER ARMS .....	20 - 2
1B12	RADIATOR AND CAP .....	20 - 10	3J16	ROTOR, FINE CUT PADDLED BLADE CHOPPER.....	130 - 8
2J1	RADIATOR DOOR AND HANDRAIL.....	80 - 24	3J14	ROTOR, FINE CUT STRAIGHT BLADE CHOPPER .....	130 - 6
1B8	RADIATOR SHELL AND SEALS.....	20 - 6	3J12	ROTOR, TRI-ROD CHOPPER .....	130 - 4
3C15	RADIO, SPEAKERS AND ANTENNA .....	90 - 40	4H18	RUSSIAN DECALS AND LABELS .....	170 - 25
1B6	RAKE, ROTARY SCREEN .....	20 - 4			
3G3	RASP BAR THRESHING CYLINDER.....	110 - 10		<b>S</b>	
4G1	REAR ARM, TENSION CYLINDER & IDLER AXLE .....	160 - 10	3C17	SAFETY CHAIN, CAB PLATFORM.....	90 - 42
2B5	REAR AXLE SPINDLE HOUSING .....	50 - 2	4G20	SAFETY DECALS AND LOCATIONS.....	170 - 2
2E22	REAR AXLE SPINDLES (HEAVY DUTY).....	60 - 30	4G22	SAFETY DECALS AND LOCATIONS.....	170 - 4
2E20	REAR AXLE SPINDLES (REGULAR DUTY) .....	60 - 28	4G24	SAFETY DECALS AND LOCATIONS.....	170 - 6
2B4	REAR AXLE SUPPORT.....	50 - 1	4H1	SAFETY DECALS AND LOCATIONS.....	170 - 8
2B6	REAR AXLE, ADJUSTABLE .....	50 - 3	4H3	SAFETY DECALS AND LOCATIONS.....	170 - 10
2B5	REAR AXLE, FIXED .....	50 - 2	4H11	SAFETY DECALS, RUBBER TRACK .....	170 - 18
2I19	REAR CORNER SHEET, L.H.....	80 - 18	4H11	SAFETY LABELS, RUBBER TRACK .....	170 - 18
2J8	REAR HOOD .....	80 - 32	4E23	SAMPLING TROUGH, GRAIN TANK .....	150 - 41
2J6	REAR LADDER LANDING LATCH ARM .....	80 - 30	3F8	SCOOP, FEEDER HOUSE RETURN .....	100 - 42
1I1	REAR LAMP ASSEMBLY (AMBER) .....	40 - 80	1B6	SCREEN DOOR, ROTARY .....	20 - 4
2J14	REAR LAMP, ENGINE ACCESS PLATFORM .....	80 - 38	1B4	SCREEN DRIVE, ROTARY .....	20 - 2
1C20	REAR OIL SEAL .....	25 - 13	2D19	SEAL AND BRAKE PEDAL, PARKING .....	60 - 2
1C20	REAR OIL SEAL GASKET .....	25 - 13	3K12	SEAL AND PAN, CHAFF SPREADER .....	130 - 30
1C20	REAR OIL SEAL HOUSING .....	25 - 13	1B8	SEAL AND RADIATOR SHELL.....	20 - 6
2E17	REAR STEERING LINES AND HOSES .....	60 - 24	2C12	SEAL KIT, HYDROSTATIC DRIVE MOTOR .....	50 - 36
1C3	REAR SUPPORT, ENGINE MOUNTS .....	20 - 26	3D11	SEAL, AIR CONDITIONER COMPRESSOR .....	95 - 11
3I15	REAR TAILINGS SHIELD, LEFT SIDE .....	125 - 14	3B6	SEAL, CAB SIDE AND REAR.....	90 - 6
1I2	REAR TURN AND TAIL LIGHTS (RED).....	40 - 81	2C15	SEAL, CAM LOBE MOTOR.....	50 - 40
2B14	REAR WHEELS (4-WHEEL DRIVE/CAM LODE MOTOR).....	50 - 11	3E17	SEAL, FEEDER HOUSE - CONTOUR MASTER.....	100 - 26
2B13	REAR WHEELS AND WHEEL WEIGHTS .....	50 - 10	1C22	SEAL, FRONT OIL.....	25 - 15
3D9	RECEIVER-DRYER, AIR CONDITIONER.....	95 - 9	1C20	SEAL, REAR OIL .....	25 - 13
4F2	RECEIVER, POSITION, YIELD MAPPING .....	155 - 2	1D14	SEAL, TUBE, WATER PUMP .....	25 - 36
2G21	REEL DRIVE FLOW CONTROL VALVE .....	70 - 44	1D14	SEAL, WATER PUMP OIL .....	25 - 36
2H1	REEL DRIVE HYD. LINES L.H. ....	70 - 48	3B20	SEAT AND BACKREST, OPERATOR'S.....	90 - 20
2H3	REEL DRIVE HYDRAULIC LINES AND HOSES .....	70 - 50	3B16	SEAT CONSOLE, PASSENGER.....	90 - 16
2H7	REEL FORE-AND-AFT HYDRAULIC LINES AND HOSES, FRONT .....	70 - 54	3B16	SEAT CUSHIONS, PASSENGER .....	90 - 16
2H5	REEL FORE-AND-AFT HYDRAULIC LINES, L.H. ....	70 - 52	3B22	SEATBELT, OPERATOR'S .....	90 - 23
2H9	REEL LIFT LINES AND HOSES.....	70 - 56	4C7	SECONDARY COUNTERSHAFT DRIVE .....	140 - 34
2G3	REEL LIFT, SOLENOID CONTROL VALVE.....	70 - 26	4C7	SECONDARY COUNTERSHAFT DRIVE PULLEY.....	140 - 34
2G23	REEL PUMP HOSES, HYDRAULIC .....	70 - 46	1H19	SENSING SWITCH, STRAW WALKER .....	40 - 73
2G23	REEL PUMP HYDRAULIC HOSES.....	70 - 46	1H21	SENSOR AND BRACKET, LOW SHAFT SPEED .....	40 - 75
1H11	REEL SPEED MOTOR .....	40 - 64	3D2	SENSOR, AIR CONDITIONER AND HEATER.....	95 - 2
1G22	RELAY PANEL AND CIRCUIT BREAKERS.....	40 - 50	3D4	SENSOR, AIR CONDITIONER AND HEATER.....	95 - 4
2F22	RELIEF VALVE, SOLENOID, CONTOUR MASTER .....	70 - 20	3C1	SENSOR, ARMREST CONTROL PANEL.....	90 - 26
2F22	RELIEF VALVE, SOLENOID, UNLOAD MODULE .....	70 - 20	1H14	SENSOR, CONCAVE INDICATOR .....	40 - 68
2F7	RESERVOIR LINES AND HOSES .....	70 - 4	1H20	SENSOR, ENGINE SPEED.....	40 - 74
			3F10	SENSOR, FEEDER HOUSE POSITION.....	100 - 44