

HP8673

-UN-23JUN99



*JOHN DEERE 9650 STS SELF-PROPELLED COMBINE™ WITH 90 SERIES CORN HEAD
MANUFACTURED (1999-)*

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE)

COPYRIGHT (C) 2000. DEERE & COMPANY. MOLINE, ILLINOIS, USA. ALL RIGHTS RESERVED.

NOTE

FOR 900 SERIES PLATFORM PARTS INFORMATION, REFER TO JOHN DEERE 900 SERIES PLATFORM PARTS CATALOG - PC-2104.

FOR 40 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 40 SERIES CORN HEAD PARTS CATALOG - PC-1223.

FOR 50A SERIES ROW-CROP HEAD PARTS INFORMATION, REFER TO JOHN DEERE 50A SERIES ROW-CROP HEAD PARTS CATALOG - PC-1747.

FOR THREE-ROLLER BELT PICKUP PARTS INFORMATION, REFER TO JOHN DEERE THREE-ROLLER BELT PICKUP PARTS CATALOG - PC-2210.

FOR 918 AND 920 DRAPER PARTS INFORMATION, REFER TO JOHN DEERE 918 AND 920 DRAPER PLATFORMS PARTS CATALOG - PC-2212.

FOR 90 SERIES CORN HEAD PARTS INFORMATION, REFER TO JOHN DEERE 90 SERIES CORN HEAD PARTS CATALOG - PC-2404.

IMPORTANT

THIS PARTS CATALOG CONTAINS PARTS INFORMATION FOR THE 9650 STS SELF-PROPELLED COMBINE. VINTAGE IS DETERMINED BY THE COMBINE SERIAL NUMBER OR THE PRODUCT IDENTIFICATION NUMBER (PIN). IT IS IMPORTANT THAT THE CORRECT NUMBERS BE USED WHEN ORDERING PARTS.

PRODUCT INFORMATION NUMBER (PIN) PLATE

THE PRODUCT IDENTIFICATION NUMBER (PIN) PLATE IS LOCATED NEAR THE RIGHT-HAND SIDE OF THE TOOL BOX.
AN EXAMPLE OF THE TWO-LINES ON THIS PIN PLATE IS:

HO9650X685000
COMBINE

(FIRST LINE)

HO - MANUFACTURING UNIT (HARVESTER WORKS)

9650 - MODEL IDENTIFIER

X - CONFIGURATION CODE/MODEL IDENTIFIER SUFFIX

900000 - SEQUENTIAL NUMBER USED IN SERIAL NO. COLUMN

(SECOND LINE)

COMBINE - TYPE OF PRODUCT

PARTS LISTING INFORMATION

SERIAL NUMBER OR PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION SHOWS ON WHICH MACHINES THE PART MAY BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE, BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRINTED.

SHORT BLOCK SERIAL NUMBER PLATE

(-RGSB076882500)

RGP3513 -UN-01JAN94



RGP3513

THE REPLACEMENT SHORT BLOCK ASSEMBLY HAS A SERIAL NUMBER PLATE ATTACHED. THE ORIGINAL ENGINE SERIAL NUMBER MUST BE STAMPED ONTO THE NEW PLATE IN THE BLANK SPACE PROVIDED, AS A REFERENCE FOR YOUR DEALER. THE PLATE CAN BE ATTACHED WITH (2) 37H44 DRIVE SCREWS.

- | | |
|---------------------------------------|----------------------------|
| 1. DESIGNATES ENGINE MANUFACTURER | RG - WATERLOO ENGINE WORKS |
| 2. DESIGNATES REPLACEMENT SHORT BLOCK | SB |
| 3. DESIGNATES LITERS | XXX- 081 (8.1) |
| 4. DESIGNATES THE PRODUCTION DATE | 8825 |
| 5. DESIGNATES COMPONENT SEQUENCE | 00 |

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

1A6

9650 STS AND 9750 STS SELF-PROPELLED COMBINES

TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE

RGP5228 -UN-21JUN99



RGP5228

FIRST LINE

RG - WATERLOO ENGINE WORKS

6

081 (8.1 LITERS)

H - AIR-TO-AIR

H

XXXXXX

SECOND LINE

6081HH005

6081HH006

DEFINES

DESIGNATES ENGINE MANUFACTURER.

DESIGNATES NUMBER OF CYLINDERS.

DESIGNATES LITER DISPLACEMENT.

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

DESIGNATES HARVESTER VEHICLE.

DESIGNATES ENGINE SERIAL NUMBER.


APPLICATION

9750

9650

SHORT BLOCK SERIAL NUMBER IDENTIFICATION

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490995

- | | |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED | 09 |
| 3. DESIGNATES YEAR ASSEMBLED | 95 |

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY. A BOX NOT KEYED INCLUDES NON-CURRENT PARTS.

KITS

KIT INFORMATION WILL BE FOUND IMMEDIATELY FOLLOWING THE STORY IN WHICH IT IS USED. THE ILLUSTRATION IS REPEATED WITH ONLY THE KIT PARTS CALLED OUT AND WITH ALL OTHER PARTS SHOWN IN PHANTOM.

JDM REMANUFACTURED COMPONENTS

THE SERVICE PARTS LISTED IN THIS CATALOG ARE INTENDED FOR THE REPAIR OF ORIGINAL EQUIPMENT COMPONENTS. ALTHOUGH MOST SERVICE PARTS MAY BE USED TO REPAIR REMANUFACTURED COMPONENTS, THE REMANUFACTURED DESIGN MAY CHANGE PARTS SUFFICIENTLY SO THAT SERVICE PARTS ARE INADEQUATE OR NOT USABLE.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER. BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO PROPERTY CLASS 10.9 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION 10.9. ALL STANDARD BOLTS AND CAP SCREWS ARE PROPERTY CLASS 8.8 OR LOWER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

TRADEMARKS

THROUGHOUT THIS PARTS CATALOG, YOU WILL FIND THE FOLLOWING DEERE & COMPANY TRADEMARKS:

DIAL-A-SPEED™
DIAL-A-MATIC™
HARVESTRAK™
CONTOUR MASTER™

POSI-TORQ™
TORQ-GARD SUPREME®
QUIK-TATCH™

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

FUNCTION CODE

(EXAMPLE - FC: 5000)

FUNCTION CODES ARE LOCATED ON EACH PAGE IN THE UPPER RIGHT-HAND CORNER IN THE BOX. THE CODE LISTED IS A GROUPING CODE THAT CAN BE USED FOR WARRANTIES AND FOR DTAC TO IDENTIFY CERTAIN AREAS.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SECTION INDEX

SECTION 10 - GENERAL INFORMATION

SECTION 20 - ENGINE ACCESSORIES

SECTION 25 - ENGINE

SECTION 30 - FUEL AND AIR

SECTION 40 - ELECTRICAL

SECTION 50 - POWER TRAIN

SECTION 60 - STEERING AND BRAKES

SECTION 70 - HYDRAULICS

SECTION 80 - BODY AND SHIELDS

SECTION 90 - OPERATOR'S STATION

SECTION 95 - AIR CONDITIONING AND HEATING

SECTION 110 - FEEDER HOUSE

SECTION 120 - THRESHING AND SEPARATION

SECTION 125 - CLEANING SHOE

SECTION 130 - ELEVATORS

SECTION 135 - RESIDUE DISPOSAL

SECTION 140 - DRIVES

SECTION 150 - GRAIN TANK AND UNLOADING AUGER

SECTION 155 - GREENSTAR YIELD MAPPING AND MONITOR SYSTEMS

SECTION 160 - RUBBER TRACK SYSTEM

SECTION 170 - DECALS

SECTION 180 - NUMERICAL INDEX

ALPHABETICAL INDEX

GRID	A	PAGE	GRID	PAGE
3B20	A/C COMPRESSOR HARDWARE R134A	95 - 14	3D7	ARM, FEEDER HOUSE CONVEYOR..... 110 - 30
3B17	A/C COMPRESSOR MANIFOLD.....	95 - 11	3C17	ARM, FEEDER HOUSE DRIVE TIGHTENER
3B17	A/C COMPRESSOR R134A	95 - 11	3D5	ARM, FEEDER HOUSE FLOOR.....
4D9	ABSORBER, AIR SUSPENSION (RUBBER TRACK)	160 - 8	3C15	ARM, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER.....
3D24	ACCELERATOR WINGS	120 - 4	4D7	ARM, FRONT AND ADJUSTABLE IDLER ASSEMBLY (RUBBER TRACK)
2I8	ACCESS DOOR, ENGINE.....	80 - 34	1B10	ARM, IDLER, ROTARY SCREEN
2H24	ACCESS DOOR, REAR.....	80 - 24	2D21	ARM, PARKING BRAKE
2G13	ACCUMULATOR PRESSURE GAUGE.....	70 - 42	3J8	ARM, PRIMARY COUNTERSHAFT
2G11	ACCUMULATOR, ONE GALLON	70 - 40	4D11	ARM, REAR (RUBBER TRACK)
2G12	ACCUMULATOR, ONE HALF GALLON	70 - 41	1D4	ARM, ROCKER
1H17	ACTUATOR, STRAW CHOPPER	40 - 64	1B8	ARM, ROTARY SCREEN DRIVE
1D11	ADAPTER, OIL COOLER	25 - 30	3E21	ARM, SHAKER PAN
1D10	ADAPTER, OIL COOLER BYPASS	25 - 29	3J21	ARM, SHOE/CONVEYOR AUGER DRIVE IDLER ASSEMBLY
1B5	ADHESIVE, ROCKER ARM COVER GASKET	25 - 23	3F14	ARM, SIEVE ELEMENT.....
1B23	ADJUSTABLE FAN DRIVE	20 - 18	2D3	ARM, STEERING
4D7	ADJUSTABLE IDLER ASSEMBLY AND FRONT ARM (RUBBER TRACK)	160 - 6	2J16	ARM, STEERING COLUMN (LOWER)
2B11	ADJUSTABLE REAR AXLE (NON-POWERED)	50 - 3	3H12	ARM, STRAW CHOPPER JACKSHAFT
2B10	ADJUSTABLE REAR AXLE (POWERED)	50 - 2	2G15	ARM, STRAW SPREADER
3E14	ADJUSTING ASSEMBLY, CONCAVE.....	120 - 20	3J19	ARM, TAILINGS ELEVATOR DRIVE IDLER ASSEMBLY
3E16	ADJUSTING ASSEMBLY, CONCAVE.....	120 - 22	3K6	ARM, UNLOADER DRIVE IDLER ASSEMBLY
1D22	AFTERCOOLER AND INTAKE MANIFOLD SENSOR....	25 - 43	2J12	ARMREST CONTROL PANEL
1E25	AIR CLEANER	30 - 21	2J14	ARMREST CONTROL PANEL (CONTINUED).....
1F1	AIR CLEANER BRACKETS, SUPPORTS.....	30 - 22	1G9	ARMREST WIRING HARNESS.....
1E24	AIR CLEANER HOSES	30 - 20	2J9	ARMREST, OPERATOR'S SEAT
3B10	AIR CONDITIONER AND HEATER HOUSING, LOWER	95 - 4	3F6	ARMS, CHAFFER FRAME
3B8	AIR CONDITIONER AND HEATER HOUSING, UPPER.....	95 - 2	3K3	ARMS, STRAW CHOPPER DRIVE IDLER ASSEMBLY
3B8	AIR CONDITIONER AND HEATER TEMPERATURE SENSOR	95 - 2	1G17	ARMS, WINDSHIELD WIPER
1C2	AIR CONDITIONER COMPRESSOR BRACKETS	20 - 22	1F3	ASPIRATOR HOSE
3B18	AIR CONDITIONER COMPRESSOR HOSE	95 - 12	1H13	ASSEMBLY, CLUTCH (STARTER).....
2F1	AIR CONDITIONER CONDENSER AND OIL COOLER	70 - 6	2F13	ASSEMBLY, SIX STACK SOLENOID CONTROL VALVE
3B13	AIR CONDITIONING AND HEATER DUCTS	95 - 7	2E11	ATTENUATOR
3B16	AIR CONDITIONING SYSTEM EVAPORATOR HEATER.....	95 - 10	3F2	AUGER BED ASSEMBLY
3B15	AIR CONDITIONING SYSTEM RECEIVER-DRYER	95 - 9	3K4	AUGER COUNTERSHAFT DRIVE, UNLOADING
3B14	AIR CONDITIONING SYSTEM WATER VALVE ASSEMBLY	95 - 8	3G6	AUGER HOUSING, LOADING, UPPER CLEAN GRAIN
1G13	AIR CONDITIONING WIRING HARNESS	40 - 36	3F4	AUGER SHAFT AND BEARINGS.....
1B17	AIR COOLER, CHARGE	20 - 12	4C5	AUGER, CROSS
2I10	AIR DEFLECTORS, ENGINE	80 - 36	4B21	AUGER, HORIZONTAL UNLOADING (17- AND 20-FT.).....
1E24	AIR DUCT, AIR CLEANER	30 - 20	3G10	AUGER, LOADING, CLEAN GRAIN
3B10	AIR DUCT, BLOWER.....	95 - 4	3G20	AUGER, LOWER TAILINGS
3B8	AIR DUCT, INTAKE	95 - 2	3F23	AUGER, LOWER, CLEAN GRAIN
1B13	AIR DUCT, RADIATOR FRAME	20 - 8	3G16	AUGER, UPPER TAILINGS ELEVATOR
1B11	AIR DUCT, ROTARY SCREEN DOOR.....	20 - 6	4B19	AUGER, VERTICAL UNLOADING
2J7	AIR SEAT SUSPENSION	90 - 18	2B12	AXLE SPACERS
4D9	AIR SUSPENSION (RUBBER TRACK).....	160 - 8	2B13	AXLE SPACERS
2J7	AIR SUSPENSION, SEAT	90 - 18	2B11	AXLE, ADJUSTABLE REAR (NON-POWERED)
1H11	ALTERNATOR ADJUSTING STRAP.....	40 - 58	4D14	AXLE, BOGEY WHEEL (RUBBER TRACK).....
1H11	ALTERNATOR SUPPORT.....	40 - 58	4D11	AXLE, IDLER (RUBBER TRACK)
1H9	ALTERNATOR, SHEAVE AND BELT (185 AMP)	40 - 56	2B10	AXLE, REAR, ADJUSTABLE (POWERED)
1H7	ALTERNATOR, SHEAVE AND BELT (95 AMP)	40 - 54	2B9	AXLE, REAR, FIXED (NON-POWERED)
2K3	ANTENNA, SPEAKERS AND RADIO	90 - 40	2E15	AXLE, REAR, SPINDLES (HEAVY DUTY).....
3K1	ARM, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER	140 - 48		
3J13	ARM, CLEAN GRAIN ELEVATOR DRIVE IDLER ASSEMBLY	140 - 35		B
3J22	ARM, DISCHARGE BEATER DRIVE IDLER ASSEMBLY	140 - 44	2J9	BACKREST, OPERATOR'S.....
3J17	ARM, FAN DRIVE	140 - 39	2E17	BALL JOINT, STEERING TIE ROD
3J10	ARM, FEED ACCELERATOR DRIVE IDLER	140 - 32	2I22	BARRIERS, CAB INTERIOR
			2I24	BASE, DOME LIGHT
			1E14	BASE, FUEL FILTER.....
			1D12	BASE, OIL FILTER

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1H4	BATTERIES AND CABLES	40 - 51	1G17	BLADE, WIPER (LONG)	40 - 40
1C21	BEARING KIT, UNDERSIZED MAIN BEARING CRANKSHAFT	25 - 13	3F16	BLADES, CLEANING FAN ASSEMBLY	125 - 16
4D16	BEARING, BOGEY WHEEL (RUBBER TRACK)	160 - 16	3H18	BLADES, STRAW SPREADER	135 - 18
4D14	BEARING, BOGEY WHEEL AXLE (RUBBER TRACK)	160 - 14	1C14	BLOCK, SHORT	25 - 6
3E8	BEARING, ROTOR	120 - 13	3B10	BLOWER AIR DUCT	95 - 4
3H22	BEARING, STRAW SPREADER	135 - 22	3B10	BLOWER FAN, AIR CONDITION AND HEATER	95 - 4
1C22	BEARING, THRUST	25 - 14	4D16	BOGEY WHEEL ASSEMBLY (RUBBER TRACK)	160 - 16
3F4	BEARINGS, AUGER BED	125 - 4	4D14	BOGEY WHEEL AXLES (RUBBER TRACK)	160 - 14
2C20	BEARINGS, CAM LOBE MOTOR	50 - 40	1D2	BOLTS, CYLINDER HEAD	25 - 20
3F19	BEARINGS, CLEANING FAN	125 - 20	3G5	BOOT ASSEMBLY, CLEAN GRAIN ELEVATOR	130 - 8
2C6	BEARINGS, FINAL DRIVE	50 - 24	4D17	BOX, GEAR, TRANSFER (RUBBER TRACK)	160 - 18
4D13	BEARINGS, IDLER WHEEL (RUBBER TRACK)	160 - 12	2I12	BOX, TOOL	80 - 38
1C22	BEARINGS, MAIN	25 - 14	3C15	BRACE, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER	110 - 14
2B24	BEARINGS, TRANSMISSION	50 - 16	3H12	BRACE, STRAW CHOPPER JACKSHAFT	135 - 12
2C1	BEARINGS, TRANSMISSION PINION SHAFT	50 - 18	3C13	BRACE, VARIABLE SPEED FEEDER HOUSE DRIVE TIGHTENER	110 - 12
3E19	BEATER ASSEMBLY, DISCHARGE	120 - 26	2B11	BRACKET, ADJUSTABLE REAR AXLE (NON-POWERED)	50 - 3
3F2	BED ASSEMBLY, AUGER	125 - 2	2B10	BRACKET, ADJUSTABLE REAR AXLE (POWERED)	50 - 2
2J20	BELLCRANK, FEEDER HOUSE REVERSER FOOT CONTROL	90 - 32	1E24	BRACKET, AIR CLEANER	30 - 20
4D23	BELT AND DRIVE WHEEL (RUBBER TRACK)	160 - 24	1H9	BRACKET, ALTERNATOR (185 AMP)	40 - 56
2F21	BELT PICKUP/REEL DRIVE, PUMP MOUNTING SHEAVE	70 - 26	1H7	BRACKET, ALTERNATOR (95 AMP)	40 - 54
1H9	BELT, ALTERNATOR (185 AMP)	40 - 56	3B8	BRACKET, ATC CONTROLLER	95 - 2
1H7	BELT, ALTERNATOR (95 AMP)	40 - 54	3F4	BRACKET, AUGER BED SHAFT	125 - 4
4F6	BELT, CLEAN GRAIN ELEVATOR	170 - 28	2E8	BRACKET, BRAKE CABLE SUPPORT	60 - 13
3K1	BELT, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER	140 - 48	2E1	BRACKET, BRAKE LINES	60 - 6
4F6	BELT, CLEANING FAN	170 - 28	2J1	BRACKET, CAB GLASS	90 - 12
3J16	BELT, CLEANING FAN DRIVE	140 - 38	2I20	BRACKET, CAB REAR SIDE PANELS	90 - 6
3H12	BELT, COUNTERSHAFT	135 - 12	3G5	BRACKET, CLEAN GRAIN ELEVATOR BOOT ASSEMBLY	130 - 8
4F8	BELT, COUNTERSHAFT, DISCHARGE BEATER AND CHOPPER	170 - 30	3F23	BRACKET, CLEAN GRAIN LOWER AUGER	130 - 2
3H12	BELT, DISCHARGE BEATER	135 - 12	3F17	BRACKET, CLEANING FAN	125 - 18
3J24	BELT, ELEVATOR DRIVE JACKSHAFT ASSEMBLY	140 - 46	4C5	BRACKET, CROSS AUGERS	150 - 24
3J17	BELT, FAN DRIVE	140 - 39	4C11	BRACKET, DISPLAY YIELD MAPPING	155 - 4
4F6	BELT, FEED ACCELERATOR	170 - 28	3I7	BRACKET, ENGINE GEARCASE OIL FILTER ASSEMBLY	140 - 4
3J10	BELT, FEED ACCELERATOR DRIVE IDLER	140 - 32	1H15	BRACKET, FEEDER HOUSE BACKSHAFT SPEED SENSOR	40 - 62
3C17	BELT, FEEDER HOUSE DRIVE TIGHTENER	110 - 16	2G5	BRACKET, FEEDER HOUSE GEARCASE OIL COOLER	70 - 34
3C17	BELT, HEADER AND REEL PUMP (HI-CAPACITY)	110 - 16	3D3	BRACKET, FEEDER HOUSE UPPER SHAFT	110 - 26
3C17	BELT, HEADER AND REEL PUMP (STANDARD)	110 - 16	2B9	BRACKET, FIXED REAR AXLE (NON-POWERED)	50 - 1
3J7	BELT, HEADER ELECTROMAGNETIC CLUTCH (HI-CAPACITY)	140 - 28	3C15	BRACKET, FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER	110 - 14
3J7	BELT, HEADER ELECTROMAGNETIC CLUTCH (STANDARD)	140 - 28	2J22	BRACKET, GEARSHIFT LEVER	90 - 34
4F6	BELT, R.H. JACKSHAFT (FRONT)	170 - 28	3J7	BRACKET, HEADER ELECTROMAGNETIC CLUTCH	140 - 28
4F6	BELT, R.H. JACKSHAFT (REAR)	170 - 28	4C3	BRACKET, HORIZONTAL UNLOADING AUGER SWIVEL	150 - 22
1B10	BELT, ROTARY SCREEN	20 - 4	2I19	BRACKET, HORN ASSEMBLY	90 - 4
1B8	BELT, ROTARY SCREEN DRIVE	20 - 2	3D9	BRACKET, IDLER, FEEDER CONVEYOR	110 - 32
4F10	BELT, ROTARY SCREEN DRIVE (ENGINE SIDE)	170 - 32	2B24	BRACKET, INPUT SHAFT	50 - 16
4F10	BELT, ROTARY SCREEN DRIVE (SCREEN SIDE)	170 - 32	1H23	BRACKET, L.H. FRONT LIGHT	40 - 70
3I19	BELT, SEPARATOR DRIVE VARIABLE SPEED	140 - 16	2K7	BRACKET, LADDER EXTENSION ASSEMBLY	90 - 44
4F6	BELT, SHOE FAN AND CONVEYOR AUGERS	170 - 28	1I5	BRACKET, LIGHT SWITCH	40 - 77
3H12	BELT, STRAW CHOPPER	135 - 12	3G20	BRACKET, LOWER TAILINGS AUGER	130 - 24
3H12	BELT, STRAW CHOPPER JACKSHAFT	135 - 12	2F17	BRACKET, MAIN HYDRAULIC FILTER	70 - 22
4F8	BELT, STS VARIABLE BELT	170 - 30	4C13	BRACKET, MASS FLOW SENSOR YIELD MAPPING	155 - 6
4F6	BELT, TAILINGS AUGER AND ELEVATOR	170 - 28	1I6	BRACKET, MOISTURE SENSOR	40 - 78
3K4	BELT, UNLOADING AUGER COUNTERSHAFT DRIVE	140 - 52	4C15	BRACKET, MOISTURE SENSOR YIELD MAPPING	155 - 8
4F8	BELT, UNLOADING AUGER SYSTEM	170 - 30	2G12	BRACKET, ONE HALF GALLON ACCUMULATOR	70 - 41
3G14	BELT, UPPER TAILINGS ELEVATOR	130 - 18	4C9	BRACKET, POSITION RECEIVER YIELD MAPPING	155 - 2
3C4	BELT, VARIABLE SPEED FEEDER HOUSE (HI-CAPACITY)	110 - 2	3J8	BRACKET, PRIMARY COUNTERSHAFT	140 - 30
3C4	BELT, VARIABLE SPEED FEEDER HOUSE (STANDARD)	110 - 2			
3H8	BLADE, STRAW CHOPPER ROTOR	135 - 8			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1H24	BRACKET, R.H. FRONT LIGHT	40 - 71	1D1	BUSHING, CAMSHAFT	25 - 18
2H19	BRACKET, R.H. FRONT PANEL	80 - 18	4D5	BUSHINGS, MAIN FRAME PIVOT (RUBBER TRACK)	160 - 4
1B11	BRACKET, ROTARY SCREEN DOOR	20 - 6	1D10	BYPASS TUBES, OIL COOLER	25 - 29
3E8	BRACKET, ROTOR	120 - 13	1D12	BYPASS VALVE, OIL FILTER.....	25 - 32
2J5	BRACKET, SEAT CONSOLE	90 - 16			
3I19	BRACKET, SEPARATOR DRIVE VARIABLE SPEED	140 - 16		C	
2E13	BRACKET, STEERING CYLINDER AND HOSES	60 - 18	3B12	CAB AIR FILTER AND HOUSING	95 - 6
3H3	BRACKET, STRAW CHOPPER	135 - 2	2J1	CAB DOOR	90 - 12
3H24	BRACKET, STRAW SPREADER LATCH AND HANDLE	135 - 24	2J3	CAB DOOR LATCH	90 - 14
3H20	BRACKET, STRAW SPREADER SHIELDS	135 - 20	2J1	CAB GLASS	90 - 12
3G18	BRACKET, TAILINGS ELEVATOR	130 - 22	2K12	CAB HARDWARE KIT	90 - 50
3J19	BRACKET, TAILINGS ELEVATOR DRIVE IDLER ASSEMBLY	140 - 41	2I22	CAB INTERIOR PANELS, SEALS AND FLOOR MAT....	90 - 8
2I12	BRACKET, TOOL BOX	80 - 38	2K8	CAB LANDING AND MIRROR L.H.	90 - 46
4C13	BRACKET, TRANSDUCER MOUNTING YIELD MAPPING	155 - 6	2K10	CAB LANDING AND MIRROR R.H.	90 - 48
3C13	BRACKET, VARIABLE SPEED FEEDER HOUSE DRIVE TIGHTENER	110 - 12	1G7	CAB MAIN WIRING HARNESS.....	40 - 30
3B14	BRACKET, WATER VALVE ASSEMBLY (AIR CONDITIONING SYSTEM)	95 - 8	2I20	CAB REAR, SIDE AND FLOOR PANELS	90 - 6
2D14	BRACKET, 4-WHEEL DRIVE HOSES AND LINES	50 - 60	1H22	CAB ROOF LIGHTS	40 - 69
1F1	BRACKETS AND SUPPORTS, AIR CLEANER	30 - 22	2I24	CAB ROOF, INTERIOR	90 - 10
1C2	BRACKETS, AIR CONDITIONER COMPRESSOR	20 - 22	2I17	CAB SUPPORT	90 - 2
2I22	BRACKETS, CAB INTERIOR	90 - 8	2E5	CABLE, BRAKE SHOES AND DRUM	60 - 10
1H3	BRACKETS, CENTRAL ELECTRONICS BOARD	40 - 50	4C21	CABLE, DATASTORE/COMPUTER	155 - 14
2I8	BRACKETS, ENGINE ACCESS DOOR	80 - 34	3D1	CABLE, FEEDER HOUSE (CONTOUR MASTER).....	110 - 24
2I6	BRACKETS, ENGINE PLATFORM LADDER, HANDRAIL	80 - 32	2J20	CABLE, FEEDER HOUSE REVERSER FOOT CONTROL	90 - 32
3D15	BRACKETS, FEEDER HOUSE POSITION SENSOR	110 - 38	2J22	CABLE, GEARSHIFT LEVER	90 - 34
4B8	BRACKETS, GRAIN TANK	150 - 2	3C19	CABLE, L.H. DRIVE SHIELDS	110 - 18
4B12	BRACKETS, GRAIN TANK EXTENSIONS (9750 STS).....	150 - 6	3C21	CABLE, R.H. DRIVE SHIELDS	110 - 20
1I4	BRACKETS, GRAIN TANK FULL BIN SENSOR	40 - 76	1F14	CABLE, WIRING	40 - 8
2D6	BRACKETS, HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (TWO WHEEL DRIVE)	50 - 52	1H4	CABLES, BATTERY.....	40 - 51
2H13	BRACKETS, L.H. GULLWING DOOR.....	80 - 12	2C8	CABLES, CONTROL, HYDROSTATIC DRIVE	50 - 26
2H11	BRACKETS, LEFT FRONT PANEL AND DOOR	80 - 10	2C22	CAM LOBE MOTOR INNER COVER, MANIFOLD, AND PACKING	50 - 42
1H20	BRACKETS, LOW SHAFT SPEED SENSORS	40 - 67	2C20	CAM LOBE MOTOR SHAFT, OUTER COVER, BEARINGS, AND SEALS	50 - 40
2F1	BRACKETS, OIL COOLER AND AIR CONDITIONER CONDENSER	70 - 6	2C24	CAM, CARRIER, AND PISTON.....	50 - 45
2H21	BRACKETS, R.H. GULLWING DOOR	80 - 20	3F6	CAMS, CHAFFER FRAME	125 - 6
2H23	BRACKETS, R.H. REAR RADIATOR DOOR	80 - 22	3I21	CAMS, SEPARATOR DRIVE TORQUE SENSING	140 - 18
2H24	BRACKETS, REAR ACCESS DOOR	80 - 24	3F14	CAMS, SIEVE ELEMENT	125 - 14
2F15	BRACKETS, SOLENOID CONTROL VALVE	70 - 20	1D1	CAMSHAFT	25 - 18
3H10	BRACKETS, STRAW CHOPPER	135 - 10	1C12	CAMSHAFT BUSHING	25 - 4
3H16	BRACKETS, STRAW SPREADER FRAME	135 - 16	1D1	CAMSHAFT BUSHING	25 - 18
1G17	BRACKETS, WINDSHIELD WIPER	40 - 40	1D1	CAMSHAFT FOLLOWER.....	25 - 18
2E8	BRAKE CABLE SUPPORT BRACKET	60 - 13	1D4	CAMSHAFT FOLLOWER.....	25 - 22
2E3	BRAKE CYLINDER, MASTER.....	60 - 8	1D1	CAMSHAFT GEAR.....	25 - 18
2E1	BRAKE LINES AND RESERVOIR	60 - 6	1E18	CAP, FILLER, FUEL TANK	30 - 14
2D23	BRAKE PEDALS	60 - 4	4B17	CAP, GRAIN TANK CLEAN OUT CHUTE	150 - 12
2E5	BRAKE SHOES AND DRUM.....	60 - 10	1C12	CAPS, MAIN BEARING	25 - 4
4D21	BRAKE SHOES AND DRUM (RUBBER TRACK)	160 - 22	2D1	CAPS, YOKE AND PIVOTS	50 - 46
2E7	BRAKE SLAVE CYLINDER	60 - 12	2C24	CARRIER, PISTON, AND CAM.....	50 - 45
1E20	BREATHING, DOUBLE, FUEL TANK.....	30 - 16	2D16	CASE DRAIN, 4-WHEEL DRIVE, HYDRAULIC LINES	50 - 62
1E18	BREATHING, FUEL TANK	30 - 14	4D17	CASE, GEAR, TRANSFER (RUBBER TRACK)	160 - 18
2B24	BREATHING, INPUT SHAFT HOUSING	50 - 16	1H1	CENTRAL ELECTRONICS MODULE AND CIRCUIT BOARDS	40 - 48
1B11	BRUSH, ROTARY SCREEN DOOR	20 - 6	1H1	CENTRAL ELECTRONICS MODULE CIRCUIT BOARDS	40 - 48
1I8	BULB, CLEANING SHOE INSPECTION LIGHT.....	40 - 80	2G18	CHAFF SPREADER MOTOR, HOSE AND FITTINGS....	70 - 47
2I24	BULB, DOME LIGHT	90 - 10	2G1	CHAFF SPREADER PUMP	70 - 30
1H23	BULB, L.H. FRONT LIGHT	40 - 70	2G1	CHAFF SPREADER PUMP, REEL/BELT PICKUP DRIVE	70 - 30
1H24	BULB, R.H. FRONT LIGHT	40 - 71	3F6	CHAFFER FRAME	125 - 6
1H25	BULB, REAR LIGHT (AMBER)	40 - 72	3F8	CHAFFER FRAME (CONTINUED)	125 - 8
1I1	BULB, REAR TURN AND TAIL LIGHTS	40 - 73	3J20	CHAFFER FRAME SHOE DRIVE	140 - 42
1I2	BULB, SIDE FINDER LIGHTS.....	40 - 74	3F10	CHAFFER SHAFT AND ELEMENT ADJUST	125 - 10
1H22	BULBS, CAB ROOF LIGHT.....	40 - 69			
1C12	BUSHING, CAMSHAFT	25 - 4			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
4C5	CHAIN SPROCKET, CROSS AUGERS	150 - 24	1H18	CONCAVE ADJUSTING MOTOR	40 - 65
3G20	CHAIN SPROCKET, LOWER TAILINGS AUGER	130 - 24	1H19	CONCAVE ADJUSTING MOTOR	40 - 66
3K4	CHAIN SPROCKET, UNLOADING AUGER COUNTERSHAFT DRIVE	140 - 52	3E14	CONCAVE CLEARANCE INDICATOR SENSOR	120 - 20
3G14	CHAIN SPROCKET, UPPER TAILINGS ELEVATOR	130 - 18	3E16	CONCAVE CLEARANCE INDICATOR SENSOR	120 - 22
3F23	CHAIN SPROCKET, CLEAN GRAIN LOWER AUGER	130 - 2	3E14	CONCAVES	120 - 20
3D9	CHAIN, DRIVE, FEEDER CONVEYOR	110 - 32	3E16	CONCAVES	120 - 22
4F6	CHAIN, FEEDER CONVEYOR	170 - 28	2F1	CONDENSER, AIR CONDITIONER AND OIL COOLER	70 - 6
3D7	CHAIN, FEEDER HOUSE CONVEYOR	110 - 30	1C11	CONDITIONER, COOLANT	25 - 2
3K7	CHAIN, UNLOADING AUGER DRIVE SPROCKET IDLER ASSEMBLY	140 - 55	3E13	CONE ASSEMBLY, SEPARATOR	120 - 18
4F8	CHAIN, UNLOADING AUGER SYSTEM	170 - 30	1C18	CONNECTING RODS	25 - 10
3E8	CHANNEL, ROTOR	120 - 13	1F8	CONNECTORS, ELECTRICAL, WEATHERPACK	40 - 2
3F14	CHANNEL, SIEVE ELEMENT	125 - 14	1C6	CONNECTORS, ENGINE HEATER HOSE	20 - 27
1B17	CHARGE AIR COOLER	20 - 12	1E10	CONNECTORS, FUEL INJECTION PUMP HOUSING ..	30 - 6
4B19	CHARGE HOUSING AND VERTICAL UNLOADING AUGER	150 - 14	1F16	CONNECTORS, SUPPLEMENTARY TERMINALS	40 - 10
3H14	CHOPPER AND SPREADER DRIVE SHIELDS	135 - 14	2K1	CONSOLE, OVERHEAD	90 - 38
3H5	CHOPPER DEFLECTORS	135 - 4	2J5	CONSOLE, SEAT	90 - 16
3H6	CHOPPER HOUSING AND KNIFEBANK	135 - 6	2J5	CONTAINER, SEAT CONSOLE	90 - 16
3H3	CHOPPER, STRAW	135 - 2	1E16	CONTAINER, STARTING FLUID	30 - 12
4B17	CHUTE, GRAIN TANK CLEAN OUT	150 - 12	2F8	CONTOUR MASTER SOLENOID CONTROL RELIEF VALVE	70 - 13
2K1	CIRCUIT BOARD, OVERHEAD CONSOLE	90 - 38	2G8	CONTOUR MASTER TILT CYLINDER	70 - 37
1H1	CIRCUIT BOARDS, CENTRAL ELECTRONICS MODULE	40 - 48	2G9	CONTOUR MASTER TILT CYLINDER HOSES FITTINGS	70 - 38
3B8	CIRCUIT BOX, ATC	95 - 2	2C8	CONTROL CABLES, HYDROSTATIC DRIVE	50 - 26
1H5	CIRCUIT BREAKER, RELAY PANEL	40 - 52	2J12	CONTROL PANEL, ARMREST	90 - 24
3G1	CLEAN GRAIN ELEVATOR	130 - 4	2J14	CONTROL PANEL, ARMREST (CONTINUED)	90 - 26
3G5	CLEAN GRAIN ELEVATOR BOOT ASSEMBLY	130 - 8	1E8	CONTROL UNIT, ELECTRONIC	30 - 4
3J13	CLEAN GRAIN ELEVATOR DRIVE IDLER ASSEMBLY	140 - 35	2D4	CONTROL VALVE	50 - 50
3K1	CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER	140 - 48	2F13	CONTROL VALVE MODULE, SIX STACK SOLENOID ASSEMBLY & MOUNTINGS	70 - 18
3G8	CLEAN GRAIN ELEVATOR GEARCASE AND SHEAVE	130 - 12	2C15	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT	50 - 34
3G3	CLEAN GRAIN ELEVATOR UPPER SHAFT, SPROCKET AND SHEAVE	130 - 6	2F7	CONTROL VALVE, SOLENOID, AUGER SWING	70 - 12
3G10	CLEAN GRAIN LOADING AUGER	130 - 14	2G17	CONTROL VALVE, STRAW SPREADER	70 - 46
3F23	CLEAN GRAIN LOWER AUGER AND HINGED DOOR	130 - 2	1G19	CONTROLLERS, GRAIN LOSS MONITOR	40 - 42
4B17	CLEAN OUT CHUTE, GRAIN TANK	150 - 12	1F17	CONVENIENCE OUTLET, KIT	40 - 12
1E25	CLEANER, AIR	30 - 21	3J23	CONVEYOR AUGER DRIVE/TAILINGS ELEVATOR SLIP CLUTCH	140 - 45
3F16	CLEANING FAN ASSEMBLY	125 - 16	1C11	COOLANT CONDITIONER, ENGINE	25 - 2
3F17	CLEANING FAN COVERS AND SUPPORTS	125 - 18	1C3	COOLANT HEATER, ENGINE BLOCK	20 - 24
3J16	CLEANING FAN DRIVE	140 - 38	1B19	COOLANT RECOVERY TANK	20 - 14
3F19	CLEANING FAN SHAFT AND BEARINGS	125 - 20	1C11	COOLANT SCAN TEST KIT	25 - 2
1I8	CLEANING SHOE INSPECTION LIGHT	40 - 80	1B17	COOLER, CHARGE AIR	20 - 12
1E22	CLEAT MATS, ENGINE PLATFORM	30 - 18	1D11	COOLER, ENGINE OIL	25 - 30
1H13	CLUTCH ASSEMBLY (STARTER)	40 - 60	2J24	CORNERPOST DISPLAY PANEL, R.H.	90 - 36
3I11	CLUTCH DISK, MAIN GEARCASE (9650 STS)	140 - 8	3K4	COUNTERSHAFT DRIVE, UNLOADING AUGER	140 - 52
3I13	CLUTCH DISK, MAIN GEARCASE (9750 STS)	140 - 10	3J5	COUNTERSHAFT GEARCASE, PRIMARY	140 - 26
3B19	CLUTCH, COMPRESSOR R134A	95 - 13	3J8	COUNTERSHAFT, PRIMARY	140 - 30
3J7	CLUTCH, HEADER ELECTROMAGNETIC	140 - 28	3D11	COUNTERSHAFT, UPPER, VARIABLE SPEED FEEDER HOUSE	110 - 34
3D19	CLUTCH, SLIP (RADIAL PIN)	110 - 42	1B25	COUPLING HUB, ENGINE GEARCASE	20 - 20
3J23	CLUTCH, SLIP, CONVEYOR AUGER DRIVE/ TAILINGS ELEVATOR	140 - 45	2C5	COUPLING, DRIVE SHAFT, FINAL DRIVE	50 - 23
3J23	CLUTCH, SLIP, TAILINGS ELEVATOR/ CONVEYOR AUGER DRIVE	140 - 45	2B24	COUPLING, INPUT SHAFT	50 - 16
2J18	COLD WEATHER START BUTTON	90 - 30	2B12	COUPLINGS, AXLE	50 - 4
1E16	COLD WEATHER STARTING AID	30 - 12	2B13	COUPLINGS, AXLE	50 - 5
2J16	COLUMN, STEERING (LOWER)	90 - 28	3E11	COVER REPAIR KIT	120 - 16
2J18	COLUMN, STEERING (UPPER)	90 - 30	1E25	COVER, AIR CLEANER	30 - 21
1C2	COMPRESSOR BRACKETS, AIR CONDITIONER	20 - 22	3H6	COVER, CHOPPER HOUSING	135 - 6
3B18	COMPRESSOR HOSE, AIR CONDITIONER	95 - 12	3H14	COVER, CHOPPER/SPREADER DRIVE SHIELDS	135 - 14
3B21	COMPRESSOR PARTS	95 - 15	3G8	COVER, CLEAN GRAIN ELEVATOR GEARCASE	130 - 12
3B17	COMPRESSOR, AIR CONDITIONING, R134A	95 - 11	3F23	COVER, CLEAN GRAIN LOWER AUGER	130 - 2
3B19	COMPRESSOR, CLUTCH R134A	95 - 13	3F17	COVER, CLEANING FAN	125 - 18
3E14	CONCAVE ADJUSTING ASSEMBLY	120 - 20	4C5	COVER, CROSS AUGERS	150 - 24
3E16	CONCAVE ADJUSTING ASSEMBLY	120 - 22	2I24	COVER, DOME LIGHT	90 - 10
			2I10	COVER, ENGINE	80 - 36
			2C14	COVER, HYDROSTATIC DRIVE CHARGE PUMP	50 - 33

ALPHABETICAL INDEX - CONTINUED

<i>GRID</i>		<i>PAGE</i>	<i>GRID</i>		<i>PAGE</i>
2C17	COVER, HYDROSTATIC DRIVE MOTOR	50 - 36	4D11	CYLINDER, TENSION AND ATTACHING HARDWARE (RUBBER TRACK)	160 - 10
2C10	COVER, HYDROSTATIC DRIVE PUMP	50 - 28	2G8	CYLINDER, TILT (CONTOUR MASTER)	70 - 37
2C22	COVER, INNER, CAM LOBE MOTOR	50 - 42	2G19	CYLINDER, UNLOADING AUGER BELT TENSIONING	70 - 48
3I15	COVER, MAIN GEARCASE	140 - 12	2G21	CYLINDER, UNLOADING AUGER SWING	70 - 50
4C15	COVER, MOISTURE SENSOR YIELD MAPPING	155 - 8	3D11	CYLINDER, VARIABLE SPEED FEEDER HOUSE	110 - 34
1D11	COVER, OIL COOLER	25 - 30			
2C20	COVER, OUTER, CAM LOBE MOTOR	50 - 40		D	
4C9	COVER, POSITION RECEIVER YIELD MAPPING	155 - 2	1C19	DAMPER KEY	25 - 11
3B8	COVER, PRESSURE BLOWER	95 - 2	1E3	DAMPER, CRANKSHAFT	25 - 50
3B10	COVER, RECIRCULATION BLOWER	95 - 4	4C21	DATASTORE	155 - 14
3C9	COVER, REVERSER GEARBOX (STANDARD)	110 - 8	4C19	DATASTORE MODULE	155 - 12
1D5	COVER, ROCKER ARM	25 - 23	4C21	DATASTORE MODULE	155 - 14
3E8	COVER, ROTOR	120 - 13	4C19	DATASTORE W/DISPLAY	155 - 12
3I21	COVER, SEPARATOR DRIVE TORQUE SENSING	140 - 18	4C22	DECALS YIELD MONITOR	155 - 15
3E18	COVER, SEPARATOR GRATE	120 - 24	4E11	DECALS AND LOCATIONS, SAFETY	170 - 8
1C1	COVER, START RELAY	20 - 21	4E9	DECALS AND ROADWAY MARKINGS LOCATIONS, SAFETY	170 - 6
2J16	COVER, STEERING COLUMN (LOWER)	90 - 28	4C22	DECALS, DISPLAY YIELD MONITOR	155 - 15
3H8	COVER, STRAW CHOPPER ROTOR	135 - 8	4E25	DECALS, FRENCH CANADIAN	170 - 22
3G18	COVER, TAILINGS ELEVATOR	130 - 22	4E19	DECALS, FRONT AND REAR	170 - 16
1D19	COVER, THERMOSTAT	25 - 40	4E23	DECALS, FRONT AND REAR TIRE	170 - 20
1C25	COVER, TIMING GEAR	25 - 17	4E17	DECALS, L.H.	170 - 14
3G6	COVER, UPPER GRAIN LOADING AUGER HOUSING	130 - 10	4C22	DECALS, MOISTURE SENSOR YIELD MONITOR	155 - 15
3G16	COVER, UPPER TAILINGS ELEVATOR	130 - 20	4F1	DECALS, PORTUGUESE	170 - 23
2I24	COVERS, CAB ROOF	90 - 10	4E15	DECALS, R.H.	170 - 12
3E5	COVERS, DUST	120 - 10	4F2	DECALS, ROMANIAN	170 - 24
4B8	COVERS, GRAIN TANK	150 - 2	4F3	DECALS, RUSSIAN	170 - 25
4C1	COVERS, HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) (17 AND 20 FT.)	150 - 20	4E13	DECALS, SAFETY AND LOCATIONS	170 - 10
4B23	COVERS, HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.)	150 - 18	4E7	DECALS, SAFETY, L.H. SIDE	170 - 4
3I9	COVERS, MAIN GEARCASE	140 - 6	4E5	DECALS, SAFETY, R.H. SIDE	170 - 2
1I6	COVERS, MOISTURE SENSOR	40 - 78	4E21	DECALS, SAFETY, RUBBER TRACK	170 - 18
4C17	COVERS, MOISTURE SENSOR YIELD MAPPING	155 - 10	4F4	DECALS, SPANISH	170 - 26
3C6	COVERS, REVERSER GEARBOX (HI-CAPACITY)	110 - 4	4F5	DECALS, UKRAINIAN	170 - 27
3E3	COVERS, TOP SEPARATOR	120 - 8	4C13	DEFLECTOR DOOR, MASS FLOW SENSOR YIELD MAPPING	155 - 6
4B17	COVERS, VERTICAL AUGER LOWER GEARCASE	150 - 12	3F17	DEFLECTOR, CLEANING FAN	125 - 18
4C17	COVERS, WHEN MOISTURE SENSOR IS NOT USED YIELD MAPPING	155 - 10	2I8	DEFLECTOR, ENGINE ACCESS DOOR	80 - 34
2C3	CRADLE, TRANSMISSION/DIFFERENTIAL	50 - 20	1E22	DEFLECTOR, ENGINE PLATFORM	30 - 18
2J16	CRANK, STEERING COLUMN (LOWER)	90 - 28	3C23	DEFLECTOR, FEEDER HOUSE FRAME	110 - 22
1C5	CRANKCASE, ENGINE, OIL DRAIN	20 - 26	3G12	DEFLECTOR, LOADING AUGER SPOUT ASSEMBLY	130 - 16
1C19	CRANKSHAFT	25 - 11	3H10	DEFLECTOR, STRAW CHOPPER	135 - 10
1C25	CRANKSHAFT FRONT OIL SEAL	25 - 17	3H3	DEFLECTOR, STRAW CHOPPER SIDE	135 - 2
1C20	CRANKSHAFT KIT, UNDERSIZE (CONNECTING ROD JOURNAL)	25 - 12	3G6	DEFLECTOR, UPPER GRAIN LOADING AUGER HOUSING	130 - 10
1C21	CRANKSHAFT KIT, UNDERSIZED MAIN BEARING	25 - 13	2I10	DEFLECTORS, AIR, ENGINE	80 - 36
1E3	CRANKSHAFT PULLEY AND DAMPER	25 - 50	3F8	DEFLECTORS, CHAFFER FRAME	125 - 8
3H18	CROP DIVIDER, STRAW SPREADER	135 - 18	3H5	DEFLECTORS, CHOPPER	135 - 4
4C5	CROSS AUGERS	150 - 24	3D22	DEFLECTORS, SEPARATOR/FEEDER HOUSE	120 - 2
3H18	CURTAIN, LIMIT, STRAW SPREADER	135 - 18	3H18	DEFLECTORS, STRAW SPREADER	135 - 18
3H20	CURTAINS, LIMIT, STRAW SPREADER SHIELDS	135 - 20	2F16	DIAL-A-MATIC HEADER HEIGHT CONTROL VALVE	70 - 21
2J9	CUSHIONS, OPERATOR'S SEAT	90 - 20	2C3	DIFFERENTIAL GEARS	50 - 20
1C12	CYLINDER BLOCK FITTINGS	25 - 4	2C3	DIFFERENTIAL SHAFTS	50 - 20
1D2	CYLINDER HEAD	25 - 20	3G8	DIPSTICK, CLEAN GRAIN ELEVATOR GEARCASE	130 - 12
1D2	CYLINDER HEAD BOLTS	25 - 20	1D16	DIPSTICK, ENGINE OIL	25 - 36
1D2	CYLINDER HEAD GASKET	25 - 20	3I15	DIPSTICK, MAIN GEARCASE	140 - 12
1E1	CYLINDER HEAD GASKET KIT	25 - 48	3J5	DIPSTICK, PRIMARY COUNTERSHAFT GEARCASE	140 - 26
1C18	CYLINDER LINERS	25 - 10	3C6	DIPSTICK, REVERSER GEARBOX (HI-CAPACITY)	110 - 4
2F5	CYLINDER SPEED SOLENOID CONTROL VALVE	70 - 10	3C9	DIPSTICK, REVERSER GEARBOX (STANDARD)	110 - 8
2E7	CYLINDER, BRAKE SLAVE	60 - 12			
2E3	CYLINDER, BRAKE, MASTER	60 - 8			
2F19	CYLINDER, HEADER LIFT, HYDRAULIC	70 - 24			
2E13	CYLINDER, STEERING	60 - 18			
4E3	CYLINDER, TENSION (RUBBER TRACK)	160 - 28			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3J1	DIPSTICK, TWO-SPEED GEARBOX	140 - 22	3C19	DRIVE SHIELDS, L.H.	110 - 18
3E19	DISCHARGE BEATER ASSEMBLY	120 - 26	3C21	DRIVE SHIELDS, R.H.	110 - 20
3J22	DISCHARGE BEATER DRIVE IDLER ASSEMBLY	140 - 44	3D9	DRIVE SPROKET, FEEDER CONVEYOR	110 - 32
3E23	DISCHARGE GRATE ASSEMBLY	120 - 30	3K1	DRIVE TIGHTENER, CLEAN GRAIN ELEVATOR	140 - 48
3E9	DISCHARGE HOUSING, SEPARATOR	120 - 14	3C17	DRIVE TIGHTENER, FEEDER HOUSE	110 - 16
3I11	DISK, CLUTCH, MAIN GEARCASE (9650 STS)	140 - 8	3C13	DRIVE TIGHTENER, FEEDER HOUSE, VARIABLE SPEED	110 - 12
3I13	DISK, CLUTCH, MAIN GEARCASE (9750 STS)	140 - 10	3C15	DRIVE TIGHTENER, FIXED SPEED FEEDER HOUSE	110 - 14
3H18	DISK, STRAW SPREADER	135 - 18	4D23	DRIVE WHEEL AND BELT (RUBBER TRACK)	160 - 24
2C15	DISPLACEMENT CONTROL VALVE, HYDROSTATIC DRIVE	50 - 34	2B14	DRIVE WHEELS	50 - 6
4C11	DISPLAY YIELD MAPPING	155 - 4	2B15	DRIVE WHEELS, HIGH FLOTATION	50 - 7
4C11	DISPLAY BRACKET YIELD MAPPING	155 - 4	2F21	DRIVE, BELT PICKUP/REEL PUMP MOUNTING SHEAVE	70 - 26
4C22	DISPLAY DECALS YIELD MONITOR	155 - 15	3J16	DRIVE, CLEANING FAN	140 - 38
2J24	DISPLAY PANEL, R.H. CORNERPOST	90 - 36	1B21	DRIVE, FAN, ENGINE	20 - 16
4C19	DISPLAY W/DATASTORE	155 - 12	2C6	DRIVE, FINAL	50 - 24
3H18	DIVIDER, CROP, STRAW SPREADER	135 - 18	2D8	DRIVE, HYDROSTATIC OIL HOSES, UPPER	50 - 54
2I24	DOME LIGHT	90 - 10	2D6	DRIVE, HYDROSTATIC, LOWER OIL LINES (TWO WHEEL DRIVE)	50 - 52
2J3	DOOR LATCH, CAB	90 - 14	2F23	DRIVE, REEL, FLOW CONTROL VALVE	70 - 28
3F2	DOOR, AUGER BED ASSEMBLY	125 - 2	3J20	DRIVE, SHOE, CHAFFER FRAME	140 - 42
2J1	DOOR, CAB	90 - 12	3K4	DRIVE, UNLOADING AUGER COUNTERSHAFT	140 - 52
3H14	DOOR, CHOPPER AND SPREADER DRIVE SHIELDS	135 - 14	3J12	DRIVER SECONDARY JACKSHAFT, FEED ACCELERATOR	140 - 34
2I10	DOOR, ENGINE	80 - 36	3B8	DRIVER, AMBIENT AIR	95 - 2
2I8	DOOR, ENGINE ACCESS	80 - 34	3J3	DRIVESHAFTS, UNIVERSAL, PRIMARY COUNTERSHAFT	140 - 24
3F23	DOOR, HINGED, CLEAN GRAIN LOWER AUGER	130 - 2	4D21	DRUM AND SHOES, BRAKE (RUBBER TRACK)	160 - 22
4B21	DOOR, HORIZONTAL UNLOADING AUGER (17- AND 20-FT.)	150 - 16	2E5	DRUM, BRAKE	60 - 10
4C1	DOOR, HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) (17 AND 20 FT.)	150 - 20	3D7	DRUM, FEEDER HOUSE CONVEYOR	110 - 30
4B23	DOOR, HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.)	150 - 18	3I11	DRUM, MAIN GEARCASE (9650 STS)	140 - 8
2H13	DOOR, L.H. GULLWING	80 - 12	3I13	DRUM, MAIN GEARCASE (9750 STS)	140 - 10
2H15	DOOR, L.H. REAR GULLWING	80 - 14	2B16	DUAL WHEELS (WIDE-SPACED)	50 - 8
2H11	DOOR, LEFT FRONT	80 - 10	3B13	DUCTS, HEATER AND AIR CONDITIONING	95 - 7
4C13	DOOR, MASS FLOW SENSOR DEFLECTOR YIELD MAPPING	155 - 6	3E5	DUST COVERS	120 - 10
2H23	DOOR, R.H. REAR RADIATOR	80 - 22	3B10	DUST SHIELD, AIR CONDITION AND HEATER	95 - 4
2H24	DOOR, REAR ACCESS	80 - 24			
1B11	DOOR, ROTARY SCREEN	20 - 6		E	
3D22	DOOR, SEPARATOR/FEEDER HOUSE	120 - 2	1E8	E.C.U.	30 - 4
3H3	DOOR, STRAW CHOPPER	135 - 2	1F3	EJECTOR	30 - 24
3G5	DOORS, CLEAN GRAIN ELEVATOR BOOT ASSEMBLY	130 - 8	1F10	ELECTRICAL CONNECTOR SERVICE KIT	40 - 4
4B8	DOORS, GRAIN TANK	150 - 2	1F12	ELECTRICAL CONNECTOR SERVICE KIT (CONTINUED)	40 - 6
3E7	DOORS, SEPARATOR	120 - 12	1F8	ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK	40 - 2
3E3	DOORS, SEPARATOR TOP COVER	120 - 8	3J7	ELECTROMAGNETIC CLUTCH, HEADER	140 - 28
3G18	DOORS, TAILINGS ELEVATOR	130 - 22	1E8	ELECTRONIC CONTROL UNIT	30 - 4
1C3	DRAIN PLUG, ENGINE BLOCK	20 - 24	1E8	ELECTRONIC FUEL INJECTION PUMP	30 - 4
2F8	DRAIN PLUG, RELIEF VALVE	70 - 13	1H1	ELECTRONICS MODULE, CENTRAL AND CIRCUIT BOARDS	40 - 48
1D19	DRAIN VALVE, CYLINDER HEAD	25 - 40	3F10	ELEMENT ADJUST, CHAFFER	125 - 10
1D14	DRAIN VALVE, OIL PAN	25 - 34	3F14	ELEMENT, SIEVE	125 - 14
1B18	DRAIN VALVE, RADIATOR	20 - 13	3J24	ELEVATOR DRIVE JACKSHAFT ASSEMBLY	140 - 46
3D9	DRIVE CHAIN, FEEDER CONVEYOR	110 - 32	3G1	ELEVATOR, CLEAN GRAIN	130 - 4
1C19	DRIVE GEAR, OIL PUMP	25 - 11	3G18	ELEVATOR, TAILINGS	130 - 22
2D17	DRIVE LINES AND HOSES, TWO-WHEEL DRIVE	50 - 64	2I8	ENGINE ACCESS DOOR	80 - 34
2C5	DRIVE SHAFT, FINAL DRIVE	50 - 23	2I10	ENGINE AIR DEFLECTORS	80 - 36
3C11	DRIVE SHAFT, FIXED SPEED FEEDER HOUSE	110 - 10	2I10	ENGINE COVERS	80 - 36
3I11	DRIVE SHAFT, MAIN GEARCASE (9650 STS)	140 - 8	1B21	ENGINE FAN AND DRIVES	20 - 16
3I13	DRIVE SHAFT, MAIN GEARCASE (9750 STS)	140 - 10	1C24	ENGINE FLYWHEEL	25 - 16
3I23	DRIVE SHAFT, TWO-SPEED GEARBOX	140 - 20	1B25	ENGINE GEARCASE COUPLING HUB	20 - 20
3D17	DRIVE SHAFT, UPPER, FIXED SPEED FEEDER HOUSE	110 - 40	3I7	ENGINE GEARCASE OIL FILTER ASSEMBLY	140 - 4
2B12	DRIVE SHAFTS	50 - 4	3I5	ENGINE GEARCASE PRESSURE REGULATOR	140 - 2
2B13	DRIVE SHAFTS	50 - 5	1C10	ENGINE OIL (TORQ-GARD PLUS-50)	25 - 1
3H14	DRIVE SHIELDS, CHOPPER AND SPREADER	135 - 14			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1D11	ENGINE OIL COOLER	25 - 30	3D15	FEEDER HOUSE POSITION SENSOR	110 - 38
1D16	ENGINE OIL DIPSTICK	25 - 36	3D13	FEEDER HOUSE RETURN FLOOR	110 - 36
1D16	ENGINE OIL DIPSTICK TUBE	25 - 36	2J20	FEEDER HOUSE REVERSER FOOT CONTROL	90 - 32
1D12	ENGINE OIL FILTER	25 - 32	3D1	FEEDER HOUSE SHELL, WEAR PLATES AND SEALS (CONTOUR MASTER)	110 - 24
1D7	ENGINE OIL PUMP	25 - 26	3D3	FEEDER HOUSE UPPER SHAFT	110 - 26
1D9	ENGINE OIL PUMP INTAKE	25 - 28	2G7	FEEDER HOUSE VARIABLE DRIVE HYDRAULIC HOSE	70 - 36
1C16	ENGINE OVERHAUL KIT	25 - 8	3D22	FEEDER HOUSE/SEPARATOR SEAL, STONE TRAP AND DOOR	120 - 2
1E22	ENGINE PLATFORM	30 - 18	1B17	FILLER CAP, RADIATOR	20 - 12
1E1	ENGINE REBUILD GASKET KIT	25 - 48	3I7	FILTER ASSEMBLY, OIL, ENGINE GEARCASE	140 - 4
1G21	ENGINE SPEED SENSOR	40 - 44	1E25	FILTER, AIR CLEANER	30 - 21
1F19	ENGINE WIRING HARNESS	40 - 14	3B10	FILTER, AIR, RECIRCULATION	95 - 4
2J18	ETHER START BUTTON	90 - 30	3B12	FILTER, CAB AIR	95 - 6
1E17	ETHER STARTING FITTINGS	30 - 13	1D12	FILTER, ENGINE OIL	25 - 32
3B16	EVAPORATOR HEATER, AIR CONDITIONING SYSTEM	95 - 10	3B16	FILTER, EVAPORATOR HEATER (AIR CONDITIONING SYSTEM)	95 - 10
3B16	EVAPORATOR TEMPERATURE SENSOR (AIR CONDITIONING SYSTEM)	95 - 10	1E14	FILTER, FUEL	30 - 10
1D25	EXHAUST MANIFOLD	25 - 46	1E18	FILTER, FUEL TANK	30 - 14
1D25	EXHAUST MANIFOLD GASKETS	25 - 46	2C14	FILTER, HYDROSTATIC DRIVE CHARGE PUMP	50 - 33
1D2	EXHAUST VALVE SHIELD	25 - 20	2F17	FILTER, MAIN HYDRAULIC	70 - 22
1D2	EXHAUST VALVES	25 - 20	1C25	FILTER, WATER PUMP (WEEP HOLE)	25 - 17
2K7	EXTENSION ASSEMBLY, LADDER	90 - 44	1G15	FILTER, WINDSHIELD WASHER	40 - 38
1C3	EXTENSION CORD, ENGINE BLOCK COOLANT HEATER	20 - 24	2C6	FINAL DRIVE	50 - 24
2K5	EXTENSION, LADDER AND HANDRAILS	90 - 42	4D19	FINAL DRIVE MOUNTING (SINGLE REDUCTION) (RUBBER TRACK)	160 - 20
1E22	EXTENSIONS, ENGINE PLATFORM	30 - 18	2C5	FINAL DRIVE, DRIVE SHAFT	50 - 23
4B10	EXTENSIONS, GRAIN TANK (9650 STS)	150 - 4	3F10	FINGERS, CHAFFER ELEMENT	125 - 10
4B12	EXTENSIONS, GRAIN TANK (9750 STS)	150 - 6	3F6	FINGERS, CHAFFER FRAME	125 - 6
F					
3F16	FAN ASSEMBLY, CLEANING	125 - 16	2G19	FITTINGS AND HOSES, UNLOADING AUGER BELT TENSIONING CYLINDER	70 - 48
1H18	FAN DRIVE ADJUSTING MOTOR, SEPARATOR	40 - 65	1C12	FITTINGS, CYLINDER BLOCK	25 - 4
1H19	FAN DRIVE ADJUSTING MOTOR, SEPARATOR	40 - 66	1E17	FITTINGS, ETHER STARTING	30 - 13
1B23	FAN DRIVE HOUSING	20 - 18	2C6	FITTINGS, FINAL DRIVE	50 - 24
3J17	FAN DRIVE SHEAVE	140 - 39	1E18	FITTINGS, FUEL TANK	30 - 14
3J14	FAN DRIVE SPEED CONTROL SUPPORT AND SHAFT	140 - 36	2F20	FITTINGS, HEADER LIFT	70 - 25
1B23	FAN DRIVE, ADJUSTABLE	20 - 18	2G18	FITTINGS, HOSE, CHAFF SPREADER MOTOR	70 - 47
3J18	FAN DRIVER JACKSHAFT ASSEMBLY	140 - 40	2G9	FITTINGS, HOSES, CONTOUR MASTER TILT CYLINDER	70 - 38
1B23	FAN PULLEY ADJUSTABLE	20 - 18	2G21	FITTINGS, HOSES, UNLOADING AUGER SWING CYLINDER	70 - 50
3F19	FAN SHAFT, CLEANING	125 - 20	2B24	FITTINGS, INPUT SHAFT HOUSING	50 - 16
3B8	FAN, AIR CONDITIONER AND HEATER	95 - 2	3C8	FITTINGS, REVERSER GEARBOX (HI CAPACITY)	110 - 6
1H7	FAN, ALTERNATOR (95 AMP)	40 - 54	3J1	FITTINGS, TWO-SPEED GEARBOX	140 - 22
3B10	FAN, BLOWER, AIR CONDITION AND HEATER	95 - 4	1G15	FITTINGS, WINDSHIELD WASHER	40 - 38
1B21	FAN, DRIVES, ENGINE	20 - 16	2B9	FIXED REAR AXLE (NON-POWERED)	50 - 1
3D24	FEED ACCELERATOR	120 - 4	3C11	FIXED SPEED FEEDER HOUSE DRIVE SHAFT, SHEAVE, AND MOUNTINGS	110 - 10
3J10	FEED ACCELERATOR DRIVE IDLER	140 - 32	3C15	FIXED SPEED FEEDER HOUSE DRIVE TIGHTENER ..	110 - 14
3J12	FEED ACCELERATOR DRIVER SECONDARY JACKSHAFT	140 - 34	3D17	FIXED SPEED FEEDER HOUSE UPPER DRIVE SHAFT, SHEAVE AND MOUNTINGS	110 - 40
3E1	FEED HOUSING ASSEMBLY	120 - 6	2I5	FIXED, REAR LANDING, HANDRAIL	80 - 30
3D5	FEED PLATE LATCH HANDLE	110 - 28	3E11	FLIGHT REPAIR KIT	120 - 16
3D9	FEEDER CONVEYOR DRIVE CHAIN, IDLER BRACKET	110 - 32	1I8	FLOODLAMP, CLEANING SHOE INSPECTION LIGHT	40 - 80
1H15	FEEDER HOUSE BACKSHAFT SPEED SENSOR	40 - 62	1I2	FLOODLAMP, SIDE FINDER LIGHTS	40 - 74
3D7	FEEDER HOUSE CONVEYOR IDLER SHAFT, DRUM AND CHAIN	110 - 30	2I22	FLOOR MAT, CAB	90 - 8
3C17	FEEDER HOUSE DRIVE TIGHTENER	110 - 16	3F6	FLOOR, CHAFFER FRAME	125 - 6
3C15	FEEDER HOUSE DRIVE TIGHTENER, FIXED SPEED	110 - 14	3F17	FLOOR, CLEANING FAN	125 - 18
3C13	FEEDER HOUSE DRIVE TIGHTENER, VARIABLE SPEED	110 - 12	3E1	FLOOR, FEED HOUSING ASSEMBLY	120 - 6
3D5	FEEDER HOUSE FLOOR AND LATCH HANDLE	110 - 28	3D5	FLOOR, FEEDER HOUSE	110 - 28
3C23	FEEDER HOUSE FRAME	110 - 22	2I20	FLOOR, REAR AND SIDE PANELS, CAB	90 - 6
2G5	FEEDER HOUSE GEARCASE OIL COOLER	70 - 34	3D13	FLOOR, RETURN, FEEDER HOUSE	110 - 36
3C3	FEEDER HOUSE LIFT SUPPORT	110 - 1	2F23	FLOW CONTROL VALVE, REEL DRIVE	70 - 28
			4C13	FLOW SENSOR, MASS YIELD MAPPING	155 - 6

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
1C24	FLYWHEEL.....	25 - 16	1D19	GASKET, THERMOSTAT	25 - 40
1G24	FOLDING CHOPPER WIRING HARNESS	40 - 47	1C25	GASKET, TIMING GEAR COVER.....	25 - 17
1D1	FOLLOWER, CAMSHAFT	25 - 18	1D23	GASKET, TURBOCHARGER	25 - 44
1D4	FOLLOWER, CAMSHAFT	25 - 22	1D19	GASKET, WATER MANIFOLD	25 - 40
2J20	FOOT PEDAL, FEEDER HOUSE REVERSER	90 - 32	1D17	GASKET, WATER PUMP	25 - 38
4D3	FRAME MOUNTING, TRACK (RUBBER TRACK)	160 - 2	1D25	GASKETS, EXHAUST MANIFOLD	25 - 46
3B8	FRAME, BLOWER MOTOR DRIVER	95 - 2	2G13	GAUGE, ACCUMULATOR PRESSURE	70 - 42
3F6	FRAME, CHAFFER	125 - 6	4D17	GEAR CASE, TRANSFER (RUBBER TRACK)	160 - 18
3F8	FRAME, CHAFFER (CONTINUED).....	125 - 8	1D1	GEAR, CAMSHAFT	25 - 18
3E23	FRAME, DISCHARGE GRATE ASSEMBLY	120 - 30	2C6	GEAR, FINAL DRIVE.....	50 - 24
1E22	FRAME, ENGINE PLATFORM	30 - 18	1E8	GEAR, INJECTION PUMP.....	30 - 4
3C23	FRAME, FEEDER HOUSE	110 - 22	1C19	GEAR, OIL PUMP DRIVE	25 - 11
4D5	FRAME, MAIN, PIVOT BUSHINGS (RUBBER TRACK)	160 - 4	1D7	GEAR, OIL PUMP DRIVE	25 - 26
2D21	FRAME, PARKING BRAKE	60 - 2	1C24	GEAR, RING	25 - 16
1B13	FRAME, RADIATOR	20 - 8	3C6	GEARBOX, REVERSER (HI CAPACITY)	110 - 4
2H5	FRAME, SEPARATOR, L.H.	80 - 4	3C9	GEARBOX, REVERSER (STANDARD)	110 - 8
2H3	FRAME, SEPARATOR, R.H.....	80 - 2	3I17	GEARBOX, TRANSFER	140 - 14
4D3	FRAME, SHIPPING (RUBBER TRACK)	160 - 2	3I23	GEARBOX, TWO-SPEED	140 - 20
3F12	FRAME, SIEVE	125 - 12	3J1	GEARBOX, TWO-SPEED, HOSES AND FITTINGS	140 - 22
3H16	FRAME, STRAW SPREADER.....	135 - 16	3F10	GEARCASE, CHAFFER ELEMENT	125 - 10
4E25	FRENCH CANADIAN DECALS AND LABELS	170 - 22	3F8	GEARCASE, CHAFFER FRAME.....	125 - 8
4E19	FRONT AND REAR DECALS	170 - 16	3G8	GEARCASE, CLEAN GRAIN ELEVATOR	130 - 12
4E23	FRONT AND REAR TIRE DECALS	170 - 20	4B16	GEARCASE, HORIZONTAL UNLOADING AUGER DRIVE	150 - 10
4D7	FRONT ARM AND ADJUSTABLE IDLER ASSEMBLY (RUBBER TRACK)	160 - 6	3I9	GEARCASE, MAIN.....	140 - 6
1H23	FRONT LIGHT, L.H.....	40 - 70	3I15	GEARCASE, MAIN (CONTINUED)	140 - 12
1C25	FRONT OIL SEAL	25 - 17	3I11	GEARCASE, MAIN (9650 STS)	140 - 8
2H11	FRONT PANEL AND DOOR, LEFT	80 - 10	3I13	GEARCASE, MAIN (9750 STS)	140 - 10
2H19	FRONT PANEL, R.H.....	80 - 18	3J5	GEARCASE, PRIMARY COUNTERSHAFT	140 - 26
1D19	FRONT WATER MANIFOLD	25 - 40	3F12	GEARCASE, SIEVE FRAME.....	125 - 12
1H24	FRONT, R.H. LIGHT	40 - 71	4B17	GEARCASE, VERTICAL AUGER LOWER	150 - 12
1E14	FUEL CHECK VALVE	30 - 10	3F4	GEARS, AUGER BED SHAFT	125 - 4
1E14	FUEL FILTER.....	30 - 10	3E14	GEARS, CONCAVE ADJUSTING ASSEMBLY.....	120 - 20
1E14	FUEL FILTER BASE	30 - 10	3E16	GEARS, CONCAVE ADJUSTING ASSEMBLY.....	120 - 22
1E14	FUEL FILTER LINES	30 - 10	2C3	GEARS, DIFFERENTIAL	50 - 20
1E6	FUEL INJ LINES	30 - 2	3I9	GEARS, MAIN GEARCASE.....	140 - 6
1E12	FUEL INJECTION NOZZLE.....	30 - 8	3I15	GEARS, MAIN GEARCASE (CONTINUED)	140 - 12
1E6	FUEL INJECTION NOZZLES (ROBERT BOSCH)	30 - 2	3I11	GEARS, MAIN GEARCASE (9650 STS)	140 - 8
1E8	FUEL INJECTION PUMP.....	30 - 4	3I13	GEARS, MAIN GEARCASE (9750 STS)	140 - 10
1E10	FUEL INJECTION PUMP HOUSING CONNECTORS	30 - 6	3C6	GEARS, REVERSER GEARBOX (HI-CAPACITY)	110 - 4
1E6	FUEL LEAK-OFF LINES	30 - 2	3C9	GEARS, REVERSER GEARBOX (STANDARD)	110 - 8
1E8	FUEL LEAK-OFF LINES	30 - 4	2B24	GEARS, TRANSMISSION	50 - 16
1E18	FUEL PICKUP, FUEL TANK	30 - 14	2C1	GEARS, TRANSMISSION PINION	50 - 18
1E18	FUEL SENDER	30 - 14	3I23	GEARS, TWO-SPEED GEARBOX	140 - 20
1E8	FUEL SHUT-OFF SOLENOID (FIP)	30 - 4	4B17	GEARS, VERTICAL AUGER LOWER GEARCASE	150 - 12
1E18	FUEL TANK	30 - 14	2J22	GEARSHIFT LEVER	90 - 34
1E20	FUEL TANK DOUBLE BREATHER.....	30 - 16	2J22	GEARSHIFT LINKAGE	90 - 34
1E18	FUEL TANK FILTER	30 - 14	2J1	GLASS, CAB	90 - 12
1E22	FUEL TANK SUPPORTS.....	30 - 18	1G19	GRAIN LOSS MONITOR SYSTEM.....	40 - 42
1E11	FUEL TRANSFER PUMP (ROBERT BOSCH)	30 - 7	4B8	GRAIN TANK	150 - 2
G					
1D5	GASKET ADHESIVE, ROCKER ARM COVER	25 - 23	4B10	GRAIN TANK EXTENSIONS (9650 STS).....	150 - 4
1E1	GASKET KIT, CYLINDER HEAD	25 - 48	4B12	GRAIN TANK EXTENSIONS (9750 STS).....	150 - 6
1E1	GASKET KIT, ENGINE REBUILD	25 - 48	1I4	GRAIN TANK FULL BIN SENSOR	40 - 76
1E1	GASKET KIT, SHORT BLOCK	25 - 48	4B14	GRAIN TANK SAMPLING TROUGH.....	150 - 8
1D2	GASKET, CYLINDER HEAD	25 - 20	4B15	GRAIN TANK WINDOW	150 - 9
1D21	GASKET, INTAKE MANIFOLD	25 - 42	1G22	GRAIN TANK WIRING HARNESS	40 - 45
1D12	GASKET, OIL FILTER HOUSING	25 - 32	2K1	GRAPHICS PANEL, OVERHEAD CONSOLE	90 - 38
1D14	GASKET, OIL PAN	25 - 34	3E23	GRATE ASSEMBLY, DISCHARGE.....	120 - 30
1D7	GASKET, OIL PUMP.....	25 - 26	3E18	GRATE, SEPARATOR	120 - 24
1D9	GASKET, OIL PUMP INTAKE	25 - 28	2C3	GROUND SPEED SENSOR	50 - 20
1C23	GASKET, REAR OIL SEAL.....	25 - 15	1G23	GROUND SPEED WIRING HARNESS EXTENSION.....	40 - 46
1D5	GASKET, ROCKER ARM COVER	25 - 23	2I19	GROUND STRAP.....	90 - 4
			2J22	GUARD, GEARSHIFT LEVER.....	90 - 34
			2J18	GUARDS, STEERING COLUMN (UPPER).....	90 - 30
			2H13	GULLWING DOOR, L.H.	80 - 12
			2H15	GULLWING DOOR, L.H. REAR	80 - 14
			2H21	GULLWING DOOR, R.H.....	80 - 20

ALPHABETICAL INDEX - CONTINUED

GRID	H	PAGE	GRID	PAGE	
2J3	HANDLE, CAB DOOR	90 - 14	1C3	HEATER, COOLANT, ENGINE BLOCK	20 - 24
3D5	HANDLE, FEED PLATE LATCH	110 - 28	2B15	HIGH FLOTATION DRIVE WHEELS	50 - 7
3H24	HANDLE, STRAW SPREADER.....	135 - 24	2I10	HINGE, ENGINE DOOR	80 - 36
3H20	HANDLE, STRAW SPREADER SHIELDS	135 - 20	4B21	HINGE, HORIZONTAL UNLOADING AUGER (17- AND 20-FT.).....	150 - 16
2I6	HANDRAIL, ENGINE PLATFORM.....	80 - 32	2H23	HINGE, R.H. REAR RADIATOR DOOR	80 - 22
2K8	HANDRAIL, L.H.....	90 - 46	2I5	HINGE, REAR FIXED LANDING AND HANDRAIL	80 - 30
2K10	HANDRAIL, R.H.	90 - 48	3F23	HINGED DOOR, CLEAN GRAIN LOWER AUGER	130 - 2
2I5	HANDRAIL, REAR FIXED LANDING	80 - 30	2H13	HINGES, L.H. GULLWING DOOR	80 - 12
2I3	HANDRAIL, REAR LADDER LANDING	80 - 28	2H15	HINGES, L.H. REAR GULLWING DOOR.....	80 - 14
2K5	HANDRAILS, EXTENSION AND LADDER	90 - 42	2H21	HINGES, R.H. GULLWING DOOR	80 - 20
2K12	HARDWARE KIT, CAB	90 - 50	3D22	HINGES, SEPARATOR/FEEDER HOUSE	120 - 2
1G23	HARNESS EXTENSION, WIRING, GROUND SPEED....	40 - 46	4B21	HORIZONTAL UNLOADING AUGER (17- AND 20-FT.).....	150 - 16
4C19	HARNESS, DATASTORE	155 - 12	4B16	HORIZONTAL UNLOADING AUGER DRIVE GEARCASE	150 - 10
1G1	HARNESS, MAIN WIRING, R.H. W/O/ GREENSTAR - REFERENCE	40 - 23	4C1	HORIZONTAL UNLOADING AUGER HOUSING (EXPORT) (17 AND 20 FT.).....	150 - 20
4C15	HARNESS, MOISTURE SENSOR MOTOR YIELD MAPPING.....	155 - 8	4B23	HORIZONTAL UNLOADING AUGER HOUSING (17 AND 20 FT.)	150 - 18
1H13	HARNESS, STARTER, WIRING	40 - 60	4C3	HORIZONTAL UNLOADING AUGER SWIVEL.....	150 - 22
2G13	HARNESS, WIRING, ACCUMULATOR PRESSURE GAUGE.....	70 - 42	2I19	HORN ASSEMBLY.....	90 - 4
1G13	HARNESS, WIRING, AIR CONDITIONING	40 - 36	2J18	HORN BUTTON	90 - 30
2J7	HARNESS, WIRING, AIR SUSPENSION SEAT.....	90 - 18	2G13	HOSE, ACCUMULATOR PRESSURE GAUGE	70 - 42
1G9	HARNESS, WIRING, ARMREST.....	40 - 32	1F3	HOSE, ASPIRATOR.....	30 - 24
1G7	HARNESS, WIRING, CAB MAIN.....	40 - 30	3B18	HOSE, COMPRESSOR, AIR CONDITIONER	95 - 12
1F19	HARNESS, WIRING, ENGINE.....	40 - 14	2G18	HOSE, FITTINGS, CHAFF SPREADER MOTOR.....	70 - 47
1G24	HARNESS, WIRING, FOLDING CHOPPER	40 - 47	3I19	HOSE, HYDRAULIC, SEPARATOR DRIVE VARIABLE SPEED	140 - 16
1G22	HARNESS, WIRING, GRAIN TANK	40 - 45	2G7	HOSE, HYDRAULIC, VARIABLE DRIVE, FEEDER HOUSE.....	70 - 36
1I4	HARNESS, WIRING, GRAIN TANK FULL BIN SENSOR	40 - 76	3E19	HOSE, LUBE, DISCHARGE BEATER ASSEMBLY	120 - 26
1G20	HARNESS, WIRING, HARVESTRAK	40 - 43	2G11	HOSE, ONE GALLON ACCUMULATOR	70 - 40
3J7	HARNESS, WIRING, HEADER ELECTROMAGNETIC CLUTCH.....	140 - 28	2G12	HOSE, ONE HALF GALLON ACCUMULATOR	70 - 41
2H13	HARNESS, WIRING, L.H. GULLWING DOOR SERVICE LIGHT	80 - 12	2G19	HOSES AND FITTINGS, UNLOADING AUGER BELT TENSIONING CYLINDER	70 - 48
1F21	HARNESS, WIRING, L.H. MAIN	40 - 17	2D10	HOSES AND LINES, HYDROSTATIC OIL COOLER.....	50 - 56
1F22	HARNESS, WIRING, L.H. MAIN	40 - 18	2D12	HOSES AND LINES, L.H. 4-WHEEL DRIVE HYDRAULIC.....	50 - 58
1F24	HARNESS, WIRING, L.H. MAIN	40 - 20	2F3	HOSES AND LINES, WET CLUTCH OIL COOLER,	70 - 8
1I6	HARNESS, WIRING, MOISTURE SENSOR.....	40 - 78	1E24	HOSES, AIR CLEANER.....	30 - 20
2J24	HARNESS, WIRING, R.H. CORNERPOST DISPLAY PANEL	90 - 36	2D17	HOSES, DRIVE, TWO-WHEEL DRIVE.....	50 - 64
2H21	HARNESS, WIRING, R.H. GULLWING DOOR SERVICE LIGHT	80 - 20	1C5	HOSES, ENGINE CRANKCASE OIL DRAIN	20 - 26
1G4	HARNESS, WIRING, R.H. MAIN, W/O GREENSTAR (REFERENCE).....	40 - 27	3B16	HOSES, EVAPORATOR HEATER (AIR CONDITIONING SYSTEM)	95 - 10
2H17	HARNESS, WIRING, REAR WALL SERVICE LIGHT	80 - 16	2G9	HOSES, FITTINGS, CONTOUR MASTER TILT CYLINDER	70 - 38
3E8	HARNESS, WIRING, ROTOR SPEED SENSOR.....	120 - 13	2G21	HOSES, FITTINGS, UNLOADING AUGER SWING CYLINDER	70 - 50
1G11	HARNESS, WIRING, STEERING COLUMN.....	40 - 34	1E18	HOSES, FUEL TANK.....	30 - 14
3H22	HARNESS, WIRING, STRAW SPREADER	135 - 22	1E20	HOSES, FUEL TANK DOUBLE BREATHER	30 - 16
1I3	HARNESS, WIRING, TRANSPORT WARNING LIGHTS.....	40 - 75	2F20	HOSES, HEADER LIFT	70 - 25
1H21	HARNESS, WIRING, UNLOADING AUGER LIGHT.....	40 - 68	4C3	HOSES, HORIZONTAL UNLOADING AUGER SWIVEL	150 - 22
1G20	HARVESTRAK WIRING HARNESS	40 - 43	2F17	HOSES, MAIN HYDRAULIC FILTER	70 - 22
1D2	HEAD BOLT KIT	25 - 20	2F1	HOSES, OIL COOLER AND AIR CONDITIONER CONDENSER	70 - 6
1D2	HEAD, CYLINDER	25 - 20	2D6	HOSES, OIL, HYDROSTATIC DRIVE, LOWER (TWO WHEEL DRIVE)	50 - 52
3J7	HEADER ELECTROMAGNETIC CLUTCH	140 - 28	2D8	HOSES, OIL, HYDROSTATIC DRIVE, UPPER	50 - 54
2F16	HEADER HEIGHT CONTROL VALVE	70 - 21	2E24	HOSES, PRESSURE, HYDRAULIC	70 - 4
2F19	HEADER LIFT CYLINDER, HYDRAULIC	70 - 24	1B15	HOSES, RADIATOR	20 - 10
2F20	HEADER LIFT HOSES AND FITTINGS	70 - 25	3B15	HOSES, RECEIVER-DRYER (AIR CONDITIONING SYSTEM)	95 - 9
2I24	HEADLINERS, CAB ROOF	90 - 10	1B19	HOSES, RECOVERY TANK, COOLANT	20 - 14
3B10	HEATER AND AIR CONDITIONER HOUSING, LOWER	95 - 4	2G4	HOSES, REEL DRIVE	70 - 33
3B8	HEATER AND AIR CONDITIONER HOUSING, UPPER.....	95 - 2	2G3	HOSES, REEL LIFT.....	70 - 32
3B13	HEATER AND AIR CONDITIONING DUCTS	95 - 7			
1C6	HEATER HOSE CONNECTORS.....	20 - 27			

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2G3	HOSES, REEL POSITION.....	70 - 32	3E19	HUB, DISCHARGE BEATER ASSEMBLY	120 - 26
2F21	HOSES, REEL/BELT PICKUP PUMP	70 - 26	3J24	HUB, ELEVATOR DRIVE JACKSHAFT ASSEMBLY	140 - 46
2E13	HOSES, STEERING.....	60 - 18	1B21	HUB, ENGINE FAN	20 - 16
2E11	HOSES, STEERING, UPPER	60 - 16	3D24	HUB, FEED ACCELERATOR ASSEMBLY	120 - 4
2G15	HOSES, STRAW SPREADER.....	70 - 44	3J7	HUB, HEADER ELECTROMAGNETIC CLUTCH	140 - 28
3J1	HOSES, TWO-SPEED GEARBOX	140 - 22	4D13	HUB, IDLER WHEEL (RUBBER TRACK).....	160 - 12
3B14	HOSES, WATER VALVE ASSEMBLY (AIR CONDITIONING SYSTEM)	95 - 8	3I9	HUB, MAIN GEARCASE	140 - 6
1G15	HOSES, WINDSHIELD WASHER	40 - 38	2F21	HUB, REEL/BELT PICKUP PUMP	70 - 26
2D14	HOSES, 4-WHEEL DRIVE.....	50 - 60	1B11	HUB, ROTARY SCREEN DOOR	20 - 6
3E1	HOUSING ASSEMBLY, FEED	120 - 6	3I21	HUB, SEPARATOR DRIVE TORQUE SENSING.....	140 - 18
1E10	HOUSING CONNECTORS, FUEL INJECTION PUMP ..	30 - 6	3I19	HUB, SEPARATOR DRIVE VARIABLE SPEED.....	140 - 16
2B23	HOUSING COVER, TRANSMISSION/ DIFFERENTIAL	50 - 15	3J23	HUB, SLIP CLUTCH	140 - 45
1B23	HOUSING, ADJUSTABLE FAN DRIVE.....	20 - 18	3H18	HUB, STRAW SPREADER	135 - 18
3B10	HOUSING, AIR CONDITIONER AND HEATER, LOWER	95 - 4	2G15	HUB, STRAW SPREADER PUMP	70 - 44
3B8	HOUSING, AIR CONDITIONER AND HEATER, UPPER.....	95 - 2	3G14	HUB, UPPER TAILINGS ELEVATOR	130 - 18
4D9	HOUSING, AIR SUSPENSION (RUBBER TRACK)	160 - 8	3D11	HUB, VARIABLE SPEED FEEDER HOUSE.....	110 - 34
3B12	HOUSING, CAB AIR FILTER	95 - 6	3K1	HUBS, CLEAN GRAIN ELEVATOR DRIVE TIGHTENER AND IDLER	140 - 48
2I24	HOUSING, CAB ROOF	90 - 10	3I11	HUBS, MAIN GEARCASE (9650 STS).....	140 - 8
3H6	HOUSING, CHOPPER.....	135 - 6	3I13	HUBS, MAIN GEARCASE (9750 STS).....	140 - 10
3G8	HOUSING, CLEAN GRAIN ELEVATOR GEARCASE	130 - 12	3K4	HUBS, UNLOADING AUGER COUNTERSHAFT DRIVE	140 - 52
3E9	HOUSING, DISCHARGE, SEPARATOR.....	120 - 14	2F17	HYDRAULIC FILTER, MAIN	70 - 22
1B21	HOUSING, ENGINE FAN	20 - 16	3I19	HYDRAULIC HOSE, SEPARATOR DRIVE VARIABLE SPEED	140 - 16
3B10	HOUSING, EVAPORATOR	95 - 4	2G7	HYDRAULIC HOSE, VARIABLE DRIVE, FEEDER HOUSE.....	70 - 36
3D7	HOUSING, FEEDER HOUSE CONVEYOR	110 - 30	2D12	HYDRAULIC LINES AND HOSES, L.H. 4-WHEEL DRIVE	50 - 58
3D3	HOUSING, FEEDER HOUSE UPPER SHAFT.....	110 - 26	2D16	HYDRAULIC LINES, CASE DRAIN, 4-WHEEL DRIVE	50 - 62
2C6	HOUSING, FINAL DRIVE	50 - 24	2E21	HYDRAULIC OIL RESERVOIR	70 - 1
3C11	HOUSING, FIXED SPEED FEEDER HOUSE	110 - 10	2E24	HYDRAULIC PRESSURE LINES AND HOSES	70 - 4
2J22	HOUSING, GEARSHIFT LEVER.....	90 - 34	2E22	HYDRAULIC PUMP, MAIN	70 - 2
4C1	HOUSING, HORIZONTAL UNLOADING AUGER (EXPORT) (17 AND 20 FT.).....	150 - 20	4E1	HYDRAULICS, TENSION CYLINDER (RUBBER TRACK)	160 - 26
4B23	HOUSING, HORIZONTAL UNLOADING AUGER (17 AND 20 FT.)	150 - 18	2C14	HYDROSTATIC DRIVE CHARGE PUMP	50 - 33
4B21	HOUSING, HORIZONTAL UNLOADING AUGER (17- AMD 20-FT.).....	150 - 16	2C8	HYDROSTATIC DRIVE CONTROL CABLES	50 - 26
4C3	HOUSING, HORIZONTAL UNLOADING AUGER SWIVEL	150 - 22	2C15	HYDROSTATIC DRIVE DISPLACEMENT CONTROL VALVE	50 - 34
2C12	HOUSING, HYDROSTATIC PUMP	50 - 30	2C17	HYDROSTATIC DRIVE MOTOR.....	50 - 36
2B24	HOUSING, INPUT SHAFT.....	50 - 16	2D8	HYDROSTATIC DRIVE OIL HOSES, UPPER	50 - 54
1H23	HOUSING, L.H. FRONT LIGHT	40 - 70	2D6	HYDROSTATIC DRIVE OIL LINES AND HOSES, LOWER (TWO WHEEL DRIVE)	50 - 52
3G6	HOUSING, LOADING AUGER, UPPER CLEAN GRAIN	130 - 10	2C12	HYDROSTATIC DRIVE PUMP	50 - 30
3I9	HOUSING, MAIN GEARCASE	140 - 6	2C10	HYDROSTATIC DRIVE PUMP COVER	50 - 28
1D12	HOUSING, OIL FILTER	25 - 32	2C10	HYDROSTATIC DRIVE PUMP SHAFT.....	50 - 28
2J24	HOUSING, R.H. CORNERPOST DISPLAY PANEL	90 - 36	2C19	HYDROSTATIC MOTOR VALVE	50 - 39
1H24	HOUSING, R.H. FRONT LIGHT	40 - 71	2D10	HYDROSTATIC OIL COOLER LINES AND HOSES	50 - 56
1C23	HOUSING, REAR OIL SEAL.....	25 - 15			
3C8	HOUSING, REVERSER GEARBOX (HI CAPACITY).....	110 - 6			
3C9	HOUSING, REVERSER GEARBOX (STANDARD)	110 - 8			
2J16	HOUSING, STEERING COLUMN (LOWER)	90 - 28			
1D19	HOUSING, THERMOSTAT, FRONT	25 - 40	1B10	IDLER ARM, ROTARY SCREEN	20 - 4
2B22	HOUSING, TRANSMISSION	50 - 14	4D7	IDLER ASSEMBLY, ADJUSTABLE AND FRONT ARM (RUBBER TRACK)	160 - 6
2C3	HOUSING, TRANSMISSION/DIFFERENTIAL	50 - 20	3J13	IDLER ASSEMBLY, CLEAN GRAIN ELEVATOR DRIVE	140 - 35
1I3	HOUSING, TRANSPORT WARNING LIGHTS	40 - 75	3J22	IDLER ASSEMBLY, DISCHARGE BEATER DRIVE.....	140 - 44
3I23	HOUSING, TWO-SPEED GEARBOX	140 - 20	3J10	IDLER ASSEMBLY, FEED ACCELERATOR	140 - 32
3I15	HOUSINGS, MAIN GEARCASE	140 - 12	3J21	IDLER ASSEMBLY, SHOE/CONVEYOR AUGER DRIVE	140 - 43
3I11	HOUSINGS, MAIN GEARCASE (9650 STS)	140 - 8	3K3	IDLER ASSEMBLY, STRAW CHOPPER DRIVE	140 - 50
3I13	HOUSINGS, MAIN GEARCASE (9750 STS)	140 - 10	3J19	IDLER ASSEMBLY, TAILINGS ELEVATOR DRIVE.....	140 - 41
3C6	HOUSINGS, REVERSER GEARBOX (HI-CAPACITY)....	110 - 4	3K6	IDLER ASSEMBLY, UNLOADER DRIVE	140 - 54
2J18	HOUSINGS, STEERING COLUMN (UPPER).....	90 - 30	3K7	IDLER ASSEMBLY, UNLOADING AUGER DRIVE SPROCKET	140 - 55
4D16	HUB, BOGEY WHEEL (RUBBER TRACK).....	160 - 16			
3J20	HUB, CHAFFER FRAME SHOE DRIVE.....	140 - 42			
3G3	HUB, CLEAN GRAIN ELEVATOR.....	130 - 6			
1B25	HUB, COUPLING, ENGINE GEARCASE	20 - 20			