

4710
SELF-PROPELLED SPRAYER



JOHN DEERE

PARTS CATALOG

4710
SELF-PROPELLED SPRAYER
PC2829 (MAR-06) English

John Deere Des Moines Works
North American Edition
Litho in U.S.A. (Revised)
COPYRIGHT © 2006
DEERE & COMPANY
Moline, Illinois
All rights reserved

NP9581

-UN-04MAY98



NP9581

*JOHN DEERE 4710 SELF-PROPELLED SPRAYER
(MANUFACTURED 2000-2004)*

(SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE)

PRODUCT IDENTIFICATION NUMBER LISTING INFORMATION

THE SPRAYER PRODUCT IDENTIFICATION NUMBER PLATE IS LOCATED ON THE LEFT SIDE OF THE FRAME, BEHIND THE CAB SUPPORT.

THE ENGINE SERIAL NUMBER IS ON THE RIGHT SIDE OF THE ENGINE BLOCK.

THE CAB SERIAL NUMBER IS ON THE INSIDE LEFT REAR CORNER OF THE CAB.

PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

-	THE PART CAN BE USED ON ALL MACHINES.
000000-	THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE PIN OR YEAR.
-000000	THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE PIN OR YEAR LISTED.
000000-000000	THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE PRODUCT IDENTIFICATION NUMBERS OR YEARS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A PRODUCT IDENTIFICATION NUMBER, A CHANGE WAS MADE BUT THE EXACT PIN WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

HOSE DIMENSIONS LISTED ARE EITHER FITTING SIZE X LENGTH X FITTING SIZE OR I.D. X LENGTH.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

ENGINE SERIAL NUMBER PLATE

TP62425 -UN-22JUN00



TORREON OPTION

TP62425

FIRST LINE (ENGINE P.I.N.)

PE - TORREON
6
068 (6.8 LITERS)
T - TURBOCHARGED
XXXXXX

DEFINES

ENGINE MANUFACTURING LOCATION.
NUMBER OF CYLINDERS.
ENGINE DISPLACEMENT
ASPIRATION TYPE
ENGINE SERIAL NUMBER

SECOND LINE (ENGINE MODEL NO.)

PE6068TN052
N (DES MOINES WORKS)
052

APPLICATION

MARKETING UNIT
SPECIFIC APPLICATION

SECTION INDEX

GENERAL INFORMATION.....	10
ENGINE.....	20
FUEL SYSTEM.....	30
ELECTRICAL SYSTEM.....	40
POWER TRAIN	50
STEERING AND BRAKES.....	60
J.D. 60' BOOM.....	65
HYDRAULIC SYSTEM	70
80/90' BOOM.....	75
SOLUTION CONTROLS	80
OPERATOR'S PLATFORM AND CAB.....	90
AUTOTRAC OPTION.....	93
MAIN FRAME AND CHASSIS.....	100
COMPRESSED AIR.....	105
DECALS	110
NUMERICAL INDEX	120

ALPHABETICAL INDEX

	PAGE		PAGE
A			
ACCESS COVER, INJECTION PUMP GEAR (ESN -173616)	20-18	ANGLE, BUMPER, WING (80/90' BOOM)	75-42
ACCESS COVER, INJECTION PUMP GEAR (ESN 173617-)	20-20	ANGLE, JACK	100-43
ACCESSORY DRIVE SUPPORT (ENGINE)	20-48	ANTENNA BASE	40-54
ACCUMULATOR (60' BOOM)	65-16	ANTENNA CABLE	40-54
ACCUMULATOR (80/90' BOOM)	75-15	ANTENNA, RADIO	40-53
ACCUMULATOR,HOSES,FITTING, TO LIFT CYL. (80/90' BOOM)	75-15	ANTENNA, RADIO	40-54
ACCUMULATOR,HOSES,FITTINGS TO LIFT CYL. J.D.60' BOOM	65-16	ANTI-VORTEX PLATE, EDUCTOR	80-50
ACTUATOR, REMOTE THROTTLE AND LADDER	40-56	ANTI-VORTEX PLATE, EDUCTOR	80-52
ACTUATOR, SINGLE VAVLE ASSY. (S/N 2024-)	80-64	APRON, BELOW GRILLE	100-34
ACTUATOR, THROTTLE	30-28	ARM, LIFT (J.D. 60' BOOM)	65-18
ADAPTER, AUXILIARY PUMP MOUNTING	70-16	ARM, LIFT (80/90' BOOM)	75-28
ADAPTER, ENGINE OIL FILTER	20-28	ARM, STEERING	100-14
ADAPTER, HYDROSTATIC PUMP MOUNTING	50-36	ARM, WINDSHIELD WIPER	90-82
ADAPTER,ENGINE OIL COOLER	20-30	ARMREST	90-40
ADJUST, OPERATOR'S SEAT (S/N 4001-)	90-46	ARMREST ADJUST (S/N -XXXXXX)	90-39
ADJUSTER, ARMREST (S/N -XXXXXX)	90-39	ARMREST AND CONSOLE DECALS	110-4
AGITATION AND RINSE FITTINGS, SOLUTION TANK (INSIDE) (S/N - 4000)	80-2	ARMREST SKIRTS AND SUPPORT	90-42
AGITATION FITTINGS, SOLUTION TANK (S/N -4000)	80-10	ARMREST WIRING HARNESS	40-27
AGITATION, SOLUTION SYSTEM NOZZLES (S/N -2023)	80-28	ARMREST, LEFT-HAND (S/N -4000)	90-36
AGITATION, SOLUTION SYSTEM NOZZLES (S/N 2024-)	80-30	ARMREST, OPERATOR'S SEAT	90-48
AGITATOR NOZZLE, SOLUTION TANK (S/N - 4000)	80-2	ARMS, ROCKER	20-13
AIR CIRCULATION DUCT	90-18	ASHTRAY	90-40
AIR CLEANER	30-8	ASHTRAY	90-62
AIR COMPRESSOR GASKET KIT, ON BOARD AIR	105-6	ASPIRATOR HOSE	30-6
AIR COMPRESSOR, ON BOARD	105-4	ASSEMBLY, STRAINER	80-69
AIR CONDITIONING COMPRESSOR	90-1	ATTACHMENT HARDWARE (80/90' BOOM)	75-38
AIR CONDITIONING COMPRESSOR CLUTCH AND STATOR	90-4	ATTENUATOR, AIR SEAT (S/N -XXXXXX)	90-34
AIR CONDITIONING CONDENSER AND LINES	90-6	AUTOTRAC ADAPTER WIRING HARNESS AND SEAT SWITCH (4710 MY2001 AND 2002 ONLY)	93-13
AIR FILTER RESTRICTION SENSOR	30-10	AUTOTRAC HARNESS AND SWITCH	93-2
AIR FILTER, CAB PRESSURIZER	90-14	AUTOTRAC PRIORITY VALVE	93-4
AIR INTAKE	30-10	AUTOTRAC STEERING AND EH VALVES	93-8
AIR INTAKE MANIFOLD	30-26	AUTOTRAC STEERING CONTROLLER	93-10
AIR PRESSURE INDICATOR, CAB	90-16	AUTOTRAC STEERING CONTROLLER	93-11
AIR SEAT RIDE KITS (S/N -XXXXXX)	90-34	AUTOTRAC WHEEL ANGLE SENSOR	93-6
AIR SEAT SUSPENSION (S/N -4000)	90-30	AUXILIARY HYDRAULIC PUMP	70-18
AIR SPRING, FRONT SUSPENSION (S/N 2384-)	100-18	AUXILIARY HYDRAULIC PUMP HOSES AND FITTINGS	70-10
AIR SPRING, FRONT SUSPENSION (S/N- 2383)	100-16	AUXILIARY POWER STRIP	40-66
AIR SPRING, REAR SUSPENSION	100-24	AUXILIARY PUMP MOUNTING	70-16
AIR SPRING, REAR SUSPENSION	100-26	AXLE, FRONT	100-14
AIR SUSPENSION, OPERATOR'S SEAT WEAR PARTS KIT (S/N 4001-)	90-54	AXLE, REAR	100-22
AIR SUSPENSION, OPERATOR'S SEAT, LOWER (S/N 4001-)	90-50	B	
AIR SUSPENSION, OPERATOR'S SEAT, UPPER (S/N 4001-)	90-52	BACK, SEAT (S/N -4000)	90-28
ALTERNATOR	40-28	BACKREST SUPPORTS, SEAT (S/N -4000)	90-38
ALTERNATOR MOUNTING	40-32	BAFFLE, HOOD	100-32
ANEROID LINE, FUEL INJECTION SYSTEM	30-22	BASE, ANTENNA	40-54
		BASE, SOLUTION TANK	80-18
		BATTERY AND CABLES (-6000)	40-2
		BATTERY AND CABLES (6001-)	40-3
		BATTERY BOX	100-8
		BATTERY BOX COVER	100-8
		BEARING KIT, SEAT (S/N -XXXXXX)	90-32
		BEARING, CRANKSHAFT THRUST	20-6
		BEARINGS, MAIN	20-6
		BEARINGS,CONNECTING ROD	20-9

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
BELT, ARMREST ADJUSTER (S/N -XXXXXX)	90-39	BRACKET, CABLE ANCHOR, HYDROSTATIC PUMP MOUNTING (S/N -4000)	50-2
BELT, FAN, ON BOARD AIR	105-4	BRACKET, CHEMICAL EDUCTOR (S/N -4000)	80-44
BELT, FAN, WITHOUT ON BOARD AIR	20-44	BRACKET, CLEAN WATE RINSE TANK	80-124
BELT, SEAT (S/N -4000)	90-28	BRACKET, EDUCTOR HOPPER (S/N -4000)	80-50
BEZEL, RADIO	40-50	BRACKET, EDUCTOR HOPPER (S/N 4001-)	80-52
BEZEL, ROOD FRONT WORK LIGHT	40-33	BRACKET, EDUCTOR, WITH WHEEL SHIELDS (S/N 4001-)	80-46
BLADE, WINDSHIELD WIPER	90-82	BRACKET, EXHAUST PIPE	30-14
BLEED HOSE, SOLUTION TANK (S/N -4000)	80-6	BRACKET, FENDER	100-30
BLEED HOSE, SOLUTION TANK (TOP) (S/N 4001-)	80-8	BRACKET, FINAL FUEL FILTER	30-18
BLOCK, CYLINDER	20-2	BRACKET, FIRE EXTINGUISHER	100-44
BLOWER AND FILTER, CAB PRESSURIZER	90-14	BRACKET, FRONT WHEEL MOTOR (S/N 2384-)	100-18
BLOWER, HEATER/AIR CONDITIONING MODULE (S/N -2174)	90-10	BRACKET, FRONT WHEEL MOTOR (S/N- 2383)	100-16
BODY, SINGLE NOZZLE	65-28	BRACKET, GREENSTAR DISPLAY MONITOR	40-59
BOOK, SPRAY MANAGEMENT GUIDE	80-125	BRACKET, GREENSTAR™ DISPLAY MOUNTING	40-6
BOOM FIELD LAMPS	40-41	BRACKET, HORN	40-67
BOOM FOLD CYLINDER, J.D. 60' BOOM	65-11	BRACKET, JACK POINT	100-43
BOOM FOLD SWITCH, FOOT CONTROL	40-14	BRACKET, KEY AND START AID SWITCHES	40-1
BOOM FOLD, INNER, HYDRAULIC CYLINDER (-4000)	75-4	BRACKET, LEFT-HAND LADDER AND PLATFORM	100-6
BOOM FOLD, INNER, HYDRAULIC CYLINDER (4001-)	75-5	BRACKET, LOAD CENTER	40-20
BOOM HARDWARE, J.D. 60' BOOM	65-4	BRACKET, MOBILE RADIO	90-8
BOOM LEVELING CYLINDER, J.D. 60' BOOM	65-10	BRACKET, MOUNTING, J.D. 60' BOOM	65-4
BOOM LIFT CYLINDER	75-6	BRACKET, OIL COOLER AND CONDENSER	70-8
BOOM SOLUTION VALVE (S/N -2023)	80-60	BRACKET, RADAR SENSOR	40-63
BOOM SOLUTION VALVE (S/N 2024-)	80-62	BRACKET, RADIO	40-50
BOOM TILT CYLINDER (80/90' BOOM)	75-3	BRACKET, REAR WHEEL MOTOR	100-24
BOOM VALVE (J.D. 60' BOOM)	65-20	BRACKET, REAR WHEEL MOTOR	100-26
BOOM VALVE (80/90' BOOM, BASIC)	75-12	BRACKET, RIGHT-HAND LADDER	100-4
BOOM VALVES AND HOSES	80-36	BRACKET, RINSE TANK	80-116
BOOM VALVES AND HOSES (S/N -2023)	80-40	BRACKET, SINGLE NOZZLE BODY CUSTOM KIT	65-28
BOOM VALVES AND HOSES (S/N -2023)	80-28	BRACKET, SMV EMBLEM (80/90' AND LESS BOOM)	100-45
BOOM VALVES AND HOSES (S/N 2024-)	80-30	BRACKET, SOLUTION PUMP AND QUICK FILL (S/N -4000)	80-32
BOOM VALVES AND HOSES (S/N 2024-)	80-42	BRACKET, STARTING CIRCUIT RELAY	40-35
BOOM WIRING HARNESS (60' BOOM)	65-24	BRACKET, STEERING VALVE	60-9
BOOM WIRING HARNESS (80/90' BOOM)	75-10	BRACKET, TRANSPORT (J.D 60' BOOM)	65-23
BOOM, 80' AND 90' HOSE DROPS	75-52	BRACKET, TRIPLET NOZZLE	65-32
BOOST/JAM/SHUTTLE VALVE (COMBO VALVE) (4001-)	50-42	BRACKET, 60' FOAM DROP (6001-)	80-103
BOOT, SEAT SUSPENSION (S/N -XXXXXX)	90-32	BRACKET, 90' FOAM DROP (6001-)	80-101
BOWL, WATER SEPERATOR FOR FUEL FILTER (EXPORT OPTION)	30-30	BRACKET,WORK LAMP	40-42
BOX, COMPRESSOR (35 GALLON) FOAM MARKER (ON-BOARD-AIR)	80-78	BRACKETS AND WIRING HARNESS, GREENSTAR_t	m 040-6
BOX, COMPRESSOR (35 GALLON) FOAM MARKER (12 VOLT)	80-77	BRACKETS, END MOUNTING (80/90' BOOM)	75-34
BOX, STORAGE, LH PLATFORM	100-8	BRACKETS, SPRAYMASTER CUSTOM PLUMBING (80/90' BOOM)	75-46
BRACKET, AIR CLEANER	30-8	BRACKETS, TRANSPORT (60/80' BOOM)	100-48
BRACKET, AUXILIARY POWER STRIP	40-66	BRACKETS, TRANSPORT (60/90' BOOM)	100-48
BRACKET, BOOM SOLUTION VALVE (S/N -2023)	80-60	BRACKETS, VALVE	50-44
BRACKET, BOOM SOLUTION VALVE (S/N 2024-)	80-62	BRACKETS, SPRAYMASTER CUSTOM PLUMBING (80/90' BOOM)	75-45
BRACKET, CAB SIDE	100-42	BRAKE CALIPER	60-18
		BRAKE HOSES AND FITTINGS, PARK (REAR DRIVE MOTORS)	50-8
		BRAKE HOSES AND FITTINGS, SERVICE (REAR DRIVE MOTORS)	50-6
		BRAKE PEDAL	60-16
		BRAKE SWITCH, PARK (IN ARMREST)	90-58
		BRAKE VALVE	50-26

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
BRAKE VALVE, SERVICE	60-19	CABLE, SIDE PANEL.....	100-34
BRAKE, REAR DISK	60-14	CABLE, TEMPERATURE CONTROL	40-64
BREAKAWAY STOP, WING (80/90' BOOM)	75-42	CABLE, TEMPERATURE CONTROL	
BREAKAWAY WING (80/90' BOOM)	75-40	(S/N 2174 -).....	90-12
BREAKAWAY WING, J.D. 60' BOOM	65-6	CABLE, THROTTLE ACTUATOR.....	30-28
BREATHER, FUEL TANK.....	30-2	CABLE, WIRING	40-74
BRUSH, ALTERNATOR	40-28	CALIBRATION KIT	80-125
BRUSH, NOZZLE TIP	80-125	CALIPER, BRAKE ASSEMBLY	60-18
BULB, DOME LIGHT	40-43	CALIPER, REAR BRAKE.....	60-14
BULB, HEADLIGHT AND SIDELIGHT.....	40-36	CAM FOLLOWER	20-13
BULB, ROOF WARNING LIGHT.....	40-37	CAM, ARMREST ADJUSTER	
BULB,CAB WORKLAMP	40-42	(S/N -XXXXXX).....	90-39
BUMPER (80/90' BOOM)	75-32	CAMSHAFT	20-12
BUMPER ANGLE, WING (80/90' BOOM).....	75-42	CAMSHAFT GEAR	20-12
BUMPER, J.D. 60' BOOM.....	65-4	CAN BUS WIRING HARNESS	
BUMPER, TRANSPORT BRACKETS (60/80' BOOM)	100-48	SN (-4000).....	40-24
BUMPER, TRANSPORT BRACKETS (60/90' BOOM)	100-48	CAN BUS WIRING HARNESS	
BUS WIRING HARNESS, CAN		SN (4001-).....	40-25
SN (-4000).....	40-24	CAP, CLEAN WATER RINSE TANK	80-124
BUS WIRING HARNESS, CAN		CAP, ENGINE OIL FILLER.....	20-23
SN (4001-).....	40-25	CAP, FUEL TANK	30-2
BUSHING, FRONT SUSPENSION.....	100-20	CAP, HYDRAULIC/HYDROSTATIC OIL RESERVOIR	
BUSHING, REAR SUSPENSION	100-28	(S/N -4000).....	70-2
BYPASS FITTING, HYDRAULIC OIL COOLER	70-4	CAP, HYDRAULIC/HYDROSTATIC OIL RESERVOIR	
BYPASS HOSE, SOLUTION TANK		(S/N 4001-).....	70-3
(S/N -4000).....	80-6	CAP, MAIN BEARING	20-2
BYPASS HOSE, SOLUTION TANK (TOP)		CAP, RADIATOR	20-42
(S/N 4001-).....	80-8	CAUTION DECALS.....	110-2
		CENTER FRAME, J.D. 60' BOOM.....	65-8
		CENTER FRAME, MOUNTED, SUSPENDED	
		(80/90' BOOM)	75-30
		CHAIN, J.D. 60' BOOM	65-4
		CHAINS, BREAKAWAY WING (80/90' BOOM).....	75-40
		CHANNEL ASSEMBLY, WEIGHT BRACKET	100-46
		CHANNEL, FRAME, J.D. 60' BOOM.....	65-8
		CHANNEL, VALVE AND FILTER SUPPORT	100-2
		CHARGE PUMP, HYDROSTATIC	50-36
		CHART, CALIBRATION	80-125
		CHASSIS CONTROL UNIT.....	40-12
		CHASSIS WIRING HARNESS	
		(S/N -4000).....	40-4
		CHASSIS WIRING HARNESS	
		(S/N 4001-).....	40-6
		CHECK VALVE, HYDROSTATIC PUMP END CAP	50-34
		CHECK VALVE, PRIORITY VALVE LINE.....	70-12
		CHECK VALVE, PROPORTIONAL VALVE	
		(S/N -112).....	70-22
		CHECK VALVE, PROPORTIONAL VALVE	
		(S/N 113-).....	70-23
		CHECK VALVE, WINDSHIELD WASHER.....	90-80
		CHEMICAL EDUCTOR BRACKET	
		(S/N -4000).....	80-44
		CHEMICAL EDUCTOR HOPPER AND BRACKET	
		(S/N -4000).....	80-50
		CHEMICAL EDUCTOR HOPPER AND BRACKET	
		(S/N 4001-).....	80-52
		CHEMICAL FILL HOSE, SOLUTION TANK	
		(S/N -4000).....	80-6
		CHEMICAL FILL HOSE, SOLUTION TANK (TOP)	
		(S/N 4001-).....	80-8
		CLAMPS, ENGINE OIL FILTER TUBE	20-28
		CLAMPS, SPRAYMASTER CUSTOM PLUMBING	
		(80/90' BOOM)	75-46
		CLAMPS, SPRAYMASTER CUSTOM PLUMBING	
		(80/90' BOOM)	75-45
		CLEAN WATER RINSE TANK.....	80-124
		CLEANER, AIR	30-8

C

CAB (BASIC UNIT OR FULLY TRIMMED)	90-20
CAB AIR CIRCULATION DUCTS	90-18
CAB DOOR, LH	
(S/N -XXXX)	90-90
CAB DOOR, LH	
(S/N XXXX-)	90-92
CAB ELECTRICAL CABLES	40-26
CAB FLOOR	90-24
CAB HEADLINER	90-72
CAB MOUNTS	90-22
CAB POWER CABLE	40-22
CAB PRESSURE INDICATOR.....	90-16
CAB SIDE COVERS	100-42
CAB SUPPORTS, MAIN FRAME	100-2
CAB WIRING HARNESS	
(S/N -4000).....	40-16
CAB WIRING HARNESS	
(S/N 4001-).....	40-18
CABLE ANCHOR BRACKET, HYDROSTATIC PUMP	
MOUNTING (S/N -4000)	50-2
CABLE, ANTENNA	40-54
CABLE, BATTERY	
(-6000).....	40-2
CABLE, BATTERY	
(6001-).....	40-3
CABLE, CAB ELECTRICAL.....	40-26
CABLE, CAB POWER	40-22
CABLE, CENTER FRAME, J.D. 60' BOOM.....	65-8
CABLE, HEATER CONTROL	
(S/N -2174).....	90-10
CABLE, HYDROSTATIC CONTROL.....	90-60
CABLE, J.D. 60' BOOM	65-4
CABLE, MOBILE RADIO ANTENNA	90-8
CABLE, SEAT ADJUSTMENT	
(S/N -XXXXXX)	90-32

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CLEANING SOLUTIONS.....	80-126	COVER, ACCESS, INJECTION PUMP GEAR	
CLOTHES HOOK.....	90-77	(ESN -173616).....	20-18
COATING, EQUIPMENT.....	80-126	COVER, ARMREST.....	90-42
COIL, BRAKE VALVE.....	50-26	COVER, BATTERY BOX.....	100-8
COIL, PROPORTIONAL VALVE		COVER, CAB SIDE.....	100-42
(S/N -112).....	70-22	COVER, COWL.....	90-64
COIL, PROPORTIONAL VALVE		COVER, EDUCTOR HOPPER	
(S/N 113-).....	70-23	(S/N -4000).....	80-50
COLLECTOR ASSEMBLY, FOAM HEAD EXT.....	80-107	COVER, EDUCTOR HOPPER	
COMBO VALVE (REVERSE HYDRO BOOST, LS		(S/N 4001-).....	80-52
JAM,SHUTTLE HOSES (4001-).....	50-42	COVER, ENGINE OIL FILLER INLET.....	20-23
COMBO VALVE(LS JAM, SHUTTLE VALVE)		COVER, FEEDER PIPES, HOSES	
(4001-).....	50-42	(80/90' BOOM).....	75-54
COMPARTMENT, STORAGE, LH PLATFORM.....	100-8	COVER, FUEL TRANSFER PUMP.....	30-17
COMPENSATOR, AUXILIARY HYDRAULIC PUMP.....	70-18	COVER, INJECTION PUMP ACCESS	
COMPENSATOR, PROPORTIONAL VALVE		(ESN 173617-).....	20-20
(S/N -112).....	70-22	COVER, REAR WIPER HOLE.....	90-96
COMPENSATOR, PROPORTIONAL VALVE		COVER, RINSE TANK	
(S/N 113-).....	70-23	(S/N -4000).....	80-112
COMPRESSOR BOX, (35 GALLON) FOAM MARKER		COVER, RINSE TANK	
(ON-BOARD-AIR).....	80-78	(S/N 4001-).....	80-114
COMPRESSOR BOX, (35 GALLON) FOAM MARKER		COVER, ROCKER ARM.....	20-14
(12 VOLT).....	80-77	COVER, SOLUTION TANK	
COMPRESSOR CLUTCH.....	90-4	(S/N 4001-).....	80-4
COMPRESSOR HARDWARE KIT.....	90-3	COVER, STARTING CIRCUIT RELAY.....	40-35
COMPRESSOR SEAL KIT.....	90-2	COVER, STEERING COLUMN.....	90-64
COMPRESSOR, A/C.....	90-1	COVER, THERMOSTAT HOUSING.....	20-36
CONCENTRATE, FOAM (MARKER).....	80-126	COVER, TIMING GEAR	
CONDENSER SUPPORT.....	70-8	(ESN -173616).....	20-18
CONDENSER, LINES AND HOSES, A/C.....	90-6	COVER, TIMING GEAR	
CONNECTING ROD.....	20-9	(ESN 173617-).....	20-20
CONNECTING ROD BEARINGS.....	20-9	COVER,WORK LAMP.....	40-42
CONNECTOR, ELECTRICAL, WEATHERPACK.....	40-68	COWL ASSEMBLY.....	90-64
CONNECTOR, SUPPLEMENTARY TERMINALS.....	40-76	COWL COVER.....	90-64
CONSOLE AND ARMREST DECALS.....	110-4	CRANKSHAFT.....	20-6
CONSOLE SWITCHES AND CONTROLS, RH.....	40-64	CRANKSHAFT DAMPER.....	20-7
CONSOLE, CONTROL.....	90-62	CRANKSHAFT GEAR.....	20-6
CONTAINER, CALIBRATED.....	80-125	CRANKSHAFT PULLEY.....	20-7
CONTROL CABLE, HYDROSTATIC.....	90-60	CRANKSHAFT REAR OIL SEAL.....	20-8
CONTROL CONSOLE.....	90-62	CRANKSHAFT THRUST BEARING.....	20-6
CONTROL HANDLE, HYDROSTATIC.....	90-58	CROP SHIELDS	
CONTROL ROD, HYDROSTATIC PUMP		(S/N -4000).....	100-36
(S/N -4000).....	50-2	CROP SHIELDS	
CONTROL UNIT, CHASSIS.....	40-12	(S/N 4001-).....	100-38
CONTROL UNIT, SPRAY RATE.....	40-12	CUSHION, OPERATOR'S SEAT.....	90-48
CONTROL VALVE, EDUCTOR		CUSHION, SEAT	
(S/N -4000).....	80-54	(S/N -4000).....	90-28
CONTROL VALVE, EDUCTOR , UPPER		CUSTOM PLUMBING,SPRAYMASTER (80/90'BOOM)	
(S/N 4001-).....	80-56	CENTER WING.....	75-46
CONTROL VALVE, EDUCTOR, LOWER		CUSTOM PLUMBING,SPRAYMASTER (80/90'BOOM)	
(S/N 4001-).....	80-58	INNER, BREAKAWAY, OUTER WINGS.....	75-45
CONTROL VALVE, STEERING.....	60-12	CYLINDER BLOCK.....	20-2
CONTROL, HYDROSTATIC PUMP DISPLACEMENT.....	50-30	CYLINDER BLOCK, HYDROSTATIC PUMP.....	50-28
COOLANT HEATER 110 V.....	20-50	CYLINDER HEAD.....	20-10
COOLANT HEATER 220 V.....	20-51	CYLINDER HEAD GASKET.....	20-10
COOLANT RESERVOIRS.....	20-42	CYLINDER HEAD REMOVAL GASKET SET.....	20-35
COOLER BYPASS FITTING, HYDRAULIC OIL.....	70-4	CYLINDER LIMIT SWITCH (-4000).....	75-36
COOLER, ENGINE OIL.....	20-30	CYLINDER POSITION SENSOR (4001-).....	75-36
COOLER, HYDRAULIC OIL.....	70-6	CYLINDER, BOOM LIFT.....	75-6
COOLER, HYDRAULIC OIL.....	70-7	CYLINDER, BOOM TILT (80/90' BOOM).....	75-3
CORE, EVAPORATOR/HEATER		CYLINDER, FOLD, J.D. 60' BOOM.....	65-4
(S/N 2174 -).....	90-12	CYLINDER, FOLD, J.D. 60' BOOM.....	65-11
CORE, HEATER		CYLINDER, LEVELING, J.D. 60' BOOM.....	65-10
(S/N -2174).....	90-10	CYLINDER, LIFT (J.D. 60' BOOM).....	65-22
COUPLING, STEERING VALVE.....	60-9	CYLINDER, OUTER FOLD (80/90' BOOM).....	75-7
COURTESY LIGHT.....	40-49	CYLINDER, OUTER FOLD (80/90' BOOM).....	75-8
		CYLINDER, OUTER WING (80/90' BOOM).....	75-26

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CYLINDER, ROLL BIAS (80/90' BOOM)	75-9	EDUCTOR BRACKET WITH WHEEL SHIELDS	
CYLINDER, STANDARD TILT (80/90' BOOM)	75-2	(S/N 4001-)	80-46
CYLINDER, STEERING	60-13	EDUCTOR FITTINGS AND HOSES	
CYLINDER, TREAD ADJUST	70-26	(S/N -4000)	80-54
CYLINDER, TREAD ADJUST (FRONT)	100-14	EDUCTOR HOPPER AND BRACKET	
CYLINDER, TREAD ADJUST (REAR)	100-22	(S/N -4000)	80-50
CYLINDER, TREAD ADJUSTING HYDRAULIC	70-14	EDUCTOR HOPPER AND BRACKET	
CYLINDERS, CENTER FRAME (80/90' BOOM)	75-36	(S/N 4001-)	80-52
D			
DAMPER, CRANKSHAFT	20-7	EDUCTOR, SWINGING	80-48
DANGER DECALS	110-2	EH VALVE, AUTOTRAC	93-8
DECALS	110-6	ELBOW, ENGINE VENTILATOR HOSE	20-15
DECALS	110-8	ELECTRIC STARTING AID	40-13
DECALS	110-10	ELECTRICAL CONNECTOR SERVICE KIT	40-70
DECALS	110-12	ELECTRICAL CONNECTOR SERVICE KIT	40-72
DECALS, CONSOLE AND ARMREST	110-4	ELECTRICAL JUNCTION BLOCK	90-8
DECALS, SAFETY	110-2	ELECTRICAL JUNCTION BLOCK (CAB)	40-22
DEFROST LOUVERS	90-64	ELECTRICAL JUNCTION BLOCK (CHASSIS)	40-22
DIAPHRAGM, NOZZLE ASSEMBLY FOR 1" PIPE		ELECTRICAL TERMINALS AND CONNECTORS,	
(80/90' BOOM)	75-47	WEATHERPACK	40-68
DIAPHRAGM, NOZZLE ASSEMBLY FOR 3/4" PIPE		ELEMENT, ENGINE OIL FILTER	20-27
(60' BOOM)	65-30	ELEMENT, FINAL FUEL FILTER	30-18
DIODE	40-20	END CAP, HYDROSTATIC PUMP	50-34
DIPSTICK, ENGINE OIL	20-24	END MOUNTING BRACKETS (80/90' BOOM)	75-34
DISPLACEMENT CONTROL, HYDROSTATIC PUMP	50-30	END PLATE, VALVE (J.D. 60' BOOM)	65-20
DISPLAY MONITOR, GREENSTAR	40-59	END PLATE, VALVE (80/90' BOOM, BASIC)	75-12
DOME LIGHT AND SWITCH	40-43	ENGINE ACCESSORY DRIVE SUPPORT	20-48
DOME LIGHT SWITCH (DOOR)	40-44	ENGINE AND GRILLE WIRING HARNESS	40-8
DOOR HANDLE, INNER	90-94	ENGINE FLYWHEEL	20-16
DOOR HANDLE, LEFT HAND	90-94	ENGINE FRONT PLATE	20-17
DOOR HINGE, LEFT HAND	90-94	ENGINE MAJOR OVERHAUL GASKET SET	20-38
DOOR, LEFT-HAND	90-94	ENGINE MOUNTS	20-46
DOOR, LEFT-HAND		ENGINE OIL BY-PASS VALVE	20-2
(S/N -XXXX)	90-90	ENGINE OIL COOLER	20-30
DOOR, LEFT-HAND		ENGINE OIL COOLER ADAPTER	20-30
(S/N XXXX-)	90-92	ENGINE OIL DIPSTICK	20-24
DOOR, RIGHT-HAND OPENING	90-87	ENGINE OIL DIPSTICK TUBE	20-24
DRAIN PLUG, FUEL TANK	30-2	ENGINE OIL FILLER INLET	20-23
DRAIN PLUG, SOLUTION TANK		ENGINE OIL FILTER ELEMENT	20-27
(S/N -4000)	80-10	ENGINE OIL FILTER HEADER	20-27
DRAWER	90-100	ENGINE OIL PAN	20-26
DRIVE BELT TENSIONER SUPPORT	20-22	ENGINE OIL PRESSURE REGULATING VALVE	20-2
DRIVE MOTOR, FRONT AND REAR	50-20	ENGINE OIL PUMP	20-25
DRIVE MOTOR, WHEEL	50-10	ENGINE OIL PUMP GEAR	20-25
DRIVE SHAFT	50-24	ENGINE OIL PUMP HOUSING	20-25
DRIVE SUPPORT, ACCESSORY (ENGINE)	20-48	ENGINE OIL PUMP INTAKE	20-25
DROP HOSES, FOAM MARKER (35 GALLON)		ENGINE OVERHAUL KIT	20-40
(60' BOOM) (-6000)	80-102	ENGINE SENSORS, OIL PRESSURE	20-29
DROP HOSES, FOAM MARKER (35 GALLON)		ENGINE SENSORS, TEMPERATURE SENDERS	20-29
(80/90' BOOM) (-6000)	80-100	ENGINE SHORT BLOCK	20-4
DROPS, HOSE, 80' AND 90' BOOM	75-52	ENGINE VENTILATOR HOSE	20-15
DRYER, ON BOARD AIR	105-2	ENGINE VENTILATOR HOSE ELBOW	20-15
DUCT, AIR CIRCULATION	90-18	EVAPORATOR/HEATER CORE	
DUCT, CAB PRESSURIZER BLOWER	90-14	(S/N 2174 -)	90-12
DYE, MARKER FOAM	80-126	EVAPORATOR, AIR CONDITIONING	
E			
EDUCTOR BRACKET AND LEVER		(S/N -2174)	90-10
(S/N -4000)	80-44	EXHAUST MANIFOLD	30-11
EDUCTOR BRACKET AND LEVER		EXHAUST MANIFOLD GASKET	30-11
(S/N 4001-)	80-46	EXHAUST PIPE AND BRACKET	30-14
		EXHAUST VALVE	20-10
		EXPANSION VALVE, A/C	90-6
		EXPANSION VALVE, HEATER AND A/C	
		(S/N 2174 -)	90-12
		EXTENSION SPRING, BREAKAWAY WING	
		(80/90' BOOM)	75-40

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
F			
FAN AND FAN BELT, WITHOUT ON BOARD AIR.....	20-44	FLOWMETER CONNECTOR, TERMINAL AND SEAL	40-76
FAN BELT, ON BOARD AIR.....	105-4	FLUID, TANK CLEANER	80-126
FAN SHROUD.....	20-42	FLUSH TUBE, EDUCTOR	
FEEDER PIPES, HOSES (80/90' BOOM)	75-54	(S/N -4000).....	80-54
FENCE ROW NOZZLES		FLUSH TUBE, EDUCTOR , UPPER	
(S/N -2023).....	80-120	(S/N 4001-).....	80-56
FENCE ROW NOZZLES		FLUSH TUBE, EDUCTOR, LOWER	
(S/N 2024-).....	80-122	(S/N 4001-).....	80-58
FENDER AND SUPPORTS	100-30	FLYWHEEL HOUSING,ENGINE.....	20-8
FENDER UPHOLSTERY, L.H. (CAB)	90-66	FLYWHEEL RING GEAR	20-16
FIELD LAMPS, BOOM.....	40-41	FLYWHEEL SHIELD	50-1
FIELD OFFICE.....	90-68	FLYWHEEL, ENGINE.....	20-16
FILL STATION LIGHT.....	40-47	FOAM CONCENTRATE AND DYE, MARKER.....	80-126
FILTER RESTRICTION SENSOR, AIR	30-10	FOAM DROP BRACKET, 60'	
FILTER, AIR	30-8	(6001-).....	80-103
FILTER, CAB FRESH AIR	90-14	FOAM DROP BRACKET, 90'	
FILTER, FINAL FUEL.....	30-18	(6001-).....	80-101
FILTER, HEATER/AIR CONDITIONING		FOAM HEAD EXTENSION, COLLECTOR ASSY.....	80-107
(S/N -2174).....	90-10	FOAM MAKER (35 GALLON) DROP HOSES AND	
FILTER, HYDRAULIC	70-12	BRACKETS (60' BOOM) (-6000)	80-102
FILTER, HYDROSTATIC PUMP	50-27	FOAM MARKER (35 GALLON) BRACKETS	80-72
FILTER, RECIRCULATING AIR		FOAM MARKER (35 GALLON) BRACKETS	80-74
(S/N -2174).....	90-10	FOAM MARKER (35 GALLON) DROP HOSES AND	
FINAL FUEL FILTER.....	30-18	BRACKETS (DUAL DROP KIT OPTION).....	80-106
FINAL FUEL FILTER BRACKET	30-18	FOAM MARKER (35 GALLON) HARNESS ASSEMBLY	80-110
FINAL FUEL FILTER HEATER	30-18	FOAM MARKER (35 GALLON) HARNESS ASSEMBLY	
FINAL FUEL FILTER SERVICE KIT	30-18	DUAL OPTION KIT.....	80-111
FINGER GUARD, ENGINE	20-48	FOAM MARKER (35 GALLON) TANK	80-72
FIRE EXTINGUISHER AND BRACKET	100-44	FOAM MARKER (35 GALLON) TANK	80-74
FITTINGS, FEEDER PIPES, HOSES		FOAM MARKER (35 GALLON) VALVE ASSEMBLY	
(80/90' BOOM).....	75-54	(FUID CIRCUIT)(ON-BOARD-AIR)	80-84
FITTINGS, HOSES, END PORT, VALVE		FOAM MARKER (35 GALLON) VALVE ASSEMBLY	
(80/90' BOOM)	75-14	(FUID CIRCUIT)(12 VOLT).....	80-82
FITTINGS, HOSES, FOLDING CYLINDERS		FOAM MARKER (35 GALLON) WIRING HARNESS.....	80-110
(80/90' BOOM).....	75-18	FOAM MARKER (35 GALLON) WIRING HARNESS	
FITTINGS, HOSES, HYDRO PUMP		DUAL OPTION KIT.....	80-111
(S/N 4001-).....	50-4	FOAM MARKER COMPRESSOR BOX (35 GALLON)	
FITTINGS, HOSES, LEVELING CYLINDER		(ON-BOARD-AIR).....	80-78
J.D. 60' BOOM.....	65-14	FOAM MARKER COMPRESSOR BOX (35 GALLON)	
FITTINGS, HOSES, LEVELING CYLINDERS		(12 VOLT)	80-77
(80/90' BOOM).....	75-16	FOAM MARKER QUICK FILL (35 GALLON)	80-109
FITTINGS, HOSES, LIFT CYLINDER		FOAM MARKER 3-WAY VALVE ASSEMBLY	80-79
(80/90' BOOM)	75-15	FOAM MARKER(35 GALLON)DROP HOSES AND	
FITTINGS, HOSES, LIFT CYLINDER		BRACKETS (80/90' BOOM) (-6000)	80-100
J.D. 60' BOOM.....	65-16	FOAM MARKER, (35 GALLON) BRACKETS	80-94
FITTINGS, HOSES, OUTER FOLD CYLINDERS		FOAM MARKER, (35 GALLON) TANK	80-94
(80/90' BOOM) (S/N -4000).....	75-20	FOAM MARKER, MOTOR AND PUMP HOUSING (35	
FITTINGS, HOSES, OUTER FOLD CYLINDERS		GALLON).....	80-80
(80/90' BOOM) (S/N 4001-).....	75-22	FOAM MARKER, MOTOR AND PUMP HOUSING (35	
FITTINGS, HOSES, SOLUTION PRESSURE.....	80-38	GALLON) (12 VOLT)	80-108
FITTINGS, HOSES, SOLUTION TANK BOTTOM		FOAM MARKER, 12 VOLT, TUBES AND HOSES	
(S/N 4001 -).....	80-12	(35 GALLON) (AIR CIRCUIT).....	80-90
FITTINGS, HOSES, VALVE, FOLD CYLINDER		FOAM MARKER,12 VOLT (35 GALLON) BRACKETS	80-96
J.D. 60' BOOM.....	65-12	FOAM MARKER,12 VOLT (35 GALLON) TANK	80-96
FITTINGS, HOSES, VALVE, J.D. 60' BOOM	65-17	FOAM MARKER,12 VOLT, TUBES AND HOSES	
FITTINGS, SOLUTION TANK (INSIDE)		(35 GALLON)(AIR CIRCUIT).....	80-86
(S/N - 4000).....	80-2	FOAM PAD SEAL, LOWER RADIATOR.....	70-8
FITTINGS, VALVE, ROLL BIAS CYLINDER		FOAM PAD SEAL, UPPER RADIATOR	20-42
(80/90' BOOM)	75-24	FOLD CYLINDER, J.D. 60' BOOM.....	65-4
FLANGE, AUXILIARY PUMP MOUNTING	70-16	FOLD CYLINDER, J.D. 60' BOOM.....	65-11
FLOOD LIGHT WIRING HARNESS, OUTER.....	40-11	FOLLOWER,CAM	20-13
FLOOR MAT	90-26	FOOT CONTROL SWITCH, BOOM FOLD	40-14
FLOOR, CAB	90-24	FOOTREST, CAB FLOOR	90-24
FLOTATION WHEEL.....	50-16	FRAME, CENTER, J.D. 60' BOOM	65-8
FLOWMETER ASSEMBLY	80-76	FRAME, CENTER, MOUNTED, SUSPENDED	
		(80/90' BOOM)	75-30
		FRAME, LIFT ARM (80/90' BOOM)	75-28

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
FRAME, LIFT, J.D. 60' BOOM	65-8	GEAR, ENGINE OIL PUMP	20-25
FRAME, MAIN	100-2	GEAR, FLYWHEEL	20-16
FRAME, OUTER (80/90' BOOM)	75-44	GEAR, FUEL INJECTION PUMP DRIVE	30-22
FRAME, OUTER WING (80/90' BOOM)	75-26	GEAR, HUB, FRONT (23.5:1)	50-12
FRAME, SOLUTION TANK SUPPORT	80-18	GEAR, HUB, REAR (30:1 RATIO)	50-14
FRONT AND REAR DRIVE MOTORS	50-20	GLASS, CAB FRONT	90-84
FRONT AND REAR DRIVE MOTORS	50-22	GLASS, DOOR, RIGHT-HAND OPENING	90-87
FRONT AND REAR WIPER ASSEMBLY KIT	90-82	GLOW PLUG, ELECTRIC STARTING AID	40-13
FRONT AXLE	100-14	GREENSTAR DISPLAY MONITOR	40-59
FRONT DRIVE MOTORS	50-20	GREENSTAR _{tm} DISPLAY MOUNTING BRACKET	40-6
FRONT HUB (23.5:1)	50-12	GREENSTAR _{tm} WIRING HARNESS AND BRACKETS	40-6
FRONT OIL SEAL (ESN -173616)	20-18	GRILLE AND SIDE SHIELDS	100-34
FRONT PLATE, ENGINE	20-17	GRILLE WIRING HARNESS	40-8
FRONT SEAL (ESN 173617-)	20-20	GRILLE, RADIO SPEAKER	40-52
FRONT STEERING LIGHTS		GROMMET, REAR WINDOW	90-74
(-4000)	40-38	GROUND CABLE, CAB	40-26
FRONT STEERING LIGHTS		GROUND CABLE, STARTER	
(4001-)	40-39	(-6000)	40-2
FRONT SUNSHADE KIT	90-98	GROUND CABLE, STARTER	
FRONT SUSPENSION (S/N 2384-)	100-18	(6001-)	40-3
FRONT SUSPENSION (S/N- 2383)	100-16	GUARD, CROP	
FRONT SUSPENSION SEALS AND BUSHINGS	100-20	(S/N -4000)	100-36
FRONT WHEEL SHIELDS	100-40	GUARD, CROP	
FRONT WINDOW	90-84	(S/N 4001-)	100-38
FUEL FILTER FUEL LINES, FINAL	30-18	GUARD, DRIVE SHAFT	50-24
FUEL FILTER WATER SEPERATOR BOWL OPTION	30-30	GUARD, WHEEL	100-40
FUEL INJECTION NOZZLE	30-25	GUIDE, HYDROSTATIC CONTROL CABLE	90-60
FUEL INJECTION PUMP	30-22		
FUEL INJECTION PUMP ANEROID LINE	30-22	H	
FUEL INJECTION PUMP DRIVE GEAR	30-22	HAND CLEANER	80-126
FUEL INJECTION PUMP LINES	30-20	HAND OPERATED VALVE, 2" QUICK FILL	80-26
FUEL INJECTION PUMP LUBE LINE	30-22	HAND OPERATED VALVE, 3" QUICK FILL	
FUEL INJECTION PUMP SOLENOID SHUT-OFF	30-24	(S/N 4001-)	80-24
FUEL INJECTION SYSTEM ANEROID LINE	30-22	HANDLE, HYDROSTATIC CONTROL	90-58
FUEL LINES, FINAL FUEL FILTER	30-18	HANDRAIL, LEFT-HAND PLATFORM	100-6
FUEL TANK	30-2	HANDRAIL, LH (60 FT. BOOM)	100-10
FUEL TANK SUPPORTS	30-4	HANDRAIL, RH	100-12
FUEL TRANSFER PUMP COVER	30-17	HANDRAILS, L.H. (80/90 FT. BOOM)	100-11
FUSE	40-20	HARDWARE KIT, COMPRESSOR	90-3
		HARDWARE KIT, SERVICE BRAKE VALVE	60-19
G		HARDWARE, ATTACHMENT (80/90' BOOM)	75-38
GASKET KIT FOR ON BOARD AIR COMPRESSOR	105-6	HARDWARE, J.D. 60' BOOM	65-4
GASKET SET,CYLINDER HEAD REMOVAL	20-35	HARNESS ASSY., FOAM MARKER (35 GALLON)	80-110
GASKET SET,ENGINE MAJOR OVERHAUL	20-38	HARNESS ASSY., FOAM MARKER (35 GALLON)	
GASKET SET,IN CHASSIS OVERHAUL	20-35	DUAL OPTION KIT	80-111
GASKET, AIR INTAKE MANIFOLD	30-26	HARNESS, ARMREST WIRING	40-27
GASKET, CYLINDER	20-10	HARNESS, BOOM WIRING (60' BOOM)	65-24
GASKET, ENGINE OIL FILTER ADAPTER	20-28	HARNESS, BOOM WIRING (80/90' BOOM)	75-10
GASKET, EXHAUST MANIFOLD	30-11	HARNESS, CAB WIRING	
GASKET, OIL PAN	20-26	(S/N -4000)	40-16
GASKET, ROCKER ARM COVER	20-14	HARNESS, CAB WIRING	
GASKET, THERMOSTAT HOUSING	20-36	(S/N 4001-)	40-18
GASKET, TIMING GEAR COVER		HARNESS, CAN BUS WIRING	
(ESN -173616)	20-18	SN (-4000)	40-24
GASKET, TIMING GEAR COVER		HARNESS, CAN BUS WIRING	
(ESN 173617-)	20-20	SN (4001-)	40-25
GASKET, TURBOCHARGER	30-12	HARNESS, CHASSIS WIRING	
GAUGE, EDUCTOR LEVEL		(S/N -4000)	40-4
(S/N -4000)	80-50	HARNESS, CHASSIS WIRING	
GAUGE, EDUCTOR LEVEL		(S/N 4001-)	40-6
(S/N 4001-)	80-52	HARNESS, ENGINE AND GRILLE WIRING	40-8
GAUGE, SOLUTION TANK		HARNESS, OUTER FLOOD LIGHT WIRING	40-11
(S/N -4000)	80-10	HARNESS, ROOF FRONT WORK LIGHT WIRING	40-33
GEAR, CAMSHAFT	20-12	HARNESS, ROOF WARNING LIGHT WIRING	40-37
GEAR, CRANKSHAFT	20-6	HARNESS, STARTER MOTOR WIRING	40-30

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HARNES, STARTING CIRCUIT WIRING	40-35	HOSE, BOOM VALVE	
HARNES, WHEEL SPEED SENSOR WIRING	40-10	(S/N -2023)	80-28
HARNES, WIRING, ROOF	40-34	HOSE, BOOM VALVE	
HEAD, CYLINDER	20-10	(S/N 2024-)	80-30
HEADER, ENGINE OIL FILTER	20-27	HOSE, BOOM VALVE	
HEADLIGHT	40-36	(S/N 2024-)	80-42
HEADLINER	90-72	HOSE, CLEAN WATER RINSE	80-124
HEADLINER SUPPORTS	90-72	HOSE, EDUCTOR	
HEAT SHIELD, HOOD	100-32	(S/N -4000)	80-54
HEATER / REFRIGERANT LINES	90-102	HOSE, EDUCTOR, LOWER	
HEATER AND A/C BLOWER MOTOR		(S/N 4001-)	80-58
(S/N 2174 -)	90-12	HOSE, EDUCTOR, UPPER	
HEATER AND A/C BLOWER MOTOR IMPELLER		(S/N 4001-)	80-56
(S/N 2174 -)	90-12	HOSE, ENGINE VENTILATOR	20-15
HEATER AND A/C EXPANSION VALVE		HOSE, FENCE ROW NOZZLE	
(S/N 2174 -)	90-12	(S/N -2023)	80-120
HEATER AND A/C HOUSING		HOSE, FENCE ROW NOZZLE	
(S/N 2174 -)	90-12	(S/N 2024-)	80-122
HEATER AND A/C RESISTOR		HOSE, HEATER (-XXXX)	90-101
(S/N 2174 -)	90-12	HOSE, HYDRAULIC OIL COOLER	70-6
HEATER AND A/C THERMOSTAT		HOSE, HYDRAULIC OIL COOLER	70-7
(S/N 2174 -)	90-12	HOSE, PARK BRAKE (REAR DRIVE MOTORS)	50-8
HEATER CONTROLS, CONSOLE	40-64	HOSE, PRIORITY VALVE, PROPORTIONAL VALVE	
HEATER HOSES (-XXXX)	90-101	AND PUMP DRIVE	70-12
HEATER/AIR CONDITIONING MODULE		HOSE, RADIATOR	20-42
(S/N -2174)	90-10	HOSE, SERVICE BRAKE (REAR DRIVE MOTORS)	50-6
HEATER, COOLANT 110 V	20-50	HOSE, SOLUTION SUCTION	
HEATER, COOLANT 220 V	20-51	(S/N -4000)	80-32
HEATER, FINAL FUEL FILTER	30-18	HOSE, STEERING	60-10
HIGH FLOW NOZZLE, 5 POSITION	75-50	HOSE, TREAD ADJUSTING VALVE	70-14
HIGH/LOW FLOW VALVE		HOSE, WHEEL DRIVE HYDRAULIC	50-10
(S/N -2023)	80-40	HOSE, WINDSHIELD WASHER	90-80
HIGH/LOW FLOW VALVE		HOSES AND FITTINGS, PRESSURE VALVE	
(S/N 2024-)	80-42	(S/N 4001-)	80-34
HINGE ASSEMBLY, REAR WINDOW	90-88	HOSES AND FITTINGS, SOLUTION TANK (TOP)	
HINGE, J.D. 60' BOOM	65-2	(S/N 4001-)	80-8
HOLDER, NOZZLE, 1" PIPE	75-50	HOSES AND TUBES, 12 VOLT FOAM MARKER	
HOOD AND SUPPORTS	100-32	(35 GALLON) (AIR CIRCUIT)	80-86
HOOK, CLOTHES	90-77	HOSES AND TUBES, 12 VOLT FOAM MARKER	
HOPPER BRACKET AND LEVER		(35 GALLON) (AIR CIRCUIT)	80-90
(S/N 4001-)	80-46	HOSES AND TUBES, ON-BOARD-AIR FOAM MARKER	
HOPPER BRACKET AND LEVER, CHEMICAL		(35 GALLON) (AIR CIRCUIT)	80-88
(S/N -4000)	80-44	HOSES AND TUBES, ON-BOARD-AIR FOAM MARKER	
HOPPER, EDUCTOR		(35 GALLON) (AIR CIRCUIT)	80-92
(S/N -4000)	80-50	HOSES, AIR CONDITIONING CONDENSER	90-6
HOPPER, EDUCTOR		HOSES, COMBO VALVE (4001)	50-42
(S/N 4001-)	80-52	HOSES, FITTINGS, END PORT, VALVE	
HORN	40-67	(80/90' BOOM)	75-14
HOSE AND FITTINGS, SOLUTION TANK (TOP)		HOSES, FITTINGS, END PORT, VALVE	
(S/N -4000)	80-6	J.D. 60' BOOM	65-17
HOSE DROPS, 80' AND 90' BOOM	75-52	HOSES, FITTINGS, FOLDING CYLINDERS	
HOSE FITTINGS, SOLUTION TANK		(80/90' BOOM)	75-18
(3" QUICK FILL)	80-20	HOSES, FITTINGS, HYDRO PUMP	
HOSE FITTINGS, SOLUTION TANK BOTTOM		(S/N 4001-)	50-4
(S/N -4000)	80-10	HOSES, FITTINGS, LEVELING CYLINDER	
HOSE GUARD, FRAME	100-2	J.D. 60' BOOM	65-14
HOSE GUIDE RODS	100-2	HOSES, FITTINGS, LEVELING CYLINDERS	
HOSE STRAINER (80/90' BOOM)	75-56	(80/90' BOOM)	75-16
HOSE, A/C HOUSING DRAIN		HOSES, FITTINGS, LIFT CYLINDER	
(S/N -2174)	90-10	(80/90' BOOM)	75-15
HOSE, AIR INTAKE	30-10	HOSES, FITTINGS, LIFT CYLINDER	
HOSE, AIR INTAKE MANIFOLD	30-26	J.D. 60' BOOM	65-16
HOSE, ASPIRATOR	30-6	HOSES, FITTINGS, OUTER FOLD CYLINDERS	
HOSE, AUXILIARY HYDRAULIC PUMP	70-10	(80/90' BOOM) (S/N -4000)	75-20
HOSE, BOOM VALVE	80-36	HOSES, FITTINGS, OUTER FOLD CYLINDERS	
HOSE, BOOM VALVE		(80/90' BOOM) (S/N 4001-)	75-22
(S/N -2023)	80-40	HOSES, FITTINGS, SOLUTION PRESSURE	80-38

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HOSES, FITTINGS, SOLUTION TANK BOTTOM (S/N 4001 -).....	80-12	HYDROSTATIC PUMP MOUNTING (S/N 4001 -).....	50-4
HOSES, FITTINGS, VALVE, FOLD CYLINDER J.D. 60' BOOM.....	65-12	HYDROSTATIC PUMP SHAFT AND SERVO	50-38
HOSES, HYDRAULIC PUMP SUCTION AND RETURN.....	70-4	HYDROSTATIC PUMP VALVES, PLUGS AND SEALS	50-32
HOSES, PIPES, FEEDER (80/90' BOOM)	75-54	I	
HOSES, PRIORITY VALVE HYDRAULIC (4710 MY2001 AND 2002 ONLY)(AUTOTRAC)	93-14	IDLER, FAN BELT	20-44
HOSES, VALVE, ROLL BIAS CYLINDER (80/90' BOOM)	75-24	IMPELLER, HEATER AND A/C BLOWER MOTOR (S/N 2174 -).....	90-12
HOUSING, ENGINE OIL PUMP	20-25	IMPELLER, SOLUTION PUMP.....	80-70
HOUSING, FLYWHEEL	20-8	IMPELLER, WATER PUMP (ESN -185675).....	20-33
HOUSING, HEATER AND A/C (S/N 2174 -).....	90-12	IMPELLER, WATER PUMP (ESN 185676-).....	20-34
HOUSING, HEATER/AIR CONDITIONING MODULE (S/N -2174).....	90-10	IN CHASSIS OVERHAUL GASKET SET	20-35
HOUSING, HYDROSTATIC PUMP	50-28	INDICATOR LIGHTS, CONSOLE	40-64
HOUSING, RADIO SPEAKER	40-52	INDICATOR, CAB PRESSURE.....	90-16
HOUSING, THERMOSTAT	20-36	INLET, ENGINE OIL FILLER.....	20-23
HUB WHEEL, FRONT (23.5:1).....	50-12	INLET, WATER PUMP.....	20-32
HUB WHEEL, REAR (30:1 RATIO).....	50-14	INNER DOOR HANDLE.....	90-94
HUB, FAN.....	20-44	INNER ROOF.....	90-96
HUB, FRONT (23.5:1).....	50-12	INSERT KIT, WATER PUMP (ESN 173617-).....	20-20
HUB, REAR (30:1 RATIO).....	50-14	INSIDE REAR VIEW MIRROR.....	90-75
HUB, REAR DISK BRAKE	60-14	INTAKE AIR PRECLEANER	30-6
HUB, WHEEL.....	50-16	INTAKE HOSE, AIR	30-10
HUBS AND WHEELS	50-18	INTAKE SYSTEM.....	30-8
HYDRAULIC CYLINDER - INNER BOOM FOLD (-4000).....	75-4	INTAKE VALVE.....	20-10
HYDRAULIC CYLINDER - INNER BOOM FOLD (4001-).....	75-5	INTAKE, ENGINE OIL PUMP.....	20-25
HYDRAULIC CYLINDER, LIFT (J.D. 60' BOOM).....	65-22	INTERMEDIATE WING, J.D. 60' BOOM	65-2
HYDRAULIC CYLINDER, TREAD ADJUST	70-26	J	
HYDRAULIC CYLINDERS, CENTER FRAME (80/90' BOOM)	75-36	JACK ANGLE	100-43
HYDRAULIC HOSES AND FITTINGS (PRIORITY VALVE)(4710 MY2001 AND 2002 ONLY).....	93-14	JUNCTION BLOCK, ELECTRICAL.....	90-8
HYDRAULIC HOSES, STEERING.....	60-10	JUNCTION BLOCK, ELECTRICAL (CAB)	40-22
HYDRAULIC MOTOR, SOLUTION PUMP.....	80-70	JUNCTION BLOCK, ELECTRICAL (CHASSIS).....	40-22
HYDRAULIC OIL COOLER AND HOSES	70-6	K	
HYDRAULIC OIL COOLER AND HOSES	70-7	KEY AND KEY SWITCH	40-1
HYDRAULIC PUMP HOSES AND FITTINGS, AUXILIARY	70-10	KEY AND START AID SWITCH BRACKET	40-1
HYDRAULIC PUMP SUCTION AND RETURN HOSES.....	70-4	KIT, COMPRESSOR HARDWARE	90-3
HYDRAULIC PUMP, AUXILIARY	70-18	KIT, CUSTOM, TRIPLET NOZZLE ASSEMBLY (60' BOOM)	65-30
HYDRAULIC VALVES, HOSES AND CYLINDERS, TREAD ADJUSTING.....	70-14	KIT, CUSTOM, TRIPLET NOZZLE ASSEMBLY (80'/90' BOOM).....	75-47
HYDRAULIC/HYDROSTATIC OIL RESERVOIR (S/N -4000).....	70-2	KIT, ELECTRICAL CONNECTOR SERVICE	40-70
HYDRAULIC/HYDROSTATIC OIL RESERVOIR (S/N 4001-).....	70-3	KIT, ELECTRICAL CONNECTOR SERVICE	40-72
HYDRO BOOST VALVE, REVERSE (-4000).....	50-40	KIT, ENGINE OVERHAUL	20-40
HYDRO PUMP HOSES, FITTINGS (S/N 4001-).....	50-4	KIT, ENGINE OVERHAUL GASKET	20-38
HYDRO PNEUMATIC SPRING, REAR WINDOW	90-88	KIT, FINAL FUEL FILTER SERVICE	30-18
HYDROSTATIC CONTROL CABLE.....	90-60	KIT, OPERATOR'S SEAT AIR SUSPENSION WEAR PARTS (S/N 4001-).....	90-54
HYDROSTATIC CONTROL HANDLE	90-58	KIT, PISTON/LINER	20-9
HYDROSTATIC DRIVE MOTORS AND HOSES.....	50-10	KIT, SEAL (A/C COMPRESSOR)	90-2
HYDROSTATIC PUMP DISPLACEMENT CONTROL	50-30	KIT, SEAL, NOZZLE ASSEMBLY, 1" PIPE.....	75-50
HYDROSTATIC PUMP END CAP	50-34	KIT, STARTER MOTOR BYPASS START	40-30
HYDROSTATIC PUMP FILTER AND FITTINGS.....	50-27	KIT, TERMINAL AND WIRING	40-74
HYDROSTATIC PUMP HOUSING, SWASH PLATE AND CYLINDER BLOCK	50-28	KIT, TURBOCHARGER HARDWARE	30-12
HYDROSTATIC PUMP MOUNTING	50-36	KIT, WATER PUMP INSERT (ESN 173617-).....	20-20
HYDROSTATIC PUMP MOUNTING (S/N -4000).....	50-2	KIT, WATER PUMP REPAIR (ESN -185675).....	20-33

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
KIT, WATER PUMP REPAIR (ESN 185676-)	20-34	LIFT ARM (80/90' BOOM)	75-28
KIT, WORK LAMP	40-42	LIFT BRACKET, HYDROSTATIC PUMP	50-34
KNEE, FRONT AXLE	100-14	LIFT CYLINDER (J.D. 60' BOOM)	65-22
KNEE, REAR AXLE	100-22	LIFT CYLINDER, BOOM	75-6
KNOB, ARMREST ADJUSTER		LIFT FRAME, J.D. 60' BOOM	65-8
(S/N -XXXXXX)	90-39	LIGHT SUPPORT, RH (60 FT. BOOM)	100-10
KNOB, SEAT ADJUST		LIGHT SWITCH	40-64
(S/N -XXXXXX)	90-32	LIGHT, CONSOLE INDICATOR	40-64
KNOBS, RADIO	40-50	LIGHT, COURTESY	40-49
		LIGHT, DOME	40-43
L		LIGHT, FILL STATION	40-47
LABEL, LOAD CENTER	40-20	LIGHT, HEAD AND SIDE	40-36
LABELS	110-6	LIGHT, PLATFORM	40-48
LABELS	110-8	LIGHT, ROOF FRONT WORK	40-33
LABELS	110-10	LIGHT, ROOF SIDE	40-49
LABELS	110-12	LIGHT, ROOF WARNING	40-37
LABELS, CONSOLE AND ARMREST	110-4	LIGHTER	40-64
LABELS, SAFETY	110-2	LIGHTS, FRONT STEERING	
LADDER POSITION SWITCH	40-15	(-4000)	40-38
LADDER SWITCH (ARMREST)	90-40	LIGHTS, FRONT STEERING	
LADDER, LEFT-HAND	100-6	(4001-)	40-39
LADDER, REMOTE WIRING HARNESS	40-56	LIGHTS, REAR CAB	40-40
LADDER, RIGHT-HAND	100-4	LIMIT SWITCH, CYLINDER (-4000)	75-36
LAMP, BOOM FIELD	40-41	LIMIT SWITCH, SPRAY VALVE	
LAMP, ROOF FRONT WORK	40-33	(S/N -2023)	80-66
LAMP, ROOF WARNING	40-37	LINE, FUEL INJECTION PUMP LUBE	30-22
LAMP, TAIL	40-77	LINE, HEATER (-XXXX)	90-101
LAMP, WARNING	40-45	LINES, FUEL INJECTION PUMP	30-20
LEFT-HAND ARMREST		LINES, REFRIGERANT/HEATER	90-102
(S/N -4000)	90-36	LINES, TURBOCHARGER OIL	30-13
LEFT-HAND DOOR	90-94	LINK, ASSEMBLY (80/90' BOOM)	75-44
LEFT-HAND DOOR		LINK, ATTACHMENT HARDWARE (80/90' BOOM)	75-38
(S/N -XXXX)	90-90	LINK, CENTER FRAME (80/90' BOOM)	75-32
LEFT-HAND DOOR		LINK, FRONT SUSPENSION SCISSOR	
(S/N XXXX-)	90-92	(S/N 2384-)	100-18
LEFT-HAND HANDRAILS (80/90 FT. BOOM)	100-11	LINK, FRONT SUSPENSION SCISSOR	
LEFT-HAND HANDRAILS AND RIGHT-HAND LIGHT		(S/N- 2383)	100-16
SUPPORT (60 FT. BOOM)	100-10	LINK, LEFT-HAND ARMREST	
LEFT-HAND LADDER AND PLATFORM	100-6	(S/N -4000)	90-36
LEFT-HAND PLATFORMS AND STORAGE		LINK, REAR SUSPENSION SCISSOR	100-24
COMPARTMENT	100-8	LINK, REAR SUSPENSION SCISSOR	100-26
LEFT-HAND, VALVE ASSEMBLY, 3" QUICK FILL		LOAD CENTER, TERMINAL BOARD, BRACKET AND	
(S/N -4000)	80-22	LABEL	40-20
LEVEL INDICATOR, EDUCTOR		LOAD SENSE VALVE	50-26
(S/N -4000)	80-50	LOAD SENSE, SHUTTLE VALVE (COMBO VALVE)	
LEVEL INDICATOR, EDUCTOR		(4001-)	50-42
(S/N 4001-)	80-52	LOCK, CHEMICAL EDUCTOR BRACKET	
LEVELER, HYDROSTATIC PUMP SERVO	50-38	(S/N -4000)	80-44
LEVELING CYLINDER, J.D. 60' BOOM	65-10	LOCK, EDUCTOR BRACKET	
LEVER, CHEMICAL EDUCTOR RELEASE		(S/N 4001-)	80-46
(S/N -4000)	80-44	LOUVER, SIDE PANEL	100-34
LEVER, EDUCTOR RELEASE		LOWER EDUCTOR FITTINGS AND HOSES	
(S/N 4001-)	80-46	(S/N 4001-)	80-58
LEVER, HYDROSTATIC CONTROL	90-58	LOWER RADIATOR FOAM PAD SEAL	70-8
LEVER, SEAT CONTROL		LUG NUT AND BOLT	50-16
(S/N -XXXXXX)	90-32		
LID, EDUCTOR HOPPER	80-50	M	
LID, EDUCTOR HOPPER	80-52	MAIN BEARING CAP	20-2
LID, RINSE TANK		MAIN BEARINGS	20-6
(S/N -4000)	80-112	MAIN FRAME AND SUPPORTS	100-2
LID, RINSE TANK		MANIFOLD - PRESSURE VALVE	80-68
(S/N 4001-)	80-114	MANIFOLD - SUCTION VALVE	80-67
LID, SOLUTION TANK		MANIFOLD, AIR INTAKE	30-26
(S/N 4001-)	80-4	MANIFOLD, EXHAUST	30-11
LIFT ARM (J.D. 60' BOOM)	65-18	MANIFOLD, HYDROSTATIC PUMP FILTER	50-27

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
MARKER APPLICATOR (35 GALLON)	80-72	NOZZLE, SINGLE (TEEJET)	65-25
MARKER APPLICATOR (35 GALLON)	80-74	NOZZLE, SINGLE NOZZLE	65-28
MARKER APPLICATOR ON-BOARD-AIR (35 GALLON)	80-98	NOZZLE, SOLUTION TANK RINSE (S/N - 4000)	80-2
MARKER APPLICATOR, (35 GALLON)	80-94	NOZZLE, WINDSHIELD WASHER	90-80
MARKER APPLICATOR, 12 VOLT (35 GALLON)	80-96	NOZZLES, PREDRILLED TUBES (80/90' BOOM) (SERIAL NO. XXXX-)	75-48
MARKER FOAM CONCENTRATE AND DYE	80-126	NOZZLES, SOLUTION SYSTEM AGITATION (S/N -2023)	80-28
MAT, FLOOR	90-26	NOZZLES, SOLUTION SYSTEM AGITATION (S/N 2024-)	80-30
METER, SOLUTION FLOW (S/N -2023)	80-40	O	
METER, SOLUTION FLOW (S/N -2023)	80-28	OIL COOLER AND CONDENSER SUPPORTS	70-8
METER, SOLUTION FLOW (S/N 2024-)	80-30	OIL COOLER, ENGINE	20-30
METER, SOLUTION FLOW (S/N 2024-)	80-42	OIL COOLER, HYDRAULIC	70-6
MIRROR, FRONT AXLE	100-14	OIL COOLER, HYDRAULIC	70-7
MIRROR, INSIDE REAR VIEW	90-75	OIL FILTER ADAPTER, ENGINE	20-28
MIRROR, REAR VIEW, FRONT AXLE	100-14	OIL FILTER ELEMENT, ENGINE	20-27
MIRROR, REMOTE	90-78	OIL LINES, TURBOCHARGER	30-13
MOBILE RADIO ANTENNA CABLE	90-8	OIL PAN GASKET	20-26
MOBILE RADIO BRACKET	90-8	OIL PRESSURE SENDING UNIT	20-29
MOBILE RADIO WIRING HARNESS	90-8	OIL RESERVOIR, HYDRAULIC/HYDROSTATIC (S/N -4000)	70-2
MOLDING, FRONT GLASS	90-84	OIL RESERVOIR, HYDRAULIC/HYDROSTATIC (S/N 4001-)	70-3
MONITOR, GREENSTAR DISPLAY	40-59	OIL SEAL, CRANKSHAFT REAR	20-8
MOTOR HOUSING, FOAM MARKER (35 GALLON)	80-80	OIL SEAL, FRONT (ESN -173616)	20-18
MOTOR HOUSING, FOAM MARKER (35 GALLON) (12 VOLT)	80-108	ON BOARD AIR	105-2
MOTOR, FRONT AND REAR DRIVE	50-20	ON BOARD, AIR COMPRESSOR	105-4
MOTOR, HEATER AND A/C BLOWER (S/N 2174 -)	90-12	ON-BOARD-AIR FOAM MARKER BRACKETS (35 GALLON)	80-98
MOTOR, SOLUTION PUMP	80-70	ON-BOARD-AIR FOAM MARKER TANK (35 GALLON)	80-98
MOTOR, STARTING	40-30	ON-BOARD-AIR FOAM MARKER TUBES AND HOSES (35 GALLON) (AIR CIRCUIT)	80-92
MOTOR, WHEEL	50-16	ON-BOARD-AIR FOAM MARKER TUBES AND HOSES (35 GALLON)(AIR CIRCUIT)	80-88
MOTOR, WHEEL DRIVE	50-10	OPERATOR PRESENCE SWITCH (S/N -4000)	90-44
MOTOR, WINDSHIELD WIPER	90-82	OPERATOR'S MANUAL HOLDER, SEAT BACK (S/N -4000)	90-28
MOTORS, WHEEL DRIVE	50-22	OPERATOR'S SEAT (S/N 4001-)	90-45
MOUNT, CAB	90-22	OPERATOR'S SEAT ADJUST AND PIVOT ASSEMBLIES (S/N 4001-)	90-46
MOUNT, ENGINE	20-46	OPERATOR'S SEAT AIR SUSPENSION WEAR PARTS KIT (S/N 4001-)	90-54
MOUNTED CENTER FRAME, (80/90' BOOM)	75-30	OPERATOR'S SEAT AIR SUSPENSION, LOWER (S/N 4001-)	90-50
MOUNTING ANGLE, HYDROSTATIC PUMP (S/N -4000)	50-2	OPERATOR'S SEAT AIR SUSPENSION, UPPER (S/N 4001-)	90-52
MOUNTING BRACKETS, END (80/90' BOOM)	75-34	OPERATOR'S SEAT CUSHION, ARMREST, AND MOUNTING	90-48
MOUNTING FLANGE AND ADAPTER, AUXILIARY PUMP	70-16	OPERATOR'S SEAT PIVOT AND ADJUST ASSEMBLIES (S/N 4001-)	90-46
MUFFLER	30-14	ORIFICE, TREAD ADJUSTING HYDRAULIC VALVE	70-14
N		OUTER FLOOD LIGHT WIRING HARNESS	40-11
NEUTRAL START SAFETY SWITCH	50-30	OUTER FOLD CYLINDER (80/90' BOOM)	75-7
NOZZLE ASSEMBLY FOR 1" PIPE (80/ 90' BOOM)	75-47	OUTER FOLD CYLINDER (80/90' BOOM)	75-8
NOZZLE ASSEMBLY FOR 3/4" PIPE (60' BOOM)	65-30	OUTER ROOF	90-97
NOZZLE ASSEMBLY, 1" PIPE	75-50	OUTER WING CYLINDER (80/90' BOOM)	75-26
NOZZLE KIT, TRIPLET	65-32	OUTLET, CONSOLE CONVENIENCE	40-64
NOZZLE SPACING, STANDARD 20" (80/90' BOOM)(SERIAL NO. XXXX-)	75-48	OUTLETS, AUXILIARY POWER	40-66
NOZZLE, FENCE ROW (S/N -2023)	80-120	OVERHAUL KIT, ENGINE	20-40
NOZZLE, FENCE ROW (S/N 2024-)	80-122		
NOZZLE, FUEL INJECTION	30-25		
NOZZLE, REMANUFACTURED FUEL INJECTION	30-25		
NOZZLE, SINGLE (SPRAYMASTER) (60 FT. BOOM)	65-26		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
P			
PADS, BRAKE.....	60-18	PRESSURE SENSOR, SOLUTION (S/N 2024-).....	80-42
PAN, ENGINE OIL.....	20-26	PRESSURE TRANSDUCER (S/N -2023).....	80-40
PANEL, CAB SIDE TRIM.....	100-42	PRESSURE TRANSDUCER (S/N 2024-).....	80-42
PANEL, GRILLE SIDE.....	100-34	PRESSURE VALVE, HOSES AND FITTINGS (S/N 4001-).....	80-34
PARK BRAKE HOSES AND FITTINGS (REAR DRIVE MOTORS).....	50-8	PRESSURE VALVE, MANIFOLD.....	80-68
PARK BRAKE SWITCH AND BRACKET (IN ARMREST).....	90-58	PRESSURIZER BLOWER AND FILTER.....	90-14
PARK BRAKE VALVE.....	50-26	PRIORITY VALVE (S/N -4000).....	70-24
PEDAL, PIVOT RELEASE.....	60-8	PRIORITY VALVE (S/N 4001-).....	70-25
PIPES, HOSES, FEEDER (80/90' BOOM).....	75-54	PRIORITY VALVE - STATIC SIGNAL.....	93-4
PIPES, SPRAYMASTER CUSTOM PLUMBING (80/90' BOOM).....	75-46	PRIORITY VALVE HYDRAULIC HOSES (4710 MY2001 AND 2002 ONLY)(AUTOTRAC).....	93-14
PIPES, SPRAYMASTER CUSTOM PLUMBING (80/90' BOOM).....	75-45	PRIORITY VALVE, HOSES AND FITTINGS.....	70-12
PISTON RINGS.....	20-9	PROP ROD, HOOD.....	100-32
PISTON/LINER KIT.....	20-9	PROPORTIONAL VALVE (S/N -112).....	70-22
PISTON, AUXILIARY HYDRAULIC PUMP.....	70-18	PROPORTIONAL VALVE (S/N 113-).....	70-23
PISTON, ENGINE.....	20-9	PROPORTIONAL VALVE, HOSES AND FITTINGS.....	70-12
PISTON, FRONT AND REAR DRIVE MOTOR.....	50-20	PULLEY, ALTERNATOR.....	40-28
PISTON, HYDROSTATIC PUMP SERVO.....	50-38	PULLEY, CRANKSHAFT.....	20-7
PISTON, SERVICE BRAKE VALVE.....	60-19	PULLEY, FAN.....	20-44
PIVOT (80/90' BOOM).....	75-32	PULLEY, WATER PUMP.....	20-32
PIVOT RELEASE PEDAL.....	60-8	PUMP COVER, FUEL TRANSFER.....	30-17
PIVOT, CENTER FRAME (80/90' BOOM).....	75-32	PUMP DRIVE HOSES AND FITTINGS.....	70-12
PIVOT, HYDROSTATIC CONTROL HANDLE.....	90-58	PUMP END CAP, HYDROSTATIC.....	50-34
PIVOT, OPERATOR'S SEAT (S/N 4001-).....	90-46	PUMP FILTER, HYDROSTATIC.....	50-27
PIVOT, STEERING COLUMN.....	60-4	PUMP HOSES AND FITTINGS, AUXILIARY HYDRAULIC.....	70-10
PIVOTS, BREAKAWAY WING (80/90' BOOM).....	75-40	PUMP HOUSING, FOAM MARKER (35 GALLON).....	80-80
PLANE, GROUND.....	40-54	PUMP HOUSING, FOAM MARKER (35 GALLON) (12 VOLT).....	80-108
PLASTIC (POLY) SOLUTION TANK.....	80-14	PUMP HOUSING, SWASH PLATE AND CYLINDER BLOCK, HYDROSTATIC.....	50-28
PLATE, DRIVE SHAFT GUARD.....	50-24	PUMP MOUNTING, AUXILIARY.....	70-16
PLATE, ENGINE FRONT.....	20-17	PUMP MOUNTING, HYDROSTATIC (S/N -4000).....	50-2
PLATE, SOLUTION VALVE SUPPORT (S/N -4000).....	80-32	PUMP MOUNTING, HYDROSTATIC (S/N 4001-).....	50-4
PLATFORM LIGHTS.....	40-48	PUMP SHAFT AND SERVO, HYDROSTATIC.....	50-38
PLATFORM SUPPORTS, MAIN FRAME.....	100-2	PUMP SWITCH, SOLUTION, REMOTE (S/N -4000).....	40-4
PLATFORM, LEFT-HAND.....	100-6	PUMP SWITCH, SOLUTION, REMOTE (S/N 4001-).....	40-6
PLATFORM, LEFT-HAND.....	100-8	PUMP VALVES, PLUGS AND SEALS, HYDROSTATIC.....	50-32
PLATFORM, RH.....	100-12	PUMP, AUXILIARY HYDRAULIC.....	70-18
PLUG AND SEALS, HYDROSTATIC PUMP.....	50-32	PUMP, ENGINE OIL.....	20-25
PLUG, STRAINER ASSEMBLY.....	80-69	PUMP, FUEL INJECTION.....	30-22
PLUMBING, SPRAYMASTER CUST.(80/90' BOOM) CENTER WING.....	75-46	PUMP, HYDROSTATIC CHARGE.....	50-36
PLUMBING, SPRAYMASTER CUSTOM (80/90' BOOM) INNER, BREAKAWAY, OUTER WINGS.....	75-45	PUMP, SOLUTION.....	80-70
POLY (PLASTIC) SOLUTION TANK.....	80-14	PUMP, SOLUTION (S/N -4000).....	80-32
POSITION SWITCH, LADDER.....	40-15	PUMP, WATER (ESN -185675).....	20-33
POST UPHOLSTERY (CAB).....	90-70	PUMP, WATER (ESN 185676-).....	20-34
POWER STRIP, AUXILIARY.....	40-66	PUMP, WINDSHIELD WASHER.....	90-80
PRECLEANER.....	30-6	PUSH RODS.....	20-13
PRESSURE COMPENSATOR, PROPORTIONAL VALVE (S/N -112).....	70-22		
PRESSURE COMPENSATOR, PROPORTIONAL VALVE (S/N 113-).....	70-23		
PRESSURE INDICATOR, CAB.....	90-16		
PRESSURE SENSOR CONNECTOR, TERMINAL, SEAL.....	40-76		
PRESSURE SENSOR, SOLUTION.....	80-36		
PRESSURE SENSOR, SOLUTION (S/N -2023).....	80-40		
PRESSURE SENSOR, SOLUTION (S/N -2023).....	80-28		
PRESSURE SENSOR, SOLUTION (S/N 2024-).....	80-30		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
Q			
QUICK FILL (2").....	80-26	RELAY MODULE, CAN ACTIVE	
QUICK FILL (3")		SN (4001-).....	40-25
(S/N 4001-).....	80-24	RELAY, ELECTRIC STARTING AID.....	40-13
QUICK FILL VALVE AND ADAPTER, RINSE TANK		RELAY, STARTING CIRCUIT.....	40-35
(S/N -4000).....	80-112	RELIEF VALVE, PRIORITY VALVE	
QUICK FILL VALVE AND ADAPTER, RINSE TANK		(S/N -4000).....	70-24
(S/N 4001-).....	80-114	RELIEF VALVE, PRIORITY VALVE	
QUICK FILL VALVE ASSEMBLY (3")		(S/N 4001-).....	70-25
(S/N -4000).....	80-22	REMANUFACTURED FUEL INJECTION NOZZLE.....	30-25
QUICK FILL VALVE, SOLUTION		REMOTE MIRROR.....	90-78
(S/N -4000).....	80-32	REMOTE SOLUTION PUMP SWITCH	
QUICK FILL, FOAM MARKER (35 GALLON).....	80-109	(S/N -4000).....	40-4
QUICK FILL, RINSE TANK.....	80-118	REMOTE SOLUTION PUMP SWITCH	
QUICK FILL, 3", SOLUTION TANK		(S/N 4001-).....	40-6
(S/N 4001-).....	80-4	REMOTE THROTTLE AND LADDER HARNESS.....	40-56
R			
R.H. LIGHT SUPPORT (80/90 FT. BOOM).....	100-11	REMOTE THROTTLE EXTENSION WIRING HARNESS.....	40-56
RADAR SENSOR AND BRACKET.....	40-63	REPAIR KIT, ELECTRONIC VALVE	
RADIATOR.....	20-42	(S/N -2023).....	80-66
RADIO.....	40-51	REPAIR PARTS, SPRAY VALVE	
RADIO ANTENNA.....	40-54	(2024-).....	80-65
RADIO SPEAKER, HOUSING AND GRILLE.....	40-52	RESERVOIR, COOLANT.....	20-42
RADIO, ANTENNA AND SPEAKER KIT.....	40-53	RESERVOIR, HYDRAULIC/HYDROSTATIC OIL	
RADIO, BRACKET, BEZEL AND KNOBS.....	40-50	(S/N -4000).....	70-2
RATE CONTROL POTENTIOMETER.....	40-64	RESERVOIR, HYDRAULIC/HYDROSTATIC OIL	
REAR AND FRONT DRIVE MOTORS.....	50-22	(S/N 4001-).....	70-3
REAR AXLE.....	100-22	RESERVOIR, WINDSHIELD WASHER.....	90-80
REAR CAB LIGHTS.....	40-40	RESISTOR, HEATER AND A/C	
REAR DISK BRAKE AND CALIPER.....	60-14	(S/N 2174 -).....	90-12
REAR DRIVE MOTOR PARK BRAKE HOSES		RESTRICTION SENSOR, AIR FILTER.....	30-10
AND FITTINGS.....	50-8	RESTRICTOR, AUXILIARY PUMP HYDRAULIC.....	70-10
REAR DRIVE MOTOR SERVICE BRAKE HOSES		REVERSE BOOST VALVE.....	50-26
AND FITTINGS.....	50-6	REVERSE HYDRO BOOST VALVE	
REAR DRIVE MOTORS.....	50-20	HOSES AND FITTINGS (-4000).....	50-40
REAR HUB, (30:1 RATIO).....	50-14	REVERSE HYDRO BOOST VALVE (COMBO VALVE)	
REAR SEAL, CRANKSHAFT OIL.....	20-8	(4001-).....	50-42
REAR SHIFT VALVE.....	50-26	REVERSE HYDRO BOOST, LS JAM, SHUTTLE	
REAR SPEAKER KIT.....	40-58	VALVE HOSES (4001-)(COMBO VALVE).....	50-42
REAR SUNSHADE KIT.....	90-99	RIDE KITS, SEAT	
REAR SUSPENSION.....	100-24	(S/N -XXXXXX).....	90-34
REAR SUSPENSION.....	100-26	RIGHT HAND LIGHT SUPPORT (60 FT. BOOM).....	100-10
REAR SUSPENSION SEALS AND BUSHINGS.....	100-28	RIGHT-HAND CONSOLE.....	90-62
REAR UPHOLSTERY (CAB).....	90-74	RIGHT-HAND LADDER AND SUPPORT.....	100-4
REAR VIEW MIRROR, FRONT AXLE.....	100-14	RIGHT-HAND OPENING DOOR.....	90-87
REAR VIEW MIRROR, INSIDE.....	90-75	RIGHT-HAND PLATFORM AND HANDRAILS.....	100-12
REAR WASHER KIT.....	90-80	RIM, WHEEL.....	50-16
REAR WINDOW.....	90-88	RING GEAR, FLYWHEEL.....	20-16
REAR WINDOW GROMMET.....	90-74	RINGS, PISTON.....	20-9
REAR WIPER HOLE COVER.....	90-96	RINSE AND AGITATION FITTINGS,	
RECEIVER-DRYER, A/C.....	90-6	SOLUTION TANK (INSIDE) (S/N - 4000).....	80-2
RECIRCULATING AIR FILTER		RINSE HOSE, SOLUTION TANK	
(S/N -2174).....	90-10	(S/N -4000).....	80-6
RECTIFIER, ALTERNATOR.....	40-28	RINSE HOSE, SOLUTION TANK (TOP)	
REFLECTORS.....	110-8	(S/N 4001-).....	80-8
REFLECTORS.....	110-12	RINSE LINE, EDUCTOR	
REFRIGERANT / HEATER LINES.....	90-102	(S/N -4000).....	80-54
REFRIGERANT, COMPRESSOR, AIR CONDITIONER.....	90-1	RINSE LINE, EDUCTOR , UPPER	
REGULATOR, ALTERNATOR.....	40-28	(S/N 4001-).....	80-56
RELAY.....	40-20	RINSE LINE, EDUCTOR, LOWER	
RELAY MODULE, CAN ACTIVE		(S/N 4001-).....	80-58
SN (-4000).....	40-24	RINSE TANK	
		(S/N -4000).....	80-112
		RINSE TANK	
		(S/N 4001-).....	80-114
		RINSE TANK QUICK FILL.....	80-118
		RINSE TANK SUPPORTS AND SHIELDS.....	80-116
		RINSE TANK, CLEAN WATER.....	80-124
		RISER, CAB FLOOR.....	90-24