

# 9930 COTTON PICKER



**JOHN DEERE**

## PARTS CATALOG

9930 COTTON PICKER

PC2172 (JUL-05) English

**John Deere Des Moines Works**

North American Edition

Litho in U.S.A. (Revised)

COPYRIGHT © 2005

DEERE & COMPANY

Moline, Illinois

All rights reserved



N38959 -UN-01JAN94



*JOHN DEERE 9930 COTTON PICKER  
(MANUFACTURED 1987 - 1996)*

*(SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE.)*

### SERIAL NUMBER LISTING INFORMATION

SERIAL NUMBER INFORMATION SHOWS ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER OR YEAR.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER OR YEAR LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS OR YEARS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

THE ENGINE SERIAL NUMBER IS LOCATED ON THE LEFT-HAND SIDE OF THE ENGINE BLOCK.  
THE MACHINE SERIAL NUMBER IS LOCATED ON THE LEFT-HAND PLATFORM SUPPORT.  
THE HYDROSTATIC MOTOR SERIAL NUMBER IS ON THE LEFT-HAND SIDE OF THE MOTOR.  
THE HYDROSTATIC PUMP SERIAL NUMBER IS ON THE TOP OF THE PUMP.  
THE HYDRAULIC PUMP SERIAL NUMBER IS ON THE LEFT-HAND SIDE OF THE PUMP.  
THE CAB SERIAL NUMBER IS ON THE LEFT-HAND INSIDE REAR CORNER OF THE CAB.

### DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

### BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

### BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

### COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

### SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.  
HOSE DIMENSIONS LISTED ARE EITHER FITTING SIZE X LENGTH X FITTING SIZE OR I.D. X LENGTH.

### CKSO SERVICE PARTS

SERVICE PARTS DESIGNATED CKSO ARE USED IN CERTAIN AREAS OF THE WORLD. IF YOUR SOURCE OF SERVICE PARTS IS IN EUROPE OR AFRICA, ORDER THESE PARTS DESIGNATED CKSO.

**Thanks very much for your reading,  
Want to get more information,  
Please click here, Then get the complete  
manual**

**JustClickHere** 

**NOTE:**

**If there is no response to click on the link above,  
please download the PDF document first, and then  
click on it.**

**Have any questions please write to me:  
[admin@servicemanualperfect.com](mailto:admin@servicemanualperfect.com)**

## SECTION INDEX

GENERAL INFORMATION . . . . .	10
ENGINE . . . . .	20
FUEL AND AIR . . . . .	30
ELECTRICAL . . . . .	40
POWER TRAIN . . . . .	50
STEERING AND BRAKES . . . . .	60
HYDRAULICS . . . . .	70
WHEELS, REAR AXLES AND SHEET METAL . . . . .	80
OPERATOR STATION . . . . .	90
PICKING UNIT LIFT . . . . .	.100
PICKING UNIT CABINET. . . . .	.110
PICKING UNIT SYSTEM. . . . .	.120
PICKING UNIT LUBRICATION SYSTEM . . . . .	.130
WATER SYSTEM. . . . .	.140
AIR SYSTEM. . . . .	.150
BASKET . . . . .	.160
DECALS . . . . .	.170
NUMERICAL INDEX. . . . .	.180

## ALPHABETICAL INDEX

	PAGE		PAGE
<b>A</b>			
ADAPTER, EXHAUST (MACH. S.N. 2481- ) . . . . .	30 - 9	BASKET LIFT HYDRAULIC TUBES AND HOSES . . . . .	70 - 28
ADJUSTMENT, SEAT (SN -18000) . . . . .	90 - 14	BASKET SUPPORTS . . . . .	160 - 4
ADJUSTMENT, SEAT (SN 18001- ) . . . . .	90 - 16	BASKET VALVE CONTROL LEVER AND LINKAGE . . . . .	160 - 2
AID COLD WEATHER . . . . .	40 - 60	BASKET, COMPLETE. . . . .	160 - 1
AIR CLEANER AND TUBES. . . . .	30 - 4	BASKET, LEFT-HAND SIDE . . . . .	160 - 8
AIR CONDITIONING COMPRESSOR (S.N. 14001- ) . . . . .	90 - 48	BATTERY, BATTERY BOX AND CABLES . . . . .	40 - 28
AIR CONDITIONING COMPRESSOR BRACKETS . . . . .	90 - 49	BEARING, CRANKSHAFT (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 40
AIR CONDITIONING COMPRESSOR PARTS . . . . .	90 - 44	BEARING, PICKER BAR (S.N. 101-8000) . . . . .	120 - 20
AIR CONDITIONING COMPRESSOR(NIPPONDENSO) (S.N. 101-2480) . . . . .	30 - 1	BEARING, PICKER BAR (S.N. 8001- ) . . . . .	120 - 22
AIR DUCTS, UPPER WITH STEPS AND HANDRAIL . . . . .	150 - 6	BEARINGS, CONNECTING ROD (MACH. S.N. 2481- ) . . . . .	20 - 20
AIR FILTER . . . . .	90 - 31	BEARINGS, CRANKSHAFT (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 34
AIR FILTER, CAB . . . . .	90 - 35	BEARINGS, MAIN (MACH. S.N. 6001- ) . . . . .	20 - 38
AIR INTAKE (MACH. S.N. 2481-6000) . . . . .	30 - 2	BELT, COTTON FAN (S.N. 101-2000) . . . . .	150 - 12
AIR INTAKE (MACH. S.N. 6001- ) . . . . .	30 - 3	BELT, COTTON FAN (S.N. 2001- ) . . . . .	150 - 14
AIR INTAKE MANIFOLD (MACH. S.N. 2481-6000) . . . . .	30 - 2	BELT, ENGINE FAN (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 66
AIR INTAKE MANIFOLD (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 1	BELT, HYDRAULIC PUMP . . . . .	70 - 1
AIR LOUVER, PANEL AND SWITCHES. . . . .	90 - 34	BELTS, ALTERNATOR (S.N. 101-2000) . . . . .	40 - 29
AIR SWITCH INSTRUMENT PANEL . . . . .	40 - 56	BELTS, ALTERNATOR (S.N. 2001- ) . . . . .	40 - 30
ALTERNATOR (90 AMP) (SERIAL NO. 2001- ) . . . . .	40 - 34	BELTS, UNIT DRIVE . . . . .	120 - 2
ALTERNATOR (90-AMP) (S.N. 101-2000) . . . . .	40 - 32	BLADE, VINE CUTTER . . . . .	120 - 30
ALTERNATOR, BRACKET, AND BELTS (S.N. 2001-) . . . . .	40 - 30	BLADE, WINDSHIELD WIPER . . . . .	90 - 39
ALTERNATOR, BRACKETS AND BELTS (SERIAL NO. 101-2000) . . . . .	40 - 29	BLOCK ASSEMBLY, SHORT (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 2
ANTENNA BRACKET KIT, LEFT-HAND . . . . .	40 - 71	BLOCK, CYLINDER . . . . .	20 - 9
ANTENNA, RADIO EXTERIOR (SEE MPC-1482) . . . . .	40 - 71	BLOCK, CYLINDER (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 4
ARMATURE. . . . .	40 - 8	BLOCK, CYLINDER (MACH. S.N. XXXXX- ) . . . . .	20 - 8
ARMATURE, STARTING MOTOR (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 20	BLOCK, CYLINDER (MACH. S.N. 2481-6000) . . . . .	20 - 6
ARMREST, SEAT (PERSONAL-POSTURE™ SEAT) . . . . .	90 - 10	BLOCK, CYLINDER, HYDROSTATIC PUMP . . . . .	50 - 18
ARMS, ROCKER (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 45	BLOCK, SHORT ENG (6359TN002 S.N. 2481- 6000/6059TN002 S.N. 6001- ) . . . . .	20 - 3
ASPIRATOR. . . . .	30 - 10	BLOWER, PRESSURIZER . . . . .	90 - 32
AUGER, BASKET COMPACTOR. . . . .	160 - 15	BOTTOM FRAMES . . . . .	110 - 2
AUXILIARY CASE . . . . .	50 - 10	BOX, BATTERY . . . . .	40 - 28
AUXILIARY UNIT DRIVE GEARS AND SHAFTS . . . . .	50 - 11	BRACKET, CONTROL VALVE . . . . .	70 - 8
AXLE KNEE AND KNUCKLE, REAR (WIDE AXLE DUAL WHEEL STEERING) . . . . .	80 - 11	BRACKET, FIRE EXTINGUISHER . . . . .	80 - 18
AXLE, FINAL DRIVE . . . . .	50 - 15	BRACKET, HEIGHT SENSING VALVE MOUNTING. . . . .	110 - 26
AXLE, REAR, ADJUSTABLE TREAD . . . . .	80 - 10	BRACKET, REAR AXLE (WIDE AXLE DUAL WHEEL STEERING) . . . . .	80 - 9
<b>B</b>			
BAFFLES . . . . .	110 - 8	BRACKET,FUEL FILTER (P.I.N. 14001- ) . . . . .	30 - 30
BAR, PICKER . . . . .	120 - 18	BRACKETS, UNIT LIFT . . . . .	100 - 2
BARS, GRID . . . . .	110 - 6	BRAKE DISKS . . . . .	60 - 8
BARS, GRID, FRONT PICKING UNIT. . . . .	110 - 7	BRAKE PEDALS AND LINKAGE . . . . .	60 - 6
BASKET COMPACTOR AUGER . . . . .	160 - 15	BRAKES . . . . .	60 - 8
BASKET COMPACTOR HYDRAULIC HOSES . . . . .	70 - 30	BRUSH KIT, REPLACEMENT STARTER . . . . .	40 - 6
BASKET CYLINDER END LUBRICATION LINES. . . . .	160 - 14	BRUSHES, STARTER. . . . .	40 - 24
BASKET DUMP HYDRAULIC CYLINDER. . . . .	70 - 40	BYPASS VALVE, ENGINE OIL (MACH. S.N. 2481- ) . . . . .	20 - 17
BASKET EXTENSION LEFT-HAND DOOR . . . . .	160 - 17	<b>C</b>	
BASKET EXTENSION, 14-INCH . . . . .	160 - 18	CAB AIR FILTER AND HOUSING . . . . .	90 - 35
BASKET HYDRAULIC CYLINDER . . . . .	70 - 39	CAB DOOR (SOUND-GARD CAB) . . . . .	90 - 24
BASKET LID LINKAGE . . . . .	160 - 12	CAB REAR UPHOLSTERY . . . . .	90 - 26
BASKET LID WITH COMPACTOR, COMPLETE . . . . .	160 - 1	CAB ROOF AND SUPPORTS . . . . .	90 - 28
BASKET LID, FRAME . . . . .	160 - 10	CAB ROOF HEADLINER . . . . .	90 - 31
BASKET LID, SCREENS, GRATES. . . . .	160 - 11	CAB TO UNIT LUBRICATION VALVE, FITTINGS, AND HOSES (S.N. 101-8000) . . . . .	130 - 10
<b>C</b>			
		CAB WINDOWS (SOUND-GARD) . . . . .	90 - 22
		CAB WIRING DIAGRAM . . . . .	40 - 50
		CAB, COMPLETE . . . . .	90 - 21

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CAB, SOUND-GARD . . . . .	90 - 21	CONTROL VALVE, HYDROSTATIC (S.N. 101-4000) . . . . .	50 - 22
CABLE, BATTERY . . . . .	40 - 28	CONTROL VALVE, HYDROSTATIC (S.N. 4001- ) . . . . .	50 - 26
CAM, PICKER BAR . . . . .	120 - 14	CONTROL, TURN SIGNAL . . . . .	40 - 43
CAMSHAFT (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 44	COOLER, ENGINE OIL (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 60
CAMSHAFT (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 42	COOLER, ENGINE OIL (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 59
CAMSHAFT GEAR (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 44	COOLER, HYDROSTATIC . . . . .	50 - 34
CAP, END, HYDROSTATIC PUMP . . . . .	50 - 18	COTTON BASKET R.H. SIDE AND FLOOR . . . . .	160 - 6
CAP, MAIN BEARING (MACH. S.N. XXXXX- ) . . . . .	20 - 8	COTTON BASKET, LEFT-HAND SIDE. . . . .	160 - 8
CAP, MAIN BEARING (MACH. S.N. 2481-6000) . . . . .	20 - 6	COTTON FAN, COMPLETE . . . . .	150 - 16
CAP, PICKER BAR . . . . .	120 - 14	COUNTERSHAFT AND SLIP CLUTCH, UNIT DRIVE . . . . .	120 - 2
CASE, AUXILIARY . . . . .	50 - 10	COUPLING, HYDROSTATIC MOTOR DRIVE . . . . .	50 - 37
CASE, DIFFERENTIAL, TRANSMISSION. . . . .	50 - 4	COVER, DOOR TRACK . . . . .	90 - 24
CASE, GEAR UNIT DRIVE . . . . .	120 - 4	COVER, FRONT, HYDROSTATIC DRIVE PUMP . . . . .	50 - 20
CHARGE PUMP, HYDROSTATIC DRIVE . . . . .	50 - 21	COVER, INSPECTION (S.N. 10001- ) . . . . .	110 - 12
CHASSIS DECALS. . . . .	170 - 4	COVER, INSPECTION (S.N. 101-10000) . . . . .	110 - 10
CIRCUIT BREAKER SUPPORT KIT . . . . .	40 - 38	COVER, KIT STARTER . . . . .	40 - 24
CIRCUIT BREAKERS . . . . .	40 - 36	COVER, RADIATOR . . . . .	80 - 2
CLEANER, AIR . . . . .	30 - 4	COVER, ROCKER ARM (6039-MACH. S.N. 2481- 6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 30
CLUSTER, GAUGE . . . . .	40 - 2	COVER, ROCKER ARM (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 22
CLUTCH, COMPRESSOR (NIPPONDENSO) . . . . .	90 - 46	COVER, SOLENOID (MACH. S.N. 8001- ) . . . . .	40 - 23
CLUTCH, LUBRICATION . . . . .	130 - 4	COVER, SOLENOID (6059) (MACH. SERIAL NO. 6001-8000) . . . . .	40 - 18
CLUTCH, LUBRICATION PUMP . . . . .	130 - 7	COVER, STARTING MOTOR SOLENOID . . . . .	40 - 4
CLUTCH, STARTING MOTOR . . . . .	40 - 24	COVER, TIMING GEAR (MACH. S.N. 2481- ) . . . . .	20 - 56
COIL, COMPRESSOR (NIPPONDENSO) . . . . .	90 - 46	COVER, TIMING GEAR (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 54
COIL, STARTING MOTOR (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 21	COVER, TRANSMISSION. . . . .	50 - 4
COLD WEATHER STARTING AID . . . . .	40 - 60	COVERS AND INNER ROOF . . . . .	90 - 30
COLUMN, STEERING . . . . .	60 - 2	CRANKSHAFT (MACH. S.N. 6001- ) . . . . .	20 - 38
COMMUTATOR, END FRAME STARTING MOTOR (6059TN002) (MACH. S.N. 6001-8000). . . . .	40 - 22	CRANKSHAFT (MACH. S.N. 2481-6000) . . . . .	20 - 36
COMPACTOR-VANE CONTROL VALVE . . . . .	70 - 11	CRANKSHAFT (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 32
COMPACTOR, BASKET, HYDRAULIC HOSES . . . . .	70 - 30	CRANKSHAFT BEARING (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 40
COMPACTOR, VANE . . . . .	160 - 16	CRANKSHAFT BEARINGS (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 34
COMPRESSOR BRACKETS, AIR CONDITIONING. . . . .	90 - 49	CRANKSHAFT DAMPER (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 41
COMPRESSOR CLUTCH PULLEY (NIPPONDENSO) . . . . .	90 - 46	CRANKSHAFT IDLER GEARS (MACH. S.N. 2481-6000) . . . . .	20 - 36
COMPRESSOR COIL (NIPPONDENSO) . . . . .	90 - 46	CRANKSHAFT IDLER GEARS (MACH. S.N. 6001- ) . . . . .	20 - 38
COMPRESSOR HARDWARE KIT (NIPPONDENSO) . . . . .	90 - 47	CRANKSHAFT KIT, UNDERSIZE (6359-MACH. SN 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 40
COMPRESSOR HEAD . . . . .	90 - 44	CRANKSHAFT PULLEY (6359-MACH. S.N. 2481- 6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 41
COMPRESSOR HOSES (NIPPONDENSO) . . . . .	90 - 42	CUSHIONS, SEAT (FABRIC). . . . .	90 - 8
COMPRESSOR PARTS. . . . .	90 - 44	CUTTER, VINE . . . . .	120 - 30
COMPRESSOR SEAL KIT . . . . .	90 - 44	CYLINDER BLOCK . . . . .	20 - 9
COMPRESSOR, AIR CONDITIONING (NIPPONDENSO) . . . . .	90 - 46	CYLINDER BLOCK (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 4
COMPRESSOR, AIR CONDITIONING (S.N. 14001- ) . . . . .	90 - 48	CYLINDER BLOCK (MACH. S.N. XXXXX- ) . . . . .	20 - 8
CONDENSER, DRIER, HOSES AND FITTINGS (NIPPONDENSO) . . . . .	90 - 42	CYLINDER BLOCK (MACH. S.N. 2481-6000) . . . . .	20 - 6
CONNECTING ROD (MACH. S.N. 2481- ) . . . . .	20 - 20	CYLINDER HEAD (MACH. S.N. 2481-6000) . . . . .	20 - 24
CONNECTING ROD BEARINGS (MACH. S.N. 2481- ) . . . . .	20 - 20	CYLINDER HEAD (MACH. S.N. 2481-6000) . . . . .	20 - 26
CONNECTING RODS (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 18		
CONNECTOR, ELECTRICAL, SERVICE KIT . . . . .	40 - 64		
CONNECTORS, ELECTRICAL, WEATHERPACK . . . . .	40 - 68		
CONSOLE (S.N. 101-4000). . . . .	90 - 1		
CONSOLE (S.N. 4001- ) . . . . .	90 - 2		
CONTROL HANDLE, HYDRO. DR. DISPLACEMENT . . . . .	50 - 28		
CONTROL HANDLE, HYDRO. DR. DISPLACEMENT (S.N. 101-4000) . . . . .	50 - 25		
CONTROL VALVE AND BRACKET . . . . .	70 - 8		
CONTROL VALVE SEAL REPAIR KIT. . . . .	70 - 10		
CONTROL VALVE, COMPACTOR-VANE . . . . .	70 - 11		
CONTROL VALVE, HEATER. . . . .	90 - 36		



## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CYLINDER HEAD		DUCT AND LADDER SUPPORT . . . . .	150 - 10
(MACH. S.N. 6001- ) . . . . .	20 - 28	DUCT, INNER . . . . .	150 - 8
CYLINDER HEAD (6359TN-02)		DUCTS, OUTER SUCTION DOOR . . . . .	150 - 6
(MACH. S.N. 101-2480) . . . . .	20 - 22		
CYLINDER HEAD GASKET		<b>E</b>	
(MACH. S.N. 2481-6000) . . . . .	20 - 24	ELBOW, EXHAUST	
CYLINDER HEAD GASKET		(MACH. S.N. 2481- ) . . . . .	30 - 9
(MACH. S.N. 2481-6000) . . . . .	20 - 26	ELECTRICAL CONNECTOR SERVICE KIT . . . . .	40 - 64
CYLINDER HEAD GASKET		ELECTRICAL TERMINALS AND CONNECTORS,	
(MACH. S.N. 6001- ) . . . . .	20 - 28	WEATHERPACK . . . . .	40 - 68
CYLINDER HEAD REMOVAL GASKET SET. . . . .	20 - 64	ELECTRICALLY OPERATED STARTING AID . . . . .	40 - 60
CYLINDER LINER		ELECTROMAGNETIC LUBRICATION PUMP CLUTCH . . . . .	130 - 7
(MACH. S.N. 2481- ) . . . . .	20 - 20	ELEMENT, FUEL FILTER . . . . .	30 - 28
CYLINDER LINER (6359TN-02) (MACH.		ELEMENT, FUEL FILTER (P.I.N. 14001- ) . . . . .	30 - 30
S.N. 101-2480) . . . . .	20 - 4	ENGINE BASIC OVERHAUL KIT	
CYLINDER LINER O-RING KIT		(P.I.N. 2481....) . . . . .	20 - 12
(MACH. S.N. 2481- ) . . . . .	20 - 20	ENGINE BASIC OVERHAUL KIT	
CYLINDER LINERS, PISTONS AND RODS		(S.N. 300000- ) . . . . .	20 - 14
(6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 18	ENGINE FAN AND BELT (6359TN-02)	
CYLINDER LUBRICATION LINES . . . . .	160 - 14	(MACH. S.N. 101-2480). . . . .	20 - 66
CYLINDER, BASKET DUMP . . . . .	70 - 40	ENGINE FAN AND BELTS (6359-MACH. S.N.	
CYLINDER, HYDRAULIC (2 X 8)		2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 69
VANE COMPACTOR. . . . .	70 - 35	ENGINE FLYWHEEL (6059-MACH.	
CYLINDER, HYDRAULIC, BASKET LIFT . . . . .	70 - 28	S.N. 6001- ) . . . . .	20 - 53
CYLINDER, STEERING, WIDE AXLE DUAL WHEEL . . . . .	70 - 38	ENGINE FLYWHEEL HOUSING 6059-MACH.	
CYLINDER, UNIT LIFT . . . . .	70 - 34	S.N. 6001- ) . . . . .	20 - 53
		ENGINE FRONT PLATE	
<b>D</b>		(MACH. S.N. 2481-6000) . . . . .	20 - 10
DAMPER, CRANKSHAFT (6359-MACH. S.N.		ENGINE FRONT PLATE (MACH. S.N. 6001- ) . . . . .	20 - 11
2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 41	ENGINE HOOD AND SCREENS . . . . .	80 - 2
DECALS . . . . .	170 - 6	ENGINE LIFT STRAPS . . . . .	20 - 7
DECALS, CHASSIS . . . . .	170 - 4	ENGINE OIL . . . . .	20 - 1
DECALS, FOREIGN . . . . .	170 - 1	ENGINE OIL COOLER (6359-MACH. S.N.	
DECALS, PICKING UNIT . . . . .	170 - 5	2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 60
DECALS, SAFETY . . . . .	170 - 2	ENGINE OIL COOLER (6359TN-02)	
DIFFERENTIAL CASE, TRANSMISSION . . . . .	50 - 4	(MACH. S.N. 101-2480). . . . .	20 - 59
DIFFERENTIAL GEARS AND SHAFTS . . . . .	50 - 14	ENGINE OIL COOLER OIL LINES (6359 MACH.	
DIMMER SWITCH . . . . .	40 - 40	S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 60
DIPSTICK, ENGINE OIL		ENGINE OIL DIPSTICK	
(MACH. S.N. 2481- ) . . . . .	20 - 17	(MACH. S.N. 2481- ) . . . . .	20 - 17
DIPSTICK, ENGINE OIL (6359TN-02) (MACH.		ENGINE OIL DIPSTICK (6359TN-02) (MACH.	
S.N. 101-2480) . . . . .	20 - 4	S.N. 101-2480) . . . . .	20 - 4
DISPLAY, MONITOR . . . . .	40 - 53	ENGINE OIL DRAIN HOSE (6359-MACH. S.N.	
DOFFER . . . . .	120 - 26	2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 47
DOFFER DRIVE TIGHTENER SPROCKET . . . . .	120 - 29	ENGINE OIL FILLER INLET	
DOFFER GAGES . . . . .	120 - 28	(MACH. S.N. 2481- ) . . . . .	20 - 16
DOME LIGHT (ROCKER TYPE) . . . . .	40 - 44	ENGINE OIL FILTER	
DOOR CAB (SOUND-GARD CAB) . . . . .	90 - 24	(MACH. S.N. 2481- ) . . . . .	20 - 17
DOOR, BASKET EXTENSION LEFT-HAND . . . . .	160 - 17	ENGINE OIL FILTER (6359TN-02) (MACH.	
DOOR, FRONT ACCESS . . . . .	150 - 1	S.N. 101-2480) . . . . .	20 - 4
DOOR, SUCTION, FRONT (S.N. 101-2000) . . . . .	150 - 2	ENGINE OIL PAN (6359-MACH. S.N.	
DOOR, SUCTION, FRONT (S.N. 2001- ) . . . . .	150 - 4	2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 47
DOOR, SUCTION, INNER. . . . .	150 - 8	ENGINE OIL PRESSURE RELIEF VALVE	
DRAIN HOSE, ENGINE OIL (6359-MACH. S.N.		(MACH. S.N. 2481- ) . . . . .	20 - 16
2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 47	ENGINE OIL PUMP (MACH. S.N. 2481- ) . . . . .	20 - 57
DRIVE HOUSING, STARTING MOTOR, 6059TN002		ENGINE OIL PUMP (6359-MACH. S.N.	
(MACH. S.N. 6001-8000) . . . . .	40 - 20	2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 49
DRIVE MOTOR, HYDROSTATIC . . . . .	50 - 30	ENGINE OVERHAUL GASKET SET . . . . .	20 - 62
DRIVE SHAFT, FINAL DRIVE . . . . .	50 - 13	ENGINE OVERHEATING SWITCH . . . . .	20 - 65
DRIVE, UNIT, GEAR CASE . . . . .	120 - 4	ENGINE PISTON	
DRUM PICKER BAR (S.N. 8001- ) . . . . .	120 - 22	(MACH. S.N. 2481- ) . . . . .	20 - 20
DRUM SLIP CLUTCH AND IDLER GEARS . . . . .	120 - 7	ENGINE SHORT BLOCK (6359TN002 S.N.	
DRUM SLIP CLUTCH AND IDLER GEARS		2481-6000/6059TN002 S.N. 6001- ) . . . . .	20 - 3
(S.N. 8001- ) . . . . .	120 - 8	ENGINE SUPPORTS AND BELT GUIDE . . . . .	20 - 74
DRUM, PICKER BAR (S.N. 101-8000) . . . . .	120 - 20	ENGINE TEMPERATURE SWITCH. . . . .	20 - 65

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
ENGINE TEMPERATURE SWITCH (MACH. S.N. 2481- ) . . . . .	20 - 71	FINAL DRIVE, GEAR AXLE . . . . .	50 - 15
ENGINE THERMOSTAT (MACH. S.N. 2481- ) . . . . .	20 - 71	FIRE EXTINGUISHER . . . . .	80 - 18
ENGINE THERMOSTAT HOUSING (MACH. S.N. 2481- ) . . . . .	20 - 71	FITTINGS, COMPRESSOR AND CONDENSOR (NIPPONDENSO) . . . . .	90 - 42
ENGINE VENT TUBE . . . . .	20 - 31	FITTINGS, LUBRICATION FILL . . . . .	130 - 8
ETHER START SWITCH . . . . .	40 - 1	FITTINGS, PUMP TO RESERVOIR . . . . .	70 - 14
ETHER STARTING FLUID . . . . .	40 - 60	FLOOR MAT . . . . .	90 - 27
EVAPORATOR AND HOSES . . . . .	90 - 38	FLOOR, COTTON BASKET . . . . .	160 - 6
EXHAUST ADAPTER (MACH. S.N. 2481- ) . . . . .	30 - 9	FLOOR, PLATFORM . . . . .	90 - 6
EXHAUST ELBOW (MACH. S.N. 2481- ) . . . . .	30 - 9	FLYWHEEL (6359-MACH. S.N. 2481-6000) . . . . .	20 - 52
EXHAUST MANIFOLD (MACH. S.N. 2481- ) . . . . .	30 - 9	FLYWHEEL (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 51
EXHAUST MANIFOLD (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 8	FLYWHEEL HOUSING (6359-MACH. S.N. 2481-6000) . . . . .	20 - 52
EXHAUST PIPE, ASPIRATOR, PRE-CLEANER . . . . .	30 - 10	FLYWHEEL HOUSING (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 50
EXHAUST VALVE INSERT (MACH. S.N. 2481-6000) . . . . .	20 - 24	FLYWHEEL HOUSING, ENGINE (6059-MACH. S.N. 6001- ) . . . . .	20 - 53
EXHAUST VALVE INSERT (MACH. S.N. 2481-6000) . . . . .	20 - 26	FLYWHEEL, ENGINE (6059-MACH. S.N. 6001- ) . . . . .	20 - 53
EXHAUST VALVE INSERT (MACH. S.N. 6601- ) . . . . .	20 - 28	FOOT FLUSH VALVE, SUPPORT & WATER LINES. . . . .	140 - 10
EXHAUST VALVES (MACH. S.N. 2481-6000) . . . . .	20 - 24	FRAME, MAIN . . . . .	80 - 1
EXHAUST VALVES (MACH. S.N. 2481-6000) . . . . .	20 - 26	FRAME, PLATFORM . . . . .	90 - 4
EXHAUST VALVES (MACH. S.N. 6001- ) . . . . .	20 - 28	FRAMES BOTTOM AND STIFFENER. . . . .	110 - 2
EXTENSION, BASKET, 14-INCH. . . . .	160 - 18	FRONT ACCESS DOOR . . . . .	150 - 1
EXTENSION, PRE-SCREENER . . . . .	30 - 6	FRONT DRUM PRESSURE PLATES . . . . .	110 - 16
EXTINGUISHER, FIRE . . . . .	80 - 18	FRONT PICKING UNIT GRID BARS . . . . .	110 - 7
F			
FAN AND BELT, ENGINE (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 66	FRONT PLATE, ENGINE (MACH. S.N. 2481-6000) . . . . .	20 - 10
FAN BELTS, ENGINE (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 69	FRONT PLATE, ENGINE (MACH. S.N. 6001- ) . . . . .	20 - 11
FAN HOUSING . . . . .	150 - 16	FRONT SUCTION DOOR AND STEPS (S.N. 101-2000) . . . . .	150 - 2
FAN IDLER AND LINKAGE . . . . .	150 - 19	FRONT SUCTION DOOR AND STEPS (S.N. 2001- ) . . . . .	150 - 4
FAN LEVER AND LINKAGE . . . . .	150 - 20	FRONT WARNING LAMP . . . . .	40 - 41
FAN PULLEY (MACH. S.N. 2481- ) . . . . .	20 - 68	FRONT WHEEL SHIELDS. . . . .	80 - 17
FAN SHAFT, SHEAVE AND ROTOR (S.N. 101-2000) . . . . .	150 - 12	FUEL FILTER . . . . .	30 - 28
FAN SHAFT, SHEAVE AND ROTOR (S.N. 2001- ) . . . . .	150 - 14	FUEL FILTER (P.I.N. 14001- ) . . . . .	30 - 30
FAN, COMPLETE COTTON . . . . .	150 - 16	FUEL FILTER AND FUEL LINES . . . . .	30 - 29
FIELD LIGHT . . . . .	40 - 46	FUEL FILTER AND LINES (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 26
FIELD LIGHT WIRING . . . . .	40 - 52	FUEL FILTER BRACKET (P.I.N. 14001- ) . . . . .	30 - 30
FILTER, AIR . . . . .	90 - 31	FUEL FILTER ELEMENT . . . . .	30 - 28
FILTER, CAB AIR . . . . .	90 - 35	FUEL FILTER ELEMENT . . . . .	30 - 29
FILTER, ENGINE OIL (MACH. S.N. 2481- ) . . . . .	20 - 17	FUEL FILTER ELEMENT (P.I.N. 14001- ) . . . . .	30 - 30
FILTER, ENGINE OIL (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 4	FUEL FILTER LINES (P.I.N. 14001- ) . . . . .	30 - 30
FILTER, FUEL . . . . .	30 - 28	FUEL INJECTION LINES (MACH. S.N. 2481-6000) . . . . .	30 - 42
FILTER, FUEL . . . . .	30 - 29	FUEL INJECTION LINES (MACH. S.N. 2481-6000) . . . . .	30 - 44
FILTER, FUEL (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 26	FUEL INJECTION LINES (6059TN002) (MACH. S.N. 6001- ) . . . . .	30 - 46
FILTER, FUEL (P.I.N. 14001- ) . . . . .	30 - 30	FUEL INJECTION LINES (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 41
FILTER, WATER (S.N. 10001- ) . . . . .	140 - 8	FUEL INJECTION NOZZLE (MACH. S.N. 2481-6000) . . . . .	30 - 34
FILTER, WATER (S.N. 101-10000) . . . . .	140 - 6	FUEL INJECTION NOZZLE (MACH. S.N. 2481-6000) . . . . .	30 - 35
FINAL DRIVE HOUSING . . . . .	50 - 13	FUEL INJECTION NOZZLE MACH. S.N. 6001- ) . . . . .	30 - 36
		FUEL INJECTION NOZZLE (STANADYNE) (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 32
		FUEL INJECTION PUMP (MACH. S.N. 2481-6000) . . . . .	30 - 42
		FUEL INJECTION PUMP (MACH. S.N. 2481-6000) . . . . .	30 - 44

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
FUEL INJECTION PUMP (6059TN002)		HARNESS, WIRING, LUBRICATION SYSTEM . . . . .	40 - 48
(MACH. S.N. 6001- ) . . . . .	30 - 46	HARNESS, WIRING, MONITOR . . . . .	40 - 54
FUEL INJECTION PUMP "STANADYNE"		HARNESS, WIRING, OPERATOR PRESENCE. . . . .	40 - 51
(6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 37	HEAD LAMP . . . . .	40 - 39
FUEL INJECTION PUMP ELECTRIC SHUT-OFF		HEAD, CYLINDER	
KIT (MACH. S.N. 2481-6000/6001- ) . . . . .	30 - 40	(MACH. S.N. 2481-6000) . . . . .	20 - 24
FUEL INJECTION PUMP REPLACEMENT PARTS		HEAD, CYLINDER	
(MACH. S.N. 2481-6000/6001- ) . . . . .	30 - 38	(MACH. S.N. 2481-6000) . . . . .	20 - 26
FUEL INJECTION SYSTEM		HEAD, CYLINDER	
(MACH. S.N. 2481-6000) . . . . .	30 - 42	(MACH. S.N. 6001- ) . . . . .	20 - 28
FUEL INJECTION SYSTEM		HEAD, CYLINDER (6359TN-02)	
(MACH. S.N. 2481-6000) . . . . .	30 - 44	(MACH. S.N. 101-2480). . . . .	20 - 22
FUEL INJECTION SYSTEM (6059TN002)		HEAD, PICKER BAR . . . . .	120 - 14
(MACH. S.N. 6001- ) . . . . .	30 - 46	HEADLINER, CAB ROOF . . . . .	90 - 31
FUEL TANK . . . . .	30 - 12	HEATER CONTROL VALVE AND HOSES . . . . .	90 - 36
FUEL TRANSFER PUMP (CORONA) (6359TN-02)		HEIGHT SENSING HYDRAULIC TUBES AND HOSES . . . . .	70 - 26
(MACH. S.N. 101-2480) . . . . .	30 - 23	HEIGHT SENSING LINKAGE, OUTER SHOE . . . . .	110 - 24
FUEL TRANSFER PUMP (MACH. S.N. 2481- ) . . . . .	30 - 24	HEIGHT SENSING UNIT VALVE	
FUEL TRANSFER PUMP (SOFABEX)		(S.N. 101-2000) . . . . .	70 - 36
(MACH. S.N. 101-2480) . . . . .	30 - 22	HEIGHT SENSING UNIT VALVE	
		(S.N. 2001- ) . . . . .	70 - 37
<b>G</b>		HEIGHT SENSING VALVE MOUNTING BRACKETS . . . . .	110 - 26
GAGES, DOFFER . . . . .	120 - 28	HEIGHT SENSING, INNER LINKAGE. . . . .	110 - 22
GASKET SET, CYLINDER HEAD REMOVAL . . . . .	20 - 64	HOOD, UNIT, R.H. AND L.H. WITH DECALS	
GASKET SET, ENGINE OVERHAUL . . . . .	20 - 62	(S.N. 10001- ) . . . . .	110 - 12
GASKET, CYLINDER HEAD		HOOD, UNIT, R.H. AND L.H. WITH DECALS	
(MACH. S.N. 2481-6000) . . . . .	20 - 24	(S.N. 101-10000) . . . . .	110 - 10
GASKET, CYLINDER HEAD		HORN . . . . .	40 - 72
(MACH. S.N. 2481-6000) . . . . .	20 - 26	HORN SWITCH . . . . .	40 - 43
GASKET, CYLINDER HEAD		HOSE, FIRE EXTINGUISHER . . . . .	80 - 18
(MACH. S.N. 6001- ) . . . . .	20 - 28	HOSES AND FITTINGS, LUBRICATION PUMP . . . . .	130 - 20
GASKET, ROCKER ARM COVER (6039-MACH.		HOSES, COMPRESSOR (NIPPONDENSO) . . . . .	90 - 42
S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 30	HOSES, HEATER . . . . .	90 - 36
GASKET, HYDRO.DR.DISPLACEMENT CTL.VALVE		HOSES, HYDRAULIC, HEIGHT SENSING. . . . .	70 - 26
GASKET, HYDRO.DR.DISPLACEMENT CTL.VALVE		HOSES, HYDRAULIC, PUMP TO RESERVOIR. . . . .	70 - 14
(S.N. 101-4000) . . . . .	50 - 25	HOSES, HYDRAULIC, UNIT LIFT . . . . .	70 - 26
GAUGES AND INDICATOR LAMPS . . . . .	40 - 2	HOSES, HYDRAULIC, VANE COMPACTOR . . . . .	70 - 32
GEAR AND AXLE, FINAL DRIVE . . . . .	50 - 15	HOSES, HYDROSTATIC COOLER . . . . .	50 - 34
GEAR AND SHAFT, TRANSMISSION . . . . .	50 - 7	HOSES, LUBRICATION, CAB TO UNIT	
GEAR CASE, UNIT DRIVE . . . . .	120 - 4	(S.N. 101-8000) . . . . .	130 - 10
GEAR, CAMSHAFT (6359-MACH. S.N.		HOSES, RADIATOR . . . . .	20 - 72
2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 44	HOSES, WATER CONTROL . . . . .	140 - 9
GEARS, DIFFERENTIAL . . . . .	50 - 14	HOUSING, DRUM SLIP CLUTCH . . . . .	120 - 7
GEARS, PICKER BAR . . . . .	120 - 16	HOUSING, DRUM SLIP CLUTCH	
GEARS, TRANSMISSION INPUT SHAFT . . . . .	50 - 12	(S.N. 8001- ) . . . . .	120 - 8
GEARS, UPPER HOUSING		HOUSING, FAN . . . . .	150 - 16
(S.N. 8001- ) . . . . .	120 - 12	HOUSING, FINAL DRIVE . . . . .	50 - 13
GEARS, UPPER HOUSING (S.N. 101-8000) . . . . .	120 - 10	HOUSING, FLYWHEEL (6359-MACH. S.N.	
GRATES, BASKET LID . . . . .	160 - 11	2481-6000) . . . . .	20 - 52
GRATES, STALK LIFTER . . . . .	110 - 18	HOUSING, FLYWHEEL (6359TN-02)	
GRID BARS AND SUPPORTS. . . . .	110 - 6	(MACH. S.N. 101-2480). . . . .	20 - 50
GRID BARS, FRONT PICKING UNIT . . . . .	110 - 7	HOUSING, HYDROSTATIC DRIVE PUMP	
GUIDE WHEEL STEERING MOTOR		(S.N. 101-2000) . . . . .	50 - 16
(S.N. 10001- ) . . . . .	60 - 10	HOUSING, HYDROSTATIC DRIVE PUMP	
GUIDE WHEEL STEERING MOTOR		(S.N. 2001- ) . . . . .	50 - 17
(S.N. 101-10000) . . . . .	60 - 9	HOUSING, STARTER DRIVE . . . . .	40 - 8
GUIDE WHEEL, SINGLE, REAR. . . . .	80 - 8	HOUSING, THERMOSTAT (6359TN-02)	
GUIDE, BELT, ENGINE . . . . .	20 - 74	(MACH. S.N. 101-2480). . . . .	20 - 70
		HOUSING, TURBOCHARGER, CENTER (6359-MACH	
<b>H</b>		S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	30 - 18
HANDRAIL, LID . . . . .	160 - 13	HOUSING, UPPER DOFFER . . . . .	120 - 24
HARDWARE KIT, COMPRESSOR (NIPPONDENSO). . . . .	90 - 47	HOUSING, UPPER DRIVE GEARS	
HARNESS, WIRING . . . . .	40 - 47	(S.N. 101-8000) . . . . .	120 - 10
		HOUSING, UPPER DRIVE GEARS	
		(S.N. 8001- ) . . . . .	120 - 12
		HOUSING, UPPER, PICKING UNIT . . . . .	110 - 4

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HYDRAULIC CYLINDER (2 X 8) VANE COMPACTOR . . . . .	70 - 35	IDLER GEARS, CRANKSHAFT (MACH. S.N. 2481-6000) . . . . .	20 - 36
HYDRAULIC CYLINDER, BASKET . . . . .	70 - 39	IDLER GEARS, CRANKSHAFT (MACH. S.N. 6001- ) . . . . .	20 - 38
HYDRAULIC CYLINDER, BASKET LIFT . . . . .	70 - 28	IDLER GEARS, DRUM SLIP CLUTCH . . . . .	120 - 7
HYDRAULIC CYLINDERS, VANE COMPACTOR . . . . .	70 - 32	IDLER GEARS, DRUM SLIP CLUTCH (S.N. 8001- ) . . . . .	120 - 8
HYDRAULIC HOOD STEERING TUBES AND FITTINGS (S.N. 10001- ) . . . . .	70 - 19	IDLER, FAN . . . . .	150 - 19
HYDRAULIC HOOD STEERING TUBES AND FITTINGS (S.N. 101-10000) . . . . .	70 - 18	INJECTION LINES, FUEL (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 41
HYDRAULIC HOSES AND FITTINGS (VANE COMPACTOR) . . . . .	70 - 32	INJECTION NOZZLE, FUEL (MACH. S.N. 2481-6000) . . . . .	30 - 34
HYDRAULIC HOSES AND TUBES, BASKET LIFT . . . . .	70 - 28	INJECTION NOZZLE, FUEL (MACH. S.N. 2481-6000) . . . . .	30 - 35
HYDRAULIC HOSES, BASKET COMPACTOR . . . . .	70 - 30	INJECTION NOZZLE, FUEL (STANADYNE) (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 32
HYDRAULIC HOSES, PUMP TO RESERVOIR . . . . .	70 - 14	INJECTION PUMP, FUEL "STANADYNE" (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 37
HYDRAULIC HOSES, WIDE AXLE DUAL WHEELS . . . . .	70 - 21	INLET, ENGINE OIL FILLER (MACH. S.N. 2481- ) . . . . .	20 - 16
HYDRAULIC MOTOR (CHAR-LYNN) . . . . .	70 - 41	INNER HEIGHT SENSING LINKAGE . . . . .	110 - 22
HYDRAULIC MOTOR (CHAR-LYNN) . . . . .	70 - 43	INNER ROOF . . . . .	90 - 30
HYDRAULIC MOTOR REPAIR KIT (WHITE) . . . . .	70 - 42	INNER ROOF AND COVERS . . . . .	90 - 30
HYDRAULIC OIL RESERVOIR . . . . .	70 - 12	INNER SUCTION DOOR AND DUCT . . . . .	150 - 8
HYDRAULIC PRESSURE LINES AND FITTINGS (CONTROL VALVE TO PUMP) . . . . .	70 - 22	INSERT, EXHAUST VALVE (MACH. S.N. 2481-6000) . . . . .	20 - 24
HYDRAULIC PUMP . . . . .	70 - 4	INSERT, EXHAUST VALVE (MACH. S.N. 2481-6000) . . . . .	20 - 26
HYDRAULIC PUMP ASSEMBLY . . . . .	70 - 3	INSERT, EXHAUST VALVE (MACH. S.N. 6001- ) . . . . .	20 - 28
HYDRAULIC PUMP MOUNTING . . . . .	70 - 1	INSERT, INTAKE VALVE (MACH. S.N. 2481-6000) . . . . .	20 - 24
HYDRAULIC PUMP OVERHAUL KIT (1.38 IN3) . . . . .	70 - 6	INSERT, INTAKE VALVE (MACH. S.N. 2481-6000) . . . . .	20 - 26
HYDRAULIC RETURN LINES AND FITTINGS (CONTROL VALVE TO RESERVOIR) . . . . .	70 - 24	INSERT, INTAKE VALVE (MACH. S.N. 6001- ) . . . . .	20 - 28
HYDRAULIC STEERING TUBES AND FITTINGS . . . . .	70 - 16	INSIDE CAB MIRROR . . . . .	90 - 40
HYDRO.DR.DISPLACEMENT CONTROL HANDLE . . . . .	50 - 28	INTAKE VALVE INSERT (MACH. S.N. 2481-6000) . . . . .	20 - 24
HYDRO.DR.DISPLACEMENT CONTROL HANDLE (S.N. 101-4000) . . . . .	50 - 25	INTAKE VALVE INSERT (MACH. S.N. 2481-6000) . . . . .	20 - 26
HYDRO.DR.DISPLACEMENT CTL.VALVE GASKET (SUNDSTRAND) . . . . .	50 - 28	INTAKE VALVE INSERT (MACH. S.N. 6001- ) . . . . .	20 - 28
HYDRO.DR.DISPLACEMENT CTL.VALVE GASKET (SUNDSTRAND) (S.N. 101-4000) . . . . .	50 - 25	INTAKE VALVES (MACH. S.N. 2481-6000) . . . . .	20 - 24
HYDRO.DR.DISPLACEMENT CTL.VALVE ORIFICE . . . . .	50 - 28	INTAKE VALVES (MACH. S.N. 2481-6000) . . . . .	20 - 26
HYDRO.DR.DISPLACEMENT CTL.VALVE ORIFICE (S.N. 101-4000) . . . . .	50 - 25	INTAKE VALVES (MACH. S.N. 6001- ) . . . . .	20 - 28
HYDROSTATIC COOLER AND HOSES . . . . .	50 - 34	INTAKE, AIR (MACH. S.N. 2481-6000) . . . . .	30 - 2
HYDROSTATIC DRIVE AUXILIARY DRIVE . . . . .	50 - 11	INTAKE, AIR (MACH. S.N. 6001- ) . . . . .	30 - 3
HYDROSTATIC DRIVE CHARGE PUMP . . . . .	50 - 21	J	
HYDROSTATIC DRIVE DISPLACEMENT VALVE (S.N. 101-4000) . . . . .	50 - 22	JOHN DEERE STARTING MOTOR (S.N. 8001- ) . . . . .	40 - 26
HYDROSTATIC DRIVE DISPLACEMENT VALVE (S.N. 4001- ) . . . . .	50 - 26	JOINT, UNIVERSAL, UNIT DRIVE . . . . .	120 - 6
HYDROSTATIC DRIVE MANIFOLD VALVE . . . . .	50 - 29	K	
HYDROSTATIC DRIVE MOTOR . . . . .	50 - 30	KIT, BASIC ENGINE OVERHAUL (P.I.N. 2481....) . . . . .	20 - 12
HYDROSTATIC DRIVE OIL LINES . . . . .	50 - 32	KIT, BASIC ENGINE OVERHAUL (S.N. 300000- ) . . . . .	20 - 14
HYDROSTATIC DRIVE OIL RESERVOIR AND MOUNTING . . . . .	50 - 36		
HYDROSTATIC DRIVE PUMP HOUSING, TRUNNION AND SERVO (S.N. 101-2000) . . . . .	50 - 16		
HYDROSTATIC DRIVE PUMP HOUSING, TRUNNION AND SERVO (S.N. 2001- ) . . . . .	50 - 17		
HYDROSTATIC DRIVE PUMP SWASHPLATE AND FRONT COVER . . . . .	50 - 20		
HYDROSTATIC MOTOR DRIVE . . . . .	50 - 37		
HYDROSTATIC PUMP DRIVE . . . . .	50 - 1		
HYDROSTATIC SPEED RANGE LEVER . . . . .	50 - 38		
I			
IDLER CLUTCH SWITCH (SER. NO. -6000) . . . . .	40 - 58		
IDLER CLUTCH SWITCH (SER. NO. 6001- ) . . . . .	40 - 59		

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
KIT, CIRCUIT BREAKER SUPPORT . . . . .	40 - 38	LINES, AIR CONDITIONING (CAB ROOF). . . . .	90 - 38
KIT, COMPRESSOR HARDWARE (NIPPONDENSO). . . . .	90 - 47	LINES, FUEL . . . . .	30 - 29
KIT, COMPRESSOR SEAL . . . . .	90 - 44	LINES, FUEL AND FUEL FILTER. . . . .	30 - 29
KIT, CONTROL VALVE SEAL REPAIR . . . . .	70 - 10	LINES, FUEL INJECTION	
KIT, COVER STARTER SOLENOID. . . . .	40 - 4	(MACH. S.N. 2481-6000) . . . . .	30 - 42
KIT, CYLINDER LINER O-RING		LINES, FUEL INJECTION	
(MACH. S.N. 2481- ) . . . . .	20 - 20	(MACH. S.N. 2481-6000) . . . . .	30 - 44
KIT, ELECTRICAL CONNECTOR SERVICE . . . . .	40 - 64	LINES, FUEL INJECTION (6059TN002)	
KIT, ENGINE OVERHAUL GASKET . . . . .	20 - 62	(MACH. S.N. 6001- ) . . . . .	30 - 46
KIT, FUEL INJECTION PUMP ELECTRIC SHUT-		LINES, FUEL INJECTION (6359TN-02)	
OFF (MACH. S.N. 2481-6000/6001- ) . . . . .	30 - 40	(MACH. S.N. 101-2480). . . . .	30 - 41
KIT, HYDRAULIC MOTOR REPAIR (WHITE). . . . .	70 - 42	LINES, HYDRAULIC STEERING . . . . .	70 - 16
KIT, HYDRAULIC PUMP OVERHAUL (1.38 IN3) . . . . .	70 - 6	LINES, OIL, HYDROSTATIC DRIVE. . . . .	50 - 32
KIT, LUBRICATOR DRIVE. . . . .	130 - 19	LINES, WATER, FOOT FLUSH. . . . .	140 - 10
KIT, PISTON AND LINER (6359TN-02_)		LINES, WATER, PRESSURE. . . . .	140 - 12
(MACH. S.N. 101-2480) . . . . .	20 - 18	LINKAGE AND SPROCKET, DOFFER DRIVE TIGHT . . . . .	120 - 29
KIT, STARTER SOLENOID COVER. . . . .	40 - 5	LINKAGE, BASKET CONTROL LEVER . . . . .	160 - 2
KIT, STARTER SOLENOID COVER. . . . .	40 - 6	LINKAGE, BASKET LID . . . . .	160 - 12
KIT, STARTER SOLENOID COVER. . . . .	40 - 16	LINKAGE, BRAKE PEDALS . . . . .	60 - 6
KIT, STARTER SOLENOID COVER. . . . .	40 - 17	LINKAGE, FAN. . . . .	150 - 19
KIT, STARTING MOTOR . . . . .	40 - 24	LINKAGE, HEIGHT SENSING OUTER SHOE . . . . .	110 - 24
KIT, STEERING CYLINDER SEAL . . . . .	70 - 38	LINKAGE, HEIGHT SENSING, INNER . . . . .	110 - 22
KIT, TERMINAL AND WIRING . . . . .	40 - 62	LINKAGE, SPEED CONTROL . . . . .	30 - 48
KIT, UNDERSIZE CRANKSHAFT (6359-MACH. SN		LINKAGE, UNIT LIFT . . . . .	100 - 5
2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 40	LINKAGE, UNIT LIFT CONTROL VALVE	
KNEE AND KNUCKLE, REAR AXLE		(SER. NO. 2001- ) . . . . .	100 - 8
(WIDE AXLE DUAL WHEEL STEERING). . . . .	80 - 11	LINKAGE, UNIT LIFT CONTROL VALVE AND	
		BASKET (SER. NO. 101-2000) . . . . .	100 - 6
L		LINKAGE, UNIT SHIFT AND LEVER . . . . .	50 - 8
LABELS, FOREIGN . . . . .	170 - 1	LOUVER, DOFFER. . . . .	110 - 14
LABELS, SAFETY . . . . .	170 - 2	LUBE LINES, PICKER BAR DRUM . . . . .	110 - 21
LAMP, FRONT WARNING. . . . .	40 - 41	LUBRICANT, SPINDLE . . . . .	130 - 3
LAMP, HEAD . . . . .	40 - 39	LUBRICATION FILL AND PRESSURE FITTINGS. . . . .	130 - 8
LAMP, REAR WARNING . . . . .	40 - 42	LUBRICATION MANIFOLD, PICKER BAR	
LAMP, STEERING WHEEL INDICATOR. . . . .	40 - 45	(S.N. 101-8000) . . . . .	130 - 14
LAMP, TAIL . . . . .	40 - 42	LUBRICATION PANEL (S.N. 101-8000) . . . . .	130 - 1
LATCH, DOOR. . . . .	90 - 24	LUBRICATION PUMP AND CLUTCH . . . . .	130 - 4
LEFT-HAND ANTENNA BRACKET KIT . . . . .	40 - 71	LUBRICATION PUMP CLUTCH . . . . .	130 - 7
LEVER, BASKET CONTROL . . . . .	160 - 2	LUBRICATION SYSTEM WIRING	
LEVER, FAN . . . . .	150 - 20	LUBRICATION SYSTEM WIRING	
LEVER, HYDROSTATIC SPEED LEVER . . . . .	50 - 38	(S.N. 8001- ) . . . . .	40 - 49
LEVER, UNIT LIFT . . . . .	100 - 4	LUBRICATION TANK AND WRAPPER . . . . .	130 - 2
LEVER, UNIT SHIFT . . . . .	50 - 8	LUBRICATION TRANSFER PUMP . . . . .	130 - 22
LID FRAME BASKET. . . . .	160 - 10	LUBRICATION TRANSFER PUMP HOSES	
LID LINKAGE, BASKET. . . . .	160 - 12	AND FITTINGS . . . . .	130 - 20
LID, BASKET COMPLETE WITH COMPACTOR . . . . .	160 - 1	LUBRICATION VALVE, CAB TO UNIT	
LID, HANDRAIL . . . . .	160 - 13	(S.N. 101-8000) . . . . .	130 - 10
LIFT STRAPS, ENGINE. . . . .	20 - 7	LUBRICATION, RESERVE PANEL . . . . .	130 - 18
LIFTERS, STALK. . . . .	110 - 18	LUBRICATION, UNIT VALVE	
LIGHT SWITCH . . . . .	40 - 1	(S.N. 2001-8000) . . . . .	130 - 12
LIGHT, DOME (ROCKER TYPE). . . . .	40 - 44	LUBRICATION, UNIT, FITTING AND HOSES	
LIGHT, FIELD . . . . .	40 - 46	(S.N. 8001- ) . . . . .	130 - 16
LINE, FUEL (6359TN-02)		LUBRICATION, UPPER UNIT MANIFOLD	
(MACH. S.N. 101-2480) . . . . .	30 - 26	(S.N. 101-8000) . . . . .	130 - 13
LINE, FUEL FILTER (P.I.N. 14001- ) . . . . .	30 - 30	LUBRICATOR DRIVE POWER KIT . . . . .	130 - 19
LINER AND PISTON KIT (6359TN-02)			
(MACH. S.N. 101-2480) . . . . .	20 - 18	M	
LINER, CYLINDER		MAGNETIC PICK-UP . . . . .	20 - 21
(MACH. S.N. 2481- ) . . . . .	20 - 20	MAIN BEARING CAP (MACH. S.N. XXXXX- ) . . . . .	20 - 8
LINER, CYLINDER (6359TN-02) (MACH.		MAIN BEARING CAP (MACH. S.N. 2481-6000) . . . . .	20 - 6
S.N. 101-2480) . . . . .	20 - 4	MAIN BEARINGS	
LINES AND FITTINGS, HYDRAULIC PRESSURE		(MACH. S.N. 6001- ) . . . . .	20 - 38
(CONTROL VALVE TO PUMP) . . . . .	70 - 22	MAIN FRAME . . . . .	80 - 1
LINES AND FITTINGS, RETURN HYDRAULIC		MAIN FRAME, STARTING MOTOR (6059TN002)	
(CONTROL VALVE TO RESERVOIR) . . . . .	70 - 24	(MACH. S.N. 6001-8000) . . . . .	40 - 21

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
MAIN WHEEL . . . . .	80 - 7	O	
MANIFOLD VALVE, HYDROSTATIC DRIVE . . . . .	50 - 29	OIL COOLER, ENGINE (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 60
MANIFOLD, AIR INTAKE (MACH. S.N. 2481-6000) . . . . .	30 - 2	OIL COOLER, ENGINE (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 59
MANIFOLD, AIR INTAKE (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 1	OIL FILLER INLET, ENGINE (MACH. S.N. 2481- ) . . . . .	20 - 16
MANIFOLD, EXHAUST (MACH. S.N. 2481- ) . . . . .	30 - 9	OIL FILTER, ENGINE (MACH. S.N. 2481- ) . . . . .	20 - 17
MANIFOLD, EXHAUST (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 8	OIL FILTER, ENGINE (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 4
MANIFOLD, LUBRICATION, UPPER UNIT (S.N. 101-8000) . . . . .	130 - 13	OIL LINES, ENGINE OIL COOLER (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 60
MANIFOLD, PICKER BAR LUBRICATION (S.N. 101-8000) . . . . .	130 - 14	OIL LINES, TURBOCHARGER (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	30 - 20
MANIFOLD, UNIT LUBRICATION (S.N. 8001- ) . . . . .	130 - 17	OIL PAN (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 46
MANIFOLD, WATER (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 70	OIL PRESSURE RELIEF VALVE (MACH. S.N. 2481- ) . . . . .	20 - 16
MAT . . . . .	90 - 27	OIL PRESSURE SENDER (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 50
MIRROR . . . . .	90 - 41	OIL PUMP (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 48
MIRROR, INSIDE CAB . . . . .	90 - 40	OIL, ENGINE . . . . .	20 - 1
MOISTENER PAD (S.N. 101-6271) . . . . .	140 - 14	OPERATOR PRESENCE INSPECTION BYPASS. . . . .	90 - 50
MOISTENER PAD (S.N. 6272- ) . . . . .	140 - 16	OPERATOR PRESENCE WIRING HARNESS . . . . .	40 - 51
MONITOR DISPLAY . . . . .	40 - 53	ORIFICE, HYDRO. DR. DISPLACEMENT CTL. VALVE . . . . .	50 - 28
MONITOR SUPPORT PANEL (S.N. 101-4000). . . . .	90 - 1	ORIFICE, HYDRO. DR. DISPLACEMENT CTL. VALVE (S.N. 101-4000) . . . . .	50 - 25
MONITOR SUPPORT PANEL (S.N. 4001- ) . . . . .	90 - 2	OVERFLOW COOLANT RESERVOIR. . . . .	20 - 73
MONITOR WIRING HARNESS . . . . .	40 - 54	OVERHAUL GASKET SET, ENGINE . . . . .	20 - 62
MOTOR, DRIVE, HYDROSTATIC. . . . .	50 - 30	OVERHAUL KIT, HYDRAULIC PUMP (1.38 IN3) . . . . .	70 - 6
MOTOR, HYDRAULIC (CHAR-LYNN). . . . .	70 - 41		
MOTOR, HYDRAULIC (CHAR-LYNN). . . . .	70 - 43	P	
MOTOR, HYDRAULIC (WHITE) . . . . .	70 - 42	PAD, MOISTENER (S.N. 101-6271). . . . .	140 - 14
MOTOR, REAR WHEEL STEERING (FOR SINGLE GUIDE WHL)(S.N. 101-10000). . . . .	60 - 9	PAD, MOISTENER (S.N. 6272- ) . . . . .	140 - 16
MOTOR, REAR WHEEL STEERING (SINGLE GUIDE WHL) (S.N. 10001- ) . . . . .	60 - 10	PAN, ENGINE OIL (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 47
MOTOR, STARTER DRIVE . . . . .	40 - 8	PAN, OIL (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 46
MOTOR, STARTING . . . . .	40 - 3	PANEL, AIR CONDITIONER . . . . .	90 - 34
MOTOR, STARTING . . . . .	40 - 4	PANEL, MONITOR AIR SWITCH . . . . .	40 - 56
MOTOR, STARTING . . . . .	40 - 12	PANELS AND SIDE SHEETS (S.N. 10001- ) . . . . .	110 - 12
MOTOR, STARTING . . . . .	40 - 14	PANELS AND SIDE SHEETS (S.N. 101-10000) . . . . .	110 - 10
MOTOR, STARTING . . . . .	40 - 24	PANELS AND SIDE SHEETS, FRONT DRUM . . . . .	110 - 14
MOTOR, STARTING (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 15	PANELS, R.H. CAB . . . . .	90 - 23
MOTOR, STARTING (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 22	PARTS, FUEL INJECTION PUMP REPLACEMENT (MACH. S.N. 2481-6000/6001- ) . . . . .	30 - 38
MOTOR, STEERING, TUBES AND FITTINGS (S.N. 10001- ) . . . . .	70 - 19	PEDALS, BRAKE AND LINKAGE. . . . .	60 - 6
MOTOR, STEERING, TUBES AND FITTINGS (S.N. 101-10000) . . . . .	70 - 18	PEDESTAL, STEERING POST. . . . .	60 - 1
MOTOR, WINDSHIELD WIPER . . . . .	90 - 39	PICKER BAR DRIVE SHAFT . . . . .	120 - 16
MOUNTING, HYDRAULIC PUMP . . . . .	70 - 1	PICKER BAR DRUM LUBE LINES . . . . .	110 - 21
MUD SCRAPERS . . . . .	80 - 6	PICKER BAR DRUM, STUD AND BEARING (S.N. 101-8000) . . . . .	120 - 20
MUD SHIELDS . . . . .	80 - 16	PICKER BAR DRUM, STUD AND BEARING (S.N. 8001- ) . . . . .	120 - 22
		PICKER BAR HEAD, CAM AND CAP . . . . .	120 - 14
N		PICKER BAR LUBRICATION MANIFOLD (S.N. 101-8000) . . . . .	130 - 14
NOZZLE, FUEL INJECTION (MACH. S.N. 2481-6000) . . . . .	30 - 34	PICKER BAR, SPINDLE AND WRENCH . . . . .	120 - 18
NOZZLE, FUEL INJECTION (MACH. S.N. 2481-6000) . . . . .	30 - 35	PICKING UNIT DECALS . . . . .	170 - 5
NOZZLE, FUEL INJECTION (MACH. S.N. 6001- ) . . . . .	30 - 36	PICKING UNIT HOUSING. . . . .	110 - 1
NOZZLE, FUEL INJECTION (STANADYNE) (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 32		

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
PICKING UNIT UPPER HOUSING . . . . .	110 - 4	RADIATOR COOLANT RESERVOIR . . . . .	20 - 73
PIPE, EXHAUST . . . . .	30 - 10	RADIATOR SUPPORTS . . . . .	80 - 4
PISTON AND LINER KIT (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 18	RADIO, (SEE MPC-1482) . . . . .	40 - 71
PISTON RINGS (MACH. S.N. 2481- ) . . . . .	20 - 20	REAR AXLE BRACKET (WIDE AXLE DUAL WHEEL STEERING) . . . . .	80 - 9
PISTON, ENGINE (MACH. S.N. 2481- ) . . . . .	20 - 20	REAR AXLE KNEE AND KNUCKLE (WIDE AXLE DUAL WHEEL STEERING) . . . . .	80 - 11
PLANT SHIELD (MAIN FRAME) . . . . .	80 - 15	REAR AXLE TIE RODS (WIDE AXLE DUAL WHEEL STEERING) . . . . .	80 - 12
PLATE, ENGINE FRONT (MACH. S.N. 2481-6000) . . . . .	20 - 10	REAR AXLE, ADJUSTABLE TREAD . . . . .	80 - 10
PLATES, PRESSURE, FRONT DRUM . . . . .	110 - 16	REAR DRUM PRESSURE PLATES . . . . .	110 - 17
PLATES, PRESSURE, REAR DRUM . . . . .	110 - 17	REAR HOOD SCREENS AND RADIATOR SUPPORTS . . . . .	80 - 4
PLATFORM FLOOR AND SKIRTS . . . . .	90 - 6	REAR POSTS AND BAFFLES . . . . .	110 - 8
PLATFORM FRAME . . . . .	90 - 4	REAR WARNING LAMP AND TAIL LAMP . . . . .	40 - 42
POST, FRONT DRUM . . . . .	110 - 14	REAR WHEEL STEERING MOTOR (FOR SINGLE GUIDE WHL)(S.N. 101-10000) . . . . .	60 - 9
POSTS, REAR. . . . .	110 - 8	REAR WHEEL STEERING MOTOR (SINGLE GUIDE WHL) (S.N. 10001- ) . . . . .	60 - 10
POWER STEERING VALVE . . . . .	60 - 4	REAR WHEELS . . . . .	80 - 14
PRE-CLEANER . . . . .	30 - 10	REFRIGERANT, AIR CONDITIONER (S.N. 14001- ) . . . . .	90 - 48
PRE-SCREENER EXTENSION . . . . .	30 - 6	RELAYS AND CIRCUIT BREAKERS . . . . .	40 - 36
PRESSURE PLATE, REAR DRUM . . . . .	110 - 17	RELAYS, FIELD LIGHT . . . . .	40 - 52
PRESSURE PLATES, FRONT DRUM . . . . .	110 - 16	RELIEF VALVE, ENGINE OIL PRESSURE (MACH. S.N. 2481- ) . . . . .	20 - 16
PRESSURE SWITCH, COTTON FAN. . . . .	40 - 56	REPAIR KIT, CONTROL VALVE SEAL. . . . .	70 - 10
PRESSURE WATER LINES AND FITTINGS. . . . .	140 - 12	REPLACEMENT STARTER . . . . .	40 - 12
PRESSURIZER BLOWER. . . . .	90 - 32	REPLACEMENT STARTER . . . . .	40 - 24
PULLEY, COMPRESSOR (NIPPONDENSO) . . . . .	90 - 46	RESERVE LUBRICATION PANEL . . . . .	130 - 18
PULLEY, CRANKSHAFT (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 41	RESERVOIR, COOLANT OVERFLOW . . . . .	20 - 73
PULLEY, FAN (MACH. S.N. 2481- ) . . . . .	20 - 68	RESERVOIR, HYDRAULIC OIL . . . . .	70 - 12
PUMP DRIVE, HYDROSTATIC. . . . .	50 - 1	RESERVOIR, OIL HYDROSTATIC DRIVE . . . . .	50 - 36
PUMP, CHARGE, HYDROSTATIC DRIVE . . . . .	50 - 21	RINGS, PISTON (MACH. S.N. 2481- ) . . . . .	20 - 20
PUMP, ENGINE OIL (MACH.S.N. 2481- ) . . . . .	20 - 57	ROCKER ARM COVER (6039-MACH. S.N. 2481- 6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 30
PUMP, ENGINE OIL (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 49	ROCKER ARM COVER (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 22
PUMP, FUEL INJECTION (MACH. S.N. 2481-6000) . . . . .	30 - 42	ROCKER ARM COVER GASKET (6039-MACH.S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 30
PUMP, FUEL INJECTION (MACH. S.N. 2481-6000) . . . . .	30 - 44	ROCKER ARM SHAFT (6359-MACH. S.N. 2481- 6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 45
PUMP, FUEL INJECTION (6059TN002) (MACH. S.N. 6001- ) . . . . .	30 - 46	ROCKER ARM SHAFT (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 42
PUMP, FUEL INJECTION "STANADYNE" (6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 37	ROCKER ARMS (6359-MACH.S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 45
PUMP, FUEL INJECTION, REPLACEMENT PARTS (MACH. S.N. 2481-6000/6001- ) . . . . .	30 - 38	ROCKSHAFT . . . . .	100 - 1
PUMP, FUEL TRANSFER (CORONA)(6359TN-02) (MACH. S.N. 101-2480) . . . . .	30 - 23	ROCKSHAFT . . . . .	100 - 2
PUMP, FUEL TRANSFER (MACH. S.N. 2481- ) . . . . .	30 - 24	ROCKSHAFT PIVOT LUBRICATION LINES . . . . .	160 - 14
PUMP, FUEL TRANSFER (SOFABEX) (MACH. S.N. 101-2480) . . . . .	30 - 22	ROCKSHAFT, BASKET . . . . .	160 - 8
PUMP, HYDRAULIC . . . . .	70 - 3	ROD, CONNECTING (MACH. S.N. 2481- ) . . . . .	20 - 20
PUMP, HYDRAULIC . . . . .	70 - 4	RODS, CONNECTING (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 18
PUMP, LUBRICATION . . . . .	130 - 4	RODS, PUSH (6359-MACH. S.N. 2481-6000/ 6059-MACH. S.N. 6001- ) . . . . .	20 - 45
PUMP, LUBRICATION TRANSFER. . . . .	130 - 22	RODS, STALKLIFTER. . . . .	110 - 20
PUMP, OIL (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 48	ROOF, CAB . . . . .	90 - 28
PUMP, WATER. . . . .	140 - 5	ROOF, INNER . . . . .	90 - 30
PUMP, WATER (MACH. S.N. 2481- ) . . . . .	20 - 68	ROTOR, COTTON FAN (S.N. 101-2000) . . . . .	150 - 12
PUMP, WATER, . . . . .	140 - 4	ROTOR, COTTON FAN (S.N. 2001- ) . . . . .	150 - 14
PUSH RODS (6359-MACH. S.N. 2481-6000/ 6059-MACH. S.N. 6001- ) . . . . .	20 - 45		
 <b>R</b>  		   <b>S</b>  	
R.H. CAB PANELS AND WINDOW HINGE . . . . .	90 - 23	SCRAPERS, MUD . . . . .	80 - 6
R.H. SIDE SCREENS, COTTON BASKET. . . . .	160 - 6	SCREENS, BASKET LID . . . . .	160 - 11
RADIATOR AND HOSES . . . . .	20 - 72		

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
SCREENS, ENGINE . . . . .	80 - 2	SINGLE GUIDE WHEEL . . . . .	80 - 8
SCREENS, REAR HOOD . . . . .	80 - 4	SKIRTS, PLATFORM . . . . .	90 - 6
SEAL KIT, COMPRESSOR . . . . .	90 - 44	SLIP CLUTCH, DRUM . . . . .	120 - 7
SEAL REPAIR KIT, CONTROL VALVE . . . . .	70 - 10	SLIP CLUTCH, DRUM (S.N. 8001- ) . . . . .	120 - 8
SEALANT, IN-LINE UNITS . . . . .	110 - 1	SOLENOID COVER . . . . .	40 - 5
SEAT ADJUSTMENT AND COVER (SN -18000) . . . . .	90 - 14	SOLENOID COVER . . . . .	40 - 6
SEAT ADJUSTMENT AND COVER (SN 18001- ) . . . . .	90 - 16	SOLENOID COVER (MACH. S.N. 8001- ) . . . . .	40 - 23
SEAT ARMREST LINKS (PERSONAL- POSTURE™ SEAT) . . . . .	90 - 10	SOLENOID COVER (6059) (MACH. SERIAL NO. 6001-8000) . . . . .	40 - 18
SEAT ASSEMBLY . . . . .	90 - 20	SOLENOID SWITCH . . . . .	40 - 6
SEAT BACKREST SUPPORT (PERSONAL-POSTURE™ SEAT) . . . . .	90 - 12	SOLENOID SWITCH, STARTER (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 19
SEAT BELT (FOR FABRIC SEAT) . . . . .	90 - 8	SOUND-GARD CAB . . . . .	90 - 21
SEAT CUSHIONS (FABRIC) . . . . .	90 - 8	SPEAKER KIT, RADIO (SEE MPC-1482) . . . . .	40 - 71
SEAT SUSPENSION . . . . .	90 - 18	SPEED CONTROL ARM, LINKAGE AND BRACKETS. . . . .	30 - 48
SEAT SUSPENSION SUPPORT . . . . .	90 - 13	SPINDLE . . . . .	120 - 18
SENDER, FUEL . . . . .	30 - 12	SPINDLE LUBRICANT . . . . .	130 - 3
SENDER, OIL PRESSURE (6059-MACH. S.N. 6001- ) . . . . .	20 - 53	SPINDLE MOISTENER (S.N. 101-6271) . . . . .	140 - 14
SENDER, OIL PRESSURE (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 50	SPINDLE MOISTENER (S.N. 6272- ) . . . . .	140 - 16
SENDER, OIL PRESSURE (6359TN002) (6359-MACH. S.N. 2481-6000) . . . . .	20 - 52	SPROCKET AND LINKAGE, DOFFER DRIVE TIGHT. . . . .	120 - 29
SENSOR, AIR DUCT . . . . .	40 - 56	SPROCKETS, UPPER DOFFER . . . . .	120 - 24
SEPARATOR, WATER . . . . .	30 - 15	SPROCKETS, UPPER HOUSING (S.N. 8001- ) . . . . .	120 - 12
SERVICE KIT, ELECTRICAL CONNECTOR . . . . .	40 - 64	SPROCKETS, UPPER HOUSING (S.N. 101-8000) . . . . .	120 - 10
SERVO, HYDROSTATIC DRIVE PUMP (S.N. 101-2000) . . . . .	50 - 16	STABILIZER, ROCKSHAFT AND PIPES. . . . .	100 - 1
SERVO, HYDROSTATIC DRIVE PUMP (S.N. 2001- ) . . . . .	50 - 17	STALK LIFTERS . . . . .	110 - 18
SET, COMPRESSOR HARDWARE (NIPPONDENSO) . . . . .	90 - 47	STALKLIFTER RODS . . . . .	110 - 20
SHAFT AND GEARS TRANSMISSION . . . . .	50 - 7	STANDARD SIZE BEARINGS, MAIN (MACH. S.N. 2481-6000) . . . . .	20 - 36
SHAFT, COTTON FAN (S.N. 101-2000) . . . . .	150 - 12	STANDARD SIZE MAIN BEARINGS (MACH. S.N. 2481-6000) . . . . .	20 - 36
SHAFT, COTTON FAN (S.N. 2001- ) . . . . .	150 - 14	STARTER . . . . .	40 - 5
SHAFT, DIFFERENTIAL . . . . .	60 - 8	STARTER . . . . .	40 - 24
SHAFT, DIFFERENTIAL . . . . .	50 - 14	STARTER DRIVE HOUSING. . . . .	40 - 8
SHAFT, DRIVE, FINAL DRIVE . . . . .	50 - 13	STARTER DRIVE MOTOR. . . . .	40 - 8
SHAFT, HYDROSTATIC PUMP . . . . .	50 - 18	STARTER SOLENOID COVER KIT . . . . .	40 - 16
SHAFT, PICKER BAR . . . . .	120 - 16	STARTER SOLENOID COVER KIT . . . . .	40 - 17
SHAFT, ROCKER ARM (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 45	STARTER SOLENOID SWITCH (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 19
SHAFT, TRANSMISSION INPUT. . . . .	50 - 12	STARTER SWITCH . . . . .	40 - 1
SHEAVE, COTTON FAN (S.N. 101-2000) . . . . .	150 - 12	STARTER, REPLACEMENT . . . . .	40 - 6
SHEAVE, COTTON FAN (S.N. 2001- ) . . . . .	150 - 14	STARTING AID, COLD WEATHER . . . . .	40 - 60
SHEAVE, PUMP DRIVE . . . . .	70 - 1	STARTING MOTOR. . . . .	40 - 3
SHEAVES, COUNTERSHAFT, UNIT DRIVE. . . . .	120 - 2	STARTING MOTOR. . . . .	40 - 4
SHIELD, PLANT (MAIN FRAME) . . . . .	80 - 15	STARTING MOTOR. . . . .	40 - 12
SHIELD, UNIT DRIVE . . . . .	120 - 6	STARTING MOTOR. . . . .	40 - 14
SHIELDS, FRONT WHEEL . . . . .	80 - 17	STARTING MOTOR. . . . .	40 - 24
SHIELDS, MUD . . . . .	80 - 16	STARTING MOTOR (S.N. 8001- ) . . . . .	40 - 26
SHIFT, UNIT, LEVER AND LINKAGE . . . . .	50 - 8	STARTING MOTOR (MACH. S.N. 8001- ) . . . . .	40 - 23
SHIFTER RAILS, TRANSMISSION. . . . .	50 - 4	STARTING MOTOR (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 15
SHIFTING LEVERS AND LINKAGE . . . . .	50 - 2	STARTING MOTOR (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 21
SHIFTING LEVERS HYDROSTATIC DRIVE AND LINKAGE. . . . .	50 - 2	STARTING MOTOR (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 22
SHIFTING LINKAGE, HYDROSTATIC DRIVE . . . . .	50 - 2	STARTING MOTOR ARMATURE (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 20
SHOE, INNER HEIGHT SENSING . . . . .	110 - 22	STARTING MOTOR ATTACHING PARTS (6059) (MACH. SERIAL NO. 6001-8000) . . . . .	40 - 18
SHOE, OUTER HEIGHT SENSING. . . . .	110 - 24	STARTING MOTOR COIL (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 21
SHORT BLOCK ASSEMBLY (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 2	STARTING MOTOR COMMUTATOR, END FRAME (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 22
SHORT BLOCK, ENG (6359TN002 S.N. 2481- 6000/6059TN002 S.N. 6001- ) . . . . .	20 - 3	STARTING MOTOR DRIVE AND SWITCH ASSEMBLY . . . . .	40 - 9
SIDE SHEETS AND FRONT HOOD (S.N. 10001- ) . . . . .	110 - 12	STARTING MOTOR DRIVE HOUSING (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 20
SIDE SHEETS AND FRONT HOOD (S.N. 101-10000) . . . . .	110 - 10		
SIDE SHEETS, FRONT DRUM . . . . .	110 - 14		



## ALPHABETICAL INDEX - CONTINUED

	PAGE
STARTING MOTOR KIT . . . . .	40 - 24
STARTING MOTOR SOLENOID COVER . . . . .	40 - 4
STARTING MOTOR SOLENOID SWITCH . . . . .	40 - 10
STARTING MOTOR, JOHN DEERE (S.N. 8001- ) . . . . .	40 - 26
STEERING COLUMN. . . . .	60 - 2
STEERING CYLINDER, WIDE AXLE DUAL WHEEL . . . . .	70 - 38
STEERING MOTOR HYDRAULIC TUBES (S.N. 10001- ) . . . . .	70 - 19
STEERING MOTOR HYDRAULIC TUBES (S.N. 101-10000) . . . . .	70 - 18
STEERING POST AND SUPPORT. . . . .	60 - 1
STEERING VALVE, POWER. . . . .	60 - 4
STEERING WHEEL INDICATOR LAMP AND SWITCH . . . . .	40 - 45
STEP, DOOR LEFT HAND . . . . .	150 - 1
STEPS (S.N. 101-2000) . . . . .	150 - 2
STEPS (S.N. 2001- ) . . . . .	150 - 4
STIFFENER. . . . .	110 - 2
STRAINER, HYDRAULIC OIL . . . . .	70 - 12
STUD, PICKER BAR (S.N. 101-8000). . . . .	120 - 20
STUD, PICKER BAR (S.N. 8001- ) . . . . .	120 - 22
SUCTION DOOR TUBES AND DUCTS. . . . .	150 - 6
SUCTION DOOR, FRONT (S.N. 101-2000) . . . . .	150 - 2
SUCTION DOOR, FRONT (S.N. 2001- ) . . . . .	150 - 4
SUCTION DOOR, INNER. . . . .	150 - 8
SUN GEAR, UPPER HOUSING (S.N. 8001- ) . . . . .	120 - 12
SUN GEAR, UPPER HOUSING (S.N. 101-8000) . . . . .	120 - 10
SUPPLEMENTARY TERMINALS AND CONNECTORS . . . . .	40 - 70
SUPPORT, DUCT AND LADDER . . . . .	150 - 10
SUPPORT, ENGINE . . . . .	20 - 74
SUPPORT, FOOT FLUSH VALVE . . . . .	140 - 10
SUPPORT, HEIGHT SENSING VALVE . . . . .	110 - 26
SUPPORT, SEAT BACKREST (PERSONAL-POSTURE™ SEAT). . . . .	90 - 12
SUPPORT, SEAT SUSPENSION. . . . .	90 - 13
SUPPORT, WATER PUMP . . . . .	140 - 4
SUPPORTS, BASKET . . . . .	160 - 4
SWASHPLATE, HYDROSTATIC DRIVE PUMP. . . . .	50 - 20
SWITCH ASSEMBLY, STARTING MOTOR DRIVE . . . . .	40 - 9
SWITCH, AIR MONITOR . . . . .	40 - 56
SWITCH, DIMMER. . . . .	40 - 40
SWITCH, ENGINE OVERHEATING. . . . .	20 - 65
SWITCH, ENGINE TEMPERATURE (MACH. S.N. 2481- ) . . . . .	20 - 71
SWITCH, ETHER START . . . . .	40 - 1
SWITCH, HORN. . . . .	40 - 43
SWITCH, HYDRAULIC THERMAL . . . . .	70 - 12
SWITCH, IDLER CLUTCH (SER. NO. -6000) . . . . .	40 - 58
SWITCH, IDLER CLUTCH (SER. NO. 6001- ) . . . . .	40 - 59
SWITCH, LIGHT . . . . .	40 - 1
SWITCH, MAGNETIC, STARTER . . . . .	40 - 24
SWITCH, SOLENOID, STARTING MOTOR . . . . .	40 - 10
SWITCH, STARTER . . . . .	40 - 1
SWITCH, STARTER SOLENOID (6059TN002) (MACH. S.N. 6001-8000) . . . . .	40 - 19
SWITCH, STEERING WHEEL . . . . .	40 - 45
SWITCH, UNIT LIFT . . . . .	40 - 11
SWITCHES, AIR CONDITIONER . . . . .	90 - 34
SYSTEM, FUEL INJECTION (MACH. S.N. 2481-6000) . . . . .	30 - 42
SYSTEM, FUEL INJECTION (MACH. S.N. 2481-6000) . . . . .	30 - 44
SYSTEM, FUEL INJECTION (6059TN002) (MACH. S.N. 6001- ) . . . . .	30 - 46

### T

	PAGE
TACHOMETER. . . . .	20 - 76
TANK, FUEL . . . . .	30 - 12
TANK, LUBRICATION. . . . .	130 - 2
TANK, WATER . . . . .	140 - 2
TEMPERATURE SWITCH, ENGINE . . . . .	20 - 65
TERMINAL AND WIRING KIT . . . . .	40 - 62
TERMINALS AND CONNECTORS . . . . .	40 - 70
TERMINALS, ELECTRICAL, WEATHERPACK . . . . .	40 - 68
TETHER, OPERATOR PRESENCE BYPASS . . . . .	90 - 50
THERMOSTAT AND HOUSING (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 70
THERMOSTAT HOUSING, ENGINE (MACH. S.N. 2481- ) . . . . .	20 - 71
THERMOSTAT, ENGINE (MACH. S.N. 2481- ) . . . . .	20 - 71
TIE RODS, REAR AXLE (WIDE AXLE DUAL WHEEL STEERING) . . . . .	80 - 12
TIGHTENER, DOFFER DRIVE. . . . .	120 - 29
TIMING GEAR COVER (MACH. S.N. 2481- ) . . . . .	20 - 56
TIMING GEAR COVER (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 54
TIMING GEARS (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 32
TRANSFER PUMP, FUEL (CORONA)(6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 23
TRANSFER PUMP, FUEL (SOFABEX) (MACH. S.N. 101-2480). . . . .	30 - 22
TRANSFER PUMP, LUBRICATION . . . . .	130 - 20
TRANSFER PUMP, LUBRICATION . . . . .	130 - 22
TRANSMISSION AND DIFFERENTIAL CASE, COVER AND SHIFTER RAILS . . . . .	50 - 4
TRANSMISSION GEAR AND SHAFT . . . . .	50 - 7
TRANSMISSION INPUT SHAFT AND GEARS . . . . .	50 - 12
TRUNNION, HYDROSTATIC DRIVE PUMP (S.N. 101-2000) . . . . .	50 - 16
TRUNNION, HYDROSTATIC DRIVE PUMP (S.N. 2001- ) . . . . .	50 - 17
TUBES, HYDRAULIC STEERING . . . . .	70 - 16
TUBES, OUTER SUCTION DOOR . . . . .	150 - 6
TURBOCHARGER (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	30 - 18
TURBOCHARGER (6359TN-02) (MACH. S.N. 101-2480). . . . .	30 - 16
TURBOCHARGER CENTER HOUSING (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	30 - 18
TURBOCHARGER OIL LINES (6359-MACH. S.N. 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	30 - 20
TURN SIGNAL CONTROL AND WIRING HARNESS . . . . .	40 - 43

### U

UNDERSIZE CRANKSHAFT KIT (6359-MACH. SN 2481-6000/6059-MACH. S.N. 6001- ) . . . . .	20 - 40
UNIT DRIVE COUNTERSHAFT . . . . .	120 - 2
UNIT DRIVE GEAR CASE. . . . .	120 - 4
UNIT DRIVE UNIVERSAL JOINT. . . . .	120 - 6
UNIT HOUSING, PICKING . . . . .	110 - 1
UNIT LIFT AND BASKET CONTROL VALVE LINKAGE (SER. NO. 101-2000) . . . . .	100 - 6
UNIT LIFT BRACKETS . . . . .	100 - 2
UNIT LIFT CONTROL VALVE LINKAGE (SER. NO. 2001- ) . . . . .	100 - 8
UNIT LIFT CYLINDER . . . . .	70 - 34
UNIT LIFT HYDRAULIC TUBES AND FITTINGS . . . . .	70 - 26

## ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
UNIT LIFT LEVER . . . . .	100 - 4	VOLTAGE REGULATOR (90-AMP)(S.N.101-2000) . . . . .	40 - 32
UNIT LIFT LINKAGE . . . . .	100 - 5		
UNIT LIFT SWITCH . . . . .	40 - 11	<b>W</b>	
UNIT LUBRICATION FITTING AND HOSES (S.N. 8001- ) . . . . .	130 - 16	WARNING LAMP, FRONT . . . . .	40 - 41
UNIT LUBRICATION MANIFOLD & FITTINGS (S.N. 8001- ) . . . . .	130 - 17	WARNING LAMP, REAR . . . . .	40 - 42
UNIT LUBRICATION VALVE (S.N. 2001-8000) . . . . .	130 - 12	WATER CONTROL HOSES AND FITTINGS . . . . .	140 - 9
UNIT SEALANT (IN-LINE). . . . .	110 - 1	WATER FILTER (S.N. 10001- ) . . . . .	140 - 8
UNIT SHIFT LEVER AND LINKAGE . . . . .	50 - 8	WATER FILTER (S.N. 101-10000) . . . . .	140 - 6
UNIT SHIFTER AND RAIL AUXILIARY CASE . . . . .	50 - 10	WATER LINES, PRESSURE . . . . .	140 - 12
UNIVERSAL JOINT, UNIT DRIVE . . . . .	120 - 6	WATER MANIFOLD (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 70
UPHOLSTERY, CAB REAR . . . . .	90 - 26	WATER PUMP (MACH. S.N. 2481- ) . . . . .	20 - 68
UPPER DOFFER ADJUSTING HOUSING AND SPROCKETS . . . . .	120 - 24	WATER PUMP ASSEMBLY . . . . .	140 - 5
UPPER HOUSING, PICKING UNIT. . . . .	110 - 4	WATER PUMP FITTINGS AND SUPPORT. . . . .	140 - 4
UPPER UNIT LUBRICATION MANIFOLD (S.N. 101-8000) . . . . .	130 - 13	WATER PUMP, FAN AND BELT (6359TN-02) (MACH. S.N. 101-2480). . . . .	20 - 66
<b>V</b>		WATER SEPARATOR . . . . .	30 - 15
VALVE MOUNTING BRACKETS, HEIGHT SENSING . . . . .	110 - 26	WATER TANK AND WRAPPER . . . . .	140 - 2
VALVE, BASKET STOP . . . . .	70 - 28	WATER VALVE . . . . .	140 - 1
VALVE, CONTROL . . . . .	70 - 8	WEATHERPACK CONNECTORS. . . . .	40 - 68
VALVE, CONTROL, COMPACTOR-VANE . . . . .	70 - 11	WEATHERPACK TERMINALS . . . . .	40 - 68
VALVE, CONTROL, HYDROSTATIC (S.N. 101-4000) . . . . .	50 - 22	WHEEL SHIELDS, FRONT . . . . .	80 - 17
VALVE, CONTROL, HYDROSTATIC (S.N. 4001- ) . . . . .	50 - 26	WHEEL, MAIN . . . . .	80 - 7
VALVE, ENGINE OIL BYPASS (MACH. S.N. 2481- ) . . . . .	20 - 17	WHEEL, REAR, SINGLE GUIDE . . . . .	80 - 8
VALVE, FOOT FLUSH . . . . .	140 - 10	WHEELS, REAR . . . . .	80 - 14
VALVE, LUBRICATION (S.N. 101-8000) . . . . .	130 - 10	WIDE AXLE DUAL WHEEL HYDRAULIC HOSES . . . . .	70 - 21
VALVE, MANIFOLD, HYDROSTATIC DRIVE. . . . .	50 - 29	WINDOW HINGE. . . . .	90 - 23
VALVE, OIL PRESSURE RELIEF (MACH. S.N. 2481- ) . . . . .	20 - 16	WINDOWS, CAB . . . . .	90 - 22
VALVE, POWER STEERING. . . . .	60 - 4	WINDSHIELD WIPER. . . . .	90 - 39
VALVE, UNIT HEIGHT SENSING (S.N. 2001- ) . . . . .	70 - 37	WINDSHIELD WIPER BLADE . . . . .	90 - 39
VALVE, UNIT HEIGHT SENSING (S.N. 2001- ). . . . .	70 - 36	WINDSHIELD WIPER MOTOR. . . . .	90 - 39
VALVE, UNIT LUBRICATION (S.N. 2001-8000) . . . . .	130 - 12	WIRING HARNESS. . . . .	40 - 47
VALVE, WATER . . . . .	140 - 1	WIRING HARNESS, AIR SWITCH . . . . .	40 - 56
VALVES, ENGINE (6359TN-02) (MACH. S.N. 101-2480) . . . . .	20 - 42	WIRING HARNESS, LUBRICATION SYSTEM . . . . .	40 - 48
VALVES, EXHAUST (MACH. S.N. 2481-6000) . . . . .	20 - 24	WIRING HARNESS, MONITOR . . . . .	40 - 54
VALVES, EXHAUST (MACH. S.N. 2481-6000) . . . . .	20 - 26	WIRING HARNESS, OPERATOR PRESENCE . . . . .	40 - 51
VALVES, EXHAUST (MACH. S.N. 6001- ) . . . . .	20 - 28	WIRING HARNESS, OPERATOR PRESENCE BYPASS. . . . .	90 - 50
VALVES, INTAKE (MACH. S.N. 2481-6000) . . . . .	20 - 24	WIRING HARNESS, TURN CONTROL . . . . .	40 - 43
VALVES, INTAKE (MACH. S.N. 2481-6000) . . . . .	20 - 26	WIRING, CAB DIAGRAM . . . . .	40 - 50
VALVES, INTAKE (MACH. S.N. 6001- ) . . . . .	20 - 28	WIRING, LUBRICATION SYSTEM (S.N. 8001- ). . . . .	40 - 49
VANE COMPACTOR . . . . .	160 - 16	WRAPPER, FAN . . . . .	150 - 16
VANE COMPACTOR HYDRAULIC LINES . . . . .	70 - 32	WRAPPER, LUBRICATION TANK . . . . .	130 - 2
VENT TUBE, ENGINE . . . . .	20 - 31	WRAPPER, WATER TANK. . . . .	140 - 2
VINE CUTTER. . . . .	120 - 30	WRENCH, SPINDLE . . . . .	120 - 18
VOLTAGE REGULATOR (90-AMP) (SERIAL NO. 2001- ) . . . . .	40 - 34		

# 10-16

9930 COTTON PICKER

---

MEMORANDA

# 20-1

ENGINE

RGP1239 -UN-01JAN94

## TORQ-GARD SUPREME ENGINE OIL



RGP1239

KEY	PART NO.	PART NAME	QTY.	ENGINE SERIAL NO.	REMARKS
**	AR63980	OIL	1		(SAE 5W/20), 0.2L (1 HALF PINT) CAN
**	AR63228	OIL	1		(SAE 5W/20), 0.9L (1 QUART) CAN
**	AR63229	OIL	1		(SAE 5W/20), 19L (5 GALLON) CAN
**	AR63230	OIL	1		(SAE 5W/20), 208L (55 GALLON) DRUM
**	TY6297	OIL	1		(SAE 15W/40), 0.9L (1 QUART) CAN
**	TY6298	OIL	1		(SAE 15W/40), 1.9L (5 GALLON) CAN
**	TY6300	OIL	1		(SAE 15W/40), 114L (30 GALLON) DRUM
**	TY6301	OIL	1		(SAE 15W/40), 208L (55 GALLON) DRUM
**	TY6311	OIL	1		(SAE 10), 0.9L (1 QUART) CAN
**	TY6312	OIL	1		(SAE 10), 19L (5 GALLON) CAN
**	TY6313	OIL	1		(SAE 10), 208L (55 GALLON) DRUM
**	AR63979	OIL	1		(SAE 30), 0.2L (1 HALF PINT) CAN
**	AR63218	OIL	1		(SAE 30), 0.9L (1 QUART) CAN
**	AR63219	OIL	1		(SAE 30), 19L (5 GALLON) CAN
**	AR63222	OIL	1		(SAE 30), 208L (55 GALLON) DRUM