

9970 COTTON PICKER



JOHN DEERE

PARTS CATALOG

9970 COTTON PICKER

PC2602 (28AUG06) English

John Deere Des Moines Works

North American Edition

Litho in U.S.A. (Revised)

COPYRIGHT © 2006

DEERE & COMPANY

Moline, Illinois

All rights reserved

NP8480 -UN-03JUL97



NP8480

*JOHN DEERE 9970 COTTON PICKER
(MANUFACTURED 1997 -)*

(SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE.)

SERIAL NUMBER LISTING INFORMATION

THE COTTON PICKER SERIAL NUMBER PLATE IS LOCATED ON LEFT-HAND SIDE OF MAIN FRAME, AT CENTER.

SERIAL NUMBER INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER OR YEAR.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER OR YEAR LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS OR YEARS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

HOSE DIMENSIONS LISTED ARE EITHER FITTING SIZE X LENGTH X FITTING SIZE OR I.D. X LENGTH.

CKSO SERVICE PARTS

SERVICE PARTS DESIGNATED CKSO ARE USED IN CERTAIN AREAS OF THE WORLD. IF YOUR SOURCE OF SERVICE PARTS IS IN EUROPE OR AFRICA, ORDER THESE PARTS DESIGNATED CKSO.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

SHORT BLOCK SERIAL NUMBER PLATE (-RGSB076882500)

RGP3513 -UN-01JAN94



RGP3513


THE REPLACEMENT SHORT BLOCK ASSEMBLY HAS A SERIAL NUMBER PLATE ATTACHED. THE ORIGINAL ENGINE SERIAL NUMBER MUST BE STAMPED ONTO THE NEW PLATE IN THE BLANK SPACE PROVIDED, AS A REFERENCE FOR YOUR DEALER. THE PLATE CAN BE ATTACHED WITH (2) 37H44 DRIVE SCREWS.

1. DESIGNATES ENGINE MANUFACTURER
2. DESIGNATES REPLACEMENT SHORT BLOCK
3. DESIGNATES LITERS
4. DESIGNATES THE PRODUCTION DATE
5. DESIGNATES COMPONENT SEQUENCE

RG - WATERLOO ENGINE WORKS
SB
XXX- 076 (7.6)
8825
00

SHORT BLOCK SERIAL NUMBER IDENTIFICATION (EXAMPLE SHOWN)

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490295

- | | |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED | 09 |
| 3. DESIGNATES YEAR ASSEMBLED | 95 |

TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE (LOCATED ON STARTER SIDE OF ENGINE)

RGP3513 -UN-01JAN94



RGP3513

FIRST LINE

DEFINES

RG - WATERLOO ENGINE WORKS

DESIGNATES ENGINE MANUFACTURER.

6

DESIGNATES NUMBER OF CYLINDERS.

076 (7.6 LITERS)
081 (8.1 LITERS)

DESIGNATES LITER DISPLACEMENT.

A - AIR-TO-WATER

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

N

DESIGNATES DES MOINES WORKS.

XXXXXX

DESIGNATES ENGINE SERIAL NUMBER.

SECOND LINE

APPLICATION

6076AN031
6081AN001

9970 (EARLY ENGINE)
9970 (LATE ENGINE) (ESN 086536-)

SECTION INDEX

GENERAL INFORMATION.....	10
ENGINE (6081AN001)	20
ENGINE (6068HN052 TIER 2).....	25
FUEL AND AIR.....	30
ELECTRICAL	40
POWER TRAIN	50
STEERING AND BRAKES.....	60
HYDRAULICS	70
WHEELS, REAR AXLES AND SHEET METAL.....	80
OPERATOR STATION	90
PICKING UNIT LIFT	100
PICKING UNIT CABINET.....	110
PICKING UNIT SYSTEM.....	120
PICKING UNIT LUBRICATION SYSTEM.....	130
WATER SYSTEM	140
AIR SYSTEM.....	150
BASKET	160
DECALS	170
PREFERRED METRIC HARDWARE.....	180
NUMERICAL INDEX	190

ALPHABETICAL INDEX

	PAGE		PAGE
A			
A/C COMPRESSOR (6081 ENGINE)	90-57	ANEROID ACTIVATOR, HYDRAULIC (6076)	30-57
ACCESS COVER FUEL INJECTION PUMP (6081 ENGINE)	40-12	ANGLE, PICKING UNIT BOTTOM FRAME (PRO-12 UNIT)	110-8
ACTIVATOR, HYDRAULIC ANEROID (6081 ENGINE)	30-55	ANTENNA, RADIO AND SPEAKERS	40-83
ACTUATOR, FAN ENGAGE	150-24	ARM, PICKER BAR	120-16
ADAPTER, FAN CONTROLLER	40-75	ARM, ROCKER (6068HN052)	25-10
ADAPTER, FAN DRIVE (W/ AUX. DRIVE) (6068HN052)	25-36	ARM, STALKLIFTER PIVOT	110-18
ADAPTER, FUEL INJECTION PUMP (6068HN052)	25-56	ARM, UNIT LIFT	100-4
ADAPTER, OIL COOLER (6081 ENGINE) (ESN -136896)	20-64	ARMREST, SEAT (PERSONAL-POSTURE™ SEAT	090-1
ADAPTER, OIL COOLER (6081 ENGINE) (ESN 136897-)	20-66	ARMS, ROCKER (6076)	20-11
ADAPTER, OIL COOLER BYPASS (6081 ENGINE)	20-67	ARMS, ROCKER (6081 ENGINE)	20-12
ADJUSTABLE TREAD REAR AXLE	80-18	ASHTRAY	90-34
ADJUSTER, DOFFER, UPPER	120-24	ASSEMBLY, CLUTCH (STARTER) (6076)	40-2
ADJUSTMENT, SEAT	90-16	ASSEMBLY, CLUTCH (STARTER) (6081 ENGINE)	40-4
AFTERCOOLER (6076)	30-4	ASSEMBLY, COMPLETE BLOCK	20-2
AFTERCOOLER (6081 ENGINE)	30-6	AUGER, COMPACTOR, LH	160-22
AFTERCOOLER BRACKETS (6076)	30-8	AUGER, COMPACTOR, RH	160-21
AFTERCOOLER INLET HOSES (6076)	30-8	AUXILIARY PLUG CONNECTOR	40-63
AID, COLD WEATHER STARTING	30-15	AXLE BRACKET, REAR	80-5
AIR CLEANER	30-67	AXLE EXTENSIONS, REAR	80-46
AIR CLEANER SUPPORT	80-6	AXLE EXTENSIONS, REAR	80-47
AIR CONDITIONER COMPRESSOR FAN PULLEY (6081 ENGINE)	90-58	AXLE KNEE AND KNUCKLE, REAR (-23000)	80-20
AIR CONDITIONER COMPRESSOR IDLER PULLEY (6081 ENGINE)	90-58	AXLE KNEE AND KNUCKLE, REAR (23001-)	80-22
AIR CONDITIONER COMPRESSOR SUPPORT (6081 ENGINE)	90-58	AXLE PIVOT SUPPORT, FRONT	80-42
AIR CONDITIONING BELT	20-88	AXLE PIVOT SUPPORT, REAR (23001-)	80-44
AIR CONDITIONING COMPRESSOR (6081 ENGINE)	90-57	AXLE SPACERS	80-48
AIR CONDITIONING COMPRESSOR (6076)	90-56	AXLE STABILIZER CYLINDER, 3 1/2 X 10"	70-61
AIR CONDITIONING COMPRESSOR PARTS	90-54	AXLE, FINAL DRIVE	50-19
AIR CONDITIONING CONDENSER (23001-)	20-82	AXLE, FRONT	80-2
AIR COOLER (23001-)	20-82	AXLE, REAR CENTER	80-19
AIR DUCT, UNIT TO BASKET (INNER)	150-14	AXLE, REAR, ADJUSTABLE TREAD	80-18
AIR FILTER, CAB	90-45	B	
AIR INTAKE (6068HN052)	25-44	BACK UP ALARM	40-67
AIR INTAKE TUBES AND PRE SCREENER	30-68	BACK UP ALARM HARNESS	40-66
AIR LOUVER, PANEL AND SWITCHES	90-44	BACKREST, OPERATOR'S SEAT	90-12
AIR TEMPERATURE SENSOR (6068HN052)	25-44	BAFFLE, ROCKER ARM COVER (6068HN052)	25-3
AIR TUBES	150-16	BAR DRUM, STUD AND BEARING, PICKER	120-20
AIR TUBES AND NOZZLES	150-17	BAR, FRAME WEIGHT	80-1
ALARM HARNESS, BACK UP	40-66	BAR, GRID, PICKING UNIT (PRO-12 18S)	110-10
ALARM, BACK UP	40-67	BAR, MIRROR	90-51
ALARM, CONSOLE (-23000)	40-20	BAR, PICKER	120-16
ALARM, CONSOLE (23001-)	40-22	BASE, FUEL FILTER (6068HN052)	25-50
ALTERNATOR ADJUSTING STRAP (6081 ENGINE)	40-12	BASE, FUEL FILTER (6081 ENGINE)	30-30
ALTERNATOR AND MOUNTING BRACKETS (6076)	40-8	BASE, OIL FILTER (6081 ENGINE)	20-68
ALTERNATOR AND PULLEY (6081 ENGINE)	40-10	BASIC ENGINE, REMANUFACTURED (6076)	20-22
ALTERNATOR BRACKET (6081 ENGINE)	40-12	BASKET COMPACTOR DRIVES	160-23
ALTERNATOR SUPPORT (6081 ENGINE) (6081 ENGINE)	40-12	BASKET COMPACTOR HYDRAULIC LINES	70-52
ANCHOR, TOW	80-4	BASKET CYLINDER END LUBRICATION LINES	160-1
ANEROID ACTIVATOR, HYDRAULIC (DENSO) (6076)	30-54	BASKET DUMP HYDRAULIC CYLINDER	70-60
ANEROID ACTIVATOR, HYDRAULIC (6081 ENGINE)	30-55	BASKET ENDS	160-8
		BASKET EXTENDER	160-34
		BASKET EXTENDER LINKAGE	160-36
		BASKET EXTENSION	160-24
		BASKET FLAP	160-32
		BASKET INTERLOCK SWITCH	40-78
		BASKET INTERLOCK VALVE	70-56
		BASKET LAMPS AND FIELD LAMPS	40-27
		BASKET LID AND TOP	160-16

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
BASKET LIFT HYDRAULIC LINES AND HOSES (-23000).....	70-22	BRACKET, HYDRAULIC PUMP MOUNTING (16001-).....	70-10
BASKET LIFT HYDRAULIC LINES AND HOSES (23001-).....	70-24	BRACKET, HYDRAULIC VALVE.....	70-1
BASKET LOCK-UP.....	160-10	BRACKET, MIRROR, WARNING LIGHT.....	90-51
BASKET SUPPORT.....	160-2	BRACKET, REAR AXLE.....	80-5
BASKET TELESCOPING HYDRAULIC CYLINDERS, LINES & HOSES.....	70-26	BRACKETS, ALTERNATOR MOUNTING (6076).....	40-8
BASKET WITH COMPACTOR, COMPLETE.....	160-4	BRACKETS, ENGINE FRONT (6068HN052).....	25-1
BASKET, LH SIDE.....	160-6	BRACKETS, HYDROSTATIC PUMP.....	50-27
BASKET, RH SIDE AND FLOOR.....	160-4	BRACKETS, MOUNTING, COMPRESSOR (6076 ENGINE).....	90-62
BATTERY, BATTERY BOX AND CABLES.....	40-1	BRACKETS, TRANSMISSION.....	50-3
BEARING CAP, FINAL DRIVE.....	50-18	BRAKE CABLE, PARK.....	60-19
BEARING, PICKER BAR DRUM.....	120-20	BRAKE CYLINDER, MASTER.....	60-10
BEARING, THRUST (6076).....	20-49	BRAKE LINES AND RESERVOIR.....	60-14
BEARING, THRUST (6081 ENGINE).....	20-50	BRAKE PEDAL, PARK.....	60-18
BEARING, WATER PUMP (6076).....	20-94	BRAKE PEDALS.....	60-17
BEARINGS, CRANKSHAFT (6068HN052).....	25-23	BRAKE SHOES AND DRUM.....	60-12
BEARINGS, CONNECTING ROD (6068HN052).....	25-21	BRAKE SLAVE CYLINDER.....	60-16
BEARINGS, FINAL DRIVE.....	50-19	BRUSH, CONVEYOR.....	160-17
BEARINGS, MAIN (6076).....	20-49	BUSHING, CAMSHAFT (6076).....	20-13
BEARINGS, MAIN (6081 ENGINE).....	20-50	BUSHING, CAMSHAFT (6076).....	20-16
BELT TENSIONER (ALT.) (6081 ENGINE).....	40-12	BUSHING, CAMSHAFT (6081 ENGINE).....	20-14
BELT, AIR CONDITIONING.....	20-88	BUSHING, CAMSHAFT (6081 ENGINE).....	20-18
BELT, COMPRESSOR (6076 ENGINE).....	90-62	BYPASS TUBES, OIL COOLER (6081 ENGINE).....	20-67
BELT, ENGINE FAN.....	20-88	BYPASS VALVE, OIL FILTER (6076).....	20-62
BELT, ENGINE FAN (6081 ENGINE).....	20-87	BYPASS VALVE, OIL FILTER (6081 ENGINE).....	20-68
BELT, LUBRICATION PUMP.....	130-6		
BELT, UNIT DRIVE COUNTERSHAFT.....	120-2	C	
BEVEL GEAR, BASKET COMPACTOR DRIVE SHAFT.....	160-23	CAB AIR FILTER AND HOUSING.....	90-45
BLADE, VINE CUTTER.....	120-26	CAB DOOR (SOUND-GARD CAB).....	90-24
BLADE, WINDSHIELD WIPER.....	90-49	CAB FLOOR TERMINAL CONNECTORS.....	40-62
BLOCK ASSEMBLY, COMPLETE.....	20-2	CAB PANELS AND WINDOW HINGE, RH.....	90-23
BLOCK ASSEMBLY, COMPLETE (6068HN052).....	25-14	CAB REAR UPHOLSTERY.....	90-26
BLOCK ASSEMBLY, COMPLETE (6081).....	20-24	CAB ROOF AND SUPPORTS.....	90-28
BLOCK HEATER.....	40-82	CAB ROOF HEADLINER.....	90-31
BLOCK, CYLINDER (6068HN052).....	25-12	CAB WINDOWS (SOUND-GARD).....	90-22
BLOCK, ENGINE SHORT (6068HN052).....	25-14	CAB WIRING HARNESS (23001-).....	40-32
BLOCK, SHORT (WITH HEAD BOLTS) (6076).....	20-22	CAB, SOUND-GARD (COMPLETE).....	90-21
BLOCK, SHORT (WITHOUT HEAD BOLTS)(6076).....	20-20	CABINET, PLUGS AND GROMMETS.....	110-24
BLOCK, SHORT (6081).....	20-24	CABLE, HYDROSTATIC CONTROL.....	90-40
BLOCK, VALVE (HYDROSTATIC MOTOR).....	50-25	CABLE, PARK BRAKE.....	60-19
BLOWER, CAB HEATER/AC (-23000).....	40-30	CABLE, REAR DRUM PRESSURE PLATE (PRO-12 18S).....	110-14
BLOWER, PRESSURIZER.....	90-42	CABLE, THROTTLE.....	30-62
BOLTS, CYLINDER HEAD (6076).....	20-4	CABLE, TOP LINK STABILIZER.....	100-1
BOLTS, CYLINDER HEAD (6081 ENGINE).....	20-6	CABLE, TRANSMISSION SHIFT.....	50-4
BOTTOM FRAME, PICKING UNIT (PRO-12 UNIT).....	110-8	CABLE, UNIT SHIFT.....	50-5
BOX, BATTERY.....	40-1	CABLES, BATTERY.....	40-1
BOX, SKIP ROW GEAR.....	130-18	CAM FOLLOWER (6068HN052).....	25-10
BRACKET, ALTERNATOR (6081 ENGINE).....	40-12	CAM, PICKER DRUM.....	120-22
BRACKET, CYLINDER, ROW FINDER (23001-).....	70-78	CAMSHAFT (6068HN052).....	25-12
BRACKET, DOFFER IDLER GEAR.....	120-29	CAMSHAFT (6076).....	20-13
BRACKET, FIRE EXTINGUISHER.....	80-34	CAMSHAFT (6081 ENGINE).....	20-14
BRACKET, FIRE EXTINGUISHER.....	80-35	CAMSHAFT BUSHING (6076).....	20-13
BRACKET, FUEL FILTER (23001-) 30 MICRON.....	30-27	CAMSHAFT BUSHING (6076).....	20-16
BRACKET, FUEL FILTER (6076).....	30-26	CAMSHAFT BUSHING (6081 ENGINE).....	20-14
BRACKET, FUEL SHUT-OFF (6076).....	30-45	CAMSHAFT BUSHING (6081 ENGINE).....	20-18
BRACKET, FUEL SHUT-OFF (6081 ENGINE).....	30-46	CAMSHAFT FOLLOWER (6076).....	20-11
BRACKET, HYDRAULIC LINE, ENGINE HOOD.....	80-6	CAMSHAFT FOLLOWER (6076).....	20-13
		CAMSHAFT FOLLOWER (6081 ENGINE).....	20-12
		CAMSHAFT FOLLOWER (6081 ENGINE).....	20-14
		CAMSHAFT GEAR (6076).....	20-13
		CAMSHAFT GEAR (6081 ENGINE).....	20-14

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CAMSHAFT PLATE (6068HN052).....	25-12	COMPRESSOR, AIR CONDITIONING (6076)	90-56
CAP, ENGINE OIL FILL (6068HN052).....	25-22	COMPRESSOR, CLUTCH.....	90-59
CAP, RADIATOR (-23000).....	20-80	CONDENSER, A/C	50-42
CAPACITOR, CAB WIRING (-23000).....	40-30	CONDITIONER, COOLANT.....	20-78
CAPS, MAIN BEARING (6076).....	20-16	CONNECTING ROD (6068HN052).....	25-21
CAPS, MAIN BEARING (6081 ENGINE).....	20-18	CONNECTING RODS (6076)	20-38
CASE, GEAR, PICKING UNIT.....	120-6	CONNECTING RODS (6081 ENGINE).....	20-39
CASE, TRANSMISSION.....	50-6	CONNECTOR, CAB FLOOR.....	40-62
CAUTION DECALS.....	170-2	CONNECTOR, CONSOLE SWITCH.....	40-57
CENTER HOUSING, TURBOCHARGER (6076) (SCHWITZER).....	30-14	CONNECTOR, DIODE MODULE.....	40-64
CHAIN, CONVEYOR.....	160-28	CONNECTOR, ELECTRICAL, SERVICE KIT.....	40-46
CHAIN, DUCT LIFT.....	160-15	CONNECTOR, FAN CONTROLLER.....	40-58
CHAIN, LOW COTTON.....	110-18	CONNECTOR, FUSE AND RELAY BLOCK.....	40-56
CHANNEL, PICKING UNIT BOTTOM FRAME (PRO-12 UNIT).....	110-8	CONNECTOR, KEY SWITCH, CONSOLE LIGHT, ETHER SWITCH AND WARNING HORN.....	40-61
CHARGE AIR COOLER HOSES (23001-).....	20-84	CONNECTOR, MICROSWITCH AND AUXILIARY PLUG.....	40-63
CHARGE PUMP, HYDROSTATIC DRIVE.....	50-35	CONNECTOR, MOMENTARY FLOOR SWITCH.....	40-65
CHASSIS DECAL SET.....	170-9	CONNECTOR, MONITOR LIGHT MODULE AND TACHOMETER.....	40-55
CHASSIS WIRING HARNESS (-4000).....	40-34	CONNECTOR, OPTION.....	40-59
CHASSIS WIRING HARNESS (20001 - 23000).....	40-38	CONNECTORS, ELECTRICAL, WEATHERPACK.....	40-50
CHASSIS WIRING HARNESS (23001-).....	40-40	CONNECTORS, ELECTRICAL, WEATHERPACK.....	40-52
CHASSIS WIRING HARNESS (4001 - 20000).....	40-36	CONNECTORS, FUEL INJECTION PUMP HOUSING (DENSO) (6076).....	30-48
CHECK VALVE, RESERVOIR (XXXX - 23000).....	70-30	CONNECTORS, FUEL INJECTION PUMP HOUSING (6081 ENGINE).....	30-49
CHECK VALVE, RESERVOIR (23001-).....	70-32	CONSOLE ASSEMBLY.....	90-34
CLAMP, FUEL INJECTOR (6068HN052).....	25-54	CONSOLE CONTROLS, FUSES AND RELAYS (-23000).....	40-20
CLAMP, ROCKER ARM SHAFT (6068HN052).....	25-10	CONSOLE CONTROLS, FUSES AND RELAYS (23001-).....	40-22
CLAMP, TURBOCHARGER OIL LINE HOSE (6068HN052).....	25-46	CONSOLE LIGHT CONNECTOR.....	40-61
CLEANER, AIR.....	30-67	CONSOLE SWITCH CONNECTOR.....	40-57
CLEANER, SPINDLE.....	140-2	CONSOLE WIRING HARNESS (20001 - 23000).....	40-16
CLEANER, SPINDLE.....	140-4	CONSOLE WIRING HARNESS (23001-).....	40-18
CLUTCH ASSEMBLY (STARTER) (6076).....	40-2	CONTROL CABLE, HYDROSTATIC.....	90-40
CLUTCH ASSEMBLY (STARTER) (6081 ENGINE).....	40-4	CONTROL CABLE, THROTTLE.....	30-62
CLUTCH, COMPRESSOR.....	90-59	CONTROL HANDLE, HYDROSTATIC.....	90-38
CLUTCH, LUBRICATION PUMP.....	130-8	CONTROL LEVERS, CONSOLE.....	90-36
CLUTCH, SLIP, DRUM (-16001).....	120-12	CONTROL LINES, FUEL (DENSO) (6076).....	30-40
CLUTCH, SLIP, LOWER GEAR CASE HUB.....	120-10	CONTROL VALVE, HEIGHT SENSING HYDRAULIC.....	70-18
COLD WEATHER DRAIN KIT.....	140-24	CONTROL VALVE, HYDRAULIC.....	70-14
COLD WEATHER STARTING AID.....	30-15	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT.....	50-36
COLUMN, SPINDLE MOISTENER.....	140-20	CONTROL VALVE, HYDROSTATIC DRIVE DISPLACEMENT.....	50-38
COLUMN, STEERING.....	60-1	CONTROL, TURN SIGNAL.....	40-74
COMPACTOR AND FLUSH SYSTEM SWITCHES.....	40-77	CONTROLLER ADAPTER, FAN.....	40-75
COMPACTOR AUGER & SUPPORTS, LH.....	160-22	CONTROLLER, ENGINE (6068HN052).....	25-56
COMPACTOR AUGER & SUPPORTS, RH.....	160-21	CONTROLS, FUSES AND RELAYS, CONSOLE (-23000).....	40-20
COMPACTOR DRIVES, BASKET.....	160-23	CONTROLS, FUSES AND RELAYS, CONSOLE (23001-).....	40-22
COMPLETE BLOCK ASSEMBLY.....	20-2	CONVEYOR BRUSHES.....	160-17
COMPLETE BLOCK ASSEMBLY (6068HN052).....	25-14	CONVEYOR DRIVE.....	160-28
COMPLETE BLOCK ASSEMBLY, REMFG (6081).....	20-24	CONVEYOR FRAME.....	160-26
COMPRESSOR BELT AND MOUNTING BRACKETS (6076 ENGINE).....	90-62	CONVEYOR FRAME ASSEMBLY.....	160-30
COMPRESSOR HARDWARE KIT.....	90-60	CONVEYOR HYDRAULIC LINES.....	70-52
COMPRESSOR PARTS.....	90-61	CONVEYOR HYDRAULIC MOTOR.....	70-66
COMPRESSOR SEAL KIT.....	90-54	COOLANT AND ENGINE TEMPERATURE SENDERS.....	20-8
COMPRESSOR, A/C (6081 ENGINE).....	90-57	COOLANT CONDITIONER.....	20-78
		COOLANT MANIFOLD (6068HN052).....	25-42

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
COOLANT TEMPERATURE SENSOR (6068HN052).....	25-42	CRANKSHAFT DAMPER (6076).....	20-47
COOLANT TEMPERATURE SENSOR (6068HN052).....	25-62	CRANKSHAFT FRONT OIL SEAL (6076).....	20-53
COOLER AND OIL FILTER HOUSING (6076).....	20-62	CRANKSHAFT FRONT OIL SEAL (6081 ENGINE).....	20-54
COOLER, ENGINE OIL (6068HN052).....	25-28	CRANKSHAFT GEAR (6068HN052).....	25-23
COOLER, ENGINE OIL (6076).....	20-62	CRANKSHAFT KIT, UNDERSIZE (6081 -142156) (CONNECTING ROD JOURNAL).....	20-46
COOLER, ENGINE OIL (6081 ENGINE) (ESN -136896).....	20-64	CRANKSHAFT POSITION SENSOR.....	20-55
COOLER, ENGINE OIL (6081 ENGINE) (ESN 136897-).....	20-66	CRANKSHAFT PULLEY (6068HN052).....	25-24
COTTON DOOR, LARGE OUTSIDE.....	150-4	CRANKSHAFT PULLEY (6076).....	20-47
COTTON DOOR, LARGE OUTSIDE CONVERSION P12 38/40 TO VRS 2M.....	150-5	CRANKSHAFT PULLEY AND DAMPERS (6081 ENGINE).....	20-48
COTTON DOOR, LARGE OUTSIDE CONVERSION VRS 2M TO VRS 38/40.....	150-6	CRANKSHAFT SEAL KIT (6068HN052).....	25-23
COTTON DOOR, SMALL INSIDE (IN-LINE).....	150-2	CRANKSHAFT THRUST WASHER (6068HN052).....	25-23
COTTON FAN ASSEMBLY, COMPLETE.....	150-1	CRANKSHAFT, BEARINGS (6068HN052).....	25-23
COTTON FAN COVER.....	80-14	CROSS SHAFT AND UNIVERSAL JOINT.....	120-5
COUNTERSHAFT, UNIT DRIVE.....	120-2	CROSS SHAFT AND UNIVERSAL JOINT 70 CM.....	120-1
COUPLER, REMOTE FILL.....	140-6	CUTTER, VINE.....	120-30
COVER, ACCESS, INJECTION PUMP (W/ AUX. DRIVE) (6068HN052).....	25-36	CYLINDER BLOCK (6068HN052).....	25-12
COVER, COTTON FAN.....	80-14	CYLINDER BLOCK FITTINGS (6076).....	20-16
COVER, DIPSTICK (6081 ENGINE).....	20-74	CYLINDER BLOCK FITTINGS (6081 ENGINE).....	20-18
COVER, DOOR TRACK.....	90-24	CYLINDER COVER, STABILIZER.....	80-16
COVER, EHERMOSTAT HOUSING (6068HN052).....	25-42	CYLINDER HEAD (6068HN052).....	25-6
COVER, FUEL INJECTION PUMP ACCESS (6081 ENGINE).....	40-12	CYLINDER HEAD (6076).....	20-4
COVER, HOUSING, TRANSMISSION AND DIFFERENTIAL.....	50-7	CYLINDER HEAD (6081 ENGINE).....	20-6
COVER, HYDROSTATIC DRIVE PUMP.....	50-32	CYLINDER HEAD BOLTS (6076).....	20-4
COVER, INJECTION PUMP ACCESS (6076).....	20-53	CYLINDER HEAD BOLTS (6081 ENGINE).....	20-6
COVER, OIL COOLER (6081 ENGINE) (ESN -136896).....	20-64	CYLINDER HEAD GASKET (6076).....	20-4
COVER, OIL COOLER (6081 ENGINE) (ESN 136897-).....	20-66	CYLINDER HEAD GASKET (6081 ENGINE).....	20-6
COVER, OIL FILLER (ENGINE) (6068HN052).....	25-22	CYLINDER HEAD GASKET KIT (6076).....	20-34
COVER, PUMP.....	80-12	CYLINDER HEAD GASKET KIT (6081 ENGINE).....	20-36
COVER, ROCKER ARM (6068HN052).....	25-3	CYLINDER HEAD REMOVAL GASKET KIT (6068HN052).....	25-20
COVER, ROCKER ARM (6076).....	20-9	CYLINDER LINERS (6076).....	20-38
COVER, ROCKER ARM (6081 ENGINE).....	20-10	CYLINDER LINERS (6081 ENGINE).....	20-39
COVER, STABILIZER CYLINDER.....	80-16	CYLINDER LUBRICATION LINES.....	160-1
COVER, THERMOSTAT (6068HN052).....	25-40	CYLINDER, BASKET DUMP.....	70-60
COVER, TIMING GEAR (6076).....	20-53	CYLINDER, BRAKE SLAVE.....	60-16
COVER, TIMING GEAR (W/ AUX. DRIVE) (6068HN052).....	25-36	CYLINDER, BRAKE, MASTER.....	60-10
COVER, TIMING GEAR (6081 ENGINE).....	20-54	CYLINDER, ROW FINDER (23001-).....	70-78
COVER, VALVE (6076).....	20-9	CYLINDER, STEERING (-23000).....	70-62
COVER, VALVE (6081 ENGINE).....	20-10	CYLINDER, STEERING (23001-).....	70-63
COVER, W/O FUEL PUMP (6068HN052).....	25-60	CYLINDER, UNIT LIFT.....	70-59
COVERS AND INNER ROOF.....	90-30		
CRANKSHAFT (6068HN052).....	25-23	D	
CRANKSHAFT (6076).....	20-44	DAMPER KEY (6076).....	20-44
CRANKSHAFT (6081 ENGINE).....	20-45	DAMPER KEY (6081 ENGINE).....	20-45
		DAMPER, CRANKSHAFT (6076).....	20-47
		DAMPER, CRANKSHAFT (6081 ENGINE).....	20-48
		DANGER DECALS.....	170-2
		DECAL SET, CHASSIS.....	170-9

ALPHABETICAL INDEX - CONTINUED

	PAGE	PAGE
DECALS, "50TH ANNIVERSARY" (SERIAL NO. 4001 - 6000).....	170-1	
DECALS, SAFETY.....	170-2	
DIAGRAM, ELECTRICAL WIRING.....	40-15	
DIAGRAM, ELECTRICAL WIRING.....	40-17	
DIAGRAM, ELECTRICAL WIRING.....	40-19	
DIFFERENTIAL GEARS AND SHAFTS.....	50-12	
DIMMER SWITCH.....	40-76	
DIODE MODULE.....	40-64	
DIPSTICK COVER (6081 ENGINE).....	20-74	
DIPSTICK, ENGINE GUIDE (6068HN052).....	25-33	
DIPSTICK, ENGINE OIL (6068HN052).....	25-33	
DIPSTICK, ENGINE OIL (6076).....	20-70	
DIPSTICK, ENGINE OIL (6081 ENGINE).....	20-71	
DISC, DOFFER.....	120-26	
DISTRIBUTOR ASSEMBLY, MOISTENER.....	140-20	
DOFFER.....	120-26	
DOFFER ADJUSTER AND STUB SHAFT.....	120-24	
DOFFER DRIVE IDLER GEAR.....	120-29	
DOFFER GAUGES.....	120-28	
DOFFER IDLER GEARS.....	120-14	
DOMELIGHT (ROCKER TYPE).....	40-28	
DOOR, CAB (SOUND-GARD CAB).....	90-24	
DOOR, COTTON, LARGE OUTSIDE.....	150-4	
DOOR, COTTON, LARGE OUTSIDE CONSERAIION P12 38/40 TO VRS 2M.....	150-5	
DOOR, COTTON, LARGE OUTSIDE CONSERAIION VRS 2M TO VRS 38/40.....	150-6	
DOOR, COTTON, SMALL INSIDE (IN-LINE).....	150-2	
DOORS, UNIT.....	110-16	
DRAIN KIT, COLD WEATHER.....	140-24	
DRIVE GEAR, OIL PUMP (6076).....	20-44	
DRIVE GEAR, OIL PUMP (6081 ENGINE).....	20-45	
DRIVE GEARS, UPPER HOUSING DRUM.....	120-14	
DRIVE SHAFT, FINAL DRIVE.....	50-20	
DRIVE SHAFT, PUMP, HYDROSTATIC.....	50-34	
DRIVE SHAFT, SPLINED.....	80-48	
DRIVE SHAFT, UNIT.....	120-4	
DRIVE WHEELS.....	80-37	
DRIVE, CONVEYOR.....	160-28	
DRIVE, ENGINE FAN (6081 ENGINE).....	20-87	
DRIVE, FINAL.....	50-17	
DRIVE, HYDRAULIC PUMP (16001-).....	70-10	
DRIVE, HYDROSTATIC MOTOR.....	50-22	
DRUM DRIVE GEARS, UPPER HOUSING.....	120-14	
DRUM HEAD AND CAM.....	120-22	
DRUM SLIP CLUTCH AND IDLER GEARS (-16001).....	120-12	
DRUM SPEED SENSOR.....	120-14	
DRUM SPPD MONITOR FIRMWARE UPGRADE.....	120-14	
DRUM, BRAKE.....	60-12	
DRUM, PICKER BAR.....	120-20	
DRVESHAFTE.....	120-8	
DRYER-RECEIVER, A/C.....	90-52	
DUCT LIFT CHAINS.....	160-15	
DUCT SUPPORT.....	160-12	
DUCT, LADDER (-23000).....	150-10	
DUCT, LADDER (23001-).....	150-11	
DUCT, R.H. OFFSET, 2.5".....	150-7	
DUCT, UNIT TO BASKET (INNER).....	150-14	
DUCTS, INNER.....	150-8	
DUCTS, UNIT TO BASKET.....	150-12	
E		
ECU (6068HN052).....	25-56	
ELBOW TRANSITION, JET POST.....	150-17	
ELECTRIC SHUT-OFF SOLENOID (6076).....	30-45	
ELECTRIC SHUT-OFF SOLENOID REPAIR KIT (6076).....	30-44	
ELECTRIC SHUT-OFF SOLENOID, FUEL (6081 ENGINE).....	30-46	
ELECTRIC SHUT-OFF SOLENOID, FUEL INJECTION (6081 ENGINE).....	30-42	
ELECTRICAL CONNECTOR LUBRICANT.....	20-78	
ELECTRICAL CONNECTOR SERVICE KIT.....	40-46	
ELECTRICAL CONNECTOR, CONSOLE SWITCH.....	40-57	
ELECTRICAL CONNECTOR, DIODE MODULE.....	40-64	
ELECTRICAL CONNECTOR, FAN CONTROLLER.....	40-58	
ELECTRICAL CONNECTOR, FUSE AND RELAY.....	40-56	
ELECTRICAL CONNECTOR, HYDRO HANDLE AND GAUGE CLUSTER.....	40-60	
ELECTRICAL CONNECTOR, KEY SWITCH, CONSOLE LIGHT, ETHER SWITCH, HORN.....	40-61	
ELECTRICAL CONNECTOR, MOMENTARY FLOOR SWITCH.....	40-65	
ELECTRICAL CONNECTOR, MONITOR LIGHT MODULE AND TACHOMETER.....	40-55	
ELECTRICAL CONNECTOR, OPTION.....	40-59	
ELECTRICAL CONNECTORS, CAB FLOOR.....	40-62	
ELECTRICAL CONNECTORS, MICROWITCH AND AUXILIARY PLUG.....	40-63	
ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK.....	40-50	
ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK.....	40-52	
ELECTRICAL WIRING DIAGRAM.....	40-15	
ELECTRICAL WIRING DIAGRAM.....	40-17	
ELECTRICAL WIRING DIAGRAM.....	40-19	
ELECTRICALLY OPERATED STARTING AID.....	30-15	
ELECTROMAGNETIC LUBRICATION PUMP CLUTCH.....	130-8	
ELEMENT, FUEL FILTER, FINAL (6068HN052).....	25-50	
ENDS, BASKET.....	160-8	
ENGINE COMPLETE BLOCK ASSEMBLY (6068HN052).....	25-14	
ENGINE CONTROLLER (6068HN052).....	25-56	
ENGINE COOLANT HEATER.....	40-82	
ENGINE FAN AND BELT.....	20-88	
ENGINE FLYWHEEL HOUSING (6068HN052).....	25-25	
ENGINE FRONT BRACKETS (6068HN052).....	25-1	
ENGINE GUIDE DIPSTICK (6068HN052).....	25-33	
ENGINE HARNESS (23001-).....	40-86	
ENGINE HOOD.....	80-6	
ENGINE HOOD SIDE SCREENS AND SUPPORTS.....	80-8	
ENGINE OIL.....	20-1	
ENGINE OIL COOLER (6068HN052).....	25-28	
ENGINE OIL COOLER (6076).....	20-62	
ENGINE OIL COOLER (6081 ENGINE) (ESN -136896).....	20-64	
ENGINE OIL COOLER (6081 ENGINE) (ESN 136897-).....	20-66	

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
ENGINE OIL COOLER GASKET (6068HN052).....	25-28	EXHAUST PIPE AND MUFFLER.....	30-64
ENGINE OIL COOLER HOUSING (6068HN052).....	25-28	EXHAUST VALVE (6068HN052).....	25-6
ENGINE OIL DIPSTICK (6068HN052).....	25-33	EXHAUST VALVE SHIELD (6076).....	20-4
ENGINE OIL DIPSTICK (6076).....	20-70	EXHAUST VALVE SHIELD (6081 ENGINE).....	20-6
ENGINE OIL DIPSTICK (6081 ENGINE).....	20-71	EXHAUST VALVES (6076).....	20-4
ENGINE OIL DIPSTICK TUBE (6076).....	20-70	EXHAUST VALVES (6081 ENGINE).....	20-6
ENGINE OIL DIPSTICK TUBE (6081 ENGINE).....	20-71	EXPANDED ENGINE OVERHAUL KIT(S) (6076).....	20-26
ENGINE OIL FILLER NECK (6068HN052).....	25-22	EXTENDER LINKAGE, BASKET.....	160-36
ENGINE OIL FILTER (6076).....	20-62	EXTENDER, BASKET.....	160-34
ENGINE OIL FILTER (6068HN052).....	25-26	EXTENSION AND GRATE, STALKLIFTERS.....	110-18
ENGINE OIL FILTER (6081 ENGINE).....	20-68	EXTENSION, BASKET.....	160-24
ENGINE OIL FILTER ADAPTER GASKET (6068HN052).....	25-26	EXTENSION, PLATFORM.....	90-10
ENGINE OIL FILTER HEADER (6068HN052).....	25-26	EXTENSIONS, REAR AXLE.....	80-46
ENGINE OIL FILTER HEADER TUBES (6068HN052).....	25-26	EXTENSIONS, REAR AXLE.....	80-47
ENGINE OIL PAN GASKET (6068HN052).....	25-31	EXTENSIONS, UNIT LIFT.....	100-2
ENGINE OIL PUMP (6076).....	20-58	EXTINGUISHER, FIRE.....	80-34
ENGINE OIL PUMP (6068HN052).....	25-30	EXTINGUISHER, FIRE.....	80-35
ENGINE OIL PUMP (6081 ENGINE).....	20-60		
ENGINE OIL PUMP GEAR (6068HN052).....	25-30	F	
ENGINE OIL PUMP INLET TUBE (6068HN052).....	25-30	F.I.P. GEAR (DENSO) (6076).....	30-40
ENGINE OIL PUMP INTAKE (6068HN052).....	25-31	F.I.P. LUBE LINES (DENSO) (6076).....	30-40
ENGINE OIL PUMP INTAKE (6076).....	20-76	FAN ASSEMBLY, COMPLETE FAN.....	150-1
ENGINE OIL PUMP INTAKE (6081 ENGINE).....	20-77	FAN BELT AND PULLEY (6081 ENGINE).....	20-87
ENGINE OVERHAUL GASKET KIT (6068HN052).....	25-18	FAN CONTROLLER ADAPTER.....	40-75
ENGINE OVERHAUL KIT (6068HN052).....	25-16	FAN CONTROLLER CONNECTOR.....	40-58
ENGINE OVERHAUL KIT (6081 ENGINE).....	20-28	FAN DRIVE ADAPTER (W/ AUX. DRIVE) (6068HN052).....	25-36
ENGINE OVERHAUL KIT(S) (6076).....	20-26	FAN DRIVE SUPPORT (6068HN052).....	25-49
ENGINE RAILS.....	80-2	FAN DRIVE, FIXED (6076).....	20-86
ENGINE REBUILD GASKET KIT (6076).....	20-34	FAN ENGAGE ACTUATOR.....	150-24
ENGINE REBUILD GASKET KIT (6081 ENGINE).....	20-36	FAN HOUSING.....	150-18
ENGINE SHORT BLOCK (6068HN052).....	25-14	FAN IDLER AND LINKAGE.....	150-22
ENGINE SPEED SENSOR (6068HN052).....	25-61	FAN IDLER AND LINKAGE.....	150-26
ENGINE SPEED SENSOR (6076).....	20-55	FAN PULLEY (6076).....	20-86
ENGINE SPEED SENSOR (6081 ENGINE).....	20-56	FAN PULLEY, AIR CONDITIONER COMPRESSOR (6081 ENGINE).....	90-58
ENGINE TEMPERATURE SENDER.....	20-8	FAN SHAFT, SHEAVE AND ROTOR.....	150-20
ENGINE THERMOSTAT AND HOUSING (6068HN052).....	25-42	FAN, COVER, COTTON.....	80-14
ENGINE UNDERHAUL KIT (STD BRGS) (6076).....	20-30	FAN, ENGINE.....	20-88
ENGINE VENTILATING SYSTEM (6068HN052).....	25-4	FEEDBACK SENSOR, ROW-TRAK.....	40-88
ENGINE VENTILATOR OUTLET HOSE (6081 ENGINE).....	20-10	FIELD LAMPS AND BASKET LAMPS.....	40-27
ENGINE VENTILATOR OUTLET HOSE (6076).....	20-9	FILTER, AIR, CAB.....	90-45
ENGINE, REMANUFACTURED BASIC (6076).....	20-22	FILTER, CAB VENT.....	90-31
ETHER STARTING FITTINGS (6081 ENGINE).....	30-16	FILTER, ENGINE OIL (6076).....	20-62
ETHER STARTING FLUID.....	30-15	FILTER, ENGINE OIL (6068HN052).....	25-26
ETHER SWITCH CONNECTOR.....	40-61	FILTER, ENGINE OIL (6081 ENGINE).....	20-68
EVAPORATOR AND HOSES.....	90-48	FILTER, FUEL (23001-) 30 MICRON.....	30-27
EXHAUST MANIFOLD (6068HN052).....	25-64	FILTER, FUEL (6076).....	30-28
EXHAUST MANIFOLD GASKETS (6076).....	30-2	FILTER, FUEL (6081 ENGINE).....	30-30
EXHAUST MANIFOLD GASKETS (6081 ENGINE).....	30-3	FILTER, FUEL, FINAL (6068HN052).....	25-50
EXHAUST MANIFOLDS (6076).....	30-2	FILTER, HYDRAULIC ASSEMBLY (XXXX - 23000).....	70-30
EXHAUST MANIFOLDS (6081 ENGINE).....	30-3	FILTER, HYDRAULIC ASSEMBLY (23001-).....	70-32
		FILTER, PRE- FUEL (6081 ENGINE).....	30-30
		FILTER, WATER.....	140-11
		FILTER, WATER PUMP (WEEP HOLE) (6081 ENGINE).....	20-54
		FILTER, WEEP HOLE (WATER PUMP) (6076).....	20-94

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
FILTERS FUEL		FRONT WATER MANIFOLD (6081 ENGINE).....	20-92
(23001-).....	30-24	FUEL CHECK VALVE (6076).....	30-28
FINAL DRIVE.....	50-17	FUEL CHECK VALVE (6081 ENGINE).....	30-30
FINAL DRIVE AXLE, GEAR AND BEARINGS.....	50-19	FUEL CONTROL LINES (DENSO)	
FINAL DRIVE HARDWARE.....	80-48	(6076).....	30-40
FINAL DRIVE HOUSING AND BEARING CAP.....	50-18	FUEL CONTROL LINES (6081 ENGINE).....	30-42
FINAL DRIVE PINION, DRIVE SHAFTS AND		FUEL COOLER KIT	
BEARINGS.....	50-20	(23001-).....	20-82
FIRE EXTINGUISHER.....	80-34	FUEL FILTER (23001-)	
FIRE EXTINGUISHER.....	80-35	30 MICRON.....	30-27
FIRMWARE, DRUM SPEED MONITOR UPGRADE.....	120-14	FUEL FILTER (6076).....	30-26
FITTING, TURBOCHARGER OIL LINE		FUEL FILTER (6076).....	30-28
(6068HN052).....	25-46	FUEL FILTER (6081 ENGINE).....	30-30
FITTINGS, CYLINDER BLOCK (6076).....	20-16	FUEL FILTER BASE (6081 ENGINE).....	30-30
FITTINGS, CYLINDER BLOCK (6081 ENGINE).....	20-18	FUEL FILTER BRACKET (23001-)	
FITTINGS, ETHER STARTING (6081 ENGINE).....	30-16	30 MICRON.....	30-27
FITTINGS, LUBRICATION FILL.....	130-10	FUEL FILTER BRACKET (6076).....	30-26
FITTINGS, WATER PUMP.....	140-8	FUEL FILTER LINES (6076).....	30-28
FIXED FAN DRIVE (6076).....	20-86	FUEL FILTER LINES (6081 ENGINE).....	30-30
FIXTURE, FEEDBACK SENSOR, ROW-TRAK.....	40-88	FUEL FILTER, FINAL AND LINE	
FLANGE, PICKER BAR DRUM.....	120-20	(6068HN052).....	25-50
FLAP MONITOR.....	40-80	FUEL FILTERS	
FLAP, BASKET.....	160-32	(23001-).....	30-24
FLAT O-RING KIT, HYDRAULIC.....	70-67	FUEL GAUGE	
FLOOR CONNECTORS, CAB ELECTRICAL.....	40-62	(-23000).....	40-70
FLOOR MAT.....	90-27	FUEL GAUGE	
FLOOR SWITCH CONNECTOR, MOMENTARY.....	40-65	(23001-).....	40-72
FLOOR, BASKET.....	160-4	FUEL INJ LINES (6076).....	30-36
FLOOR, LEFT-HAND PLATFORM.....	90-6	FUEL INJ NOZZLES (6076).....	30-36
FLOOR, PLATFORM.....	90-4	FUEL INJECTION INJECTOR (6068HN052).....	25-54
FLUSH SYSTEM SWITCH, FOOT CONTROL.....	40-77	FUEL INJECTION LINE RAIL (6068HN052).....	25-56
FLUSH WATER LINES AND FITTINGS.....	140-18	FUEL INJECTION LINES (6068HN052).....	25-56
FLYWHEEL		FUEL INJECTION NOZZLE (DENSO)	
(6076).....	20-40	(6076).....	30-32
FLYWHEEL		FUEL INJECTION NOZZLE (6068HN052).....	25-54
(6081).....	20-41	FUEL INJECTION NOZZLE (6081 ENGINE).....	30-34
FLYWHEEL		FUEL INJECTION NOZZLES AND LINES	
(6081).....	20-42	(6081 ENGINE).....	30-38
FLYWHEEL HOUSING		FUEL INJECTION PUMP	
(6068HN052).....	25-25	(6068HN052).....	25-52
FOLLOWER, CAM (6068HN052).....	25-10	FUEL INJECTION PUMP (DENSO)	
FOLLOWER, CAMSHAFT (6076).....	20-11	(6076).....	30-40
FOLLOWER, CAMSHAFT (6076).....	20-13	FUEL INJECTION PUMP (6068HN052).....	25-56
FOLLOWER, CAMSHAFT (6081 ENGINE).....	20-12	FUEL INJECTION PUMP (6081 ENGINE).....	30-42
FOLLOWER, CAMSHAFT (6081 ENGINE).....	20-14	FUEL INJECTION PUMP ACCESS COVER	
FRAME WEIGHTS.....	80-1	(6081 ENGINE).....	40-12
FRAME, CONVEYOR.....	160-26	FUEL INJECTION PUMP ADAPTER (6068HN052).....	25-56
FRAME, CONVEYOR ASSEMBLY.....	160-30	FUEL INJECTION PUMP DRIVE GEAR	
FRAME, LID LINKAGE.....	160-19	(6068HN052).....	25-56
FRAME, MAIN.....	80-2	FUEL INJECTION PUMP GOVERNOR LEVERS	
FRAME, PICKING UNIT BOTTOM		(DENSO) (6076).....	30-51
(PRO-12 UNIT).....	110-8	FUEL INJECTION PUMP GOVERNOR LEVERS	
FRAME, PLATFORM.....	90-2	(6081 ENGINE).....	30-52
FRAME, UNIT LIFT.....	100-2	FUEL INJECTION PUMP HOUSING CONNECTORS	
FRONT CHASSIS WIRING HARNESS		(DENSO) (6076).....	30-48
(23001-).....	40-42	FUEL INJECTION PUMP HOUSING CONNECTORS	
FRONT DRUM PRESSURE PLATE (PRO-12 18S).....	110-12	(6081 ENGINE).....	30-49
FRONT OIL SEAL		FUEL INJECTION PUMP SENSOR (6068HN052).....	25-56
(6076).....	20-53	FUEL INJECTION SYSTEM (6068HN052).....	25-56
FRONT OIL SEAL (6081 ENGINE).....	20-54	FUEL INJECTOR FEED TUBE (6068HN052).....	25-54
FRONT PLANT SHIELDS.....	80-32	FUEL INJECTOR GLOW PLUG WIRING HARNESS	
FRONT PLATE (6068HN052).....	25-34	(6068HN052).....	25-58
FRONT SEAL (W/ AUX. DRIVE)		FUEL INJECTOR KIT (6068HN052).....	25-54
(6068HN052).....	25-36	FUEL INJECTOR WIRE HARNESS (6068HN052).....	25-56
FRONT STRAPS, ENGINE (6068HN052).....	25-2	FUEL INJECTOR GLOW PLUG (6068HN052).....	25-58
FRONT WATER MANIFOLD		FUEL LEAK-OFF LINE (DENSO)	
(6076).....	20-90	(6076).....	30-40

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
FUEL LEAK-OFF LINES (6076)	30-36	GASKET, OIL PAN (6081 ENGINE)	20-74
FUEL LINES		GASKET, OIL PUMP (6081 ENGINE)	20-60
(23001-)	30-24	GASKET, OIL PUMP INTAKE (6076)	20-76
FUEL LINES / FUEL FILTER-FUEL INJECTION		GASKET, OIL PUMP INTAKE (6081 ENGINE)	20-77
PUMP (6068HN052)	25-52	GASKET, REAR OIL SEAL	
FUEL PUMP, W/O, COVER		(6076)	20-51
(6068HN052)	25-60	GASKET, REAR OIL SEAL (6081 ENGINE)	20-52
FUEL SHUT-OFF BRACKET (6076)	30-45	GASKET, ROCKER ARM COVER	
FUEL SHUT-OFF BRACKET (6081 ENGINE)	30-46	(6068HN052)	25-3
FUEL SHUT-OFF LEVER KIT (6081 ENGINE)	30-46	GASKET, ROCKER ARM COVER (6076)	20-9
FUEL SHUT-OFF SOLENOID AND BRACKET		GASKET, ROCKER ARM COVER (6081 ENGINE)	20-10
(6081 ENGINE)	30-46	GASKET, ROCKER ARM SHAFT SUPPORT	
FUEL TANK		(6068HN052)	25-10
(S/N -14000)	30-18	GASKET, THERMOSTAT COVER	
FUEL TANK		(6068HN052)	25-40
(14001 - 23000)	30-20	GASKET, TIMING GEAR COVER	
FUEL TANK		(W/ AUX. DRIVE) (6068HN052)	25-36
(23001-)	30-22	GASKET, TIMING GEAR COVER	
FUEL TRANSFER PUMP (DENSO)		(6076)	20-53
(6076)	30-40	GASKET, TIMING GEAR COVER (6081 ENGINE)	20-54
FUEL TRANSFER PUMP (DENSO) (6076)	30-59	GASKET, TURBOCHARGER	
FUEL TRANSFER PUMP (6081 ENGINE)	30-60	(6068HN052)	25-47
FUSE AND RELAY BLOCK	40-56	GASKET, TURBOCHARGER (6076)	30-10
FUSE LABEL	90-34	GASKET, TURBOCHARGER (6081 ENGINE)	30-12
FUSE PANEL COVER	90-34	GASKET, TURBOCHARGER OIL LINE	
FUSES AND RELAYS, CONSOLE		(6068HN052)	25-46
(-23000)	40-20	GASKET, WATER MANIFOLD	
FUSES AND RELAYS, CONSOLE		(6076)	20-90
(23001-)	40-22	GASKET, WATER MANIFOLD (6081 ENGINE)	20-92
FUSES, MAIN, AND RELAYS	40-68	GASKET, WATER PUMP (6076)	20-94
		GASKET, WATER PUMP (6081 ENGINE)	20-96
G		GASKETS, EXHAUST MANIFOLD (6076)	30-2
GASKET KIT, CYLINDER HEAD (6076)	20-34	GASKETS, EXHAUST MANIFOLD (6081 ENGINE)	30-3
GASKET KIT, CYLINDER HEAD (6081 ENGINE)	20-36	GASKETS, INTAKE MANIFOLD (6076)	30-4
GASKET KIT, CYLINDER HEAD REMOVAL		GASKETS, INTAKE MANIFOLD (6081 ENGINE)	30-6
(6068HN052)	25-20	GAUGE CLUSTER CONNECTOR	40-60
GASKET KIT, ENGINE OVERHAUL (6068HN052)	25-18	GAUGES, DOFFER	120-28
GASKET KIT, ENGINE REBUILD (6076)	20-34	(-23000)	40-70
GASKET KIT, ENGINE REBUILD (6081 ENGINE)	20-36	GAUGES, MONITOR	
GASKET KIT, SHORT BLOCK (6076)	20-34	(23001-)	40-72
GASKET KIT, SHORT BLOCK (6081 ENGINE)	20-36	GEAR BOX, SKIP ROW	130-18
GASKET, COOLANT MANIFOLD		GEAR CASE HUB, LOWER	120-10
(6068HN052)	25-42	GEAR CASE, PICKING UNIT	120-6
GASKET, CYLINDER HEAD (6068HN052)	25-6	GEAR, BASKET COMPACTOR DRIVE SHAFT	160-23
GASKET, CYLINDER HEAD (6076)	20-4	GEAR, CAMSHAFT (6076)	20-13
GASKET, CYLINDER HEAD (6081 ENGINE)	20-6	GEAR, CAMSHAFT (6081 ENGINE)	20-14
GASKET, ENGINE OIL COOLER		GEAR, CRANKSHAFT	
(6068HN052)	25-28	(6068HN052)	25-23
GASKET, ENGINE OIL FILTER ADAPTER		GEAR, DOFFER	120-24
(6068HN052)	25-26	GEAR, DOFFER DRIVE IDLER	120-29
GASKET, ENGINE OIL PAN		GEAR, DOFFER IDLER	120-14
(6068HN052)	25-31	GEAR, ENGINE OIL PUMP (6068HN052)	25-30
GASKET, FUEL TRANSFER PUMP		GEAR, F.I.P. (DENSO)	
(6081 ENGINE)	30-60	(6076)	30-40
GASKET, OIL COOLER		GEAR, FINAL DRIVE	50-19
(6076)	20-62	GEAR, FUEL INJECTION PUMP DRIVE	
GASKET, OIL COOLER (6081 ENGINE)		(6068HN052)	25-56
(ESN -136896)	20-64	GEAR, OIL PUMP DRIVE	
GASKET, OIL COOLER (6081 ENGINE)		(6076)	20-44
(ESN 136897-)	20-66	GEAR, OIL PUMP DRIVE	
GASKET, OIL FILTER HOUSING		(6076)	20-58
(6076)	20-62	GEAR, OIL PUMP DRIVE (6081 ENGINE)	20-45
GASKET, OIL FILTER HOUSING (6081 ENGINE)	20-68	GEAR, OIL PUMP DRIVE (6081 ENGINE)	20-60
GASKET, OIL PAN		GEAR, RH COMPACTOR AUGER BEVEL	160-21
(6076)	20-72	GEAR, STARTER	
		(6076)	20-40

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
GEAR, STARTER (6081).....	20-41	HEAD BOLT KIT (6076).....	20-4
GEAR, STARTER (6081).....	20-42	HEAD BOLT KIT (6081 ENGINE).....	20-6
GEARBOX, OFFSET.....	120-8	HEAD, CYLINDER (6068HN052).....	25-6
GEARS-IDLE (UPPER AND LOWER) (6068HN052).....	25-34	HEAD, CYLINDER (6076).....	20-4
GEARS, DIFFERENTIAL.....	50-12	HEAD, CYLINDER (6081 ENGINE).....	20-6
GEARS, DRUM IDLER (-16001).....	120-12	HEAD, PICKER DRUM.....	120-22
GEARS, PICKER BAR.....	120-18	HEADER, ENGINE OIL FILTER (6068HN052).....	25-26
GEARS, SPIRAL BEVEL.....	50-14	HEADER, PRE-FUEL FILTER (6081 ENGINE).....	30-30
GEARS, UPPER HOUSING DRUM DRIVE.....	120-14	HEADLINER, CAB ROOF.....	90-31
GLASS, CAB WINDOW.....	90-22	HEAT EXCHANGER CORES (23001-).....	20-82
GOVERNOR LEVERS, FUEL INJECTION PUMP (DENSO) (6076).....	30-51	HEATER CONTROL VALVE AND HOSES.....	90-46
GOVERNOR LEVERS, FUEL INJECTION PUMP (6081 ENGINE).....	30-52	HEATER, ENGINE COOLANT.....	40-82
GRATE, STALKLIFTER.....	110-18	HEIGHT SENSING HYDRAULIC LINE AND HOSES (TOP OF UNIT TO VALVE).....	70-18
GREASE CHIME CONNECTOR.....	40-61	HEIGHT SENSING HYDRAULIC LINES, SUPPLEMENTAL.....	70-20
GREEN FLUSH WATER LINES.....	140-18	HEIGHT SENSING HYDRAULICS.....	70-16
GRID BARS AND SUPPORTS, PICKING UNIT (PRO-12 18S).....	110-10	HEIGHT SENSING LINKAGE AND VALVE.....	110-20
GRILLE, SPEAKER.....	90-31	HEIGHT SENSING VALVE.....	70-54
GROMMETS, UNIT CABINET.....	110-24	HINGE, CAB WINDOW.....	90-23
GROUND WIRE, A/C ELECTRIC CLUTCH.....	90-59	HOLDER, MOISTENER PAD.....	140-20
GROUND WIRE, AIR CONDITIONING COMPRESSOR (6076 ENGINE).....	90-62	HOOD, ENGINE.....	80-6
GUIDE, PLANT.....	110-18	HOOD, REAR.....	80-13
H			
HAND PRIMER, FUEL TRANSFER PUMP (6081 ENGINE).....	30-60	HORN.....	40-81
HANDBRAKE LEVER.....	60-18	HORN CONNECTOR, 3-SECOND AND PULSING.....	40-61
HANDLE, HYDROSTATIC CONTROL.....	90-38	HORN SWITCH.....	40-74
HANDLE, UNIT DOOR.....	110-16	HOSE, A/C RECEIVER-DRYER.....	90-52
HANDRAIL, FRONT & REAR.....	160-19	HOSE, BASKET CYL. END AND ROCKSHAFT PIVOT LUBRICATION.....	160-1
HANDRAILS AND LADDER.....	90-8	HOSE, ENGINE VENT (6068HN052).....	25-4
HANDRAILS, SIDE.....	160-20	HOSE, ENGINE VENTILATOR OUTLET (6081 ENGINE).....	20-10
HANGER, PICKING UNIT.....	110-6	HOSE, ENGINE VENTILATOR OUTLET (6076).....	20-9
HARDWARE KIT, COMPRESSOR.....	90-60	HOSE, FIRE EXTINGUISHER.....	80-34
HARDWARE, FINAL DRIVE.....	80-48	HOSE, HEIGHT SENSING HYDRAULIC (TOP OF UNIT TO VALVE).....	70-18
HARDWARE, PREFERRED METRIC.....	180-2	HOSE, TURBOCHARGER OIL LINE (6068HN052).....	25-46
HARNES, ALTERNATOR WIRING (6081 ENGINE).....	40-10	HOSE, UNIT LIFT ARM LUBRICATION.....	100-4
HARNES, BACK UP ALARM.....	40-66	HOSE, UNIT LUBRICATION.....	130-12
HARNES, CHASSIS WIRING (-4000).....	40-34	HOSES AND FITTINGS, OIL COOLER BYPASS.....	50-40
HARNES, CHASSIS WIRING (20001 - 23000).....	40-38	HOSES AND FITTINGS, ROW TRAK.....	70-72
HARNES, CHASSIS WIRING (23001-).....	40-40	HOSES AND LINES, HYDRAULIC RETURN (-23000).....	70-34
HARNES, CHASSIS WIRING (4001 - 20000).....	40-36	HOSES AND LINES, HYDRAULIC RETURN (23001-).....	70-36
HARNES, ENGINE (23001-).....	40-86	HOSES AND LINES, HYDRAULIC RETURN (23001-).....	70-38
HARNES, FRONT CHASSIS WIRING (23001-).....	40-42	HOSES AND VALVES, ROW TRAK.....	70-70
HARNES, ROW TRAK.....	40-84	HOSES, FLUSH WATER, GREEN.....	140-18
HARNES, ROW UNIT MONITOR WIRING.....	40-79	HOSES, HEATER.....	90-46
HARNES, STARTER, WIRING (6076).....	40-2	HOSES, LUBRICATION TRANSFER PUMP.....	130-16
HARNES, TETHER SWITCH (NO. 4 UNIT).....	90-63	HOSES, RADIATOR (-23000).....	20-80
HARNES, WIRING, FAN CONTROLLER ADAPTER.....	40-75	HOSES, RADIATOR (23001-).....	20-84
HARNES, WIRING, PICKING UNIT/WARNING LAMP.....	40-33	HOSES, WATER, MOISTENER COLUMN (CLEAR).....	140-16
HARNES, WIRING, PLATFORM.....	40-29	HOUSING CONNECTORS, FUEL INJECTION PUMP (6081 ENGINE).....	30-49
		HOUSING, ENGINE OIL COOLER (6068HN052).....	25-28
		HOUSING, FAN.....	150-18
		HOUSING, FINAL DRIVE.....	50-18
		HOUSING, FLYWHEEL (6068HN052).....	25-25
		HOUSING, HYDROSTATIC PUMP.....	50-30

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HOUSING, OIL COOLER AND FILTER (6076).....	20-62	HYDRAULIC PUMP DRIVE AND SUPPORTS (-16000).....	70-2
HOUSING, OIL FILTER (6081 ENGINE).....	20-68	HYDRAULIC PUMP DRIVE AND SUPPORTS (16001-).....	70-10
HOUSING, PICKING UNIT.....	110-1	HYDRAULIC PUMP OVERHAUL KIT (2.4 IN3) (-16000).....	70-8
HOUSING, PICKING UNIT UPPER (PRO-12 UNIT).....	110-2	HYDRAULIC PUMP STROKE CONTROL VALVE (-16000).....	70-6
HOUSING, REAR OIL SEAL (6076).....	20-51	HYDRAULIC PUMP SUCTION & BLEED-OFF HOSES (-23000).....	70-40
HOUSING, REAR OIL SEAL (6081 ENGINE).....	20-52	HYDRAULIC PUMP SUCTION & BLEED-OFF HOSES (23001-).....	70-42
HOUSING, THERMOSTAT (6068HN052).....	25-42	HYDRAULIC PUMP, REPLACEMENT (-16000).....	70-3
HOUSING, THERMOSTAT, FRONT (6076).....	20-90	HYDRAULIC PUMP, REPLACEMENT (16001-).....	70-12
HOUSING, THERMOSTAT, FRONT (6081 ENGINE).....	20-92	HYDRAULIC RESERVOIR ASSEMBLY (XXXX - 23000).....	70-30
HOUSING, TRANSMISSION AND DIFFERENTIAL.....	50-6	HYDRAULIC RESERVOIR ASSEMBLY (23001-).....	70-32
HOUSING, TURBOCHARGER CENTER (6076) (SCHWITZER).....	30-14	HYDRAULIC RETURN LINES AND HOSES (-23000).....	70-34
HOUSING, UPPER DOFFER ADJUSTING.....	120-24	HYDRAULIC RETURN LINES AND HOSES (23001-).....	70-36
HUB, FAN DRIVE (6068HN052).....	25-49	HYDRAULIC RETURN LINES AND HOSES (23001-).....	70-38
HUB, LOWER GEAR CASE.....	120-10	HYDRAULIC TUBES & HOSES, STEERING TO CYLINDERS.....	60-8
HYDRAULIC ANEROID ACTIVATOR (DENSO) (6076).....	30-54	HYDRAULIC TUBES AND HOSES, STEERING.....	60-6
HYDRAULIC ANEROID ACTIVATOR (6076).....	30-57	HYDRAULIC VALVE AND HOSES, ROW FINDER.....	70-74
HYDRAULIC ANEROID ACTIVATOR, FUEL INJECTION (6081 ENGINE).....	30-55	HYDRAULIC VALVE BRACKET.....	70-1
HYDRAULIC CONTROL VALVE.....	70-14	HYDRAULIC/HYDROSTATIC RESERVOIR (S/N -XXXX).....	70-28
HYDRAULIC CYLINDER, UNIT LIFT.....	70-59	HYDRO HANDLE CONNECTOR.....	40-60
HYDRAULIC CYLINDER, 3-1/2" X 10".....	70-61	HYDROSTATIC CONTROL CABLE.....	90-40
HYDRAULIC CYLINDERS, BASKET TELESCOPING.....	70-26	HYDROSTATIC CONTROL HANDLE.....	90-38
HYDRAULIC FILTER (23001-).....	70-36	HYDROSTATIC DRIVE CHARGE PUMP.....	50-35
HYDRAULIC FILTER ASSEMBLY (XXXX - 23000).....	70-30	HYDROSTATIC DRIVE DISPLACEMENT CONTROL VALVE.....	50-36
HYDRAULIC FILTER ASSEMBLY (23001-).....	70-32	HYDROSTATIC DRIVE DISPLACEMENT CONTROL VALVE.....	50-38
HYDRAULIC HOSE, HYDRAULIC PUMP SUCTION AND BLEED-OFF.....	70-40	HYDROSTATIC DRIVE MOTOR.....	50-22
HYDRAULIC HOSE, HYDRAULIC PUMP SUCTION AND BLEED-OFF (23001-).....	70-42	HYDROSTATIC DRIVE MOTOR, KIT.....	50-24
HYDRAULIC HOSES, STABILIZER CYLINDER & FITTINGS (-23000).....	70-44	HYDROSTATIC DRIVE OIL LINES.....	50-41
HYDRAULIC HOSES, STABILIZER CYLINDER (23001-).....	70-46	HYDROSTATIC DRIVE PISTON.....	50-33
HYDRAULIC LINES & HOSES, BASKET LIFT (-23000).....	70-22	HYDROSTATIC DRIVE PUMP AND SHAFT.....	50-28
HYDRAULIC LINES & HOSES, BASKET LIFT (23001-).....	70-24	HYDROSTATIC DRIVE PUMP COVER.....	50-32
HYDRAULIC LINES AND HOSES, BASKET COMPACTOR AND CONVEYOR.....	70-52	HYDROSTATIC DRIVE PUMP KIT.....	50-26
HYDRAULIC LINES AND HOSES, UNIT LIFT & HEIGHT SENSING.....	70-16	HYDROSTATIC OIL COOLER AND SUPPORTS.....	50-42
HYDRAULIC LINES, BASKET TELESCOPING.....	70-26	HYDROSTATIC PUMP DRIVE SHAFT.....	50-34
HYDRAULIC LINES, HEIGHT SENSING (TOP OF UNIT TO VALVE).....	70-18	HYDROSTATIC PUMP HOUSING, SWASHPLATE AND SERVO.....	50-30
HYDRAULIC LINES, MAIN PRESSURE (-23000).....	70-48	HYDROSTATIC PUMP, SHEAVE, BRACKETS AND FITTINGS.....	50-27
HYDRAULIC LINES, MAIN PRESSURE (23001-).....	70-50		
HYDRAULIC MOTOR, COMPACTOR.....	70-65	I	
HYDRAULIC MOTOR, CONVEYOR.....	70-66	IDLE GEARS (UPPER AND LOWER) (6068HN052).....	25-34
HYDRAULIC OIL COOLER.....	50-42	IDLER AND LINKAGE, FAN.....	150-22
HYDRAULIC OIL TEMPERATURE SWITCH (XXXX - 23000).....	70-30	IDLER AND LINKAGE, FAN.....	150-26
HYDRAULIC OIL TEMPERATURE SWITCH (23001-).....	70-32	IDLER GEAR, DOFFER DRIVE.....	120-29
HYDRAULIC PUMP (-16000).....	70-4	IDLER GEARS, DRUM (-16001).....	120-12
		IDLER PULLEY, AIR CONDITIONER COMPRESSOR (6081 ENGINE).....	90-58
		IDLER PULLEY, FAN BELT (6068HN052).....	25-49

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
IGNITION SWITCH AND KEY (-23000).....	40-20	KEY, IGNITION (23001-).....	40-22
IGNITION SWITCH AND KEY (23001-).....	40-22	KIT(S), ENGINE OVERHAUL (6076).....	20-26
IMPELLER, WATER PUMP (6076).....	20-94	KIT(S), EXPANDED ENGINE OVERHAUL (6076).....	20-26
INDICATOR LIGHTS.....	40-70	KIT, COLD WEATHER DRAIN.....	140-24
INDICATOR LIGHTS (23001-).....	40-72	KIT, COMPRESSOR HARDWARE.....	90-60
INJECTION NOZZLE, FUEL (DENSO) (6076).....	30-32	KIT, COMPRESSOR SEAL.....	90-54
INJECTION NOZZLE, FUEL (6081 ENGINE).....	30-34	KIT, CRANKSHAFT SEAL (6068HN052).....	25-23
INJECTION PUMP (DENSO) (6076).....	30-40	KIT, CYLINDER HEAD REMOVAL GASKET (6068HN052).....	25-20
INJECTION PUMP ACCESS COVER (W/ AUX. DRIVE) (6068HN052).....	25-36	KIT, ELECTRIC SHUT-OFF SOLENOID REPAIR (6076).....	30-44
INJECTION PUMP ACCESS COVER (6076).....	20-53	KIT, ELECTRICAL CONNECTOR SERVICE.....	40-46
INJECTION PUMP GOVERNOR LEVERS (6081 ENGINE).....	30-52	KIT, ENGINE OVERHAUL (6068HN052).....	25-16
INJECTION PUMP, FUEL (6081 ENGINE).....	30-42	KIT, ENGINE OVERHAUL (6081 ENGINE).....	20-28
INJECTOR, FUEL INJECTION (6068HN052).....	25-54	KIT, ENGINE OVERHAUL GASKET (6068HN052).....	25-18
INLET HOSES, AFTERCOOLER (6076).....	30-8	KIT, HEAD BOLT (6076).....	20-4
INLET OIL FILL (ENGINE) (6068HN052).....	25-22	KIT, HEAD BOLT (6081 ENGINE).....	20-6
INLET, WATER PUMP (6081 ENGINE).....	20-96	KIT, HYDRAULIC PUMP OVERHAUL (2.4 IN3) (-16000).....	70-8
INNER DUCT POST.....	150-8	KIT, HYDROSTATIC DRIVE MOTOR.....	50-24
INNER DUCTS.....	150-8	KIT, HYDROSTATIC DRIVE PUMP.....	50-26
INNER ROOF AND COVERS.....	90-30	KIT, LUBRICATOR POWER DRIVE.....	130-14
INPUT SHAFT, TRANSMISSION.....	50-8	KIT, PISTON/LINER (6068HN052).....	25-21
INSERT, VALVE SEAT (6068HN052).....	25-6	KIT, PISTON/LINER (6076).....	20-38
INSERTS, VALVE SEAT (6076).....	20-4	KIT, PISTON/LINER (6081 ENGINE).....	20-39
INSERTS, VALVE SEAT (6081 ENGINE).....	20-6	KIT, REPAIR, UNIT LIFT CYLINDER.....	70-59
INSIDE CAB MIRROR.....	90-50	KIT, SEAL, 1.50 DIA. MASTER HYDRAULIC CYLINDER.....	70-57
INTAKE MANIFOLD (6068HN052).....	25-44	KIT, SEAL, 1.50 DIA. SLAVE HYDRAULIC CYLINDER.....	70-58
INTAKE MANIFOLD (6076).....	30-4	KIT, SPRAY VALVE.....	140-22
INTAKE MANIFOLD (6081 ENGINE).....	30-6	KIT, STEERING CYLINDER.....	70-64
INTAKE MANIFOLD AND GASKET (6068HN052).....	25-44	KIT, STROKE CONTROL VALVE SHUT-OFF (-16000).....	70-6
INTAKE MANIFOLD GASKETS (6076).....	30-4	KIT, TERMINAL AND WIRING.....	40-44
INTAKE MANIFOLD GASKETS (6081 ENGINE).....	30-6	KIT, UNDERHAUL ENGINE (STD BRGS) (6076).....	20-30
INTAKE VALVE (6068HN052).....	25-6	KIT, WATER PUMP REPAIR.....	20-98
INTAKE VALVES (6076).....	20-4	KIT, WATER PUMP SEAL (6081 ENGINE).....	20-96
INTAKE VALVES (6081 ENGINE).....	20-6	KNEE AND KNUCKLE, REAR AXLE (-23000).....	80-20
INTAKE, ENGINE OIL PUMP (6068HN052).....	25-31	KNEE AND KNUCKLE, REAR AXLE (23001-).....	80-22
INTAKE, ENGINE OIL PUMP (6076).....	20-76		
INTAKE, ENGINE OIL PUMP (6081 ENGINE).....	20-77	L	
INTAKE, WATER PUMP (6068HN052).....	25-39	LABELS, CHASSIS.....	170-9
J		LABELS, SAFETY.....	170-2
JACKSHAFT, UNIT DRIVE.....	120-2	LADDER AND HANDRAILS.....	90-8
JET POST TRANSITION ELBOW.....	150-17	LADDER DUCT (-23000).....	150-10
JETS, PISTON COOLING (6076).....	20-16	LADDER DUCT (23001-).....	150-11
JETS, PISTON COOLING (6081 ENGINE).....	20-18	LAMP, REAR WARNING/TAIL (-4000).....	40-24
JOURNAL, PICKER BAR.....	120-16	LAMP, REAR WARNING/TAIL (4001-).....	40-25
K		LAMPS, FIELD AND BASKET.....	40-27
KEY SWITCH CONNECTOR.....	40-61	LARGE OUTSIDE COTTON DOOR.....	150-4
KEY, DAMPER (6076).....	20-44	LARGE OUTSIDE COTTON DOOR CONVERSION P12 38/40 TO VRS 2M.....	150-5
KEY, DAMPER (6081 ENGINE).....	20-45		
KEY, IGNITION (-23000).....	40-20		