

9986 COTTON PICKER



JOHN DEERE

PARTS CATALOG

9986 COTTON PICKER

PC2843 (MAR-06) English

John Deere Des Moines Works

North American Edition

Litho in U.S.A. (Revised)

COPYRIGHT © 2006

DEERE & COMPANY

Moline, Illinois

All rights reserved

N57758

-UN-22JUN01



*JOHN DEERE 9986 COTTON PICKER
(MANUFACTURED 2002-2005)*

(SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE.)

PRODUCT IDENTIFICATION NUMBER LISTING INFORMATION

THE COTTON PICKER PRODUCT IDENTIFICATION NUMBER PLATE IS LOCATED ON LEFT-HAND SIDE OF MAIN FRAME, AT CENTER.

PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

-	THE PART CAN BE USED ON ALL MACHINES.
000000-	THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE PIN OR YEAR.
-000000	THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE PIN OR YEAR LISTED.
000000-000000	THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE PRODUCT IDENTIFICATION NUMBERS OR YEARS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A PRODUCT IDENTIFICATION NUMBER, A CHANGE WAS MADE BUT THE EXACT PIN WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

HOSE DIMENSIONS LISTED ARE EITHER FITTING SIZE X LENGTH X FITTING SIZE OR I.D. X LENGTH.

CHANGE INDICATOR LINE (MICROFICHE CATALOGS ONLY)

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 


NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

SHORT BLOCK SERIAL NUMBER IDENTIFICATION (EXAMPLE SHOWN)

RGP4574 -UN-02OCT95



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE650490295

- | | |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE65049 |
| 2. DESIGNATES MONTH ASSEMBLED | 09 |
| 3. DESIGNATES YEAR ASSEMBLED | 95 |

TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE (LOCATED ON STARTER SIDE OF ENGINE)

RGP3513 -UN-01JAN94



RGP3513

FIRST LINE

RG - WATERLOO ENGINE WORKS
6
081 (8.1 LITERS)
H - AIR-TO-AIR
N
XXXXXX

DEFINES

DESIGNATES ENGINE MANUFACTURER.
DESIGNATES NUMBER OF CYLINDERS.
DESIGNATES LITER DISPLACEMENT.
DESIGNATES TYPE OF AIR INTAKE SYSTEM.
DESIGNATES DES MOINES WORKS.
DESIGNATES ENGINE SERIAL NUMBER.

SECOND LINE

6081HN003

9986 COTTON PICKER

APPLICATION

SECTION INDEX

GENERAL INFORMATION.....	10
ENGINE.....	20
FUEL AND AIR.....	30
ELECTRICAL.....	40
POWER TRAIN.....	50
STEERING AND BRAKES.....	60
HYDRAULICS.....	70
WHEELS, REAR AXLES AND SHEET METAL.....	80
POWER AXLE.....	85
OPERATOR STATION.....	90
PICKING UNIT LIFT.....	100
PICKING UNIT CABINET.....	110
PICKING UNIT SYSTEM.....	120
PICKING UNIT LUBRICATION SYSTEM.....	130
WATER SYSTEM.....	140
AIR SYSTEM.....	150
BASKET.....	160
DECALS.....	170
NUMERICAL INDEX.....	190

ALPHABETICAL INDEX

	PAGE		PAGE
A			
A/C COMPRESSOR (6081HN003).....	90-56	ARMREST, OPERATOR'S SEAT	90-46
A/C COMPRESSOR HARDWARE KIT (6081HN003).....	90-58	ARMS, ROCKER (6081HN003).....	20-23
ABSORBER, FUEL INJECTION LINES (6081HN003).....	30-12	ARMS, UNIT LIFT	100-4
ACCESS COVER FUEL INJECTION PUMP (6081HN003).....	40-36	ASHTRAY	90-22
ACCUMULATOR AND BASKET DOOR OPEN-CLOSE	70-24	ASHTRAY	90-38
ACTIVE CAN BUS DEVICE	40-24	ASSEMBLY, FINGER GRATES (S/N -14000)	160-54
ADAPTER, ENGINE OIL COOLER	20-30	ASSEMBLY, FINGER GRATES (S/N 14001-).....	160-55
ADAPTER, OIL COOLER (6081HN003).....	20-29	AUGER, COMPACTOR.....	160-36
ADAPTER, OIL COOLER BYPASS	20-28	AXLE KNEE AND KNUCKLE, REAR.....	80-6
ADAPTOR, HYDROSTATIC TO HYDRAULIC PUMP	50-26	AXLE PIVOT SUPPORT, FRONT	80-4
ADJUST, OPERATOR'S SEAT	90-50	AXLE PIVOT SUPPORT, REAR.....	80-2
ADJUSTER, DOFFER, UPPER.....	120-22	AXLE SPACERS	80-12
ADJUSTING STRAP, ALTERNATOR (6081HN003).....	40-36	AXLE SPACERS	80-16
AID, COLD WEATHER STARTING	30-22	AXLE TIE RODS, REAR	80-8
AIR CLEANER AND AIR INTAKE TUBES	30-2	AXLE, FINAL DRIVE	50-14
AIR CONDITIONER COMPRESSOR FAN PULLEY (6081HN003).....	90-65	AXLE, FRONT.....	80-10
AIR CONDITIONER COMPRESSOR HOSE (6081HN003).....	90-60	AXLE, POWER.....	85-4
AIR CONDITIONER COMPRESSOR IDLER PULLEY (6081HN003).....	90-65	AXLE, REAR CENTER	80-1
AIR CONDITIONER COMPRESSOR SUPPORT (6081HN003).....	90-65	AXLE, WHEEL, AXLE	85-3
AIR CONDITIONING AND HEATER DUCTS	90-64	B	
AIR CONDITIONING AND HEATER HOUSING, LOWER	90-54	BAR DRUM, STUD AND BEARING, PICKER	120-20
AIR CONDITIONING AND HEATER HOUSING, UPPER.....	90-52	BAR, GRID, PICKING UNIT (PRO-12 18S)	110-16
AIR CONDITIONING COMPRESSOR (6081HN003).....	90-56	BAR, GRID, PICKING UNIT (PRO-16 20S)	110-18
AIR CONDITIONING COMPRESSOR HARDWARE KIT (6081HN003).....	90-58	BAR, MIRROR	90-32
AIR CONDITIONING CONDENSER	20-1	BAR, PICKER	120-16
AIR CONDITIONING SYSTEM - RECEIVER-DRYER	90-61	BASE, FUEL FILTER (6081HN003).....	30-20
AIR CONDITIONING SYSTEM, EVAPORATOR HEATER	90-62	BASE, OIL FILTER (6081HN003).....	20-32
AIR CONDITIONING SYSTEM, WATER VALVE	90-63	BASKET ASSEMBLY, LOWER FRONT	160-6
AIR CONDITIONING WIRING HARNESS.....	40-58	BASKET ASSEMBLY, LOWER REAR.....	160-12
AIR COOLER	20-1	BASKET ASSEMBLY, LOWER, RIGHT SIDE	160-8
AIR DUCT, INTAKE	90-52	BASKET DOOR CONVEYOR.....	160-18
AIR MANIFOLD AND DUCTS	150-4	BASKET DOOR CONVEYOR CHAIN PROTECTORS AND SUPPORTS	160-20
AIR TUBES AND NOZZLES	150-6	BASKET DOOR EXTENSION	160-26
ALTERNATOR (6081HN003).....	40-30	BASKET DOOR FLAP AND SAFETY SWITCH	160-22
ALTERNATOR BRACKETS (6081HN003).....	40-36	BASKET DOOR OPEN-CLOSE AND ACCUMULATOR HYDRAULIC LINES.....	70-24
ANGLE, PICKING UNIT BOTTOM FRAME (PRO-12 UNIT).....	110-12	BASKET DOOR OPENING, UPPER	160-10
ANGLE, PICKING UNIT BOTTOM FRAME (PRO-16 UNIT).....	110-14	BASKET DOOR STRUCTURE	160-16
ANTENNA, SPEAKERS AND RADIO	40-40	BASKET EXTENSION HYDRAULICS	70-22
ARM, PICKER BAR	120-16	BASKET EXTENSION LATCH.....	160-48
ARM, STALKLIFTER PIVOT PRO-12 - 18S	110-32	BASKET EXTENSION LID ASSEMBLY	160-38
ARMREST CONTROL PANEL, OPERATOR'S.....	90-38	BASKET EXTENSION, FRONT	160-40
ARMREST PANEL, OPERATOR'S	90-36	BASKET EXTENSION, LEFT	160-44
ARMREST ROCKER SWITCHES	90-36	BASKET EXTENSION, REAR	160-46
ARMREST ROCKER SWITCHES	90-38	BASKET EXTENSION, RIGHT	160-42
ARMREST WIRING HARNESS.....	40-16	BASKET FLOOR.....	160-4
		BASKET FLOOR BRUSHES	160-34
		BASKET FLOOR CONVEYOR	160-28
		BASKET FLOOR CONVEYOR CHAIN PROTECTORS AND SUPPORTS	160-30
		BASKET FULL MONITORING SYSTEM	160-58
		BASKET HOOD ASSEMBLY	160-52
		BASKET LAMPS AND WIRING HARNESS	40-19
		BASKET LID EXTENSION.....	160-50
		BASKET LID HANDRAILS.....	160-56
		BASKET RAISE HYDRAULICS	70-20
		BASKET STAND, REAR.....	160-14
		BASKET SUPPORT ASSEMBLY	160-2

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
BASKET WIPER FLAP	160-4	BYPASS TUBES, OIL COOLER	20-28
BATTERIES AND CABLES	40-1	BYPASS VALVE, OIL FILTER	
BATTERY SUPPORT TRAY	80-38	(6081HN003)	20-32
BEAM, BASKET SUPPORT	160-2		
BEARING CAP, FINAL DRIVE	50-13	C	
BEARING, PICKER BAR DRUM	120-20	CAB AIR FILTER AND HOUSING	90-33
BEARINGS, FINAL DRIVE	50-14	CAB DOOR	90-20
BEARINGS, MAIN AND MAIN THRUST		CAB DOOR AND GLASS	90-22
(6081HN003)	20-14	CAB DOOR LATCH	90-24
BELT TENSIONER, ALTERNATOR		CAB GLASS	90-20
(6081HN003)	40-36	CAB INTERIOR TRIM PANELS	90-18
BELT, ALTERNATOR		CAB REAR AND SIDE SEALS	90-16
(6081HN003)	40-30	CAB ROOF	90-26
BELT, COTTON FAN DRIVE	150-2	CAB ROOF LIGHTS	40-57
BELT, ENGINE FAN DRIVE	20-56	CAB, MAIN WIRING HARNESS	40-24
BELT, HYDRAULIC PUMP DRIVE	70-1	CABINET, PLUGS AND GROMMETS	110-38
BELT, INSTRUCTIONAL SEAT	90-44	CABLE, HYDROSTATIC CONTROL	50-22
BELT, OPERATOR'S ARMREST CONTROL PANEL	90-38	CABLE, REAR DRUM PRESSURE PLATE	
BELT, ROTARY SCREEN DRIVE	20-58	(PRO-12 18S)	110-24
BELT, UNIT DRIVE COUNTERSHAFT	120-2	CABLE, REAR DRUM PRESSURE PLATE	
BELT, WATER PUMP DRIVE	140-4	(PRO-16 20S)	110-26
BELTS, ENGINE DRIVE AND DRIVEN	20-62	CABLE, WIRING	40-44
BELTS, ENGINE FAN	20-54	CABLES, BATTERY	40-1
BEVEL GEAR, COMPACTOR DRIVE	160-36	CAM, PICKER DRUM	120-14
BLADE, VINE CUTTER	120-24	CAMSHAFT	
BLOCK HEATER	40-3	(6081HN003)	20-20
BLOCK, COMPLETE, ASSEMBLY(CBA)		CAMSHAFT BUSHING	
(BLOCK AND CYLINDER HEAD)	20-8	(6081HN003)	20-2
BLOCK, SHORT	20-8	CAMSHAFT BUSHING	
BOLTS, CYLINDER HEAD		(6081HN003)	20-20
(6081HN003)	20-12	CAMSHAFT FOLLOWER	
BOOT, HYDROSTATIC CONTROL CABLE	50-22	(6081HN003)	20-20
BOTTOM FRAME, PICKING UNIT		CAMSHAFT FOLLOWER	
(PRO-12 UNIT)	110-12	(6081HN003)	20-23
BOTTOM FRAME, PICKING UNIT		CAMSHAFT GEAR	
(PRO-16 UNIT)	110-14	(6081HN003)	20-20
BOX, MONITOR	90-34	CAN BUS DEVICE, ACTIVE	40-24
BRACE, FEEDBACK SENSOR, ROW-TRAK	60-34	CAN BUS DEVICE, PASSIVE	40-12
BRACKET, CAB GLASS	90-20	CAP, FUEL	30-10
BRACKET, DOFFER IDLER GEAR	120-27	CAP, HYDRAULIC RESERVOIR	70-2
BRACKET, ETHER AID		CAP, HYDROSTATIC PUMP END	50-36
(6081HN003)	30-23	CAP, LUBRICATION TANK	130-2
BRACKET, TRANSMISSION	50-2	CAP, REAR WHEEL BEARING	80-15
BRACKET, WATER PUMP	140-4	CAPS, MAIN BEARING	
BRACKETS, ALTERNATOR		(6081HN003)	20-2
(6081HN003)	40-36	CARTRIDGE, FILTER	85-16
BRACKETS, FIRE EXTINGUISHER	80-18	CASE, GEAR, PICKING UNIT	120-6
BRACKETS, FLOOR BRUSHES	160-32	CASE, MONITOR	90-34
BRACKETS, MIRROR	90-32	CASE, TRANSMISSION	50-10
BRAKE CYLINDER, MASTER	60-14	CENTERFRAME, KNEE AND CYLINDER	
BRAKE LINES AND RESERVOIR	60-12	(REAR AXLE)(POWERED AXLE)	85-10
BRAKE PEDAL AND MASTER CYLINDER	60-16	CHAIN PROTECTORS AND SUPPORTS,	
BRAKE PEDAL AND SEAL, PARKING	60-18	BASKET DOOR CONVEYOR	160-20
BRAKE SHOES AND DRUM	60-20	CHAIN PROTECTORS AND SUPPORTS,	
BRAKE SLAVE CYLINDER	60-22	BASKET FLOOR CONVEYOR	160-30
BREAKERS, CIRCUIT	40-32	CHAIN, BASKET DOOR EXTENSION	160-26
BREAKERS, CIRCUIT	40-34	CHAIN, CONVEYOR, BASKET DOOR	160-18
BREATHER, FUEL TANK	30-10	CHAIN, CONVEYOR, BASKET FLOOR	160-28
BRUSH BRACKETS, FLOOR	160-32	CHAIN, LIFT ARM	100-4
BRUSHES, BASKET FLOOR	160-34	CHAIN, LOW COTTON, PRO-12 - 18S	110-32
BULB, INTERIOR CAB ROOF	90-26	CHANNEL, BASKET DOOR EXTENSION	160-26
BULB, ARMREST CONTROL PANEL	90-36	CHANNEL, PICKING UNIT BOTTOM FRAME	
BULB, CAB ROOF LIGHT	40-57	(PRO-12 UNIT)	110-12
BULB, OVERHEAD CONSOLE	90-42	CHANNEL, PICKING UNIT BOTTOM FRAME	
BULB, STEERING COLUMN CONTROLS	60-2	(PRO-16 UNIT)	110-14
BUSHING, CAMSHAFT			
(6081HN003)	20-20		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CHARGE AIR PIPING	30-1	CONTAINER, TRASH	90-18
CHARGE PUMP SHAFT, HYDROSTATIC	50-26	CONTROL CABLE, HYDROSTATIC	50-22
CHARGE PUMP, HYDROSTATIC DRIVE	50-25	CONTROL PANEL, OPERATOR'S ARMREST	90-36
CHARGE RELIEF VALVE, HYDROSTATIC PUMP	50-30	CONTROL PANEL, OPERATOR'S ARMREST	90-38
CHASSIS SIDE SHIELDING	80-22	CONTROL VALVE	85-18
CHASSIS WIRING HARNESS	40-14	CONTROL VALVE, CONVEYOR	70-10
CHECK VALVE, FUEL TANK	30-10	CONTROL VALVE, HYDRAULIC	85-14
CHECK VALVE, HEATING AND AIR CONDITIONER	90-54	CONTROL VALVE, UNIT LIFT	70-16
CHECK VALVE, HYDROSTATIC PUMP	50-36	CONTROL VALVE, UNIT LIFT	85-15
CHECK VALVE, WATER SYSTEM	140-8	CONTROL VALVES AND MANIFOLD, WATER	140-8
CHECK VALVE, WATER TANK	140-2	CONTROLLER, ENGINE	30-14
CIGARETTE LIGHTER	90-38	CONVENIENCE OUTLET, KIT	40-60
CIRCUIT BOARD, OPERATOR'S ARMREST		CONVEYOR CHAIN PROTECTORS, BASKET DOOR	160-20
CONTROL PANEL	90-38	CONVEYOR CHAIN PROTECTORS, BASKET FLOOR	160-30
CIRCUIT BOARD, OVERHEAD CONSOLE	90-42	CONVEYOR CONTROL VALVE	70-10
CIRCUIT BOX, HEATER AND AIR CONDITIONER	90-52	CONVEYOR DOOR FRAME	160-16
CIRCUIT BREAKERS AND RELAYS	40-32	CONVEYOR DOOR WING ASSEMBLIES	160-24
CIRCUIT BREAKERS AND RELAYS	40-34	CONVEYOR EXTENSION, DOOR	160-26
CLAMPS, FUEL INJECTION LINES		CONVEYOR HYDRAULICS, FLOOR AND DOOR	70-26
(6081HN003)	30-12	CONVEYOR, BASKET DOOR	160-18
CLEAN-OUT DOOR, COTTON DOOR	150-8	CONVEYOR, BASKET FLOOR	160-28
CLEANING SOLUTION, SPINDLE	140-2	COOLANT RECOVERY SYSTEM	20-61
CLUTCH, COMPRESSOR		COOLANT TEMPERATURE SENDER	
(6081HN003)	90-59	(6081HN003)	20-22
CLUTCH, FAN DRIVE	150-2	COOLER BYPASS TEE, HYDROSTATIC	50-20
CLUTCH, SLIP, DRUM	120-10	COOLER, ENGINE OIL	20-30
CLUTCH, SLIP, LOWER GEAR CASE HUB	120-8	COOLER, ENGINE OIL	
CLUTCH, STARTING MOTOR		(6081HN003)	20-29
(6081HN003)	40-38	COOLER, HYDRAULIC OIL	70-3
COIL, FAN	150-2	COOLING PACKAGE SUPPORT	20-48
COLD WEATHER START BUTTON	60-2	COTTON DOOR	
COLD WEATHER STARTING AID	30-22	NUMBER 6 OFFSET	150-1
COLUMN, SPINDLE MOISTENER	140-14	COTTON DOORS	150-8
COMPACTOR	160-36	COTTON FAN AND DRIVE	150-2
COMPACTOR HYDRAULIC LINES	70-18	COUNTERSHAFT, UNIT DRIVE	120-2
COMPACTOR SWITCH, FOOT CONTROL	40-10	COUPLING, HYDROSTATIC TO HYDRAULIC PUMP	50-26
COMPLETE BLOCK ASSEMBLY(CBA)		COVER, ALTERNATOR	
(BLOCK AND CYLINDER HEAD)	20-8	(6081HN003)	40-30
COMPLETE UNIT SHELL (PRO-16 UNIT)	110-4	COVER, CYLINDER HEAD TOP	
COMPLETE UNIT SHELL (PRO-16)	110-8	(6081HN003)	20-44
COMPRESSOR HARDWARE KIT, AIR		COVER, ENGINE OIL COOLER	20-30
CONDITIONING (6081HN003)	90-58	COVER, FUEL INJECTION PUMP ACCESS	
COMPRESSOR PARTS (REFRIGERANT)		(6081HN003)	40-36
(6081HN003)	90-57	COVER, INSPECTION, HEAT EXCHANGER	80-21
COMPRESSOR, AIR CONDITION, HOSE		COVER, OIL COOLER	
(6081HN003)	90-60	(6081HN003)	20-29
COMPRESSOR, AIR CONDITIONING		COVER, OIL DIPSTICK	
(6081HN003)	90-56	(ENGINE SERIAL NO. 209311-)	20-36
COMPRESSOR, CLUTCH		COVER, ROCKER ARM	
(6081HN003)	90-59	(6081HN003)	20-24
CONNECTING RODS/CYLINDER LINER/PISTON		CRANKSHAFT	
(6081HN003)	20-10	(6081HN003)	20-11
CONNECTOR, CONSOLE SWITCH	40-55	CRANKSHAFT OIL SEAL AND HOUSING	
CONNECTOR, ELECTRICAL, WEATHERPACK	40-50	(6081HN003)	20-15
CONNECTOR, ELECTRONIC CONTROLLER,		CRANKSHAFT POSITION SENSOR	20-18
ENGINE SPEED SENSOR AND HORN	40-53	CRANKSHAFT PULLEY AND DAMPENERS	
CONNECTOR, FUEL INJECTION NOZZLE		(6081HN003)	20-16
(6081HN003)	30-12	CROSS SHAFT AND UNIVERSAL JOINT	120-5
CONNECTOR, KEY SWITCH, CONSOLE LIGHT,		CUSHION, OPERATOR'S SEAT	90-46
ETHER SWITCH AND WARNING HORN	40-54	CUSHION, SEAT, PASSENGER	90-30
CONNECTOR, MONITOR LIGHT MODULE AND		CUTTER, VINE	120-28
TACHOMETER	40-56	CYLINDER BLOCK FITTINGS	
CONNECTORS, FUEL INJECTION PUMP HOUSING		(6081HN003)	20-2
(6081HN003)	30-16	CYLINDER BLOCK, HYDROSTATIC PUMP	50-32
CONSOLE LIGHT CONNECTOR	40-54	CYLINDER HAD TOP COVER	
CONSOLE SWITCH CONNECTOR	40-55	(6081HN003)	20-44
CONSOLE, OVERHEAD	90-42		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
CYLINDER HEAD AND VALVES (6081HN003).....	20-12	DOOR EXTENSION, BASKET	160-26
CYLINDER HEAD GASKET KIT (6081HN003).....	20-4	DOOR HINGE, CONVEYOR.....	160-18
CYLINDER LINER/CONNECTING RODS/PISTON (6081HN003).....	20-10	DOOR LATCH, CAB.....	90-24
CYLINDER SEAL KIT, STEERING	60-11	DOOR OPEN-CLOSE HYDRAULIC LINES, BASKET	70-24
CYLINDER STOP, UNIT LIFT ARM	100-4	DOOR OPENING, BASKET, UPPER.....	160-10
CYLINDER, ACCUMULATOR HYDRAULIC LINES.....	70-24	DOOR SAFETY SWITCH AND FLAP.....	160-22
CYLINDER, BASKET DOOR OPEN-CLOSE AND ACCUM. HYDRAULIC	70-24	DOOR STRUCTURE, BASKET	160-16
CYLINDER, BASKET EXTENSION HYDRAULIC	70-22	DOOR WING ASSEMBLY, CONVEYOR.....	160-24
CYLINDER, BASKET RAISE HYDRAULIC	70-20	DOOR, CAB	90-20
CYLINDER, BRAKE PEDAL	60-16	DOOR, CAB AND GLASS	90-22
CYLINDER, BRAKE SLAVE	60-22	DOOR, COTTON NUMBER 6 OFFSET.....	150-1
CYLINDER, BRAKE, MASTER.....	60-14	DOOR, ROTARY SCREEN	20-46
CYLINDER, CENTERFRAME AND KNEE (REAR AXLE)(POWERED AXLE).....	85-10	DOOR, ROTARY SCREEN.....	20-52
CYLINDER, HYDRAULIC, 2-1/2" X 12" (EATON).....	70-29	DOORS, HYDRAULIC MODULE	80-42
CYLINDER, HYDRAULIC, 3-1/2" X 24" (BASKET RAISE-UNLOAD).....	70-28	DOORS, UNIT.....	110-30
CYLINDER, HYDRAULIC, 3-3/4" X 8" (UNIT LIFT).....	70-15	DOORS, UNIT, PRO-12 - 18S.....	110-28
CYLINDER, MASTER BRAKE.....	60-16	DRIVE BELTS AND PULLEYS ARRANGEMENT	20-62
CYLINDER, STEERING	60-10	DRIVE GEAR, OIL PUMP (6081HN003).....	20-11
CYLINDER, HYDRAULIC POWER AXLE.....	85-6	DRIVE GEARS, UPPER HOUSING DRUM.....	120-12
CYLINDERS, HYDRAULIC (DUCT SUPPORT)	150-16	DRIVE SHAFT, FINAL DRIVE.....	50-16
		DRIVE SHAFT, SPLINED	80-12
D		DRIVE SHAFT, UNIT	120-4
DAMPENER KEY (6081HN003).....	20-11	DRIVE WHEELS, SINGLE.....	80-17
DAMPENERS AND PULLEY, CRANKSHAFT (6081HN003).....	20-16	DRIVE, ENGINE FAN.....	20-56
DECALS.....	170-2	DRIVE, FINAL.....	50-12
DECALS.....	170-4	DRIVE, PUMP, HYDROSTATIC (SERIAL NO. 4001-).....	50-19
DECALS.....	170-6	DRUM DRIVE GEARS, UPPER HOUSING.....	120-12
DECALS.....	170-14	DRUM HEAD AND CAM	120-14
DECALS - "IMPORTANT"	170-2	DRUM SLIP CLUTCH AND IDLER GEARS	120-10
DECALS, FUSES.....	170-6	DRUM SPEED SENSOR	120-12
DECALS, INSTRUCTIONS.....	170-4	DRUM SPED MONITOR FIRMWARE UPGRADE	120-12
DECALS, SAFETY.....	170-12	DRUM, BRAKE	60-20
DECALS, UNIT LOCATION	170-6	DRUM, PICKER BAR.....	120-20
DIFFERENTIAL (TRANSMISSION).....	50-8	DUAL WHEELS.....	80-16
DIODE, LOAD CENTER WIRING HARNESS	40-4	DUCT SUPPORT	150-16
DIODE, LOAD CENTER WIRING HARNESS	40-5	DUCT SUPPORT HYDRAULIC HOSES.....	70-17
DIPSTICK COVER (ENGINE SERIAL NO. 209311-).....	20-36	DUCT, LADDER.....	150-14
DIPSTICK COVER GASKET (ENGINE SERIAL NO. 209311-).....	20-36	DUCT, ROTARY SCREEN	20-50
DIPSTICK, ENGINE OIL (6081HN003).....	20-31	DUCTS, AIR.....	150-4
DISC, DOFFER.....	120-24	DUCTS, HEATER AND AIR CONDITIONING.....	90-64
DISPLACEMENT CONTROL, HYDROSTATIC PUMP	50-34	DUCTS, UNIT TO BASKET	150-10
DISTRIBUTOR ASSEMBLY, MOISTENER	140-14	DUCTS, UNIT TO BASKET (36"-38"-40").....	150-12
DOFFER	120-24		
DOFFER ADJUSTER AND STUB SHAFT	120-22	E	
DOFFER DRIVE IDLER GEAR	120-27	ECU.....	30-14
DOFFER GAUGES.....	120-26	ELBOW TRANSITION, JET POST	150-6
DOFFER IDLER GEARS.....	120-12	ELECTRICAL CONNECTOR SERVICE KIT	40-46
DOME LIGHT EXTENSION WIRING HARNESS	40-8	ELECTRICAL CONNECTOR SERVICE KIT	40-48
DOOR AND FLOOR CONVEYOR HYDRAULIC LINES	70-26	ELECTRICAL CONNECTOR, CONSOLE SWITCH	40-55
DOOR ASSEMBLY, COTTON.....	150-8	ELECTRICAL CONNECTOR, ELECTRONIC CONTROLLER, ENGINE SPEED SENSOR, HORN	40-53
DOOR CONTACT SWITCH WIRING HARNESS	40-9	ELECTRICAL CONNECTOR, KEY SWITCH, CONSOLE LIGHT, ETHER SWITCH, HORN.....	40-54
		ELECTRICAL CONNECTOR, MONITOR LIGHT MODULE AND TACHOMETER.....	40-56
		ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK.....	40-50
		ELECTRICAL WIRING HARNESS, CAB.....	40-24
		ELECTRICAL WIRING SCHEMATIC	40-14
		ELECTRICALLY OPERATED STARTING AID	30-22
		ELECTRONIC CONTROL UNIT, (OPTIONAL ROWTRAK).....	40-2

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
ELECTRONIC CONTROLLER CONNECTOR	40-53	FAN DRIVE	
ELEMENT, AIR CLEANER	30-2	(6081HN003)	20-25
END CAP, HYDROSTATIC PUMP	50-36	FAN DRIVE, ENGINE	20-56
ENGINE CONTROLLER	30-14	FAN PULLEY	
ENGINE CONTROLLER, FOCUS	40-2	(6081HN003)	20-25
ENGINE COOLANT HEATER	40-3	FAN PULLEY, AIR CONDITIONER COMPRESSOR	
ENGINE DRIVE AND DRIVEN BELTS & PULLEYS	20-62	(6081HN003)	90-65
ENGINE FAN AND DRIVES	20-54	FAN, ALTERNATOR	
ENGINE FAN DRIVE	20-56	(6081HN003)	40-30
ENGINE HOODS	80-24	FAN, BLOWER, HEATER AND AIR CONDITIONER	90-54
ENGINE OIL		FAN, ENGINE	20-54
(6081HN003)	20-38	FAN, HEATER AND AIR CONDITIONER	90-52
ENGINE OIL COOLER		FEEDBACK LINK, HYDROSTATIC PUMP	50-32
(6081HN003)	20-29	FEEDBACK SENSOR BRACE, ROW-TRAK	60-34
ENGINE OIL DIPSTICK		FEEDBACK SENSOR, ROW-TRAK	60-28
(6081HN003)	20-31	FIELD OFFICE	90-30
ENGINE OIL DIPSTICK TUBE		FILETR, HYDRAULIC	85-16
(6081HN003)	20-31	FILL HOSE, LUBRICATION	130-12
ENGINE OIL FILTER		FILTER CARTRIDGE	85-16
(6081HN003)	20-32	FILTER HYDRAULIC LINES	85-16
ENGINE OIL PRESSURE SWITCH		FILTER/PRE-FUEL FILTER AND LINES, FUEL	
(6081HN003)	20-45	(6081HN003)	30-20
ENGINE OIL PUMP		FILTER, AIR (ENGINE)	30-2
(6081HN003)	20-26	FILTER, AIR, RECIRCULATION	90-54
ENGINE OVERHAUL KIT	20-6	FILTER, CAB AIR	90-33
ENGINE REBUILD GASKET KIT		FILTER, ENGINE OIL	
(6081HN003)	20-4	(6081HN003)	20-32
ENGINE SIDE FRAMES	80-14	FILTER, EVAPORATOR HEATER	90-62
ENGINE SPEED SENSOR		FILTER, GREASE	130-7
(6081HN003)	20-18	FILTER, HYDRAULIC RESERVOIR	70-2
ENGINE SPEED SENSOR CONNECTOR	40-53	FILTER, WATER	140-7
ENGINE WIRING HARNESS	40-27	FINAL DRIVE	50-12
ETHER AID BRACKET		FINAL DRIVE AXLE, GEAR AND BEARINGS	50-14
(6081HN003)	30-23	FINAL DRIVE HOUSING AND BEARING CAP	50-13
ETHER START BUTTON	60-2	FINAL DRIVE PINION, DRIVE SHAFTS AND	
ETHER STARTING FLUID	30-22	BEARINGS	50-16
ETHER SWITCH CONNECTOR	40-54	FINGER GRATES ASSEMBLY	
EVAPORATOR HEATER, AIR CONDITIONER	90-62	(S/N - 14000)	160-54
EXHAUST MANIFOLDS		FINGER GRATES ASSEMBLY	
(6081HN003)	30-18	(S/N 14001 -)	160-55
EXHAUST PIPE	30-8	FIRE EXTINGUISHER	80-18
EXHAUST VALVES AND SHIELD		FIRMWARE, DRUM SPEED MONITOR UPGRADE	120-12
(6081HN003)	20-12	FITTINGS, CYLINDER BLOCK	
EXTENSION AND GRATE, STALKLIFTERS		(6081HN003)	20-2
PRO-12 - 18S	110-32	FITTINGS, HYDROSTATIC SOLENOID VALVE	50-42
EXTENSION LID ASSEMBLY, BASKET	160-38	FIXTURE, FEEDBACK SENSOR, ROW-TRAK	60-28
EXTENSION, BASKET DOOR	160-26	FLANGE, PICKER BAR DRUM	120-20
EXTENSION, BASKET LID	160-50	FLAP MONITOR	40-21
EXTENSION, BASKET, FRONT	160-40	FLAP, BASKET DOOR	160-22
EXTENSION, BASKET, LEFT	160-44	FLAP, BASKET WIPER	160-4
EXTENSION, BASKET, REAR	160-46	FLAP, LOWER BASKET	160-8
EXTENSION, BASKET, RIGHT	160-42	FLOOR AND DOOR CONVEYOR HYDRAULIC LINES	70-26
EXTENSION, PLATFORM FLOOR		FLOOR BRUSH BRACKETS	160-32
(38" & 40"/64" SKIP ROW)	90-10	FLOOR BRUSHES	160-34
EXTENSION, PLATFORM FLOOR		FLOOR MAT	90-18
(4 ROW 34" SINGLE WHL.)	90-10	FLOOR PANELS	90-16
EXTENSION, PLATFORM FLOOR		FLOOR, BASKET	160-4
(4 ROW)	90-8	FLOORS, OUTSIDE OF CAB	
EXTENSION, PLATFORM FLOOR		(38" & 40"/64" SKIP ROW)	90-10
(6 ROW)	90-6	FLOORS, OUTSIDE OF CAB	
EXTENSIONS, UNIT LIFT FRAME	100-2	(4 ROW 34" SINGLE WHL.)	90-10
EXTINGUISHER, FIRE	80-18	FLOORS, OUTSIDE OF CAB	
		(4 ROW)	90-8
F		FLOORS, OUTSIDE OF CAB	
		(6 ROW)	90-6
FAN	150-2	FLUIDS, SPINDLE CLEANER AND	
		WETTING AGENT	140-2

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
FLUSH SYSTEM SWITCH, FOOT CONTROL	40-10	G	
FLUSH WATER LINES AND FITTINGS	140-12		
FLYWHEEL			
(6081HN003)	20-17		
FLYWHEEL HUB			
(6081HN003)	20-17		
FOCUS ENGINE CONTROLLER	40-2		
FOLLOWER, CAMSHAFT			
(6081HN003)	20-20		
FOLLOWER, CAMSHAFT			
(6081HN003)	20-23		
FOOT CONTROL SWITCHES, COMPACTOR AND FLUSH SYSTEM	40-10		
FRAME ASSEMBLY, HYDRO PUMP	80-38		
FRAME SUPPORT, COOLING	20-48		
FRAME, CENTER (POWERED AXLE)	85-10		
FRAME, CONVEYOR DOOR	160-16		
FRAME, DUCT SUPPORT	150-16		
FRAME, ENGINE SIDE	80-14		
FRAME, MAIN	80-10		
FRAME, PICKING UNIT BOTTOM (PRO-12 UNIT)	110-12		
FRAME, PICKING UNIT BOTTOM (PRO-16 UNIT)	110-14		
FRAME, PLATFORM (S/N -14000)	90-2		
FRAME, PLATFORM (S/N 14001-)	90-4		
FRAMES, UNIT LIFT	100-2		
FRONT AXLE	80-10		
FRONT CHASSIS WIRING HARNESS	40-12		
FRONT DRUM PRESSURE PLATE (PRO-12 18S)	110-20		
FRONT DRUM PRESSURE PLATE (PRO-16 20S)	110-22		
FRONT OIL SEAL AND TIMING GEAR COVER (6081HN003)	20-19		
FRONT WHEEL SHIELD, LH, 4 ROW WITH DUAL WHEELS	80-46		
FRONT WHEEL SHIELD, RH	80-44		
FUEL CHECK VALVE			
(6081HN003)	30-20		
FUEL COOLER KIT	20-1		
FUEL FILTER/PRE-FUEL FILTER AND LINES (6081HN003)	30-20		
FUEL GAUGE	40-28		
FUEL INJECTION NOZZLE (6081HN003)	30-19		
FUEL INJECTION NOZZLES AND LINES (6081HN003)	30-12		
FUEL INJECTION PUMP ACCESS COVER (6081HN003)	40-36		
FUEL INJECTION PUMP AND LINES	30-14		
FUEL INJECTION PUMP HOUSING CONNECTORS (6081HN003)	30-16		
FUEL LEAK-OFF LINE (6081HN003)	30-12		
FUEL SENDER AND REAR LIGHTS WIRING HARNESS	40-7		
FUEL TANK WITH FUEL COOLER	30-10		
FUEL TEMPERATURE SENSOR	30-14		
FUEL TRANSFER PUMP (ROBERT BOSCH) (6081HN003)	30-17		
FUSES, DECALS	170-6		
FUSES, RELAYS AND CIRCUIT BREAKERS	40-32		
FUSES, RELAYS AND CIRCUIT BREAKERS	40-34		
GASKET KIT, CYLINDER HEAD (6081HN003)	20-4		
GASKET KIT, ENGINE REBUILD (6081HN003)	20-4		
GASKET KIT, SHORT BLOCK (6081HN003)	20-4		
GASKET, CYLINDER HEAD (6081HN003)	20-12		
GASKET, CYLINDER HEAD TOP COVER (6081HN003)	20-44		
GASKET, DIPSTICK COVER (ENGINE SERIAL NO. 209311-)	20-36		
GASKET, INTAKE MANIFOLD (6081HN003)	30-6		
GASKET, OIL FILTER HOUSING (6081HN003)	20-32		
GASKET, OIL PAN	20-34		
GASKET, OIL PAN	20-36		
GASKET, OIL PUMP INTAKE (ESN -209310)	20-27		
GASKET, REAR OIL SEAL (6081HN003)	20-15		
GASKET, ROCKER ARM COVER (6081HN003)	20-24		
GASKET, WATER MANIFOLD (6081HN003)	20-42		
GASKET, WATER PUMP (6081HN003)	20-40		
GASKET,OIL PUMP (ESN 209311-)	20-36		
GASKETS, EXHAUST MANIFOLD (6081HN003)	30-18		
GASKETS, OIL PUMP (6081HN003)	20-26		
GASKETS, TURBOCHARGER	30-4		
GAUGES, DOFFER	120-26		
GAUGES, MONITOR	40-28		
GEAR BOX, SKIP ROW	120-1		
GEAR CASE HUB, LOWER	120-8		
GEAR CASE, PICKING UNIT	120-6		
GEAR, CAMSHAFT (6081HN003)	20-20		
GEAR, COMPACTOR DRIVE	160-36		
GEAR, DOFFER	120-22		
GEAR, DOFFER DRIVE IDLER	120-27		
GEAR, DOFFER IDLER	120-12		
GEAR, FINAL DRIVE	50-14		
GEAR, FUEL INJECTION PUMP	30-14		
GEAR, OIL PUMP (6081HN003)	20-26		
GEAR, OIL PUMP DRIVE (6081HN003)	20-11		
GEAR, STARTER (6081HN003)	20-17		
GEAR, WATER PUMP (6081HN003)	20-40		
GEARS, DIFFERENTIAL	50-8		
GEARS, DRUM IDLER	120-10		
GEARS, PICKER BAR	120-18		
GEARS, TRANSMISSION INPUT	50-4		
GEARS, TRANSMISSION INTERMEDIATE	50-6		
GEARS, UPPER HOUSING DRUM DRIVE	120-12		
GEARSHIFT LEVER AND LINKAGE	90-40		
GLASS, CAB	90-20		
GLASS, CAB AND DOOR	90-22		
GRATE, FINGER, BASKET EXTENSION LID	160-38		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
GRATE, STALKLIFTER, PRO-12 - 18S	110-32	HEAT EXCHANGER HOODS	80-21
GREASE CHIME CONNECTOR	40-54	HEAT SHIELD, AIR TUBE	30-1
GREASE MANIFOLD	130-7	HEATER AND AIR CONDITIONING DUCTS	90-64
GREASE PUMP SYSTEM	130-4	HEATER AND AIR CONDITIONING HOUSING, LOWER	90-54
GREASE TANK	130-2	HEATER AND AIR CONDITIONING HOUSING, UPPER	90-52
GREEN FLUSH WATER LINES	140-12	HEATER HOSES	90-68
GRID BARS AND SUPPORTS, PICKING UNIT (PRO-12 18S)	110-16	HEATER, ENGINE COOLANT	40-3
GRID BARS AND SUPPORTS, PICKING UNIT (PRO-16 20S)	110-18	HEIGHT SENSING LINKAGE AND SENSOR	110-34
GRILLE, RADIO SPEAKER	40-40	HINGE, CONVEYOR DOOR	160-18
GRILLE, SPEAKER	90-26	HINGE, PASSENGER SEAT CONSOLE	90-30
GROMMETS, UNIT CABINET	110-38	HOLDER, MOISTENER PAD	140-14
GROUND WIRE, A/C ELECTRIC CLUTCH (6081HN003)	90-59	HOOD ASSEMBLY, BASKET	160-52
GUARD, TANK (S/N -14000)	80-36	HOODS, ENGINE	80-24
GUARD, TANK (S/N 14001-)	80-37	HOODS, HEAT EXCHANGER	80-21
GUIDANCE SYSTEM PROBE ASSEMBLY (S/N -14000)	60-30	HORN	40-42
GUIDANCE SYSTEM PROBE ASSEMBLY (S/N 14001-)	60-32	HORN BUTTON	60-2
GUIDE, PLANT, PRO-12 - 18S	110-32	HORN CONNECTOR	40-53
 H 			
HANDLE BASKET RESET	160-48	HORN CONNECTOR, 3-SECOND AND PULSING	40-54
HANDLE, CAB	90-16	HOSE, ACCUMULATOR HYDRAULIC LINES	70-24
HANDLE, CAB DOOR	90-24	HOSE, AIR CONDITIONER COMPRESSOR (6081HN003)	90-60
HANDLE, OPERATORS CONTROL PANEL	90-38	HOSE, BASKET DOOR OPEN-CLOSE HYDRAULIC	70-24
HANDLE, UNIT DOOR	110-30	HOSE, BASKET EXTENSION HYDRAULIC	70-22
HANDLE, UNIT DOOR, PRO-12 - 18S	110-28	HOSE, BASKET RAISE HYDRAULIC	70-20
HANDRAILS, BASKET LID	160-56	HOSE, FLOOR AND DOOR CONVEYOR HYDRAULIC	70-26
HANDRAILS, PLATFORM (4 ROW)	90-12	HOSE, LIFT ARM LUBRICATION	100-4
HANDRAILS, PLATFORM (6 ROW)	90-14	HOSE, LUBRICATION FILL	130-12
HANGER, PICKING UNIT	110-10	HOSE, LUBRICATION MANIFOLD	130-7
HARDWARE KIT, AIR CONDITIONING COMPRESSOR (6081HN003)	90-58	HOSE, LUBRICATION PUMP	130-4
HARNESS, BASKET LAMP WIRING	40-19	HOSE, LUBRICATION TANK	130-2
HARNESS, CHASSIS WIRING	40-14	HOSE, ROTARY SCREEN	20-50
HARNESS, DOOR CONTACT SWITCH WIRING	40-9	HOSE, ROW-TRAK STEERING VALVE (S/N -14000)	60-24
HARNESS, ENGINE WIRING	40-27	HOSE, UNIT LUBRICATION	130-8
HARNESS, FRONT CHASSIS WIRING	40-12	HOSE, WATER PUMP	140-4
HARNESS, HYDRO PUMP AND RESERVOIR WIRING	40-11	HOSES, DUCT SUPPORT HYDRAULIC	70-17
HARNESS, LOAD CENTER WIRING	40-4	HOSES, FLUSH WATER, GREEN	140-12
HARNESS, LOAD CENTER WIRING	40-5	HOSES, HEATER	90-68
HARNESS, MAIN CAB WIRING	40-24	HOSES, HYDRAULIC OIL COOLER	70-3
HARNESS, PICKING UNIT WIRING	40-22	HOSES, HYDRAULIC UNIT LIFT	70-12
HARNESS, REAR LIGHTS AND FUEL SENDER WIRING	40-7	HOSES, HYDROSTATIC	50-20
HARNESS, STEERING COLUMN	40-43	HOSES, LUBRICATION TRANSFER PUMP	130-10
HARNESS, TETHER SWITCH (NO. 3 OR 4 UNIT)	40-20	HOSES, RADIATOR	20-60
HARNESS, UNIT SPEED SYNCHRONIZATION (SERVICE TOOL)	40-22	HOSES, STEERING HYDRAULIC	60-8
HARNESS, WIRING, PICKING UNIT	40-26	HOSES, WATER TANK	140-2
HARNESS, WIRING, POWERED REAR AXLE	85-21	HOSES, WATER VALVE	140-8
HEAD AND VALVES, CYLINDER (6081HN003)	20-12	HOSES, WATER, MOISTENER COLUMN (CLEAR)	140-10
HEAD, PICKER DRUM	120-14	HOUSING CONNECTORS, FUEL INJECTION PUMP (6081HN003)	30-16
HEADER, PRE-FUEL FILTER (6081HN003)	30-20	HOUSING, AIR CONDITIONER/HEATER, LOWER	90-54
HEADLINER, CAB	90-26	HOUSING, AIR CONDITIONER/HEATER, UPPER	90-52
HEAT EXCHANGER CORES	20-1	HOUSING, CAB AIR FILTER	90-33
		HOUSING, FAN	150-2
		HOUSING, FINAL DRIVE	50-13
		HOUSING, HYDROSTATIC PUMP	50-32
		HOUSING, MANIFOLD (WATER, GREASE AND HYDRAULIC)	140-8
		HOUSING, MONITOR	90-34
		HOUSING, OIL FILTER (6081HN003)	20-32
		HOUSING, PICKING UNIT	110-1
		HOUSING, PICKING UNIT UPPER (PRO-12 UNIT)	110-2
		HOUSING, PICKING UNIT UPPER (PRO-16 UNIT)	110-4

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HOUSING, REAR OIL SEAL (6081HN003).....	20-15	HYDROSTATIC PUMP HOUSING, SWASHPLATE AND CYLINDER BLOCK.....	50-32
HOUSING, THERMOSTAT (6081HN003).....	20-42	HYDROSTATIC PUMP SHAFT AND SERVO ASSY.	50-28
HOUSING, TRANSMISSION.....	50-10	HYDROSTATIC PUMP VALVES, PLUGS AND SEALS	50-30
HOUSING, UPPER DOFFER ADJUSTING.....	120-22	HYDROSTATIC SOLENOID VALVE FITTINGS	50-42
HUB, FLYWHEEL (6081HN003).....	20-17	I	
HUB, LOWER GEAR CASE	120-8	IDLER ARM, ROTARY SCREEN DRIVE	20-58
HUB, REAR WHEEL.....	80-15	IDLER GEAR, DOFFER DRIVE.....	120-27
HYDRAULIC CONTROL VALVE.....	85-14	IDLER GEARS, DRUM	120-10
HYDRAULIC CONTROL VALVE, UNIT LIFT	70-16	IDLER PULLEY, AIR CONDITIONER COMPRESSOR (6081HN003).....	90-65
HYDRAULIC CONTROL VALVE, UNIT LIFT	85-15	IGNITION SWITCH.....	60-2
HYDRAULIC CONTROL, CONVEYOR.....	70-10	IMPELLER, WATER PUMP.....	140-6
HYDRAULIC CYLINDER POWER AXLE.....	85-6	IMPELLER, WATER PUMP (6081HN003).....	20-40
HYDRAULIC CYLINDER, 2-1/2" X 12" (EATON).....	70-29	INJECTION NOZZLES AND LINES, FUEL (6081HN003).....	30-12
HYDRAULIC CYLINDER, 3-1/2" X 24" (BASKET RAISE-UNLOAD).....	70-28	INJECTION PUMP ACCESS COVER (6081HN003).....	20-19
HYDRAULIC CYLINDER, 3-3/4" X 8" (UNIT LIFT).....	70-15	INJECTION PUMP AND LINES, FUEL.....	30-14
HYDRAULIC CYLINDERS (DUCT SUPPORT).....	150-16	INPUT SHAFT, TRANSMISSION.....	50-4
HYDRAULIC FILTER	85-16	INSERTS, VALVE SEAT (6081HN003).....	20-12
HYDRAULIC HOSE, ROW-TRAK STEERING VALVE (S/N -14000).....	60-24	INSIDE CAB MIRROR.....	90-69
HYDRAULIC HOSES, DUCT SUPPORT.....	70-17	INSTRUCTIONAL SEAT SEATBELT.....	90-44
HYDRAULIC HOSES, LUBRICATION PUMP.....	130-4	INTAKE MANIFOLD (6081HN003).....	30-6
HYDRAULIC HOSES, UNIT LIFT	70-12	INTAKE MANIFOLD GASKET (6081HN003).....	30-6
HYDRAULIC LINES, BASKET DOOR OPEN-CLOSE AND ACCUMULATOR.....	70-24	INTAKE MANIFOLD TEMPERATURE SENSOR	30-7
HYDRAULIC LINES, BASKET EXTENSION	70-22	INTAKE VALVES (6081HN003).....	20-12
HYDRAULIC LINES, BASKET RAISE	70-20	INTAKE, OIL PUMP (ESN -209310) (U/WRE508040).....	20-27
HYDRAULIC LINES, COMPACTOR	70-18	INTAKE,OIL PUMP (ESN 209311-) (U/W RE506166).....	20-36
HYDRAULIC LINES, FILTER.....	85-16	INTERMEDIATE SHAFT, TRANSMISSION	50-6
HYDRAULIC LINES, FLOOR AND DOOR CONVEYOR.....	70-26	J	
HYDRAULIC MODULE PANELS AND DOORS	80-42	JACKSHAFT, UNIT DRIVE	120-2
HYDRAULIC MOTOR POWER AXLE.....	85-6	JET POST TRANSITION ELBOW	150-6
HYDRAULIC MOTOR ASSY., 100 CC SAUER-SUNDSTRAND (PROPULSION)	50-40	JOURNAL, PICKER BAR.....	120-16
HYDRAULIC MOTOR ASSY., 75 CC SAUER-SUNDSTRAND (UNIT DRIVE).....	50-38	K	
HYDRAULIC MOTOR, TRANSMISSION DRIVE	50-2	KEY SWITCH CONNECTOR.....	40-54
HYDRAULIC OIL COOLER AND HOSES	70-3	KEY, DAMPENOR (6081HN003).....	20-11
HYDRAULIC OIL, HY-GARD.....	70-2	KIT, CONVENIENCE, OUTLET	40-60
HYDRAULIC PUMP (45 CM3 (2.75 CU. IN.)).....	70-8	KIT, ELECTRICAL CONNECTOR SERVICE	40-46
HYDRAULIC PUMP DRIVE	70-1	KIT, ELECTRICAL CONNECTOR SERVICE	40-48
HYDRAULIC RESERVOIR.....	70-2	KIT, ENGINE OVERHAUL.....	20-6
HYDRAULIC STEERING LINES AND HOSES	60-8	KIT, HEAD BOLT (6081HN003).....	20-12
HYDRAULIC SYSTEM POWER AXLE.....	85-6	KIT, LUBRICATION PUMP.....	130-6
HYDRAULIC VALVE POWER AXLE.....	85-6	KIT, SEAL, COMPRESSOR, REFRIGERANT (6081HN003).....	90-57
HYDRO PUMP MODULE ASSEMBLY	80-38	KIT, STEERING CYLINDER SEAL (ADJUSTABLE AXLE).....	60-11
HYDRO PUMPS AND RESERVOIR WIRING HARNESS	40-11	KIT, TERMINAL AND WIRING.....	40-44
HYDROSTATIC CIRCUIT.....	50-20		
HYDROSTATIC CONTROL CABLE	50-22		
HYDROSTATIC DRIVE CHARGE PUMP	50-25		
HYDROSTATIC PUMP	50-20		
HYDROSTATIC PUMP AUXILIARY PUMP MOUNTING	50-26		
HYDROSTATIC PUMP CONTROL LEVERS AND RODS	50-24		
HYDROSTATIC PUMP DISPLACEMENT CONTROL	50-34		
HYDROSTATIC PUMP DRIVE.....	70-1		
HYDROSTATIC PUMP DRIVE (SERIAL NO. 4001-).....	50-19		
HYDROSTATIC PUMP END CAP	50-36		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
KIT, WATER PUMP SEAL (6081HN003).....	20-40		
KIT, WINDSHIELD.....	90-22		
KNEE AND KNUCKLE, REAR AXLE.....	80-6		
KNOB GEARSHIFT.....	90-40		
KNOB, ARMREST CONTROL PANEL.....	90-36		
KNOB, CAB AIR FILTER DOOR.....	90-33		
KNOB, OFFSET, ROW-TRAK.....	60-35		
KNOB, OVERHEAD CONSOLE.....	90-42		
 L 			
LADDER DUCT.....	150-14		
LADDER, PLATFORM (4 ROW).....	80-46		
LADDER, PLATFORM FRAME (6 ROW)(S/N -14000).....	90-2		
LADDER, PLATFORM FRAME (6 ROW)(S/N 14001-).....	90-4		
LAMPS AND WIRING HARNESS, BASKET.....	40-19		
LATCH, BASKET EXTENSION.....	160-48		
LATCH, CAB DOOR.....	90-24		
LATCH, MOISTENER COLUMN.....	140-14		
LENS, CAB ROOF LIGHT.....	40-57		
LEVELER ASSY., HYDROSTATIC PUMP.....	50-28		
LEVER, GEARSHIFT.....	90-40		
LEVERS, HYDROSTATIC PUMP CONTROL.....	50-24		
LID ASSEMBLY, BASKET EXTENSION.....	160-38		
LID EXTENSION, BASKET.....	160-50		
LIFT ARMS, UNIT.....	100-4		
LIFT BRACKET, HYDROSTATIC PUMP.....	50-36		
LIFT FRAMES, UNIT.....	100-2		
LIFT HOSES.....	70-12		
LIFT STRAPS, ENGINE (6081HN003).....	20-21		
LIGHT, CAB ROOF.....	40-57		
LIGHTER, CIGARETTE.....	90-38		
LIGHTS - HALOGEN (CAB) (OPTIONAL) (S/N 14001-).....	90-66		
LINE, BRAKE.....	60-12		
LINE, FILTER HYDRAULIC.....	85-16		
LINE, UNIT LUBRICATION.....	130-8		
LINER, CYLINDER/CONNECTING RODS/PISTON (6081HN003).....	20-10		
LINES, FUEL FILTER/PRE-FUEL FILTER (6081HN003).....	30-20		
LINES, FUEL INJECTION (6081HN003).....	30-12		
LINES, FUEL INJECTION PUMP.....	30-14		
LINES, HYDROSTATIC.....	50-20		
LINES, TURBOCHARGER OIL.....	30-4		
LINES, WATER SYSTEM CONTROL.....	140-8		
LINES, WATER, MOISTENER COLUMN (CLEAR).....	140-10		
LINKAGE, GEARSHIFT.....	90-40		
LINKAGE, HEIGHT SENSING.....	110-34		
LOAD CENTER WIRING HARNESS.....	40-4		
LOAD CENTER WIRING HARNESS.....	40-5		
LOWER GEAR CASE HUB.....	120-8		
LUBRICATION FILL HOSE.....	130-12		
LUBRICATION HOSE, LIFT ARM.....	100-4		
LUBRICATION MANIFOLD.....	130-7		
LUBRICATION PUMP.....	130-6		
LUBRICATION PUMP KIT.....	130-6		
LUBRICATION PUMP SYSTEM.....	130-4		
LUBRICATION TANK.....	130-2		
LUBRICATION TRANSFER PUMP.....	130-10		
 M 			
MAGNETIC PICK-UP (6081HN003).....	20-18		
MAIN AND MAIN THRUST BEARINGS (6081HN003).....	20-14		
MAIN BEARING CAPS (6081HN003).....	20-2		
MAIN CAB WIRING HARNESS.....	40-24		
MAIN FRAME.....	80-10		
MANIFOLD, AIR.....	150-4		
MANIFOLD, AIR CONDITIONING COMPRESSOR (6081HN003).....	90-56		
MANIFOLD, INTAKE (6081HN003).....	30-6		
MANIFOLD, LUBRICATION.....	130-7		
MANIFOLD, THERMOSTAT AND WATER (6081HN003).....	20-42		
MANIFOLD, UNIT LUBRICATION.....	130-8		
MANIFOLD, WATER.....	140-8		
MANIFOLDS, EXHAUST (6081HN003).....	30-18		
MASTER BRAKE CYLINDER.....	60-14		
MASTER CYLINDERS.....	60-16		
MAT, CAB FLOOR.....	90-18		
MDC KIT, HYDROSTATIC PUMP.....	50-34		
MINI ARMREST WIRING HARNESS.....	40-16		
MIRROR SUPPORTS.....	90-32		
MIRROR, REAR VIEW (INSIDE AND OUTSIDE).....	90-69		
MIRRORS AND LIGHT BAR (OPTIONAL) (S/N 14001-).....	90-66		
MIRRORS, REAR VIEW (CAB)(OPTIONAL) (S/N 14001-).....	90-66		
MODULE, MONITOR LIGHT.....	40-56		
MOISTENER COLUMN.....	140-14		
MOISTENER COLUMN WATER LINES (CLEAR).....	140-10		
MOISTENER COLUMN WATER LINES, FLUSH (GREEN).....	140-12		
MONITOR ASSEMBLY.....	90-34		
MONITOR CONSOLE (HEADER HEIGHT).....	40-2		
MONITOR CONSOLE (VEHICLE).....	40-2		
MONITOR GAUGES.....	40-28		
MONITOR LIGHT MODULES AND TACHOMETER CONNECTORS.....	40-56		
MONITOR, FLAP.....	40-21		
MONITORING SYSTEM, BASKET FULL.....	160-58		
MOTOR ASSY., HYDRAULIC, SAUER-SUNDSTRAND 100 CC (PROPULSION).....	50-40		
MOTOR ASSY., HYDRAULIC, SAUER-SUNDSTRAND 75 CC (UNIT DRIVE).....	50-38		
MOTOR, COMPACTOR DRIVE.....	160-36		
MOTOR, FLOOR AND DOOR CONVEYOR HYDRAULIC.....	70-26		
MOTOR, HEATER AND AIR CONDITIONER.....	90-52		
MOTOR, HYDRAULIC POWER AXLE.....	85-6		
MOTOR, PRESSURE BLOWER.....	90-52		
MOTOR, RECIRCULATION BLOWER, HEATER AND AIR CONDITIONER.....	90-54		
MOTOR, STARTING (6081HN003).....	40-38		
MOTOR, TRANSMISSION DRIVE.....	50-2		
MOTOR, UNIT DRIVE.....	50-20		
MOTOR, WIPER (SHORT).....	90-28		
MOUNTING FLANGE, AUXILIARY, HYDROSTATIC PUMP.....	50-26		
MUD SCRAPERS.....	80-48		
MUFFLER.....	30-8		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
N			
NOZZLE, PICKING UNIT BOTTOM FRAME (PRO-16 UNIT).....	110-14		
NOZZLE, DUCT.....	150-10		
NOZZLE, DUCT (36"-38"-40").....	150-12		
NOZZLE, FUEL INJECTION (6081HN003).....	30-19		
NOZZLE, PICKING UNIT BOTTOM FRAME (PRO-12 UNIT).....	110-12		
NOZZLES AND LINES, FUEL INJECTION (6081HN003).....	30-12		
NOZZLES, AIR DUCT.....	150-6		
NUMBER 6 OFFSET COTTON DOOR.....	150-1		
O			
OFFSET CONTROL, ROW-TRAK.....	60-35		
OFFSET COTTON DOOR NUMBER 6.....	150-1		
OIL COOLER.....	20-1		
OIL COOLER ADAPTER, ENGINE.....	20-30		
OIL COOLER BYPASS ADAPTER.....	20-28		
OIL COOLER BYPASS TUBES.....	20-28		
OIL COOLER COVER, ENGINE.....	20-30		
OIL COOLER TUBES, ENGINE.....	20-30		
OIL COOLER, ENGINE.....	20-30		
OIL COOLER, ENGINE (6081HN003).....	20-29		
OIL COOLER, HYDRAULIC.....	70-3		
OIL FILTER BASE (6081HN003).....	20-32		
OIL FILTER BYPASS VALVE (6081HN0030).....	20-32		
OIL FILTER HOUSING (6081HN003).....	20-32		
OIL FILTER HOUSING GASKET (6081HN003).....	20-32		
OIL FILTER, ENGINE (6081HN003).....	20-32		
OIL LINES AND TURBOCHARGER.....	30-4		
OIL PAN (ENGINE SERIAL NO. -209310).....	20-34		
OIL PAN(ENGINE SERIAL NO. 209311-).....	20-36		
OIL PRESSURE REGULATING VALVE (ENGINE OIL COOLER)(6081HN003).....	20-29		
OIL PRESSURE REGULATING VALVE (6081HN003).....	20-32		
OIL PRESSURE REGULATING VALVE, ENGINE.....	20-30		
OIL PRESSURE SWITCH, ENGINE (6081HN003).....	20-45		
OIL PUMP DRIVE GEAR (6081HN003).....	20-11		
OIL PUMP INTAKE (ESN -209310) (U/WRE508040).....	20-27		
OIL PUMP INTAKE (ESN 209311-) (U/W RE506166).....	20-36		
OIL PUMP, ENGINE (6081HN003).....	20-26		
OIL RESERVOIR, HYDRAULIC.....	70-2		
OIL SEAL AND HOUSING, CRANKSHAFT (6081HN003).....	20-15		
OIL SEAL, FRONT AND TIMING GEAR COVER (6081HN003).....	20-19		
OIL SEAL, WATER PUMP (6081HN003).....	20-40		
		OIL, ENGINE (6081HN003).....	20-38
		OIL, HY-GARD HYDRAULIC/TRANSMISSION.....	70-2
		OPERATOR'S ARMREST PANEL.....	90-36
		OPERATOR'S ARMREST PANEL.....	90-38
		OPERATOR'S SEAT.....	90-45
		OPERATOR'S SEAT ADJUST AND PIVOT ASSEMBLIES.....	90-50
		OPERATOR'S SEAT CUSHION, ARMREST, AND MOUNTING.....	90-46
		OPERATOR'S SEAT PIVOT AND ADJUST.....	90-50
		ORIFICE, UNIT LUBRICATION.....	130-8
		OUTLET, CONVENIENCE, KIT.....	40-60
		OUTSIDE MIRRORS.....	90-69
		OUTTEXT.....	70-9
		OVERFLOW TANK, RADIATOR.....	20-61
		OVERHAUL KIT, ENGINE.....	20-6
		OVERHEAD CONSOLE.....	90-42
P			
		PAD, MOISTENER.....	140-14
		PAN, OIL(ENGINE SERIAL NO. -209310).....	20-34
		PAN,OIL(ENGINE SERIAL NO. 209311-).....	20-36
		PANEL, ARMREST.....	90-36
		PANEL, CAB INTERIOR TRIM.....	90-18
		PANEL, FLOOR.....	90-16
		PANEL, OPERATOR'S ARMREST CONTROL.....	90-38
		PANEL, OVERHEAD CONSOLE.....	90-42
		PANELS, CHASSIS SIDE SHIELDING.....	80-22
		PANELS, HYDRAULIC MODULE.....	80-42
		PANELS, TUNNEL BOTTOM, CENTER (S/N -14000).....	80-28
		PANELS, TUNNEL BOTTOM, CENTER (S/N 14001-).....	80-30
		PANELS, TUNNEL BOTTOM, FRONT.....	80-26
		PANELS, TUNNEL BOTTOM, REAR (S/N -14000).....	80-32
		PANELS, TUNNEL BOTTOM, REAR (S/N 14001-).....	80-34
		PARKING BRAKE PEDAL AND SEAL.....	60-18
		PASSIVE CAN BUS DEVICE.....	40-12
		PEDAL, BRAKE.....	60-16
		PICK-UP, MAGNETIC (6081HN003).....	20-18
		PICKER BAR DRUM, STUD AND BEARING.....	120-20
		PICKER BAR JOURNAL.....	120-16
		PICKER BAR SPINDLE DRIVE SHAFT.....	120-18
		PICKER BAR, SPINDLE AND WRENCH.....	120-16
		PICKER DRUM HEAD AND CAM.....	120-14
		PICKING UNIT BOTTOM FRAME (PRO-12 UNIT).....	110-12
		PICKING UNIT BOTTOM FRAME (PRO-16 UNIT).....	110-14
		PICKING UNIT GEAR CASE.....	120-6
		PICKING UNIT GRID BARS AND SUPPORTS (PRO-12 18S).....	110-16
		PICKING UNIT GRID BARS AND SUPPORTS (PRO-16 20S).....	110-18
		PICKING UNIT HANGER.....	110-10
		PICKING UNIT HOUSING.....	110-1
		PICKING UNIT POSTS (PRO-12, 18S).....	110-6
		PICKING UNIT POSTS (PRO-16 20S).....	110-8
		PICKING UNIT UPPER HOUSING (PRO-12 UNIT).....	110-2

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
PICKING UNIT UPPER HOUSING (PRO-16 UNIT).....	110-4	POWERED SENSOR ROW-TRAK.....	85-1
PICKING UNIT WIRING HARNESS.....	40-22	POWERED SENSOR ROW-TRAK.....	85-2
PICKING UNIT WIRING HARNESS.....	40-26	PRE-FUEL FILTER AND LINES (6081HN003).....	30-20
PIN, REAR AXLE PIVOT.....	80-1	PRESSURE PLATE, FRONT DRUM (PRO-12 18S).....	110-20
PINION, FINAL DRIVE.....	50-16	PRESSURE PLATE, FRONT DRUM (PRO-16 20S).....	110-22
PINION, PICKING UNIT GEAR CASE.....	120-6	PRESSURE PLATE, REAR DRUM (PRO-12 18S).....	110-24
PIPE, EXHAUST.....	30-8	PRESSURE PLATE, REAR DRUM (PRO-16 20S).....	110-26
PISTON KIT, HYDROSTATIC PUMP SERVO.....	50-28	PROBE ASSEMBLY, ROW-TRAK GUIDANCE SYSTEM (S/N -14000).....	60-30
PISTON/CONNECTING RODS/CYLINDER LINER (6081HN003).....	20-10	PROBE ASSEMBLY, ROW-TRAK GUIDANCE SYSTEM (S/N 14001-).....	60-32
PISTON, HYDROSTATIC PUMP.....	50-32	PROTECTORS AND SUPPORTS, BASKET FLOOR CONVEYOR CHAIN.....	160-30
PIVOT PLATE, DUCT.....	150-10	PULLEY AND BELT ARRANGEMENT.....	20-62
PIVOT PLATE, DUCT (36"-38"-40").....	150-12	PULLEY AND DAMPENERS, CRANKSHAFT (6081HN003).....	20-16
PIVOT SUPPORT, REAR AXLE (FRONT).....	80-4	PULLEY, AIR CONDITIONER COMPRESSOR FAN (6081HN003).....	90-65
PIVOT SUPPORT, REAR AXLE (REAR).....	80-2	PULLEY, COTTON FAN DRIVE.....	150-2
PIVOT, OPERATOR'S SEAT.....	90-50	PULLEY, FAN (6081HN003).....	20-25
PLANT GUIDE, PRO-12 - 18S.....	110-32	PULLEY, HYDRAULIC PUMP DRIVE.....	70-1
PLATE, FRONT DRUM PRESSURE (PRO-12 18S).....	110-20	PUMP AND LINES, FUEL INJECTION.....	30-14
PLATE, FRONT DRUM PRESSURE (PRO-16 20S).....	110-22	PUMP CONTROL LEVERS AND RODS, HYDROSTATIC.....	50-24
PLATE, PICKING UNIT BOTTOM FRAME (PRO-12 UNIT).....	110-12	PUMP DISPLACEMENT CONTROL, HYDROSTATIC.....	50-34
PLATE, PICKING UNIT BOTTOM FRAME (PRO-16 UNIT).....	110-14	PUMP DRIVE, HYDROSTATIC (SERIAL NO. 4001-).....	50-19
PLATE, REAR DRUM PRESSURE (PRO-12 18S).....	110-24	PUMP END CAP, HYDROSTATIC.....	50-36
PLATE, REAR DRUM PRESSURE (PRO-16 20S).....	110-26	PUMP FRAME ASSEMBLY, HYDRO.....	80-38
PLATFORM FLOORS, AROUND CAB (38" & 40"/64" SKIP ROW).....	90-10	PUMP HOUSING, SWASHPLATE AND CYLINDER BLOCK, HYDROSTATIC.....	50-32
PLATFORM FLOORS, AROUND CAB (4 ROW 34" SINGLE WHL.).....	90-10	PUMP MOUNTING, AUX. PUMP TO HYDROSTATIC PUMP.....	50-26
PLATFORM FLOORS, AROUND CAB (4 ROW).....	90-8	PUMP SHAFT AND LEVELER ASSY., HYDROSTATIC.....	50-28
PLATFORM FLOORS, AROUND CAB (6 ROW).....	90-6	PUMP VALVES, HYDROSTATIC.....	50-30
PLATFORM FRAME (S/N -14000).....	90-2	PUMP WIRING HARNESS, HYDRO.....	40-11
PLATFORM FRAME (S/N 14001-).....	90-4	PUMP, CHARGE, HYDROSTATIC DRIVE.....	50-25
PLATFORM HANDRAILS (4 ROW).....	90-12	PUMP, ENGINE OIL (6081HN003).....	20-26
PLATFORM HANDRAILS (6 ROW).....	90-14	PUMP, FUEL TRANSFER (ROBERT BOSCH) (6081HN003).....	30-17
PLATFORM LADDER (4 ROW).....	80-46	PUMP, HYDRAULIC (45 CM3 (2.75 CU. IN.)).....	70-8
PLUGS AND SEALS, HYDROSTATIC PUMP.....	50-30	PUMP, HYDROSTATIC.....	50-20
PLUGS, UNIT CABINET.....	110-38	PUMP, LUBRICATION.....	130-4
PLUS-50 ENGINE OIL (6081HN003).....	20-38	PUMP, LUBRICATION.....	130-6
POINT, STALKLIFTER, PRO-12 - 18S.....	110-32	PUMP, LUBRICATION TRANSFER.....	130-10
POPPET, HYDROSTATIC PUMP.....	50-30	PUMP, SOLUTION.....	140-6
POST, BASKET SUPPORT.....	160-2	PUMP, WATER.....	140-6
POSTS, PICKING UNIT (PRO-12, 18S).....	110-6	PUMP, WATER (6081HN003).....	20-40
POSTS, PICKING UNIT (PRO-16 20S).....	110-8	PUMP, WATER, SUPPORT AND FITTINGS.....	140-4
POTENTIOMETER.....	90-42	PUSH RODS (6081HN003).....	20-23
POTENTIOMETER, CONSOLE, ROW-TRAK.....	60-35		
POTENTIOMETER, ROW-TRAK HYDRAULIC SYSTEM POWER AXLE.....	85-8	R	
POWER AXLE.....	85-4	RADIATOR.....	20-1
POWER AXLE HYDRAULIC SYSTEM.....	85-6	RADIATOR HOODS.....	80-21
POWER AXLE ROW-TRAK HYDRAULIC SYSTEM.....	85-8	RADIATOR HOSES.....	20-60
POWER AXLE SWITCH.....	85-20	RADIATOR OVERFLOW TANK.....	20-61
POWER AXLE T-BLOCK.....	85-20	RADIATOR SIDE PANELS.....	80-22
POWER AXLE WHEEL.....	85-3		
POWER STEERING VALVE.....	60-6		
POWERED AXLE CENTERFRAME, CYLINDER AND KNEE.....	85-10		
POWERED REAR AXLE HARNESS.....	85-21		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
RADIO, SPEAKERS AND ANTENNA.....	40-40	ROW-TRAK STEERING VALVE	
RADIUS GAUGES, DOFFER.....	120-26	(S/N -14000).....	60-24
RAIL AND SHIFTER, TRANSMISSION HOUSING.....	50-10		
RAILS, BASKET LID.....	160-56	S	
RAKE BAR, ROTARY SCREEN.....	20-50	SADDLE, WATER TANK.....	140-2
REAR AND SIDE CAB SEALS.....	90-16	SAFETY DECALS.....	170-12
REAR AXLE CENTER.....	80-1	SCHEMATIC, ELECTRICAL WIRING.....	40-14
REAR AXLE FRONT PIVOT SUPPORT.....	80-4	SCRAPER, FRONT DRUM PRESSURE PLATE	
REAR AXLE KNEE AND KNUCKLE.....	80-6	(PRO-12 18S).....	110-20
REAR AXLE REAR PIVOT SUPPORT.....	80-2	SCRAPER, FRONT DRUM PRESSURE PLATE	
REAR AXLE TIE RODS.....	80-8	(PRO-16 20S).....	110-22
REAR DRUM PRESSURE PLATE (PRO-12 18S).....	110-24	SCRAPERS, MUD.....	80-48
REAR DRUM PRESSURE PLATE (PRO-16 20S).....	110-26	SCREEN AND TUBE, TRANSMISSION OIL.....	50-4
REAR LIGHTS AND FUEL SENDER WIRING		SCREEN, BASKET EXTENSION LID.....	160-38
HARNES.....	40-7	SCREEN, BASKET EXTENSION, FRONT.....	160-40
REAR OIL SEAL AND HOUSING		SCREEN, BASKET EXTENSION, LEFT.....	160-44
(6081HN003).....	20-15	SCREEN, BASKET EXTENSION, REAR.....	160-46
REAR VIEW MIRROR (CAB)(OPTIONAL)		SCREEN, BASKET EXTENSION, RIGHT.....	160-42
(S/N 14001-).....	90-66	SCREEN, BASKET, LOWER RIGHT SIDE.....	160-8
REAR VIEW MIRRORS.....	90-69	SCREEN, CONTROL FILTER, HYDROSTATIC	
REAR WHEEL.....	80-15	PUMP.....	50-30
RECEIVER-DRYER, AIR CONDITIONER.....	90-61	SCREEN, ROTARY.....	20-50
REFLECTORS.....	170-14	SCREEN, ROTARY, DOOR ASSEMBLY.....	20-46
RELAY, STARTER.....	40-34	SCREEN, ROTARY, DOOR ASSEMBLY.....	20-52
RELAYS AND CIRCUIT BREAKERS.....	40-32	SCREENS, BASKET LID EXTENSION.....	160-50
RELAYS AND CIRCUIT BREAKERS.....	40-34	SEAL AND BRAKE PEDAL, PARKING.....	60-18
RELAYS, LOAD CENTER WIRING HARNESS.....	40-4	SEAL KIT, STEERING CYLINDER.....	60-11
RELAYS, LOAD CENTER WIRING HARNESS.....	40-5	SEAL, CAB SIDE AND REAR.....	90-16
RESERVOIR WIRING HARNESS, HYDRO.....	40-11	SEAL, FRONT OIL AND TIMING GEAR COVER	
RESERVOIR, BRAKE.....	60-12	(6081HN003).....	20-19
RESERVOIR, HYDRAULIC.....	70-2	SEAL, REAR OIL	
RESET HANDLE, BASKET.....	160-48	(6081HN003).....	20-15
RIMS, SINGLE DRIVE WHEELS.....	80-17	SEAL, WATER PUMP OIL	
RING, REAR WHEEL BOLT.....	80-15	(6081HN003).....	20-40
RING, WATER PUMP RETAINING		SEALS, STARTING MOTOR	
(6081HN003).....	20-40	(6081HN003).....	40-38
ROCKER ARM COVER		SEAT CONSOLE, PASSENGER.....	90-30
(6081HN003).....	20-24	SEAT CUSHIONS, PASSENGER.....	90-30
ROCKER ARM SHAFT		SEAT SUSPENSION.....	90-48
(6081HN003).....	20-23	SEAT, OPERATOR'S.....	90-45
ROCKER ARMS		SEATBELT, INSTRUCITONAL SEAT.....	90-44
(6081HN003).....	20-23	SENDER, COOLANT TEMPERATURE	
ROD, HEIGHT SENSING LINKAGE.....	110-34	(6081HN003).....	20-22
ROD, PISTON/CYLINDER LINER/CONNECTING		SENDER, FUEL GAUGE.....	30-10
(6081HN003).....	20-10	SENDER, FUEL TEMPERATURE.....	30-14
RODS, HYDROSTATIC PUMP CONTROL LEVER.....	50-24	SENDER, LUBRICATION PRESSURE.....	130-7
RODS, PUSH		SENSOR BRACE, ROW-TRAK.....	60-34
(6081HN003).....	20-23	SENSOR, BASKET FULL MONITORING SYSTEM.....	160-58
RODS, STALKLIFTER.....	110-36	SENSOR, CRANKSHAFT POSITION.....	20-18
ROLLER, PICKING UNIT HANGER.....	110-10	SENSOR, CRANKSHAFT SPEED.....	20-18
ROOF, INTERIOR CAB.....	90-26	SENSOR, DIFFERENTIAL.....	50-8
ROTARY SCREEN.....	20-50	SENSOR, DRUM SPEED.....	120-12
ROTARY SCREEN DOOR.....	20-46	SENSOR, ENGINE SPEED	
ROTARY SCREEN DOOR TRASH SHIELD.....	20-52	(6081HN003).....	20-18
ROTARY SCREEN DRIVE AND IDLER ARMS.....	20-58	SENSOR, EVAPORATOR TEMPERATURE.....	90-62
ROTOR, FAN.....	150-2	SENSOR, FAN.....	150-2
ROW-TRAK FEEDBACK SENSOR AND WRENCH.....	60-28	SENSOR, FEEDBACK, ROW-TRAK.....	60-28
ROW-TRAK FEEDBACK SENSOR BRACE.....	60-34	SENSOR, FUEL TEMPERATURE.....	30-14
ROW-TRAK HYDRAULIC SYSTEM		SENSOR, HEIGHT SENSING.....	110-34
POWER AXLE.....	85-8	SENSOR, OPERATOR'S ARMREST CONTROL PANEL.....	90-36
ROW-TRAK HYDRAULIC SYSTEM POTENTIOMETER		SENSOR, OVERHEAD CONSOLE.....	90-42
POWER AXLE.....	85-8	SENSOR, POWERED	
ROW-TRAK OFFSET CONTROL.....	60-35	ROW-TRAK.....	85-1
ROW-TRAK PROBE ASSEMBLY		SENSOR, POWERED	
(S/N -14000).....	60-30	ROW-TRAK.....	85-2
ROW-TRAK PROBE ASSEMBLY			
(S/N 14001-).....	60-32		