

**310G,310SG AND 315SG
BACKHOE LOADERS**



JOHN DEERE

PARTS CATALOG

**310G,310SG AND 315SG
BACKHOE LOADERS**

PC2755 (FEB-06)

Worldwide Construction and Forestry Division

Worldwide Edition


customer service email: admin@servicemanualperfect.com

1A2

310G, 310SG AND 315SG BACKHOE LOADERS

INTRODUCTION AND CUSTOMER INFORMATION

T134142 -UN-10OCT00



T134142

*SIDE VIEW OF JOHN DEERE BACKHOE LOADER
(MANUFACTURED 2000-)*

TO THE CUSTOMER

THE PART NUMBERS IN THIS PARTS CATALOG WERE CORRECT AT THE TIME YOUR CATALOG WAS PUBLISHED. IT IS OUR POLICY TO CONSTANTLY IMPROVE OUR MACHINES AND, THEREFORE, PART NUMBERS MAY CHANGE. WHEN ORDERING PARTS, VERIFY PART NUMBERS THROUGH YOUR DEALER'S

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.)

1A3

310G, 310SG AND 315SG BACKHOE LOADERS

ENGINE SERIAL NUMBER PLATE

T134833 -UN-23OCT00



T134833

- | | |
|--|--|
| 1. DESIGNATES ENGINE MANUFACTURER | T-JOHN DEERE DUBUQUE WORKS |
| 1. | P-JOHN DEERE MOTORES |
| 2. DESIGNATES NUMBER OF CYLINDERS AND LITERS. | 4045 (4.5 LITER) |
| 3. DESIGNATES FUEL TYPE OR SPECIAL COND. | DT NON-TURBOCHARGED DIESEL ENGINE
TT TURBOCHARGED DIESEL ENGINE |
| 4. DESIGNATES ENGINE SERIAL NUMBER | 123456 |
| 5. DESIGNATES THE ENGINE APPLICATION AND FACTORY USER. | T04045DT056 (WITHOUT TURBOCHARGER)(310G) |
| | ^PE4045DT056 (WITHOUT TURBOCHARGER)(310G) |
| | T04045TT080 (WITH TURBOCHARGER)(310G) |
| | PE4045TT080 (WITH TURBOCHARGER)(310G) |
| | ^T04045TT081 (WITH TURBOCHARGER)(310SG,315SG) |
| | ^PE4045TT081 (WITH TURBOCHARGER)(310SG,315SG) |
| | ^PE4045DT058 (WITHOUT TURBOCHARGER)(310G) |
| | ^PE4045TT088 (WITH TURBOCHARGER)(310G) |
| | ^PE4045TT089 (WITH TURBOCHARGER)(310SG) |

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

1A4

310G, 310SG AND 315SG BACKHOE LOADERS

SERIAL NUMBER LISTING INFORMATION

SERIAL NUMBER INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER LISTED.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

USE OF VEHICLE SERIAL NUMBERS ON ENGINE PAGES:
PLEASE PROVIDE THE VEHICLE SERIAL NUMBER (VSN-T0450HX910011), ENGINE SERIAL NUMBER (ESN-PE4045T190332), AND ENGINE MODEL NO. (PE4045TT058) WHEN ORDERING REPLACEMENT PARTS. ENGINE PARTS PAGES HAVE BEEN REVISED TO DETAIL THE VSN IN THE HEADER, ENGINE MODEL NO. IN THE REMARKS SECTION, AND VEHICLE SERIAL NO. IN THE ALPHABETICAL INDEX. PLEASE PROVIDE ALL THREE NUMBERS WHEN ORDERING ENGINE PARTS TO INSURE EFFICIENT SERVICE.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES OF THE LOADER OR TRACTOR PARTS ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL

EXCEPTION: FOR ALL BACKHOE PARTS, "RIGHT-HAND" AND "LEFT-HAND" SIDES, "FRONT" AND "REAR" ARE DETERMINED WHEN SEATED FOR BACKHOE OPERATION.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN THE REMARKS COLUMN AS WHOLE GOODS. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

CHANGE INDICATOR LINE

CHANGES AFFECTING THE ORDERING OF PARTS ARE IDENTIFIED BY VERTICAL LINES MARKED IN THE LEFT-HAND MARGIN OF REVISED PARTS LISTING IMAGES. A LINE IS ALSO AT THE LEFT-HAND EDGE OF THE SAME PART NUMBER IN THE NUMERICAL INDEX TO SHOW THE LOCATION OF REVISED INFORMATION.

1A5

310G, 310SG AND 315SG BACKHOE LOADERS

SERIAL NUMBER LOCATIONS

EACH 310G, 310SG AND 315SG BACKHOE LOADER HAS SIX SERIAL NUMBERS, A PRODUCT IDENTIFICATION NUMBER PLATE, AN ENGINE SERIAL NUMBER PLATE, A HYDRAULIC PUMP SERIAL NUMBER PLATE, A MFWD AXLE SERIAL NUMBER PLATE, A TRANSMISSION SERIAL NUMBER PLATE, AND A REAR AXLE SERIAL NUMBER PLATE.

THE PRODUCT IDENTIFICATION NUMBER IS ON THE LEFT-HAND SIDE OF THE LOADER FRAME JUST ABOVE THE LIFT CYLINDER PIVOT BOSS.

THE ENGINE SERIAL NUMBER PLATE IS LOCATED ON THE RIGHT-HAND SIDE OF THE CYLINDER BLOCK NEAR THE FUEL PUMP.

THE MFWD AXLE SERIAL NUMBER PLATE IS LOCATED ON THE RIGHT-HAND (REAR) SIDE OF THE MFWD AXLE HOUSING.

THE REAR AXLE SERIAL NUMBER PLATE IS LOCATED ON THE RIGHT-HAND (FRONT) SIDE OF THE AXLE HOUSING.

THE TRANSMISSION SERIAL NUMBER PLATE IS LOCATED ON THE BOTTOM-REAR FACE OF THE HOUSING.

THE HYDRAULIC PUMP SERIAL NUMBER IS LOCATED ON THE BOTTOM FACE OF THE PUMP.

LEFT-HAND SIDE, RIGHT-HAND SIDE, FRONT AND REAR OF THE BACKHOE LOADER ARE VIEWED BY FACING IN THE DIRECTION OF THE BACKHOE LOADER FORWARD TRAVEL.

LEFT-HAND SIDE, RIGHT-HAND SIDE, FRONT AND REAR OF THE BACKHOE COMPONENTS ARE DETERMINED WHEN SEATED IN THE BACKHOE OPERATING POSITION.

IF PRODUCT IDENTIFICATION NUMBERS OR SERIAL NUMBERS ARE REQUIRED FOR WARRANTY CLAIMS OR CORRESPONDENCE PERTAINING TO THIS PRODUCT. IT IS EXTREMELY IMPORTANT THAT ALL CHARACTERS BE FURNISHED. THIS POINT CANNOT BE OVEREMPHASIZED.

1A6

310G, 310SG AND 315SG BACKHOE LOADERS

MFWD AXLE SERIAL NUMBER PLATE

TP19438 -UN-01JAN94

The diagram shows a rectangular serial number plate with four mounting holes. At the top, it reads "Zahnradfabrik Passau GmbH". Below this is the ZF logo. The plate is divided into several sections: "Type" (field 4) and "Serial No." (field 5) at the top; "Parts List No." (field 3) and "Total Ratio/Version:" (fields 6 and 7) in the middle; "Oil" (field 2) and "Ltri" (field 9) on the left; and "List of Lubricants" (fields 8) on the right. The "List of Lubricants" section contains three rows, each with "TE-ML" and a field for capacity (field 8). At the bottom, it says "Customer's Code No." (field 1).

TP19438

- | | |
|---|--|
| 1. DESIGNATES CUSTOMER'S CODE NUMBER | JOHN DEERE PART NUMBER |
| 2. DESIGNATES TYPE OF LUBRICANT | M1L-L-2105B, SAE90 |
| 3. DESIGNATES ZF-PARTS-LIST NUMBER | 4464 006 101 |
| 4. DESIGNATES AXLE TYPE | AP-11H |
| 5. DESIGNATES AXLE SERIAL NUMBER | 12345 |
| 6. DESIGNATES TOTAL - RATIO OF THE AXLE | 20.28 |
| 7. DESIGNATES VERSION | SP. DIFF. (WITH OR WITHOUT SELF-LOCKING DIFFERENTIAL) |
| 8. DESIGNATES LUBRICANT SPECIFICATION | 05 |
| 9. DESIGNATES CAPACITY | LTR (DIFFERENTIAL CARRIER AND PLANETARY GEAR ASSEMBLY) |

1A7

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX

GRID	PAGE	GRID	PAGE
A			
3C11	A/C PRESSURE SWITCH HARNESS 1674 - 4	3C17	AIR SUSPENSION SEAT SWITCH..... 1674 - 6
3C17	A/C SWITCH 1674 - 6	3I12	ALARM SYSTEM, BACK-UP (315SG) 2004 - 4
3E18	ACCELERATOR PEDAL RUBBER BUMPER..... 1812 - 4	3I10	ALARM, BACK-UP ALARM (310G,310SG) 2004 - 2
2C22	ACCESS COVER, INJECTION PUMP GEAR (VSN -911768) 310G (W/O TURBO) 0402 - 4	3I10	ALARM, TRAVEL WARNING (310G,310SG) 2004 - 2
2D1	ACCESS COVER, INJECTION PUMP GEAR (VSN-910055) 310G(TURBO), 310SG, 315SG 0402 - 6	3I12	ALARM, TRAVEL WARNING (315SG) 2004 - 4
2C24	ACCESS COVER, INJECTION PUMP GEAR 310G (W/O TURBO) (VSN 911769-) 0402 - 4B	3C1	ALTERNATOR 1672 - 2
2D3	ACCESS COVER, INJECTION PUMP GEAR 310G(TURBO), 310SG, 315SG (VSN910056-) 0402 - 6B	2G22	ALTERNATOR ADJUSTING STRAP..... 0423 - 2
5G11	ACCU-SWING VALVE KIT 3362 - 29A	3C1	ALTERNATOR FAN 1672 - 2
3J21	ACCUMULATOR SEAL KIT..... 2160 - 24	2G22	ALTERNATOR MOUNTING BRACKETS 0423 - 2
3J23	ACCUMULATOR SEAL KIT..... 2160 - 26	3C1	ALTERNATOR PULLEY..... 1672 - 2
3J21	ACCUMULATOR VALVE 2160 - 24	3C5	ANCHOR, TIE BAND MOUNT, HARNESS SERIAL NO. -XXXXXX 1673 - 4
3J23	ACCUMULATOR VALVE 2160 - 26	3C7	ANCHOR, TIE BAND MOUNT, HARNESS SERIAL NO. XXXXXX- 1673 - 6
5G14	ACCUMULATOR, MANIFOLD (PILOT CONTROL) 3362 - 31	3G5	ANGLE, BACKREST ADJUSTMENT 1821 - 2
3J21	ACCUMULATOR, RIDE CONTROL 2160 - 24	3I6	ANTENNA, RADIO..... 2001 - 2
3J23	ACCUMULATOR, RIDE CONTROL 2160 - 26	4D19	ANTI-CAVITATION, BOOM SECTION 3162 - 10
2D1	ACCESS COVER, INJECTION PUMP GEAR (VSN-910055) 310G(TURBO), 310SG, 315SG 0402 - 6	4D23	ANTI-CAVITATION, BUCKET SECTION..... 3162 - 14
3C11	ACTUATOR DOOR RELAY 1674 - 4	3E18	ANTI-SKID MAT 1812 - 4
2G20	ADAPTER KIT, STARTER MOTOR 0422 - 6	5F5	ARM GRIP REPAIR KIT,EXT.DIPPER 3346 - 6
2G1	ADAPTER,ENGINE OIL COOLER 0419 - 2	3G5	ARM RESTS..... 1821 - 2
2E15	ADAPTER,EXHAUST 310G(TURBO), 310SG, 315SG 0410 - 2	4D7	ARM, LOADER LIFT 3140 - 2
2G22	ADJUSTING STRAP, ALTERNATOR 0423 - 2	3G1	ARM, PILOT CONTROLLER (LEFT SIDE)..... 1816 - 14
2H23	AIR CLEANER 0520 - 2	3G3	ARM, PILOT CONTROLLER (RIGHT SIDE) 1816 - 16
2H23	AIR CLEANER ELEMENT 0520 - 2	5F1	ARM, STANDARD 3346 - 2
2H23	AIR CLEANER HOSE 0520 - 2	3G13	ARM, SUSPENSION SEAT 1821 - 10
2H23	AIR CLEANER RESTRICTION INDICATOR SWITCH 0520 - 2	5F6	ARM,STABILIZER (310G,310SG)..... 3348 - 2
3H1	AIR CONDITIONING 1830 - 6	2C20	ARMS, ROCKER 0402 - 2
3H3	AIR CONDITIONING 1830 - 7A	5J5	ATTACHMENT PLUMBING KIT 3363 - 42
3H3	AIR CONDITIONING (FREEZE/COMPRESSOR) SWI TCH 1830 - 7A	3C15	AUDIBLE ALARM, QUICK COUPLER PIN ENGAGEM ENT 1674 - 5C
3H8	AIR CONDITIONING COMPRESSOR..... 1830 - 12	5J3	AUGER COUPLERS (STANDARD DIPPERSTICK) 3363 - 40
3H10	AIR CONDITIONING COMPRESSOR..... 1830 - 14	5J1	AUGER COUPLERS (WITH EXTENDIBLE DIPPERSTICK)..... 3363 - 38
3H8	AIR CONDITIONING COMPRESSOR MOUNTING BRACKETS 1830 - 12	5J1	AUGER HYDRAULIC OIL LINES (WITH EXTENDIBLE DIPPERSTICK)..... 3363 - 38
3H10	AIR CONDITIONING COMPRESSOR MOUNTING BRACKETS 1830 - 14	5J3	AUGER HYDRAULICS (STANDARD DIPPERSTICK) 3363 - 40
3C19	AIR CONDITIONING COMPRESSOR DIODE 1674 - 8	5I7	AUXILIARY HYDRAULICS, STD. DIPPERSTICK (310G AND 310SG)..... 3363 - 20
3C21	AIR CONDITIONING COMPRESSOR DIODE 1674 - 9A	5I11	AUXILIARY EQUIPMENT HYDRAULICS, EXTENDIB LE DIPPERSTICK (310G AND 310SG) 3363 - 24
3H8	AIR CONDITIONING COMPRESSOR DRIVE BELT 1830 - 12	5D23	AUXILIARY FUNCTION PEDAL (PILOT CONTROL) 3315 - 15A
3H10	AIR CONDITIONING COMPRESSOR DRIVE BELT 1830 - 14	5I13	AUXILIARY HYDRAULICS, EXT.DIPPERSTICK (315SG) 3363 - 26
3H8	AIR CONDITIONING COMPRESSOR HOSES..... 1830 - 12	5I9	AUXILIARY HYDRAULICS, STD.DIPPERSTICK (315SG) 3363 - 22
3H10	AIR CONDITIONING COMPRESSOR HOSES..... 1830 - 14	3J19	AUXILIARY OIL COOLER KIT (310G) 2160 - 22
3H8	AIR CONDITIONING CONDENSER 1830 - 12	4E1	AUXILIARY SECTION RELIEF VALVE (SERIAL NO. -913416) 3162 - 16
3H10	AIR CONDITIONING CONDENSER 1830 - 14	4E5	AUXILIARY SECTION RELIEF VALVE (SERIAL NO. 913417-) 3162 - 20
3C11	AIR CONDITIONING DOOR ACTUATOR RELAY 1674 - 4	5G3	AUXILIARY SECTION, BACKHOE VALVE..... 3362 - 22
3G22	AIR CONDITIONING DUCTS 1830 - 2	4E1	AUXILIARY SECTION, LOADER VALVE (SERIAL NO. -913416) 3162 - 16
3G24	AIR CONDITIONING DUCTS 1830 - 4	4E5	AUXILIARY SECTION, LOADER VALVE (SERIAL NO. 913417-) 3162 - 20
3H8	AIR CONDITIONING RECEIVER DRYER 1830 - 12	4E3	AUXILIARY VALVE KIT, LOADER (SERIAL NO. -913416) 3162 - 18
3H10	AIR CONDITIONING RECEIVER DRYER 1830 - 14	1B22	AXLE HOUSING..... 0201 - 2
3F23	AIR CONDITIONING THERMOSTAT SWITCH 1816 - 12	1B24	AXLE HOUSING..... 0201 - 4
2F9	AIR INTAKE SYSTEM 310(W/O TURBO) 0414 - 3	1C17	AXLE HOUSING ASSEMBLY (MFWD)..... 0250 - 4
2F7	AIR INTAKE SYSTEM 310G(TURBO), 310SG, 315SG (VSN -910055)..... 0414 - 1		
2F8	AIR INTAKE SYSTEM 310G(TURBO),310SG,315S G (VSN 910056-) 0414 - 2		
2F8	AIR INTAKE TEMPERATURE SENSOR 310G (TURB O),310SG,315SG (VSN 910056-) 0414 - 2		
3G18	AIR SUSPENSION SEAT COMPRESSOR..... 1821 - 16		

1A8

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
1C12	0230 - 6	5J23	3365 - 14
1C8	0230 - 2	5J25	3365 - 16
1B22	0201 - 2	5J22	3365 - 13
1B24	0201 - 4	5H19	3363 - 8
1B22	0201 - 2	5J19	3365 - 10
1B24	0201 - 4	5J20	3365 - 11
1C13	0230 - 7	5J21	3365 - 12
1C15	0250 - 1	5J24	3365 - 15
1C8	0230 - 2	5J23	3365 - 14
1C11	0230 - 5	5J25	3365 - 16
B			
3I10	2004 - 2	5J22	3365 - 13
3I12	2004 - 4	5E25	3345 - 6
3G7	1821 - 4	5D1	3302 - 14
5E19	3344 - 2	5D3	3302 - 16
5J11	3365 - 2	3F15	1816 - 5A
5J13	3365 - 4	5E11	3315 - 26
5J15	3365 - 6	5F10	3362 - 4
5J17	3365 - 8	5F12	3362 - 6
5J11	3365 - 2	5D11	3315 - 6
5J13	3365 - 4	3F11	1816 - 2
5J15	3365 - 6	3G1	1816 - 14
5J17	3365 - 8	3G3	1816 - 16
5E5	3315 - 20	5H19	3363 - 32
5E3	3315 - 18	3F13	1816 - 4
5E7	3315 - 22	3F11	1816 - 2
5E7	3315 - 22	5E1	3315 - 16
5E7	3315 - 22	3D17	1740 - 4
5I17	3363 - 30	5E19	3344 - 2
5E19	3344 - 2	5H11	3363 - 2
5E19	3344 - 2	5H13	3363 - 3A
5E20	3344 - 3	5H15	3363 - 4
5D1	3302 - 14	5I3	3363 - 16
5D3	3302 - 16	5E7	3315 - 22
5D1	3302 - 14	5D13	3315 - 8
5D3	3302 - 16	5G3	3362 - 22
5J19	3365 - 10	5F16	3362 - 10
5J20	3365 - 11	5G23	3362 - 40
5J21	3365 - 12	5F18	3362 - 12
5J24	3365 - 15	5H1	3362 - 42
		5F20	3362 - 14
		5H3	3362 - 44
		5F24	3362 - 18
		5D7	3315 - 3A
		5D5	3315 - 2

1A9

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
5D9	BACKHOE VALVE MOUNTING PLATE 315SG	2D10	BLOCK, CYLINDER 310G(TURBO), 310SG, 315SG (VSN-910055)
5F14	BACKHOE VALVE PRIORITY INLET SECTION	5E13	BLOCK, TRUNNION SWING CYLINDER, 315SG
5G1	BACKHOE VALVE SELECTIVE FLOW SECTION	3D15	BLOCK,TRUNNION SWING CYLINDER,310G,310SG....
5F22	BACKHOE VALVE SWING SECTION	3H1	BLOWER MOTOR PRESSURIZER.....
5H5	BACKHOE VALVE SWING, PILOT SECTION	3H3	BLOWER MOTOR PRESSURIZER.....
5D11	BACKHOE VALVE TWO LEVER CONVERSION KIT (310G AND 310SG).....	3H15	BOLT, STRIKER, HOOD
5D15	BACKHOE, FOUR-LEVER CONTROLS, STANDARD (310G,310SG)	3H17	BOLT, STRIKER, HOOD
5D13	BACKHOE, THREE LEVER CONTROL VALVE LINKAGE (310G AND 310SG)	5I21	BOOM CYL.KIT, CONTOLED LOWERING DEVICE
3G5	BACKREST ADJUSTMENT ANGLE	5I21	BOOM CYL.KIT, LOWERING DEVICE,CONTOLED
2F10	BALANCER SHAFT, ENGINE 310G(TURBO), 310SG, 315SG	4F8	BOOM CYLINDER (310SG AND 315SG)(SER.# 910492-926248).....
2K18	BANK, FRONT AXLE GREASE	5H17	BOOM CYLINDER HYDRAULIC HOSES.....
2J23	BAR, CYLINDER SERVICE LOCK	5H17	BOOM CYLINDER HYDRAULIC OIL LINES
2I24	BARREL, STEERING CYLINDER (MFWD)	4E15	BOOM CYLINDER HYDRAULICS, LOADER
3H12	BARRIER, HEAT AND NOISE	4E17	BOOM CYLINDER HYDRAULICS, LOADER
3G16	BASE, SEAT FOR NON-SUSPENDED SEAT	4F8	BOOM CYLINDER REPAIR KIT (310SG AND 315SG)(SER.# 910492-926248).....
3G14	BASE, SEAT WITH NON-SUSPENDED SEAT	5J11	BOOM CYLINDER REPAIR KIT, BACKHOE (310G)
3B21	BATTERIES,DUAL	5J13	BOOM CYLINDER REPAIR KIT, BACKHOE (310G)
3H19	BATTERY BOX	5J15	BOOM CYLINDER REPAIR KIT, BACKHOE (310SG,315SG)
3B19	BATTERY CABLE, SINGLE.....	5J17	BOOM CYLINDER REPAIR KIT, BACKHOE (310SG,315SG)
3H19	BATTERY COVER	5J11	BOOM CYLINDER, BACKHOE (310G)
3B23	BATTERY DISCONNECT SWITCH,MASTER.....	5J13	BOOM CYLINDER, BACKHOE (310G)
3B19	BATTERY INSTALLATION, SINGLE.....	5J15	BOOM CYLINDER, BACKHOE (310SG,315SG)
3C3	BEACON, ROTATING	3F21	BOOM LEVER LOCK COVER
3C3	BEACON, STROBE	3F23	BOOM LEVER LOCK COVER
1C10	BEARING, FRONT WHEEL (WITHOUT MFWD) (SERIAL NO. -911131)	5E3	BOOM LOCK CONTROL LEVER (310G AND 310SG).....
1C12	BEARING,FRONT AXLE HOUSING (WITHOUT MFWD)(SERIAL NO. 911132-).....	5E5	BOOM LOCK, BACKHOE (310G AND 310SG).....
2C12	BEARINGS, MAIN 310G (W/O TURBO) (VSN 911769-)	5E19	BOOM PIN, BACKHOE
2C11	BEARINGS, MAIN 310G (W/O TURBO) (VSN-911768)	4D19	BOOM SECTION ANTI-CAVITATION RELIEF
2C14	BEARINGS, MAIN 310G(TURBO),310SG,315SG (VSN -910055)	4D17	BOOM SECTION RELIEF VALVE.....
2C15	BEARINGS, MAIN 310G(TURBO),310SG,315SG (VSN 910056-)	4D19	BOOM SECTION RELIEF VALVE.....
2D6	BEARINGS,CONNECTING ROD 310G (W/O TURBO) (VSN 911769-)	5F16	BOOM SECTION RELIEF VALVE.....
2D8	BEARINGS,CONNECTING ROD 310G(TURBO) 310SG 315SG (VSN 910056-).....	5F16	BOOM SECTION, BACKHOE VALVE.....
2D7	BEARINGS,CONNECTING ROD 310G(TURBO), 310SG, 315SG (VSN-910055)	4D17	BOOM SECTION, LOADER VALVE
2D5	BEARINGS,CONNECTING ROD 310G (W/O TURBO) (VSN -911768).....	4D19	BOOM SECTION, LOADER VALVE
1D14	BELL HOUSING	2J23	BOOM SERVICE LOCK BAR
1D15	BELL HOUSING	5E19	BOOM STOP/CLAMP,BACKHOE
1E5	BELLVILLEWASHER, FIRST GEAR, POWER SHIFT	4D7	BOOM, LOADER
1E13	BELLVILLEWASHER, FORWARD, POWER SHIFT	5G23	BOOM, PILOT SECTION RELIEF VALVE
1E15	BELLVILLEWASHER, REVERSE, POWER SHIFT	5E19	BOOM,BACKHOE
1E7	BELLVILLEWASHER, 2ND GEAR, POWER SHIFT	5G23	BOOM,PILOT SECTION, BACKHOE VALVE
1E9	BELLVILLEWASHER, 3RD GEAR, POWER SHIFT.....	1D7	BOOT, TRANSMISSION SHIFTER CARROT.....
1E11	BELLVILLEWASHER, 4TH GEAR, POWER SHIFT	1D11	BOOT, TRANSMISSION SHIFTER LEVER
2G24	BELT, DRIVE 310G(TURBO),310SG,315SG	3F15	BOOT, WINCH CONTROL (PILOT CONTROL)
3G18	BELT, TETHER	3D20	BOTTOM GUARD
3H8	BELT,AIR CONDITIONING COMPRESSOR DRIVE	3H19	BOX, BATTERY
3H10	BELT,AIR CONDITIONING COMPRESSOR DRIVE	3H19	BOX, TOOL
2H17	BELT,FAN DRIVE	2H23	BRACKET, AIR CLEANER MOUNTING
3G5	BELTS, SEAT.....	2I9	BRACKET, ENGINE MOUNTING
3G14	BELTS, TETHER WITH NON-SUSPENDED SEAT	3I9	BRACKET, EXTERNAL REAR VIEW MIRROR
1C23	BEVEL DRIVE GEAR (MFWD) (310SG,315SG)	3E18	BRACKET, HARNESS COVER
		3I13	BRACKET, HORN (SERIAL NO. -910147).....
		3I8	BRACKET, INTERIOR REAR VIEW MIRROR

1A10

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2K1	BRACKET, LICENCE PLATE	1314 - 2	4C21	BUCKET LEVELING ROD	3115 - 4
3H15	BRACKET, STRIKER BOLT	1910 - 2	4C19	BUCKET LEVELING YOKE	3115 - 2
3H17	BRACKET, STRIKER BOLT	1910 - 4	4C21	BUCKET LEVELING YOKE	3115 - 4
5D7	BRACKET, BACKHOE VALVE MOUNTING (PILOT CONTROL)	3315 - 3A	4D9	BUCKET LINKAGE, LOADER	3140 - 4
5D5	BRACKET, BACKHOE VALVE MOUNTING 310G, 310SG	3315 - 2	5E23	BUCKET LINKS AND PINS, BACKHOE (310SG AND 315SG)	3345 - 4
5D9	BRACKET, BACKHOE VALVE MOUNTING 315SG	3315 - 4	5E21	BUCKET LINKS AND PINS, BACKHOE (310G)	3345 - 2
3I6	BRACKET, RADIO ANTENA	2001 - 2	5F1	BUCKET PIN	3346 - 2
5D7	BRACKET, STABILIZER VALVE MOUNTING (PILOT CONTROL)	3315 - 3A	4B24	BUCKET PINS, LOADER	3102 - 6
5D5	BRACKET, STABILIZER VALVE MOUNTING 310G, 310SG	3315 - 2	4D23	BUCKET SECTION ANTI-CAVITATION RELIEF	3162 - 14
5D9	BRACKET, STABILIZER VALVE MOUNTING 315SG	3315 - 4	4D21	BUCKET SECTION RELIEF VALVE	3162 - 12
1D11	BRACKET, TRANSMISSION SHIFTER LEVER	0315 - 6	4D23	BUCKET SECTION RELIEF VALVE	3162 - 14
3G5	BRACKETS ,SEAT	1821 - 2	5F18	BUCKET SECTION RELIEF VALVE	3362 - 12
2G22	BRACKETS, ALTERNATOR MOUNTING	0423 - 2	5F18	BUCKET SECTION, BACKHOE VALVE	3362 - 12
2J5	BRAKE DISK	1011 - 2	4D21	BUCKET SECTION, LOADER VALVE	3162 - 12
2J5	BRAKE HOUSING	1011 - 2	4D23	BUCKET SECTION, LOADER VALVE	3162 - 14
2J7	BRAKE LIGHT PRESSURE SWITCH	1060 - 2	5F1	BUCKET SPACER, SYNTHETIC	3346 - 2
2J7	BRAKE PEDAL	1060 - 2	4B20	BUCKET, LOADER .76 CUBIC METER (1.00 CUBIC YARD)	3102 - 2
2J5	BRAKE PISTON	1011 - 2	4B20	BUCKET, LOADER .90 CUBIC METER (1.20 CUBIC YARD)	3102 - 2
2J11	BRAKE SERVICE, HYDRAULICS	1060 - 6	4B20	BUCKET, LOADER .96 CUBIC METER (1.25 CUBIC YARD)	3102 - 2
2J7	BRAKE VALVE	1060 - 2	4C7	BUCKET, LOADER, COUPLER .76 CUBIC METER (1.00 CUBIC YARD)	3102 - 14
2J9	BRAKE VALVE	1060 - 4	4C7	BUCKET, LOADER, COUPLER .96 CUBIC METER (1.25 CUBIC YARD)	3102 - 14
2J13	BRAKE VALVE BOOST PLUMBING (CAB), 310G AND 310SG	1060 - 8	4C1	BUCKET, MULTI-PURPOSE	3102 - 8
2J15	BRAKE VALVE BOOST PLUMBING (ROPS), 310G AND 310SG	1060 - 10	5H1	BUCKET, PILOT SECTION RELIEF VALVE	3362 - 42
2J7	BRAKE VALVE HOUSING	1060 - 2	5H1	BUCKET, PILOT SECTION, BACKHOE VALVE	3362 - 42
2J9	BRAKE VALVE HOUSING	1060 - 4	5D1	BUCKET, BACKHOE	3302 - 14
2J9	BRAKE VALVE KIT	1060 - 4	5D3	BUCKET, BACKHOE	3302 - 16
2J7	BRAKE VALVE MOUNTING PLATE	1060 - 2	4B22	BUCKET, LOADER .86 CUBIC METER (1.13 CUBIC YARD)	3102 - 4
2J9	BRAKE VALVE PUSH ROD	1060 - 4	4B22	BUCKET, LOADER 1.00 CUBIC METER (1.30 CUBIC YARD)	3102 - 4
2J18	BRAKE, PARK (AXLE SERIAL NO. -217496)	1111 - 2	4C9	BUCKET, LOADER, COUPLER .86 CUBIC METER (1.13 CUBIC YARD)	3102 - 16
2J20	BRAKE, PARK (AXLE SERIAL NO. 217497 -)	1111 - 4	4C9	BUCKET, LOADER, COUPLER 1.00 CUBIC METER (1.31 CUBIC YARD)	3102 - 16
2J5	BRAKES, SERVICE	1011 - 2	4C3	BUCKET, MULTI-PURPOSE	3102 - 10
3J9	BREATHER FILTER, HYDRAULIC RESERVOIR	2160 - 12	4C11	BUCKET, MULTI-PURPOSE, COUPLER	3102 - 18
1D14	BREATHER, TRANSMISSION	0341 - 1	3D22	BUMPER (SERIAL NUMBER -901551)	1747 - 2
1D15	BREATHER, TRANSMISSION	0341 - 2	3D24	BUMPER (SERIAL NUMBER 901552-)	1747 - 4
5H21	BUCKET CYLINDER HYDRAULIC HOSES (EXTENDIBLE DIPPERSTICK)	3363 - 10	3E1	BUMPER (SERIAL NUMBER 901552-)	1747 - 6
5H19	BUCKET CYLINDER HYDRAULICS, BACKHOE	3363 - 8	3E18	BUMPER, ACCELERATOR PEDAL, RUBER	1812 - 4
5H19	BUCKET CYLINDER LINES, BACKHOE	3363 - 8	3D22	BUMPER, MAIN FRAME (SERIAL NUMBER -901551)	1747 - 2
5J24	BUCKET CYLINDER, BACKHOE (310SG, 315SG) SERIAL NO. -926788)	3365 - 15	3D24	BUMPER, MAIN FRAME (SERIAL NUMBER 901552-)	1747 - 4
5J23	BUCKET CYLINDER, BACKHOE (310SG, 315SG) SERIAL NO. 926130-)	3365 - 14	3E1	BUMPER, MAIN FRAME (SERIAL NUMBER 901552-)	1747 - 6
5J25	BUCKET CYLINDER, BACKHOE (310SG, 315SG) SERIAL NO. 926789-)	3365 - 16	5F3	BUSHING, EXTENDIBLE ARM	3346 - 4
5J22	BUCKET CYLINDER, BACKHOE 310SG, 315SG (SERIAL NO. -926129)	3365 - 13	4C3	BUSHING, MULTI-PURPOSE BUCKET CYLINDER	3102 - 10
4F10	BUCKET CYLINDER, LOADER (SERIAL NO. -941225)	3165 - 10	4C11	BUSHING, MULTI-PURPOSE BUCKET CYLINDER, COUPLER	3102 - 18
4F12	BUCKET CYLINDER, LOADER (SERIAL NO. 941226-)	3165 - 12	1C12	BUSHING, FRONT AXLE HOUSING (WITHOUT MFWD)(SERIAL NO. 911132-)	0230 - 6
4C5	BUCKET CYLINDER, MULTI-PURPOSE (SERIAL NO. -925076)	3102 - 12	5E13	BUSHING, SLIDING FRAME, 315SG	3342 - 2
4C6	BUCKET CYLINDER, MULTI-PURPOSE (SERIAL NO. 925077-)	3102 - 13			
4C19	BUCKET LEVELING LINKAGE	3115 - 2			
4C21	BUCKET LEVELING LINKAGE	3115 - 4			
4C19	BUCKET LEVELING ROD	3115 - 2			

C

316 CAB DOME LIGHT

2001 - 2

1A11

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3E20	CAB DOOR CYLINDER.....	1814 - 2	3H5	CANOPY HEATER.....	1830 - 8
3E22	CAB DOOR CYLINDER.....	1814 - 4	3H5	CANOPY HEATER HOSE.....	1830 - 8
3E20	CAB DOOR HINGES.....	1814 - 2	3H5	CANOPY HEATER SHUT-OFF VALVE.....	1830 - 8
3E22	CAB DOOR HINGES.....	1814 - 4	3H5	CANOPY HEATER VALVE CONTROL CABLE.....	1830 - 8
3E20	CAB DOORS.....	1814 - 2	2I11	CAP, FUEL TANK.....	0560 - 2
3E22	CAB DOORS.....	1814 - 4	2H17	CAP, RADIATOR.....	0510 - 2
3E12	CAB FRAME.....	1811 - 4	2D16	CAP,ENGINE OIL FILL INLET.....	0407 - 2
3E12	CAB HEADLINER.....	1811 - 4	2D10	CAP,MAIN BEARING	
3H1	CAB HEATER.....	1830 - 6		310G(TURBO), 310SG, 315SG (VSN-910055).....	0404 - 2
3H3	CAB HEATER.....	1830 - 7A	1C1	CARRIER, PLANETARY PINION.....	0210 - 1
3H7	CAB HEATER (20,000 BTU).....	1830 - 10	2I7	CATALYTIC MUFFLER KIT.....	0530 - 6
3G22	CAB HEATER DUCTS.....	1830 - 2	2F12	CENTER HOUSING,TURBOCHARGER(VSN -910055)	
3G24	CAB HEATER DUCTS.....	1830 - 4		310G(TURBO), 310SG, 315SG.....	0416 - 2
3H7	CAB HEATER MOTOR (20,000 BTU).....	1830 - 10	3E16	CENTER KICK PANEL, REAR.....	1812 - 2
3C9	CAB MAIN WIRE HARNESS.....	1674 - 2	2K18	CENTRAL LUBRICATION SYSTEM, FRONT AXLE.....	1370 - 2
3C11	CAB MAIN WIRE HARNESS.....	1674 - 4	1E22	CHARGE PUMP.....	0360 - 5
3E12	CAB MOUNTING ISOLATORS.....	1811 - 4	1E22	CHARGE PUMP OIL FILTER.....	0360 - 5
3F1	CAB REAR WINDOWS		1E22	CHARGE PUMP, AXIAL BEARING.....	0360 - 5
	(SER.NO. -920856).....	1814 - 8	3C9	CIRCUIT BREAKERS.....	1674 - 2
3F3	CAB REAR WINDOWS		5E19	CLAMP, BACKHOE OIL LINES.....	3344 - 2
	(SER.NO. 920857-).....	1814 - 9A	3J1	CLAMP,GATHERING.....	2160 - 6
3E14	CAB ROOF.....	1811 - 6	3J3	CLAMP,GATHERING.....	2160 - 8
3E20	CAB SIDE WINDOW LATCH.....	1814 - 2	3J5	CLAMP,GATHERING.....	2160 - 9A
3E22	CAB SIDE WINDOW LATCH.....	1814 - 4	1E5	CLUTCH ASSEMBLY, FIRST GEAR, POWER SHIFT ..	0350 - 14
3E20	CAB SIDE WINDOWS.....	1814 - 2	1D19	CLUTCH ASSEMBLY, FORWARD.....	0350 - 2
3E22	CAB SIDE WINDOWS.....	1814 - 4	1D19	CLUTCH ASSEMBLY, PISTON.....	0350 - 2
3I3	CAB SKIRT.....	1927 - 2	1D21	CLUTCH ASSEMBLY, PISTON.....	0350 - 4
3E24	CAB WINDSHIELD.....	1814 - 6	1D21	CLUTCH ASSEMBLY, REVERSE.....	0350 - 4
2H19	CABLE, ENGINE SPEED CONTROL.....	0515 - 2	1E13	CLUTCH ASSEMBLY,FORWARD, POWER SHIFT.....	0350 - 22
2H21	CABLE, ENGINE SPEED CONTROL.....	0515 - 4	1E11	CLUTCH ASSEMBLY,FOURTH GEAR, POWER SHIFT.....	0350 - 20
3H1	CABLE, HEATER VALVE CONTROL.....	1830 - 6	1E15	CLUTCH ASSEMBLY,REVERSE, POWER SHIFT.....	0350 - 24
3I6	CABLE, RADIO.....	2001 - 2	1E7	CLUTCH ASSEMBLY,SECOND GEAR, POWER SHIFT.....	0350 - 16
4C19	CABLE, RETURN-TO-DIG.....	3115 - 2	1E9	CLUTCH ASSEMBLY,THIRD GEAR, POWER SHIFT	0350 - 18
4C19	CABLE, SELF-LEVELING.....	3115 - 2	1E9	CLUTCH BACKING PLATE, POWER SHIFT.....	0350 - 18
3B19	CABLE, SINGLE BATTERY.....	1671 - 2	1E11	CLUTCH BACKING PLATE, POWER SHIFT.....	0350 - 20
3H5	CABLE,HEATER VALVE CONTROL,CANOPY.....	1830 - 8	1E13	CLUTCH BACKING PLATE, POWER SHIFT.....	0350 - 22
5E9	CABLES, STABILIZER CONTROL.....	3315 - 24	1E15	CLUTCH BACKING PLATE, POWER SHIFT.....	0350 - 24
3B21	CABLES,DUAL BATTERY.....	1671 - 4	1E5	CLUTCH CARRIER, FIRST GEAR, POWER SHIFT.....	0350 - 14
3C23	CAM/CRANKSHAFT SWITCH (FRONT WIRE		1E13	CLUTCH CARRIER, FORWARD, POWER SHIFT.....	0350 - 22
	HARNESS) (SN 910056-).....	1674 - 9C	1E11	CLUTCH CARRIER, FOURTH GEAR, POWER SHIFT ..	0350 - 20
2C17	CAMSHAFT GEAR 310G (W/O TURBO)		1E15	CLUTCH CARRIER, REVERSE, POWER SHIFT.....	0350 - 24
	(VSN -911768)PE4045DT056.....	0402 - 1	1E7	CLUTCH CARRIER, SECOND GEAR, POWER SHIFT ..	0350 - 16
2C17	CAMSHAFT GEAR 310G (W/O TURBO)		1E9	CLUTCH CARRIER, THIRD GEAR, POWER SHIFT.....	0350 - 18
	(VSN 893079-907963)T04045DT056.....	0402 - 1	2J18	CLUTCH DISK, PARK BRAKE	
2C17	CAMSHAFT GEAR 310G (W/O TURBO)			(AXLE SERIAL NO. -217496).....	1111 - 2
	(VSN 911769-)T04045DT058.....	0402 - 1	2J20	CLUTCH DISK, PARK BRAKE	
2C18	CAMSHAFT GEAR 310G(TURBO), 310SG, 315SG			(AXLE SERIAL NO. 217497-).....	1111 - 4
	(VSN -910055).....	0402 - 1A	1D19	CLUTCH HUB.....	0350 - 2
2C18	CAMSHAFT GEAR 310G(TURBO), 310SG, 315SG		1D21	CLUTCH HUB.....	0350 - 4
	(VSN 893079-907963).....	0402 - 1A	1E21	COIL,CONTROL VALVE SOLENOID,	
2C19	CAMSHAFT GEAR 310G(TURBO), 310SG, 315SG			SYNCHRO-SHUTTLE.....	0360 - 4
	(VSN 910056-).....	0402 - 1B	2H13	COLD WEATHER STARTING AID.....	0505 - 4
2C17	CAMSHAFT 310G (W/O TURBO)		2H15	COLD WEATHER STARTING AID.....	0505 - 6
	(VSN -911768)PE4045DT056.....	0402 - 1	2H13	COLD WEATHER STARTING AID SOLENOID.....	0505 - 4
2C17	CAMSHAFT 310G (W/O TURBO)		2H15	COLD WEATHER STARTING AID SOLENOID.....	0505 - 6
	(VSN 893079-907963)T04045DT056.....	0402 - 1	2I15	COLUMN, STEERING.....	0960 - 2
2C17	CAMSHAFT 310G (W/O TURBO)		2I17	COLUMN, STEERING.....	0960 - 4
	(VSN 911769-)T04045DT058.....	0402 - 1	2I17	COLUMN, TILT STEERING.....	0960 - 4
2C18	CAMSHAFT 310G(TURBO), 310SG, 315SG (VSN		3C19	COMPRESSOR DIODE, A/C.....	1674 - 8
	-910055).....	0402 - 1A	3C21	COMPRESSOR DIODE, A/C.....	1674 - 9A
2C18	CAMSHAFT 310G(TURBO), 310SG, 315SG (VSN		3H8	COMPRESSOR MOUNTING BRACKETS,	
	893079-907963).....	0402 - 1A		AIR CONDITIONING.....	1830 - 12
2C19	CAMSHAFT 310G(TURBO), 310SG, 315SG (VSN		3H10	COMPRESSOR MOUNTING BRACKETS,	
	910056-).....	0402 - 1B		AIR CONDITIONING.....	1830 - 14
3C21	CAN TERMINATION RESISTOR.....	1674 - 9A	3H8	COMPRESSOR,AIR CONDITIONING.....	1830 - 12
3C11	CAN TERMINATION RESISTORS.....	1674 - 4	3H10	COMPRESSOR,AIR CONDITIONING.....	1830 - 14
3E10	CANOPY.....	1811 - 2	3G18	COMPRESSOR,AIR SUSPENSION SEAT.....	1821 - 16

1A12

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
3H8	CONDENSER,AIR CONDITIONING	1830 - 12	5I23	CONTROLLED LOWERING DEVICE,CROWD CYL.KIT	3363 - 36
3H10	CONDENSER,AIR CONDITIONING	1830 - 14	3G1	CONTROLLER ARM, PILOT	
2D6	CONNECTING ROD			(LEFT SIDE).....	1816 - 14
	310G (W/O TURBO) (VSN 911769-)	0403 - 2A	3G3	CONTROLLER ARM, PILOT	
2D8	CONNECTING ROD			(RIGHT SIDE)	1816 - 16
	310G(TURBO) 310SG 315SG (VSN 910056-).....	0403 - 3A	5G17	CONTROLLER, LEFT HAND VALVE	3362 - 34
2D7	CONNECTING ROD		5G19	CONTROLLER, RIGHT HAND VALVE	3362 - 36
	310G(TURBO), 310SG, 315SG (VSN-910055)	0403 - 2B	2F3	CONTROLLER,ENGINE	
2D6	CONNECTING ROD BEARINGS			310G(TURBO),310SG,315SG (VSN 910056-)	0413 - 10
	310G (W/O TURBO) (VSN 911769-)	0403 - 2A	2E23	CONTROLLER,ENGINE	
2D8	CONNECTING ROD BEARINGS			310G(W/O TURBO)(VSN 911769-)	0413 - 6
	310G(TURBO) 310SG 315SG (VSN 910056-).....	0403 - 3A	5D15	CONTROLS, FOUR-LEVER STANDARD BACKHOE	
2D7	CONNECTING ROD BEARINGS			(310G,310SG)	3315 - 10
	310G(TURBO), 310SG, 315SG (VSN-910055)	0403 - 2B	5E11	CONVERSION, BACKHOE CONTROL LEVER	
2D5	CONNECTING ROD BEARINGS 310G (W/O TURBO)			LINKAGE (SAE PATTERN).....	3315 - 26
	(VSN -911768).....	0403 - 2	1D18	CONVERTER, TORQUE	0350 - 1
2D5	CONNECTING ROD 310G (W/O TURBO)		2H17	COOLANT RECOVERY TANK	0510 - 2
	(VSN -911768).....	0403 - 2	2H11	COOLANT, ENGINE HEATER	0505 - 2
2F5	CONNECTOR, SOLENOID, STANADYNE DE10		3J7	COOLER LINES	2160 - 10
	310G (W/O TURBO) (VSN 911769-)	0413 - 12	2I13	COOLER, FUEL	0560 - 4
2F6	CONNECTOR, SOLENOID, STANADYNE DE10		3J19	COOLER, HYD. OIL KIT AND HOSES (310G)	2160 - 22
	310G(TURBO),310SG/315SG (VSN 910056-)	0413 - 13	3J15	COOLER, TRANSMISSION, HYD. OIL.....	2160 - 18
3D10	CONNECTORS, WEATHERPACK	1674 - 20	3J17	COOLER,HYD. OIL AND HOSES (HI-AMBIENT)	2160 - 20
3C9	CONSOLE WIRING HARNESS,FRONT		3J15	COOLER,HYDRAULIC OIL AND HOSES.....	2160 - 18
	WITH CAB	1674 - 2	3J13	COOLER,HYDRAULIC OIL AND HOSES (310G)	2160 - 16
3C11	CONSOLE WIRING HARNESS,SIDE		3E10	CORD, MANUAL HOLDER ATTACHMENT	1811 - 2
	WITH CAB	1674 - 4	2I13	CORE, FUEL COOLER	0560 - 4
3F15	CONSOLE, BACKHOE		3H7	CORE, HEATER (20,000 BTU)	1830 - 10
	(PILOT CONTROL)	1816 - 5A	3F1	CORNER WINDOWPANE, REAR	
3F13	CONSOLE, BACKHOE CONTROL LEVER	1816 - 4		(SER.NO. -920856)	1814 - 8
3F19	CONSOLE, FRONT	1816 - 8	3F3	CORNER WINDOWPANE, REAR	
5I21	CONTROLLED LOWERING DEVICE, BOOM CYL.KIT	3363 - 34		(SER.NO. 920857-)	1814 - 9A
3H1	CONTROL CABLE, HEATER VALVE	1830 - 6	3E4	COUNTERWEIGHT FRAME	1749 - 3
3H5	CONTROL CABLE, HEATER VALVE	1830 - 8	3E3	COUNTERWEIGHT, FRONT	1749 - 2
3F11	CONTROL COVER, BACKHOE, TWO LEVER	1816 - 2	4C13	COUPLER FRAME, FORKLIFT.....	3103 - 2
5G21	CONTROL HANDLE, PILOT,BUTTON FUNTION KIT	3362 - 38	4C7	COUPLER LOADER BUCKET	
3F13	CONTROL LEVER CONSOLE, BACKHOE	1816 - 4		.76 CUBIC METER (1.00 CUBIC YARD)	3102 - 14
1D9	CONTROL LEVER, TRANSMISSION	0315 - 4	4C9	COUPLER LOADER BUCKET	
5E3	CONTROL LEVER,BACKHOE BOOM LOCK			.86 CUBIC METER (1.13 CUBIC YARD)	3102 - 16
	(310G AND 310SG).....	3315 - 18	4C7	COUPLER LOADER BUCKET	
5E7	CONTROL LEVER,BACKHOE BOOM LOCK			.96 CUBIC METER (1.25 CUBIC YARD)	3102 - 14
	(315SG)	3315 - 22	4C9	COUPLER LOADER BUCKET	
5E7	CONTROL LEVER,BACKHOE SWING LOCK			1.00 CUBIC METER (1.31 CUBIC YARD)	3102 - 16
	(315SG)	3315 - 22	4C11	COUPLER MULTI-PURPOSE BUCKET	3102 - 18
5E9	CONTROL VALVE LINKAGE, STABILIZER	3315 - 24	4C17	COUPLER, CYLINDER, FRONT	3104 - 4
5D13	CONTROL VALVE LINKAGE, THREE LEVER,		4E23	COUPLER, FRONT	3163 - 10
	BACKHOE (310G AND 310SG)	3315 - 8	4F1	COUPLER, HYDRAULIC HOSES	3163 - 12
5D11	CONTROL VALVE LINKAGE,BACKHOE, TWO LEVER		4F1	COUPLER, HYDRAULIC LINES	3163 - 12
	(310G AND 310GS).....	3315 - 6	4C15	COUPLER, HYDRAULIC, FRONT.....	3104 - 2
1E19	CONTROL VALVE PISTON.....	0360 - 2	4E23	COUPLER, LOADER BUCKET	3163 - 10
1E23	CONTROL VALVE PISTON, POWER SHIFT.....	0360 - 6	4E13	COUPLER, LOADER BUCKET VALVE	3162 - 28
1E21	CONTROL VALVE SOLENOID COIL,		5C17	COUPLER, QUICK (STANDARD)	
	SYNCHRO-SHUTTLE	0360 - 4		(310G)	3302 - 8
1E21	CONTROL VALVE SOLENOID KIT,		5C15	COUPLER, QUICK (STANDARD)	
	SYNCHRO-SHUTTLE	0360 - 4		(310SG AND 315SG)	3302 - 6
1E21	CONTROL VALVE SOLENOID,		3J1	COUPLER, QUICK CONNECT	2160 - 6
	SYNCHRO-SHUTTLE	0360 - 4	3J3	COUPLER, QUICK CONNECT	2160 - 8
5F10	CONTROL VALVE, BACKHOE	3362 - 4	5C19	COUPLER, QUICK COUPLER	
5F12	CONTROL VALVE, BACKHOE	3362 - 6		(CASE)	3302 - 10
4D13	CONTROL VALVE, LOADER/STABILIZER.....	3162 - 4	5C21	COUPLER, QUICK COUPLER	
5G17	CONTROL VALVE, PILOT, LEFT	3362 - 34		(FORD)	3302 - 12
5G19	CONTROL VALVE, PILOT, RIGHT	3362 - 36	5C13	COUPLER, QUICK COUPLER (UNIVERSAL)	
1E19	CONTROL VALVE, TRANSMISSION	0360 - 2		(310G)	3302 - 4
1E23	CONTROL VALVE, TRANSMISSION, POWER SHIFT ..	0360 - 6	5C11	COUPLER, QUICK COUPLER (UNIVERSAL)	
3J21	CONTROL, RIDE	2160 - 24		(310SG AND 315SG)	3302 - 2
3J23	CONTROL, RIDE	2160 - 26	5J3	COUPLERS,AUGER	
3H5	CONTROL,TEMPERATURE HEATER	1830 - 8		(STANDARD DIPPERSTICK)	3363 - 40

1A13

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
5J1	COUPLERS,AUGER (WITH EXTENDIBLE DIPPERSTICK).....	2C15	CRANKSHAFT GEAR 310G(TURBO),310SG,315SG (VSN 910056-)
	3363 - 38		0401 - 6
2C22	COVER, ACCESS, INJECTION PUMP GEAR (VSN -911768) 310G (W/O TURBO)	2H2	CRANKSHAFT REAR OIL SEAL (VSN -910055).....
	0402 - 4	2H3	CRANKSHAFT REAR OIL SEAL (VSN 910056-).....
2D1	COVER, ACCESS, INJECTION PUMP GEAR (VSN-910055) 310G(TURBO), 310SG, 315SG	2D3	CRANKSHAFT SPEED SENSOR (VSN 910056-) 310G(TURBO), 310SG, 315SG
	0402 - 6		0402 - 6B
2C24	COVER, ACCESS, INJECTION PUMP GEAR 310G (W/O TURBO) (VSN 911769-)	2C24	CRANKSHAFT SPEED SENSOR 310G (W/O TURBO) (VSN 911769-)
	0402 - 4B		0402 - 4B
2D3	COVER, ACCESS, INJECTION PUMP GEAR 310G(TURBO), 310SG, 315SG (VSN910056-)	2C12	CRANKSHAFT TIMING WHEEL 310G (W/O TURBO) (VSN 911769-)
	0402 - 6B		0401 - 2
3F11	COVER, BACKHOE CONTROLS	2C11	CRANKSHAFT TIMING WHEEL 310G (W/O TURBO) (VSN-911768)
	1816 - 2		0401 - 1
3F13	COVER, BACKHOE LEVER	2C14	CRANKSHAFT TIMING WHEEL 310G(TURBO),310SG,315SG (VSN -910055)
	1816 - 4		0401 - 4
3F11	COVER, BACKHOE LEVERS	2C15	CRANKSHAFT TIMING WHEEL 310G(TURBO),310SG,315SG (VSN 910056-)
	1816 - 2		0401 - 6
3H19	COVER, BATTERY	3C23	CRANKSHAFT/CAM SWITCH (FRONT WIRE HARNESSES) (SN 910056-)
	1913 - 2		1674 - 9C
3F21	COVER, BOOM LEVER LOCK	5I23	CROWD CYL.KIT,CONTROLLED LOWERING DEVICE
	1816 - 10		3363 - 36
3F23	COVER, BOOM LEVER LOCK	5I23	CROWD CYL.KIT,LOWERING DEVICE,CONTROLLED
	1816 - 12		3363 - 36
3E16	COVER, FLOOR TO FRONT CONSOLE	5K1	CROWD CYLINDER
	1812 - 2		3365 - 17
3F19	COVER, FUSE PANEL	5K2	CROWD CYLINDER 310SG,315SG
	1816 - 8		3365 - 18
3C19	COVER, JUMP START PROTECTION.....	5H23	CROWD CYLINDER HYDRAULIC HOSE.....
	1674 - 8		3363 - 12
3C21	COVER, JUMP START PROTECTION.....	5H23	CROWD CYLINDER HYDRAULIC OIL LINES
	1674 - 9A		3363 - 12
3E16	COVER, LINKAGE	5K1	CROWD CYLINDER REPAIR KIT.....
	1812 - 2		3365 - 17
3F23	COVER, LOADER CONTROL	5K2	CROWD CYLINDER REPAIR KIT 310SG,315SG
	1816 - 12		3365 - 18
3H21	COVER, LOADER CONTROL VALVE PLUMBING	5F1	CROWD PIN.....
	1913 - 4		3346 - 2
3E16	COVER, MIDDLE FLOOR	5F20	CROWD SECTION RELIEF VALVE
	1812 - 2		3362 - 14
2D16	COVER, OIL FILLER OPENING	5F20	CROWD SECTION, BACKHOE VALVE
	0407 - 2		3362 - 14
3I3	COVER, OPERATOR STATION	5F1	CROWD SPACER, SYNTHETIC.....
	1927 - 2		3346 - 2
3E16	COVER, REAR FLOOR.....	5H3	CROWD, PILOT SECTION RELIEF VALVE.....
	1812 - 2		3362 - 44
2C21	COVER, ROCKER ARM	5H3	CROWD, PILOT SECTION, BACKHOE VALVE.....
	0402 - 3		3362 - 44
3G5	COVER, SEAT BELT	3G5	CUSHIONS, SEAT
	1821 - 2		1821 - 2
1D7	COVER, SHIFT HOUSING	4C9	CUTTING EDGE ,COUPLER, LOADER BUCKET .86 CUBIC METER (1.13 CUBIC YARD)
	0315 - 2		3102 - 16
3F21	COVER, STABILIZER CONTROL	4C9	CUTTING EDGE ,COUPLER, LOADER BUCKET 1.00 CUBIC METER (1.31 CUBIC YARD).....
	1816 - 10		3102 - 16
3F23	COVER, STABILIZER CONTROL	5D1	CUTTING EDGE,BACKHOE BUCKET
	1816 - 12		3302 - 14
3F17	COVER, STEERING COLUMN	5D3	CUTTING EDGE,BACKHOE BUCKET
	1816 - 6		3302 - 16
2F23	COVER, THERMOSTAT	4B20	CUTTING EDGE,LOADER BUCKET.....
	0418 - 2		3102 - 2
2C22	COVER, TIMING GEAR (VSN -911768) 310G (W/O TURBO)	4B22	CUTTING EDGE,LOADER BUCKET.....
	0402 - 4		3102 - 4
2D1	COVER, TIMING GEAR (VSN -910055) 310G(TURBO), 310SG, 315SG	4C7	CUTTING EDGE,LOADER BUCKET .76 CUBIC METER (1.00 CUBIC YARD)
	0402 - 6		3102 - 14
2D3	COVER, TIMING GEAR (VSN 910056-) 310G(TURBO), 310SG, 315SG (VSN910056-)	4C7	CUTTING EDGE,LOADER BUCKET .96 CUBIC METER (1.25 CUBIC YARD)
	0402 - 6B		3102 - 14
2C24	COVER, TIMING GEAR 310G (W/O TURBO) (VSN 911769-)	4C1	CUTTING EDGE,MULTI-PURPOSE BUCKET
	0402 - 4B		3102 - 8
1C14	COVER, WHEEL HUB (WITHOUT MFWD) (SERIAL NO. 911132-)	2D10	CYLINDER BLOCK 310G(TURBO), 310SG, 315SG (VSN-910055)
	0230 - 8		0404 - 2
3B25	COVER,REMOTE START POST	2E12	CYLINDER HEAD
	1671 - 8		0409 - 2
2C12	CRANKSHAFT 310G (W/O TURBO) (VSN 911769-)	2E12	CYLINDER HEAD GASKET
	0401 - 2		0409 - 2
2C11	CRANKSHAFT 310G (W/O TURBO) (VSN-911768)	2H6	CYLINDER HEAD REMOVAL GASKET SET 310G(TURBO), 310SG, 315SG
	0401 - 1		0452 - 1
2C14	CRANKSHAFT 310G(TURBO),310SG,315SG (VSN -910055)	5I3	CYLINDER HYDRAULICS,BACKHOE SWING (315SG)
	0401 - 4		3363 - 16
2C15	CRANKSHAFT 310G(TURBO),310SG,315SG (VSN 910056-)	2D6	CYLINDER LINER 310G (W/O TURBO) (VSN 911769-)
	0401 - 6		0403 - 2A
2C22	CRANKSHAFT FRONT OIL SEAL (VSN -911768) 310G (W/O TURBO)	2D8	CYLINDER LINER 310G(TURBO) 310SG 315SG (VSN 910056-).....
	0402 - 4		0403 - 3A
2D1	CRANKSHAFT FRONT OIL SEAL (VSN-910055) 310G(TURBO), 310SG, 315SG	2D7	CYLINDER LINER 310G(TURBO), 310SG, 315SG (VSN-910055)
	0402 - 6		0403 - 2B
2C24	CRANKSHAFT FRONT OIL SEAL 310G (W/O TURBO) (VSN 911769-)	2D5	CYLINDER LINER O-RING KIT 310G (W/O TURBO) (VSN -911768)
	0402 - 4B		0403 - 2
2D3	CRANKSHAFT FRONT OIL SEAL 310G(TURBO), 310SG, 315SG (VSN910056-)	2D6	CYLINDER LINER O-RING KIT 310G (W/O TURBO) (VSN 911769-)
	0402 - 6B		0403 - 2A
2C12	CRANKSHAFT GEAR 310G (W/O TURBO) (VSN 911769-)		
	0401 - 2		
2C11	CRANKSHAFT GEAR 310G (W/O TURBO) (VSN-911768)		
	0401 - 1		
2C14	CRANKSHAFT GEAR 310G(TURBO),310SG,315SG (VSN -910055)		
	0401 - 4		

1A14

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
2D8		5J23	
CYLINDER LINER O-RING KIT		CYLINDER, BACKHOE BUCKET	
310G(TURBO) 310SG 315SG (VSN 910056-).....	0403 - 3A	(310SG,315SG) SERIAL NO. 926130-)	3365 - 14
2D7		5J25	
CYLINDER LINER O-RING KIT		CYLINDER, BACKHOE BUCKET	
310G(TURBO), 310SG, 315SG (VSN-910055)	0403 - 2B	(310SG,315SG) SERIAL NO. 926789-)	3365 - 16
2D5		5J22	
CYLINDER LINER 310G (W/O TURBO)		CYLINDER, BACKHOE BUCKET	
(VSN -911768).....	0403 - 2	310SG,315SG (SERIAL NO. -926129).....	3365 - 13
5J11		5H19	
CYLINDER REPAIR KIT, BACKHOE BOOM		CYLINDER, BACKHOE BUCKET HYDRAULICS.....	3363 - 8
(310G)	3365 - 2	5H11	
5J13		CYLINDER, BACKHOE STABILIZER HYDRAULICS.....	3363 - 2
CYLINDER REPAIR KIT, BACKHOE BOOM		5H13	
(310G)	3365 - 4	CYLINDER, BACKHOE STABILIZER HYDRAULICS.....	3363 - 3A
5J15		5H15	
CYLINDER REPAIR KIT, BACKHOE BOOM		CYLINDER, BACKHOE STABILIZER HYDRAULICS	
(310SG,315SG)	3365 - 6	SIDESHIFT 315SE	3363 - 4
5J17		4F8	
CYLINDER REPAIR KIT, BACKHOE BOOM		CYLINDER, BOOM	
(310SG,315SG)	3365 - 8	(310SG AND 315SG)(SER.# 910492-926248).....	3165 - 8
5J19		5K1	
CYLINDER REPAIR KIT, BACKHOE BUCKET		CYLINDER, CROWD	3365 - 17
(310G)	3365 - 10	5K2	
5J20		CYLINDER, CROWD	
CYLINDER REPAIR KIT, BACKHOE BUCKET		310SG,315SG	3365 - 18
(310G)(SER.# 910901-925926).....	3365 - 11	5K19	
5J21		CYLINDER, EXTENDIBLE ARM	
CYLINDER REPAIR KIT, BACKHOE BUCKET		(310G)	3365 - 30
(310G)(SER.# 925927-)	3365 - 12	5K20	
5J24		CYLINDER, EXTENDIBLE ARM	
CYLINDER REPAIR KIT, BACKHOE BUCKET		(310G) (SERIAL NO. 928457-953470)	3365 - 31
(310SG,315SG) SERIAL NO. -926788)	3365 - 15	5K21	
5J23		CYLINDER, EXTENDIBLE ARM	
CYLINDER REPAIR KIT, BACKHOE BUCKET		(310G) (SERIAL NO. 953471-)	3365 - 32
(310SG,315SG) SERIAL NO. 926130-)	3365 - 14	5K23	
5J25		CYLINDER, EXTENDIBLE ARM	
CYLINDER REPAIR KIT, BACKHOE BUCKET		(310SG,315SG)	3365 - 34
(310SG,315SG) SERIAL NO. 926789-)	3365 - 16	5K24	
5J22		CYLINDER, EXTENDIBLE ARM	
CYLINDER REPAIR KIT, BACKHOE BUCKET		(310SG,315SG)	3365 - 35
310SG,315SG (SERIAL NO. -926129).....	3365 - 13	5K25	
5K6		CYLINDER, EXTENDIBLE ARM	
CYLINDER REPAIR KIT, STABILIZER		(310SG,315SG)	3365 - 36
310G (SERIAL NO. -925946)	3365 - 21	5F3	
5K16		CYLINDER, EXTENDIBLE DIPPERSTICK	3346 - 4
CYLINDER REPAIR KIT, STABILIZER (315SG)	3365 - 27	5K19	
5K17		CYLINDER, EXTENDIBLE DIPPERSTICK	
CYLINDER REPAIR KIT, STABILIZER (315SG)		(310G)	3365 - 30
(SERIAL NO. 944156-)	3365 - 28	5K20	
5K9		CYLINDER, EXTENDIBLE DIPPERSTICK	
CYLINDER REPAIR KITS, STABILIZER		(310G) (SERIAL NO. 928457-953470)	3365 - 31
310G (SERIAL NO. XXXXXX-).....	3365 - 22A	5K21	
5K8		CYLINDER, EXTENDIBLE DIPPERSTICK	
CYLINDER REPAIR KITS, STABILIZER		(310G) (SERIAL NO. 953471-)	3365 - 32
310G (SERIAL NO. 925947-XXXXXX)	3365 - 22	5K23	
5K10		CYLINDER, EXTENDIBLE DIPPERSTICK	
CYLINDER REPAIR KITS, STABILIZER		(310SG,315SG)	3365 - 34
310SG (SER.NO.-926206)	3365 - 23	5K24	
5K12		CYLINDER, EXTENDIBLE DIPPERSTICK	
CYLINDER REPAIR KITS, STABILIZER		(310SG,315SG)	3365 - 35
310SG (SER.NO.XXXXXX-)	3365 - 24A	5K25	
5K11		CYLINDER, EXTENDIBLE DIPPERSTICK	
CYLINDER REPAIR KITS, STABILIZER		(310SG,315SG)	3365 - 36
310SG (SER.NO.926207-XXXXXX)	3365 - 24	4C17	
5K13		CYLINDER, FRONT COUPLER	3104 - 4
CYLINDER REPAIR KITS, STABLIZER		4C15	
310SG (SERIAL NO. -925993)	3365 - 25	CYLINDER, HYDRAULIC FRONT COUPLER	3104 - 2
5K15		4F3	
CYLINDER REPAIR KITS, STABILIZER		CYLINDER, LOADER BOOM LIFT	
310SG (SERIAL NO. XXXXXX-).....	3365 - 26A	(310G)(SER.# -926493).....	3165 - 2
5K14		4F5	
CYLINDER REPAIR KITS, STABLIZER		CYLINDER, LOADER BOOM LIFT	
310SG (SERIAL NO. 925994-XXXXXX).....	3365 - 26	(310G)(SER.# 926494-)	3165 - 4
2J23		4F9	
CYLINDER ROD LOCK BAR	1313 - 2	CYLINDER, LOADER BOOM LIFT	
5J11		(310SG AND 315SG)(SER.# 926249-)	3165 - 9
CYLINDER, BACKHOE BOOM		4F6	
(310G)	3365 - 2	CYLINDER, LOADER BOOM LIFT	
5J13		(310SG AND 315SG)(SERIAL NO. -910491).....	3165 - 6
CYLINDER, BACKHOE BOOM		4F3	
(310G)	3365 - 4	CYLINDER, LOADER BOOM LIFT PINS	
5J15		(310G)(SER.# -926493).....	3165 - 2
CYLINDER, BACKHOE BOOM		5I15	
(310SG,315SG)	3365 - 6	CYLINDER, LOCK SIDE SHIFT 315SG	3363 - 28
5J17		4C3	
CYLINDER, BACKHOE BOOM		CYLINDER, MULTI-PURPOSE BUCKET	3102 - 10
(310SG,315SG)	3365 - 8	4C5	
5J19		CYLINDER, MULTI-PURPOSE BUCKET	
CYLINDER, BACKHOE BUCKET		(SERIAL NO. -925076)	3102 - 12
(310G)	3365 - 10	4C6	
5J20		CYLINDER, MULTI-PURPOSE BUCKET	
CYLINDER, BACKHOE BUCKET		(SERIAL NO. 925077-)	3102 - 13
(310G)(SER.# 910901-925926).....	3365 - 11	2J1	
5J21		CYLINDER, POWER STEERING (WITHOUT MFWD)	
CYLINDER, BACKHOE BUCKET		(SERIAL NO. -911131)	0960 - 14
(310G)(SER.# 925927-)	3365 - 12	2J2	
5J24		CYLINDER, POWER STEERING (WITHOUT MFWD)	
CYLINDER, BACKHOE BUCKET		(SERIAL NO. -911131)	0960 - 16
(310SG,315SG) SERIAL NO. -926788)	3365 - 15	5K6	
		CYLINDER, STABILIZER	
		310G (SERIAL NO. -925946)	3365 - 21
		5K12	
		CYLINDER, STABILIZER	
		310SG (SER.NO.XXXXXX-)	3365 - 24A

1A15

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
5K11	CYLINDER, STABILIZER 310SG (SER.NO.926207-XXXXXX)	3365 - 24	5F1	DIPPERSTICK	3346 - 2
5K16	CYLINDER, STABILIZER (315SG)	3365 - 27	5F3	DIPPERSTICK EXTENDIBLE	3346 - 4
5K17	CYLINDER, STABILIZER (315SG) (SERIAL NO. 944156-)	3365 - 28	5F1	DIPPERSTICK PIN.....	3346 - 2
5K13	CYLINDER, STABILIZER, EXTENDED 310SG (SERIAL NO. -925993)	3365 - 25	5K19	DIPPERSTICK, CYLINDER EXTENDIBLE (310G)	3365 - 30
5K15	CYLINDER, STABILIZER, EXTENDED 310SG (SERIAL NO. XXXXXX-).....	3365 - 26A	5K20	DIPPERSTICK, CYLINDER EXTENDIBLE (310G) (SERIAL NO. 928457-953470).....	3365 - 31
5K14	CYLINDER, STABILIZER, EXTENDED 310SG (SERIAL NO. 925994-XXXXXX).....	3365 - 26	5K21	DIPPERSTICK, CYLINDER EXTENDIBLE (310G) (SERIAL NO. 953471-)	3365 - 32
5K10	CYLINDER, STABILIZER, STANDARD 310SG (SER.NO.-926206)	3365 - 23	5K23	DIPPERSTICK, CYLINDER EXTENDIBLE (310SG,315SG)	3365 - 34
2I24	CYLINDER, STEERING, MECHANICAL FRONT WHEEL DRIVE (MFWD)	0960 - 12	5K24	DIPPERSTICK, CYLINDER EXTENDIBLE (310SG,315SG)	3365 - 35
5K3	CYLINDER, SWING	3365 - 19	5K25	DIPPERSTICK, CYLINDER EXTENDIBLE (310SG,315SG)	3365 - 36
5K4	CYLINDER, SWING	3365 - 19A	5F5	DIPPERSTICK,EXT. ARM GRIP REPAIR.....	3346 - 6
5K5	CYLINDER, SWING 310SG,315SG	3365 - 20	5F5	DIPPERSTICK,EXT.PROTECTION KIT	3346 - 6
5E13	CYLINDER, SWING TRUNNION BLOCK, 315SG	3342 - 2	2D17	DIPSTICK TUBE, ENGINE OIL	0407 - 4
3E20	CYLINDER,CAB DOOR	1814 - 2	1D17	DIPSTICK TUBE, TRANSMISSION.....	0341 - 4
3E22	CYLINDER,CAB DOOR	1814 - 4	2D17	DIPSTICK, ENGINE OIL	0407 - 4
5I5	CYLINDER,EXTENSION,EXTENDIBLE DIPPERSTIC K HYDRAULICS	3363 - 18	2D18	DIPSTICK, ENGINE OIL PE4045DT058 (VSN 929330-)	0407 - 5
1C13	CYLINDER,FRONT AXLE STEERING (WITHOUT MFWD)(SERIAL NO. 911132-).....	0230 - 7	3D20	DIPSTICK, GUARD, TRANSMISSION	1746 - 4
4F10	CYLINDER,LOADER BUCKET (SERIAL NO. -941225)	3165 - 10	1D17	DIPSTICK,TRANSMISSION	0341 - 4
4F12	CYLINDER,LOADER BUCKET (SERIAL NO. 941226-)	3165 - 12	3D17	DIPSTICK,SLIDING FRAME (315SG)	1740 - 4
5K9	CYLINDER,STABILIZER 310G (SERIAL NO. XXXXXX-)	3365 - 22A	1E19	DISCONNECT SOLENOID, TRANSMISSION	0360 - 2
5K8	CYLINDER,STABILIZER 310G (SERIAL NO. 925947-XXXXXX)	3365 - 22	2J5	DISK, BRAKE	1011 - 2
3D15	CYLINDER,SWING TRUNNION BLOCK,310G,310SG....	1740 - 2	1D25	DOG GEAR,OUTPUT SHAFT	0350 - 8
D					
2K3	DECALS	1320 - 2	3E12	DOE LIGHT	1811 - 4
2K5	DECALS	1320 - 4	3C11	DOOR FLAP RELAY,A/C.....	1674 - 4
2K7	DECALS	1320 - 6	3E22	DOOR STRAP	1814 - 4
2K9	DECALS	1320 - 8	3E22	DOOR TETHER	1814 - 4
3C5	DELUXE LIGHTS SERIAL NO. -XXXXXX	1673 - 4	3E18	DOOR THRESHOLD	1812 - 4
3C7	DELUXE LIGHTS SERIAL NO. XXXXXX-	1673 - 6	3E20	DOORS, CAB	1814 - 2
3D13	DEUTSCH TERMINALS.....	1674 - 23	3E22	DOORS, CAB.....	1814 - 4
5I21	DEVICE,CONTROLLED LOWERING,BOOM CYL.KIT	3363 - 34	3J11	DP SWITCH KIT	2160 - 14
5I23	DEVICE,CONTROLLED LOWERING,CROWD CYL.KIT	3363 - 36	2K16	DRAIN PACKAGE, ENVIORNMENTAL	1369 - 6
1C2	DIFFERENTIAL ASSEMBLY WITH LOCK	0210 - 2	2H17	DRAIN VALVE,RADIATOR	0510 - 2
1B22	DIFFERENTIAL HOUSING	0201 - 2	1C16	DRIVE SHAFT YOKE (MFWD)	0250 - 2
1B24	DIFFERENTIAL HOUSING	0201 - 4	1C16	DRIVE SHAFT, UNIVERSAL (MFWD)	0250 - 2
1C2	DIFFERENTIAL HOUSING WITH LOCK	0210 - 2	1D13	DRIVE SHAFT,REAR(REVERSER).....	0325 - 2
1C6	DIFFERENTIAL LOCK PLUMBING	0210 - 6	1C21	DRIVE,PLANETARY (MFWD)	0250 - 8
3D3	DIFFERENTIAL LOCK PUSH BUTTON	1674 - 12	1C22	DRIVE,PLANETARY (MFWD)(310G)	0250 - 9
1E21	DIFFERENTIAL LOCK SOLENOID, SYNCHRO-SHUTTLE	0360 - 4	2G16	DRIVE,STARTER MOTOR (310G) (ENG.SER.NO. 866618-908991)	0422 - 2
3D3	DIFFERENTIAL LOCK SWITCH	1674 - 12	2G17	DRIVE,STARTER MOTOR (310SG,315SG)(SERIAL NO. -894292)	0422 - 3
1D1	DIFFERENTIAL SPIRAL BEVEL GEAR (MFWD).....	0250 - 12	2G16	DRIVE,STARTER MOTOR (WITH TURBOCHARGER) (310G) (ENGINE SERIAL NO. -268961)	0422 - 2
1C2	DIFFERENTIAL WITH LOCK.....	0210 - 2	2G16	DRIVE,STARTER MOTOR (WITHOUT TURBO) (310G) (ENGINE SERIAL NO. -257521)	0422 - 2
1C23	DIFFERENTIAL,LIMITED SLIP (MFWD) (310SG,315SG)	0250 - 10	5E21	DRIVER LINK (310G)	3345 - 2
3C19	DIODE, A/C COMPRESSOR.....	1674 - 8	5E23	DRIVER LINK (310SG AND 315SG)	3345 - 4
3C21	DIODE, A/C COMPRESSOR.....	1674 - 9A	3H8	DRYER,RECEIVER, AIR CONDITIONING	1830 - 12
3C19	DIODES	1674 - 8	3H10	DRYER,RECEIVER, AIR CONDITIONING	1830 - 14
3C21	DIODES	1674 - 9A	3B21	DUAL BATTERIES.....	1671 - 4
			3B21	DUAL BATTERY CABLES.....	1671 - 4
			3G22	DUCTS, AIR CONDITIONING	1830 - 2
			3G24	DUCTS, AIR CONDITIONING	1830 - 4
			3G22	DUCTS, CAB HEATER	1830 - 2
			3G24	DUCTS, CAB HEATER	1830 - 4
			E		
			2E23	ECU - ENGINE CONTROLLER 310G(W/O TURBO)(VSN 911769-)	0413 - 6

1A16

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2H17	EDGING, ISOLATOR	0510 - 2	2E3	ENGINE OIL FILTER (VSN 911769-) 310G (W/O TURBO)	0407 - 14
2E10	ELBOW, ENGINE VENTILATING PE4045DT058	0408 - 4	2E1	ENGINE OIL FILTER HEADER (VSN -911768) 310G (W/O TURBO)	0407 - 12
2E15	ELBOW,EXHAUST 310G(TURBO), 310SG, 315SG	0410 - 2	2E4	ENGINE OIL FILTER HEADER (VSN -910055) 310G(TURBO),310SG,315SG	0407 - 16
3C15	ELECTRICAL, FRONT COUPLER HARNESS	1674 - 5C	2E6	ENGINE OIL FILTER HEADER (VSN 910056-) 310G(TURBO),310SG,315SG	0407 - 18
3C13	ELECTRICAL, PILOT ENABLE	1674 - 5A	2E3	ENGINE OIL FILTER HEADER (VSN 911769-) 310G (W/O TURBO)	0407 - 14
2H13	ELECTRONIC ETHER STARTING AID	0505 - 4	2D20	ENGINE OIL PAN 310G (W/O TURBO) (VSN -911768)(VSN 911769-)	0407 - 6
2H23	ELEMENT, AIR CLEANER	0520 - 2	2D20	ENGINE OIL PAN 310G (W/O TURBO) (VSN 893079 - 907963)	0407 - 6
2E1	ELEMENT, ENGINE OIL FILTER (VSN -911768) 310G (W/O TURBO)	0407 - 12	2D22	ENGINE OIL PAN 310G(TURBO),310SG,315SG (VSN 893079-907963)(VSN -910055)	0407 - 8
2E4	ELEMENT, ENGINE OIL FILTER (VSN -910055) 310G(TURBO),310SG,315SG	0407 - 16	2D24	ENGINE OIL PAN 310G(TURBO),310SG,315SG (VSN 910056-)	0407 - 10
2E6	ELEMENT, ENGINE OIL FILTER (VSN 910056-) 310G(TURBO),310SG,315SG	0407 - 18	2C22	ENGINE OIL PRESSURE REGULATING VALVE (VSN -911768) 310G (W/O TURBO)	0402 - 4
2E3	ELEMENT, ENGINE OIL FILTER (VSN 911769-) 310G (W/O TURBO)	0407 - 14	2D1	ENGINE OIL PRESSURE REGULATING VALVE (VSN-910055) 310G(TURBO), 310SG, 315SG	0402 - 6
3J11	ELEMENT, FILTER	2160 - 14	2D10	ENGINE OIL PRESSURE REGULATING VALVE 310G(TURBO), 310SG, 315SG (VSN-910055)	0404 - 2
2G9	ELEMENT, FUEL FILTER 310G (TURBO),310SG, 315SG) (VSN -910055)	0420 - 8	3C19	ENGINE OIL PRESSURE SWITCH	1674 - 8
2G3	ELEMENT, FUEL FILTER 310G (W/O TURBO) (VSN -911768)	0420 - 2	3C21	ENGINE OIL PRESSURE SWITCH	1674 - 9A
2G5	ELEMENT, FUEL FILTER 310G (W/O TURBO) (VSN 911769-)	0420 - 4	2E7	ENGINE OIL PUMP	0407 - 19
2G11	ELEMENT, FUEL FILTER 310G(TURBO), 310SG, 315SG (VSN 910056-)	0420 - 10	2E7	ENGINE OIL PUMP GEAR	0407 - 19
3I18	EMBLEM, SMV	2008 - 2	2E7	ENGINE OIL PUMP HOUSING	0407 - 19
3F9	ENABLE SWITCH, REAR WIPER	1814 - 14	2E7	ENGINE OIL PUMP INTAKE	0407 - 19
2I24	END CAP, STEERING CYLINDER (MFWD)	0960 - 12	2H4	ENGINE OVERHAUL KIT	0450 - 2
2F10	ENGINE BALANCER SHAFT 310G(TURBO), 310SG, 315SG	0415 - 2	2H7	ENGINE OVERHAUL KIT 310G(TURBO), 310SG, 315SG	0452 - 2
2F3	ENGINE CONTROLLER 310G(TURBO),310SG,315SG (VSN 910056-)	0413 - 10	2D6	ENGINE PISTON 310G (W/O TURBO) (VSN 911769-)	0403 - 2A
2E23	ENGINE CONTROLLER 310G(W/O TURBO)(VSN 911769-)	0413 - 6	2D8	ENGINE PISTON 310G(TURBO) 310SG 315SG (VSN 910056-)	0403 - 3A
2E23	ENGINE CONTROLLER UNIT - ECU 310G(W/O TURBO)(VSN 911769-)	0413 - 6	2D7	ENGINE PISTON 310G(TURBO), 310SG, 315SG (VSN-910055)	0403 - 2B
2H11	ENGINE COOLANT HEATER	0505 - 2	2D5	ENGINE PISTON 310G (W/O TURBO) (VSN -911768)	0403 - 2
3C19	ENGINE COOLANT TEMPERATURE SENDER	1674 - 8	2H7	ENGINE REBUILD KIT 310G(TURBO), 310SG, 315SG	0452 - 2
3C21	ENGINE COOLANT TEMPERATURE SENDER	1674 - 9A	2D12	ENGINE SHORT BLOCK (ENG. SER. NO. -221705)	0404 - 4
2F23	ENGINE COOLANT TEMPERATURE SENSOR	0418 - 2	2D14	ENGINE SHORT BLOCK (ENG. SER. NO. 221706-)	0404 - 6
3C23	ENGINE COOLANT TEMPERATURE SWITCH (FRONT WIRE HARNESS) (SN 910056-)	1674 - 9C	2D12	ENGINE SHORT BLOCK (ENG.SER.NO.866618-90 8991)	0404 - 4
2H1	ENGINE FLYWHEEL	0433 - 2	3H15	ENGINE SIDE PANELS	1910 - 2
2D9	ENGINE FRONT PLATE	0404 - 1	3H17	ENGINE SIDE PANELS	1910 - 4
3C23	ENGINE FRONT WIRE HARNESS (SN 910056-)	1674 - 9C	3H15	ENGINE SIDE SHIELDS	1910 - 2
2H7	ENGINE MAJOR OVERHAUL GASKET SET 310G(TURBO), 310SG, 315SG	0452 - 2	3H17	ENGINE SIDE SHIELDS	1910 - 4
2I9	ENGINE MOUNT ISOLATOR	0540 - 2	2H19	ENGINE SPEED CONTROL	0515 - 2
2I9	ENGINE MOUNTING BRACKET	0540 - 2	2H21	ENGINE SPEED CONTROL	0515 - 4
2D10	ENGINE OIL BY-PASS VALVE 310G(TURBO), 310SG, 315SG (VSN-910055)	0404 - 2	2H19	ENGINE SPEED CONTROL CABLE	0515 - 2
2G1	ENGINE OIL COOLER	0419 - 2	2H21	ENGINE SPEED CONTROL CABLE	0515 - 4
2G1	ENGINE OIL COOLER ADAPTER	0419 - 2	2H19	ENGINE SPEED CONTROL LEVER	0515 - 2
2D17	ENGINE OIL DIPSTICK	0407 - 4	2H21	ENGINE SPEED CONTROL LEVER	0515 - 4
2D18	ENGINE OIL DIPSTICK PE4045DT058 (VSN 929330-)	0407 - 5	2H19	ENGINE SPEED CONTROL LINKAGE	0515 - 2
2D17	ENGINE OIL DIPSTICK TUBE	0407 - 4	2H21	ENGINE SPEED CONTROL POTENTIOMETER	0515 - 4
2D18	ENGINE OIL DIPSTICK TUBE PE4045DT058 (VSN 929330-)	0407 - 5	2H21	ENGINE SPEED SENSOR	0515 - 4
2D16	ENGINE OIL FILL INLET CAP	0407 - 2	2I9	ENGINE SUPPORT	0540 - 2
2E1	ENGINE OIL FILTER (VSN -911768) 310G (W/O TURBO)	0407 - 12	2F23	ENGINE THERMOSTAT	0418 - 2
2E4	ENGINE OIL FILTER (VSN -910055) 310G(TURBO),310SG,315SG	0407 - 16	2E8	ENGINE VENTILATING HOSE (DT056, TT080/81/88/89)	0408 - 2
2E6	ENGINE OIL FILTER (VSN 910056-) 310G(TURBO),310SG,315SG	0407 - 18			

1A17

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID	PAGE	GRID	PAGE
2E8	ENGINE VENTILATING SYSTEM (DT056, TT080/81/88/89)	5I5	EXTENSION CYLINDER HYDRAULICS,EXTENDIBLE DIPPERSTICK
	0408 - 2		3363 - 18
2E10	ENGINE VENTILATING SYSTEM PE4045DT058	2I5	EXTENSION, EXHAUST
	0408 - 4	2I3	EXTENSION, EXHAUST (310G)
3C19	ENGINE WIRING HARNESS	3I9	EXTERNAL REAR VIEW MIRROR
	1674 - 8		2002 - 3
3C21	ENGINE WIRING HARNESS		
	1674 - 9A		
2K16	ENVIRONMENTAL DRAIN PACKAGE		
	1369 - 6		
3C17	ETHER SWITCH		
	1674 - 6		
3H1	EVAPORATOR		
	1830 - 6		
3H3	EVAPORATOR		
	1830 - 7A		
3H3	EVAPORATOR TEMPERATURE SWITCH		
	1830 - 7A		
2E15	EXHAUST ADAPTER 310G(TURBO), 310SG, 315SG		
	0410 - 2		
2E15	EXHAUST ELBOW 310G(TURBO), 310SG, 315SG		
	0410 - 2		
2I5	EXHAUST EXTENSION		
	0530 - 4		
2I3	EXHAUST EXTENSION (310G)		
	0530 - 2		
2E14	EXHAUST MANIFOLD		
	0410 - 1		
2E14	EXHAUST MANIFOLD GASKET		
	0410 - 1		
2E12	EXHAUST VALVE		
	0409 - 2		
3H1	EXPANSION VALVE		
	1830 - 6		
3H3	EXPANSION VALVE		
	1830 - 7A		
5I13	EXT. DIPPERSTICK AUXILIARY HYDRAULICS (315SG)		
	3363 - 26		
5F5	EXT.DIPPER ARM GRIP REPAIR KIT		
	3346 - 6		
5F5	EXT.DIPPERSTICK PROTECTION KIT		
	3346 - 6		
3I1	EXTENDED GRILLE HOUSING		
	1921 - 4		
5K19	EXTENDIBLE ARM CYLINDER (310G)		
	3365 - 30		
5K20	EXTENDIBLE ARM CYLINDER (310G) (SERIAL NO. 928457-953470)		
	3365 - 31		
5K21	EXTENDIBLE ARM CYLINDER (310G) (SERIAL NO. 953471-)		
	3365 - 32		
5K23	EXTENDIBLE ARM CYLINDER (310SG,315SG)		
	3365 - 34		
5K24	EXTENDIBLE ARM CYLINDER (310SG,315SG)		
	3365 - 35		
5K25	EXTENDIBLE ARM CYLINDER (310SG,315SG)		
	3365 - 36		
5F3	EXTENDIBLE ARM LOCKING PIN		
	3346 - 4		
5F3	EXTENDIBLE ARM PAD		
	3346 - 4		
5F3	EXTENDIBLE ARM WEARSTRIPS		
	3346 - 4		
5D19	EXTENDIBLE DIPPER PEDAL (PILOT CONTROL)		
	3315 - 13A		
5K19	EXTENDIBLE DIPPERSTICK CYLINDER (310G)		
	3365 - 30		
5K20	EXTENDIBLE DIPPERSTICK CYLINDER (310G) (SERIAL NO. 928457-953470)		
	3365 - 31		
5K21	EXTENDIBLE DIPPERSTICK CYLINDER (310G) (SERIAL NO. 953471-)		
	3365 - 32		
5K23	EXTENDIBLE DIPPERSTICK CYLINDER (310SG,315SG)		
	3365 - 34		
5K24	EXTENDIBLE DIPPERSTICK CYLINDER (310SG,315SG)		
	3365 - 35		
5K25	EXTENDIBLE DIPPERSTICK CYLINDER (310SG,315SG)		
	3365 - 36		
5F3	EXTENDIBLE DIPPERSTICK		
	3346 - 4		
5I11	EXTENDIBLE DIPPERSTICK AUXILIARY HYDRAUL ICS (310G AND 310SG)		
	3363 - 24		
5H21	EXTENDIBLE DIPPERSTICK BUCKET CYLINDER HYDRAULICS		
	3363 - 10		
5I5	EXTENDIBLE DIPPERSTICK EXTENSION CYLINDER R HYDRAULICS		
	3363 - 18		
5I5	EXTENDIBLE DIPPERSTICK HYDRAULICS		
	3363 - 18		
5I5	EXTENDIBLE DIPPERSTICK LINES		
	3363 - 10		
5H21	EXTENDIBLE DIPPERSTICK LINES, BUCKET		
	3362 - 18		
5F24	EXTENDIBLE SECTION, BACKHOE VALVE		
	3362 - 18		
			F
		2H17	FAN DRIVE BELT
			0510 - 2
		2G24	FAN DRIVE BELT TENSIONER 310G(TURBO),310SG,315SG
			0429 - 2
		2G24	FAN DRIVE HOUSING 310G(TURBO),310SG,315SG
			0429 - 2
		2G24	FAN DRIVE HUB 310G(TURBO),310SG,315SG
			0429 - 2
		2G24	FAN DRIVE PULLEY 310G(TURBO),310SG,315SG
			0429 - 2
		2H17	FAN SHROUD
			0510 - 2
		2H17	FAN SHROUD, RADIATOR
			0510 - 2
		3C1	FAN, ALTERNATOR
			1672 - 2
		3H7	FAN, CAB HEATER (20,000 BTU)
			1830 - 10
		3I3	FENDERS
			1927 - 2
		5E1	FIFTH FN LEVER FOR THREE LEVER CONTROLS
			3315 - 16
		5D17	FIFTH FUNCTION FOOT CONTROL
			3315 - 12
		5G5	FIFTH FUNCTION MANUAL VALVE KIT (310G)
			3362 - 24
		5G6	FIFTH FUNCTION MANUAL VALVE KIT (310SG AND 315SG)
			3362 - 25
		5D17	FIFTH FUNCTION PEDAL
			3315 - 12
		5D19	FIFTH FUNCTION PEDAL (PILOT CONTROL)
			3315 - 13A
		3J11	FILTER ELEMENT
			2160 - 14
		5H7	FILTER ELEMENT, PILOT CONTROL
			3363 - 1A
		2G13	FILTER LINES, FUEL 310G (TURBO), 310SG, 315SG (VSN 910056-)
			0420 - 12
		2G9	FILTER LINES, FUEL 310G (TURBO),310SG, 315SG (VSN -910055)
			0420 - 8
		2G3	FILTER LINES, FUEL 310G (W/O TURBO) (VSN -911768)
			0420 - 2
		2G7	FILTER LINES, FUEL 310G (W/O TURBO) (VSN 911769-)
			0420 - 6
		3J9	FILTER, BREATHER, HYDRAULIC RESERVOIR
			2160 - 12
		1E22	FILTER, CHARGE PUMP
			0360 - 5
		2E1	FILTER, ENGINE OIL (VSN -911768) 310G (W/O TURBO)
			0407 - 12
		2E4	FILTER, ENGINE OIL (VSN -910055) 310G(TURBO),310SG,315SG
			0407 - 16
		2E6	FILTER, ENGINE OIL (VSN 910056-) 310G(TURBO),310SG,315SG
			0407 - 18
		2E3	FILTER, ENGINE OIL (VSN 911769-) 310G (W/O TURBO)
			0407 - 14
		3F23	FILTER, FRESH AIR
			1816 - 12
		2G9	FILTER, FUEL 310G (TURBO),310SG,315SG (VSN -910055)
			0420 - 8
		2G3	FILTER, FUEL 310G (W/O TURBO) (VSN -911768)
			0420 - 2
		2G5	FILTER, FUEL 310G (W/O TURBO) (VSN 911769-)
			0420 - 4
		2G11	FILTER, FUEL 310G(TURBO), 310SG, 315SG (VSN 910056-)
			0420 - 10
		3J11	FILTER, HYDRAULIC OIL
			2160 - 14
		1E22	FILTER, TRANSMISSION
			0360 - 5
		2H23	FILTERS, AIR CLEANER
			0520 - 2
		1E5	FIRST GEAR CLUTCH ASSEMBLY, POWER SHIFT
			0350 - 14
		1E5	FIRST GEAR CLUTCH CARRIER, POWER SHIFT
			0350 - 14
		1E5	FIRST GEAR, BELLVILLEWASHER, POWER SHIFT
			0350 - 14

1A18

310G, 310SG AND 315SG BACKHOE LOADERS

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE	GRID		PAGE
2J9	FITTINGS, BRAKE VALVE	1060 - 4	1C13	FRONT AXLE SWIVEL HOUSING (WITHOUT MFWD) (SERIAL NO. 911132-)	0230 - 7
5I1	FITTINGS, SWING CYLINDER (310G,310SG)	3363 - 14	1C19	FRONT AXLE UNIVERSAL DRIVE SHAFT (MFWD).....	0250 - 6
3C9	FLASHER, 12 VOLT	1674 - 2	1C14	FRONT AXLE WHEEL HUB(WITHOUT MFWD) (SERIAL NO. 911132-)	0230 - 8
3C9	FLASHER, 4-WAY	1674 - 2	3F19	FRONT CONSOLE.....	1816 - 8
1D18	FLEXPLATE, TORQUE CONVERTOR	0350 - 1	3E16	FRONT CONSOLE COVER,FLOOR	1812 - 2
3E16	FLOOR COVER, REAR	1812 - 2	3C9	FRONT CONSOLE SWITCHES	1674 - 2
3E18	FLOOR HOLES, FRONT CAB MOUNT PLUGS	1812 - 4	3C9	FRONT CONSOLE WIRING HARNESS WITH CAB	1674 - 2
3E16	FLOOR MATS	1812 - 2	3E3	FRONT COUNTERWEIGHT	1749 - 2
4C23	FLOOR PLATE, LOADER LINKAGE.....	3115 - 6	4C17	FRONT COUPLER CYLINDER	3104 - 4
5H7	FLOW CONTROL VALVE	3363 - 1A	4E13	FRONT COUPLER VALVE	3162 - 28
2K12	FLUID ANALYSIS PRODUCTS (OILSCAN PLUS TEST KIT).....	1369 - 2	4C15	FRONT COUPLER, HYDRAULIC	3104 - 2
2H13	FLUID, STARTING	0505 - 4	1B17	FRONT DRIVE WHEEL (MFWD)	0110 - 4
2H2	FLYWHEEL HOUSING (VSN -910055).....	0433 - 3	3E16	FRONT FLOOR MAT	1812 - 2
2H3	FLYWHEEL HOUSING (VSN 910056-).....	0433 - 4	3C9	FRONT LIGHTS SWITCH	1674 - 2
2H1	FLYWHEEL RING GEAR.....	0433 - 2	2D9	FRONT PLATE, ENGINE.....	0404 - 1
2H1	FLYWHEEL, ENGINE	0433 - 2	1B18	FRONT WHEEL (WITHOUT MFWD)	0120 - 1
1D9	FNR, RANGE SWITCH	0315 - 4	1C10	FRONT WHEEL BEARING (WITHOUT MFWD) (SERIAL NO. -911131)	0230 - 4
5D17	FOOT CONTROL, FIFTH FUNCTION	3315 - 12	1C10	FRONT WHEEL HUB (WITHOUT MFWD) (SERIAL NO. -911131)	0230 - 4
5D21	FOOT CONTROL, SIXTH FUNCTION	3315 - 14	3F5	FRONT WINDSHIELD WIPER MOTOR	1814 - 10
3D17	FOOT, STABILIZER (315SG)	1740 - 4	3C9	FRONT WINDSHILD WIPER SWITCH	1674 - 2
1D6	FORK, SHIFT	0315 - 1	2I13	FUEL COOLER, HI-AMBIENT.....	0560 - 4
4C13	FORKLIFT FORKS.....	3103 - 2	2G9	FUEL FILTER HEATER 310G (TURBO), 310SG,315SG (VSN -910055)	0420 - 8
4C13	FORKS, PALLET	3103 - 2	2G11	FUEL FILTER HEATER 310G (TURBO), 310SG, 315SG (VSN 910056-).....	0420 - 10
4C13	FORKS,LOADER FORKLIFT	3103 - 2	2G3	FUEL FILTER HEATER 310G (W/O TURBO) (VSN -911768)	0420 - 2
1D19	FORWARD CLUTCH ASSEMBLY.....	0350 - 2	2G5	FUEL FILTER HEATER 310G (W/O TURBO) (VSN 911769-).....	0420 - 4
1E13	FORWARD CLUTCH ASSEMBLY, POWER SHIFT.....	0350 - 22	2G13	FUEL FILTER LINES 310G (TURBO), 310SG, 315SG (VSN 910056-).....	0420 - 12
1E13	FORWARD CLUTCH CARRIER, POWER SHIFT	0350 - 22	2G9	FUEL FILTER LINES 310G (TURBO),310SG, 315SG (VSN -910055)	0420 - 8
1E13	FORWARD, BELLVILLEWASHER, POWERSHIFT	0350 - 22	2G3	FUEL FILTER LINES 310G (W/O TURBO) (VSN -911768)	0420 - 2
1E19	FORWARD, NEUTRAL AND REVERSE SOLENOIDS ..	0360 - 2	2G7	FUEL FILTER LINES 310G (W/O TURBO) (VSN 911769-).....	0420 - 6
1D9	FORWARD, NEUTRAL, REVERSE CONTROL	0315 - 4	2G9	FUEL FILTER 310G (TURBO),310SG,315SG (VSN -910055).....	0420 - 8
1E11	FOURTH GEAR CLUTCH ASSEMBLY, POWER SHIFT 0350-20		2G3	FUEL FILTER 310G (W/O TURBO) (VSN -911768).....	0420 - 2
1E11	FOURTH GEAR CLUTCH CARRIER, POWER SHIFT ..	0350 - 20	2G5	FUEL FILTER 310G (W/O TURBO) (VSN 911769-).....	0420 - 4
1E11	FOURTH GEAR, BELLVILLEWASHER, POWERSHIFT	0350 - 20	2G11	FUEL FILTER 310G(TURBO), 310SG, 315SG (VSN 910056-).....	0420 - 10
5E13	FRAME, BACKHOE SLIDING,315SG	3342 - 2	2I11	FUEL GAUGE SENDER	0560 - 2
3E12	FRAME, CAB	1811 - 4	2I11	FUEL HOSES.....	0560 - 2
3E4	FRAME, COUNTERWEIGHT.....	1749 - 3	2F3	FUEL INJECTION LINES 310G(TURBO),310SG,315SG (VSN 910056-)	0413 - 10
4C13	FRAME, FORKLIFT COUPLER.....	3103 - 2	2E23	FUEL INJECTION LINES 310G(W/O TURBO)(VSN 911769-)	0413 - 6
3I1	FRAME, GRILLE, EXTENDED	1921 - 4	2F1	FUEL INJECTION LINES 310G(TURBO),310SG, 315SG(VSN 893079-907963)(VSN-910055).....	0413 - 8
3D17	FRAME, MAIN FRAME (315SG).....	1740 - 4	2E21	FUEL INJECTION LINES 310G(W/O TURBO) (VSN 893079-907963)(VSN -911768)	0413 - 4
3E10	FRAME, ROPS.....	1811 - 2	2E17	FUEL INJECTION NOZZLE (PE4045TT089) 310SG,315SG (VSN -943548)	0413 - 2
3G13	FRAME, SCISSOR.....	1821 - 10	2E18	FUEL INJECTION NOZZLE (PE4045TT089) 310S G,315SG (VSN 943549-)	0413 - 3
3D17	FRAME, SLIDING (315SG)	1740 - 4	2E17	FUEL INJECTION NOZZLE (TT088, 89) 310G(TURBO),310SG,315SG (VSN 910056-)	0413 - 2
5E17	FRAME, SWING 315SG	3343 - 4			
3D15	FRAME,MAIN FRAME(310G,310SG)	1740 - 2			
5E13	FRAME,SLIDING,315SG	3342 - 2			
5E15	FRAME,SWING (310G,310SG)	3343 - 2			
3H3	FREEZE/COMPRESSOR SWITCH, AIR CONDITIONI NG	1830 - 7A			
3F23	FRESH AIR FILTER.....	1816 - 12			
1C15	FRONT AXLE (MFWD)	0250 - 1			
1C8	FRONT AXLE (WITHOUT MFWD) (SERIAL NO. -911131)	0230 - 2			
1C11	FRONT AXLE (WITHOUT MFWD) (SERIAL NO. 911132-)	0230 - 5			
1C17	FRONT AXLE HOUSING (MFWD)	0250 - 4			
1C19	FRONT AXLE HOUSING (MFWD)	0250 - 6			
1C17	FRONT AXLE HOUSING (MWFD)	0250 - 4			
1C12	FRONT AXLE HOUSING (WITHOUT MFWD) (SERIAL NO. 911132-)	0230 - 6			
1C19	FRONT AXLE HUB (MFWD).....	0250 - 6			
2K18	FRONT AXLE LUBRICATION SYSTEM.....	1370 - 2			
1C15	FRONT AXLE PIVOT PIN (MFWD)	0250 - 1			
1C11	FRONT AXLE PIVOT PIN (WITHOUT MFWD) (SERIAL NO. 911132-)	0230 - 5			