

9935 COTTON PICKER



JOHN DEERE

PARTS CATALOG

9935 COTTON PICKER

PC2447 (AUG-05) English

John Deere Des Moines Works

North American Edition

Litho in U.S.A. (Revised)

COPYRIGHT © 2005

DEERE & COMPANY

Moline, Illinois

All rights reserved

NP7870 -UN-27FEB97



NP7870

*JOHN DEERE 9935 COTTON PICKER
(MANUFACTURED 1997-2004)*

(SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE.)

PRODUCT IDENTIFICATION NUMBER LISTING INFORMATION

THE COTTON PICKER PRODUCT IDENTIFICATION NUMBER PLATE IS LOCATED ON MAIN FRAME BEHIND DIAGONAL BRACE.

PRODUCT IDENTIFICATION NUMBER (PIN) INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

-	THE PART CAN BE USED ON ALL MACHINES.
000000-	THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE PIN OR YEAR.
-000000	THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE PIN OR YEAR LISTED.
000000-000000	THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE PRODUCT IDENTIFICATION NUMBERS OR YEARS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A PRODUCT IDENTIFICATION NUMBER, A CHANGE WAS MADE BUT THE EXACT PIN WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

HOSE DIMENSIONS LISTED ARE EITHER FITTING SIZE X LENGTH X FITTING SIZE OR I.D. X LENGTH.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

ENGINE SERIAL NUMBER PLATE

RGP3513 -UN-



RGP 35 13

FIRST LINE

T0 - JOHN DEERE DUBUQUE ENGINE WORKS
PE - JOHN DEERE TORREON ENGINE WORKS

6

068 (6.8 LITERS)

T - TURBO-DIESEL WITH AIR-TO-AIR INTERCOOLER

N - JOHN DEERE DES MOINES WORKS

XXXXXX

SECOND LINE

6068TN051

DEFINES

DESIGNATES ENGINE MANUFACTURER

DESIGNATES NUMBER OF CYLINDERS

DESIGNATES LITER DISPLACEMENT

DESIGNATES TYPE OF AIR INTAKE SYSTEM

DESIGNATES USER FACTORY

DESIGNATES ENGINE SERIAL NUMBER

APPLICATION

9935 COTTON PICKER

SECTION INDEX

GENERAL INFORMATION	10
ENGINE	20
FUEL AND AIR	30
ELECTRICAL	40
POWER TRAIN	50
STEERING AND BRAKES	60
HYDRAULIC SYSTEM	70
WHEELS, REAR AXLES AND SHEET METAL	80
OPERATOR'S STATION	90
PICKING UNIT LIFT100
PICKING UNIT CABINET (PRO-12 - 18S)110
PICKING UNIT CABINET (IN-LINE).115
PICKING UNIT SYSTEM (PRO-12 - 18S).120
PICKING UNIT SYSTEM (IN-LINE)125
PICKING UNIT LUBRICATION SYSTEM130
WATER SYSTEM.140
AIR SYSTEM.150
BASKET160
DECALS170
PREFERRED METRIC HARDWARE180
NUMERICAL INDEX190

ALPHABETICAL INDEX

	PAGE		PAGE
A			
A/C COMPRESSOR (6081HN003)	90 - 50	AUGER MOTOR, COMPACTOR	170 - 18
A/C COMPRESSOR COVER AND PULLEY	90 - 53	AUXILIARY PLUG CONNECTOR.	40 - 47
ACCESS COVER, INJECTION PUMP GEAR (ENG. SER. NO. 900552-)	20 - 12	AXLE KNEE SPINDLE KNUCKLE, REAR	80 - 14
ACCESS COVER, INJECTION PUMP GEAR (ENG.SER.NO.-900551)	20 - 10	AXLE PIVOT SUPPORT, FRONT	80 - 10
ACTUATOR, FAN ENGAGE	150 - 8	AXLE PIVOT SUPPORT, REAR	80 - 12
ADAPTER, FAN CONTROLLER	40 - 37	AXLE TIE RODS, REAR.	80 - 16
ADAPTER, OIL FILTER	20 - 30	AXLE, FINAL DRIVE	50 - 21
ADAPTER, OIL FILTER	20 - 31	AXLE, REAR CENTER	80 - 9
ADAPTER,ENGINE COOLANT	20 - 42	B	
ADAPTOR, HYDROSTATIC TO HYDRAULIC PUMP	50 - 36	BACKREST, OPERATOR'S SEAT.	90 - 30
ADJUSTER, BRAKE	60 - 16	BAR DRUM, STUD AND BEARING, PICKER IN-LINE (101 - 2000)	125 - 16
ADJUSTER, DOFFER, UPPER, IN-LINE (101 - 2000)	125 - 22	BAR DRUM, STUD AND BEARING, PICKER PRO-12 - 18S (2001 -)	120 - 18
ADJUSTER, DOFFER, UPPER, PRO-12 - 18S (2001 -)	120 - 20	BAR, GRID, PICKING UNIT, IN-LINE (101 - 2000)	115 - 10
ADJUSTING STRAP, ALTERNATOR	40 - 30	BAR, GRID, PICKING UNIT, PRO-12 - 18S (2001 -)	110 - 10
ADJUSTMENT, SEAT.	90 - 34	BAR, JOURNAL BEARING, IN-LINE (101 - 2000)	125 - 14
AIR CLEANER AND TUBES.	30 - 2	BAR, JOURNAL BEARING, PRO-12 - 18S (2001 -)	120 - 12
AIR CONDITIONING COMPRESSOR BRACKET	20 - 58	BAR, PICKER, IN-LINE (101 - 2000)	125 - 20
AIR CONDITIONING BLOWER (CAB)	90 - 40	BAR, PICKER, PRO-12 - 18S (2001 -)	120 - 16
AIR CONDITIONING COMPRESSOR (6081HN003)	90 - 50	BASKET CYLINDER END LUBRICATION LINES	160 - 22
AIR CONDITIONING COMPRESSOR, CONDENSER, HOSES AND FITTINGS	90 - 48	BASKET DUMP HYDRAULIC CYLINDER	70 - 25
AIR CONDITIONING EVAPORATOR, HOSES AND LOW PRESSURE SWITCH	90 - 46	BASKET EXTENSION LEFT-HAND DOOR	160 - 20
AIR DUCTS, TUBES AND NOZZLES.	150 - 9	BASKET EXTENSION, 14-INCH	160 - 21
AIR FILTER, CAB	90 - 43	BASKET FLOOR AND FAN ENCLOSURE.	160 - 10
AIR HOSES	150 - 7	BASKET INTERLOCK VALVE	70 - 29
AIR INTAKE	30 - 17	BASKET LID FRAME	160 - 12
AIR INTAKE HEATER.	40 - 32	BASKET LID GRATES, SCREENS AND FINGERS	160 - 14
AIR LOUVER, PANEL AND SWITCHES.	90 - 42	BASKET LID HANDRAILS AND STEP	160 - 16
ALARM, CONSOLE	40 - 10	BASKET LID LINKAGE	160 - 1
ALTERNATOR	40 - 34	BASKET LIFT HYDRAULICS	70 - 10
ALTERNATOR CAPACITOR	40 - 34	BASKET SUPPORTS	160 - 2
ALTERNATOR MOUNTING BRACKETS AND ADJUSTING STRAP	40 - 30	BASKET, FRONT AND REAR	160 - 4
ALTERNATOR PULLEY	40 - 34	BASKET, LEFT SIDE	160 - 6
ANGLE, PICKING UNIT BOTTOM FRAME IN-LINE (101 - 2000)	115 - 8	BASKET, RIGHT SIDE	160 - 8
ANGLE, PICKING UNIT BOTTOM FRAME PRO-12 - 18S (2001 -)	110 - 8	BATTERY, BATTERY BOX AND CABLES	40 - 1
ANTENNA, RADIO AND SPEAKERS.	40 - 36	BEARING, PICKER BAR DRUM, IN-LINE (101 - 2000)	125 - 16
ANTIFREEZE	20 - 62	BEARING, PICKER BAR DRUM, PRO-12 - 18S (2001 -)	120 - 18
ARM, PICKER BAR, IN-LINE (101 - 2000)	125 - 20	BEARING,CRANKSHAFT THRUST.	20 - 7
ARM, PICKER BAR, PRO-12 - 18S (2001 -)	120 - 16	BEARINGS, MAIN	20 - 7
ARM, ROCKER	20 - 9	BEARINGS,CONNECTING ROD	20 - 14
ARM, STALKLIFTER PIVOT IN-LINE (101 - 2000)	115 - 18	BELT IDLER TENSIONER.	20 - 48
ARM, STALKLIFTER PIVOT PRO-12 - 18S (2001 -)	110 - 18	BELT IDLER TENSIONER.	20 - 50
ARM, UNIT LIFT	100 - 2	BELT, FAN (ENGINE)	20 - 4
ARM, VANE COMPACTOR	160 - 17	BELT, FAN DRIVE (COTTON)	150 - 4
ARMATURE, STARTER.	40 - 28	BELTS, FAN	20 - 46
ARMREST, SEAT (PERSONAL-POSTURE™ SEAT)	90 - 32	BEVEL GEARS	50 - 16
ASHTRAY.	90 - 22	BLADE, WINDSHIELD WIPER	90 - 54
ASPIRATOR.	30 - 4	BLOCK, CYLINDER	20 - 18
AUGER COMPACTOR	160 - 18	BLOCK, ENGINE SHORT	20 - 20
AUGER COMPACTOR HYDRAULICS	70 - 12	BLOCK, REMANUFACTURED COMPLETE ENGINE	20 - 20
AUGER MOTOR, COMPACTOR	70 - 30	BLOWER RESISTOR, CAB	40 - 8

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
BOOT, SEAT ADJUSTMENT	90 - 34	CABLES, BATTERY	40 - 1
BOTTOM FRAME, PICKING UNIT, IN-LINE (101 - 2000)	115 - 8	CAM, PICKER DRUM, IN-LINE (101 - 2000)	125 - 14
BOTTOM FRAME, PICKING UNIT, PRO-12 - 18S (2001 -)	110 - 8	CAM, PICKER DRUM, PRO-12 - 18S (2001 -)	120 - 12
BOTTOM PANELS, TUNNEL	80 - 6	CAMSHAFT	20 - 16
BOX, BATTERY	40 - 1	CAMSHAFT GEAR	20 - 16
BOX, MONITOR	90 - 20	CAP, FUEL	30 - 6
BRACE, HOOD	20 - 45	CAP, HYDROSTATIC PUMP END.	50 - 34
BRACKET TENSIONER	20 - 48	CAP, RADIATOR (SERIAL NO. 101-3000)	20 - 1
BRACKET, ALTERNATOR MOUNTING	40 - 30	CAP, RADIATOR (SERIAL NO. 4001-)	20 - 2
BRACKET, DOFFER IDLER GEAR, IN-LINE (101 - 2000)	125 - 26	CAP, REAR WHEEL BEARING.	80 - 20
BRACKET, DOFFER IDLER GEAR, PRO-12 - 18S (2001 -)	120 - 24	CAP,ENGINE OIL FILL	20 - 22
BRACKET, FIRE EXTINGUISHER	80 - 26	CAP,MAIN BEARING	20 - 18
BRACKET, HYDROSTATIC CABLE.	50 - 2	CAPACITOR, NOISE SUPPRESSION.	40 - 8
BRACKET, PARK BRAKE CABLE	60 - 14	CAPACITOR,ALTETNATOR	40 - 34
BRACKET, TENSIONER	20 - 50	CASE, GEAR UNIT DRIVE, LH IN-LINE (101 - 2000)	125 - 4
BRACKET, WATER PUMP.	140 - 6	CASE, GEAR UNIT DRIVE, RH IN-LINE (101 - 2000)	125 - 6
BRACKET, WATER VALVE	140 - 1	CASE, GEAR, PICKING UNIT PRO-12 - 18S (2001 -)	120 - 4
BRACKET,AIR CONDITIONING COMPRESSOR	20 - 58	CASE, MONITOR	90 - 20
BRACKETS, TRANSMISSION	50 - 8	CASE, TRANSMISSION.	50 - 18
BRAKE CABLE, PARK	60 - 14	CAUTION LABELS	170 - 12
BRAKE LINES AND RESERVOIR	60 - 10	CAUTION LIGHT, MONITOR.	40 - 24
BRAKE MASTER CYLINDER	60 - 8	CHAIN, LOW COTTON, IN-LINE (101 - 2000).	115 - 18
BRAKE PEDAL, PARK	60 - 13	CHAIN, LOW COTTON, PRO-12 - 18S (2001 -)	110 - 18
BRAKE PEDALS.	60 - 12	CHANNEL, PICKING UNIT BOTTOM FRAME IN-LINE (101 - 2000)	115 - 8
BRAKE SHOES AND DRUM	60 - 16	CHANNEL, PICKING UNIT BOTTOM FRAME PRO-12 - 18S (2001 -)	110 - 8
BRAKE SLAVE CYLINDER	60 - 18	CHARGE PUMP SHAFT, HYDROSTATIC	50 - 36
BREAKERS, CIRCUIT	40 - 38	CHARGE RELIEF VALVE, HYDROSTATIC PUMP	50 - 30
BULB, DOME LIGHT	40 - 26	CHASSIS WIRING HARNESS	40 - 14
BULB, WARNING LAMP (-XXXXXX)	40 - 3	CHECK VALVE, HYDRAULIC CONTROL VALVE	70 - 20
BULB, WARNING LAMP (XXXXXX-)	40 - 4	CHECK VALVE, HYDROSTATIC PUMP	50 - 34
BYPASS VALVE, HYDROSTATIC CIRCUIT	50 - 24	CHECK VALVE, WATER SYSTEM	140 - 4
BYPASS, HYDRAULIC OIL COOLER	70 - 2	CIRCUIT BREAKERS AND RELAYS	40 - 38
		CLEAN-OUT DOOR, COTTON DOOR	150 - 10
C		CLEANER SOLUTION, SPINDLE	140 - 2
CAB AIR CONDITIONING COMPRESSOR, CONDENSER, RECEIVER-DRYER AND HOSES	90 - 48	CLEANER, AIR	30 - 2
CAB AIR CONDITIONING EVAPORATOR AND HOSES	90 - 46	CLUTCH, FAN (COTTON)	150 - 4
CAB AIR FILTER AND HOUSING	90 - 43	CLUTCH, SLIP, DRUM, PRO-12 - 18S (2001 - 16000)	120 - 8
CAB DOOR	90 - 10	CLUTCH, SLIP, LOWER GEAR CASE HUB IN-LINE (101 - 2000)	125 - 8
CAB FLOOR MAT	90 - 18	CLUTCH, SLIP, LOWER GEAR CASE HUB PRO-12 - 18S (2001 -)	120 - 6
CAB FLOOR TERMINAL CONNECTORS	40 - 41	COIL, HYDRAULIC CONTROL VALVE SOLENOID	70 - 20
CAB REAR UPHOLSTERY	90 - 12	COLLAR, SHIFT, TRANSMISSION UNIT DRIVE SHAFT	50 - 17
CAB ROOF AND SUPPORTS	90 - 14	COLUMN, SPINDLE MOISTENER, IN-LINE (-2000)	140 - 16
CAB ROOF HEADLINER	90 - 17	COLUMN, SPINDLE MOISTENER, PRO-12 - 18S (2001-)	140 - 14
CAB WINDOWS	90 - 7	COLUMN, STEERING	60 - 1
CAB WIRING HARNESS	40 - 8	COMPACTOR AUGER HYDRAULIC MOTOR	70 - 30
CAB, SOUND-GARD® (COMPLETE)	90 - 6	COMPACTOR AUGER HYDRAULIC MOTOR	170 - 18
CABINET, PLUGS AND GROMMETS PRO-12 - 18S (2001 -)	110 - 24	COMPACTOR HYDRAULICS, AUGER	70 - 12
CABLE, HYDROSTATIC CONTROL	50 - 6	COMPACTOR HYDRAULICS, VANE	70 - 14
CABLE, PARK BRAKE	60 - 14	COMPACTOR SWITCH, FOOT CONTROL	40 - 7
CABLE, REAR DRUM PRESSURE PLATE IN-LINE (101 - 2000).	115 - 14	COMPACTOR, AUGER	160 - 18
CABLE, REAR DRUM PRESSURE PLATE PRO-12 - 18S (2001 -)	110 - 14		
CABLE, THROTTLE	30 - 8		
CABLE, TRANSMISSION SHIFT.	50 - 4		
CABLE, UNIT SHIFT	50 - 5		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
COMPACTOR, VANE	160 - 17	COVER, TIMING GEAR	
COMPLETE ENGINE BLOCK, REMANUFACTURED . .	20 - 20	(ENG.SER.NO.-900551)	20 - 10
COMPLETE REPAIR UNIT, IN-LINE		COVER, WHEEL LUGS	80 - 18
(101 - 2000)	115 - 1	CRANKSHAFT	20 - 7
COMPRESSOR HARDWARE KIT	90 - 51	CRANKSHAFT DAMPER	20 - 44
COMPRESSOR PARTS	90 - 52	CRANKSHAFT GEAR	20 - 7
COMPRESSOR, AIR CONDITIONING	90 - 48	CRANKSHAFT PULLEY	20 - 44
COMPRESSOR, AIR CONDITIONING		CRANKSHAFT REAR OIL SEAL	20 - 53
(6081HN003)	90 - 50	CRANKSHAFT THRUST BEARING	20 - 7
CONDENSER, DRYER, HOSES AND FITTINGS		CROSS AUGER LIFT HYDRAULIC CYLINDER	70 - 3
(AIR CONDITIONING)	90 - 48	CROSS SHAFT AND UNIVERSAL JOINT	
CONNECTING ROD	20 - 14	IN-LINE (101 - 2000)	125 - 2
CONNECTING ROD BEARINGS	20 - 14	CROSS SHAFT AND UNIVERSAL JOINT	
CONNECTOR, CAB FLOOR	40 - 41	PRO-12 - 18S (2001 -)	120 - 3
CONNECTOR, CONSOLE SWITCH	40 - 49	CUSHION, SEAT	90 - 30
CONNECTOR, DIODE MODULE	40 - 43	CUTTER, VINE, IN-LINE	
CONNECTOR, FAN CONTROLLER	40 - 40	(101 - 2000)	125 - 28
CONNECTOR, FUSE AND RELAY BLOCK	40 - 44	CUTTER, VINE, PRO-12 - 18S	
CONNECTOR, KEY SWITCH, CONSOLE LIGHT,		(2001 -)	120 - 26
ETHER SWITCH AND WARNING HORN	40 - 48	CYLINDER AND LINES, BASKET LIFT	70 - 10
CONNECTOR, MICROSWITCH AND		CYLINDER BLOCK	20 - 18
AUXILIARY PLUG	40 - 47	CYLINDER BLOCK, HYDROSTATIC PUMP	50 - 26
CONNECTOR, MOMENTARY FLOOR SWITCH	40 - 45	CYLINDER HEAD	20 - 34
CONNECTOR, MONITOR LIGHT MODULE AND		CYLINDER HEAD GASKET	20 - 34
TACHOMETER	40 - 46	CYLINDER HEAD REMOVAL GASKET SET	20 - 56
CONSOLE ASSEMBLY	90 - 22	CYLINDER LINER	20 - 14
CONSOLE CONTROL LEVERS	90 - 24	CYLINDER LINER O-RING KIT	20 - 14
CONSOLE CONTROLS, FUSES AND RELAYS	40 - 10	CYLINDER LUBRICATION LINES	160 - 22
CONSOLE LIGHT CONNECTOR	40 - 48	CYLINDER, BASKET DUMP	70 - 25
CONSOLE SWITCH CONNECTOR	40 - 49	CYLINDER, BRAKE MASTER	60 - 8
CONSOLE WIRING HARNESS (PIN -2000)	40 - 18	CYLINDER, BRAKE SLAVE	60 - 18
CONSOLE WIRING HARNESS (PIN 2001-)	40 - 20	CYLINDER, HYDRAULIC (2" X 8")	
CONTROL CABLE, HYDROSTATIC	50 - 6	VANE COMPACTOR	70 - 23
CONTROL HANDLE, HYDROSTATIC	90 - 26	CYLINDER, HYDRAULIC, CROSS AUGER LIFT	70 - 3
CONTROL LEVERS, CONSOLE	90 - 24	CYLINDER, STEERING	70 - 24
CONTROL SWITCHES, AIR CONDITIONER	90 - 42	CYLINDER, STEERING HYDRAULIC	60 - 6
CONTROL VALVE, HEATER	90 - 44	CYLINDER, VANE COMPACTOR HYDRAULIC	70 - 14
CONTROL VALVE, HYDRAULIC	70 - 20		
CONTROL, TURN SIGNAL	40 - 2	D	
CONTROL, WATER SYSTEM	140 - 4	DAMPER, CRANKSHAFT	20 - 44
CONTROLLER ADAPTER, FAN	40 - 37	DECALS, CHASSIS	170 - 2
CONTROLS, FUSES AND RELAYS, CONSOLE	40 - 10	DECALS, CHASSIS	170 - 4
COOLANT	20 - 62	DECALS, SAFETY	170 - 12
COOLANT RESERVOIR	20 - 5	DIFFERENTIAL (TRANSMISSION)	50 - 14
COOLER, HYDRAULIC OIL	70 - 2	DIMMER SWITCH	40 - 5
CORE, HEATER AND EVAPORATOR	90 - 46	DIODE MODULE	40 - 43
COTTON BASKET FLOOR AND FAN ENCLOSURE	160 - 10	DIPSTICK, ENGINE OIL	20 - 23
COTTON BASKET, FRONT AND REAR	160 - 4	DISC, DOFFER, IN-LINE (101 - 2000)	125 - 24
COTTON BASKET, LEFT SIDE	160 - 6	DISC, DOFFER, PRO-12 - 18S (2001 -)	120 - 22
COTTON BASKET, RIGHT SIDE	160 - 8	DISPLACEMENT CONTROL, HYDROSTATIC PUMP	50 - 32
COTTON DOORS	150 - 10	DISTRIBUTOR ASSEMBLY, MOISTENER,	
COUPLING, HYDROSTATIC TO HYDRAULIC PUMP	50 - 36	IN-LINE (-2000)	140 - 16
COVER, ACCESS, INJECTION PUMP GEAR		DISTRIBUTOR ASSEMBLY, MOISTENER,	
(ENG. SER. NO. 900552-)	20 - 12	PRO-12 - 18S (2001-)	140 - 14
COVER, ACCESS, INJECTION PUMP GEAR		DOFFER ADJUSTER AND STUB SHAFT	
(ENG.SER.NO.-900551)	20 - 10	IN-LINE (101 - 2000)	125 - 22
COVER, AIR CONDITIONING COMPRESSOR	90 - 53	DOFFER ADJUSTER AND STUB SHAFT	
COVER, CAB DOOR TRACK	90 - 10	PRO-12 - 18S (2001 -)	120 - 20
COVER, FAN, BASKET FLOOR	160 - 10	DOFFER DRIVE IDLER GEAR, IN-LINE	
COVER, FINAL DRIVE GEAR	50 - 21	(101 - 2000)	125 - 26
COVER, INNER ROOF	90 - 16	DOFFER DRIVE IDLER GEAR, PRO-12 - 18S	
COVER, OIL FILLER OPENING	20 - 22	(2001 -)	120 - 24
COVER, RADIATOR	80 - 2	DOFFER FLAP, IN-LINE	
COVER, ROCKER ARM	20 - 8	(101 - 2000)	115 - 4
COVER, THERMOSTAT	20 - 40		
COVER, TIMING GEAR			
(ENG. SER. NO. 900552-)	20 - 12		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
DOFFER FLAP, PRO-12 - 18S (2001 -)	110 - 4	ELECTRICAL CONNECTOR, CONSOLE SWITCH	40 - 49
DOFFER GAUGES, IN-LINE (101-2000)	125 - 27	ELECTRICAL CONNECTOR, DIODE MODULE	40 - 43
DOFFER GAUGES, PRO-12 - 18S (2001 -)	120 - 25	ELECTRICAL CONNECTOR, FAN CONTROLLER	40 - 40
DOFFER IDLER GEARS, PRO-12 - 18S (2001 -)	120 - 10	ELECTRICAL CONNECTOR, FUSE AND RELAY.	40 - 44
DOFFER, ADJUSTING HOUSING, UPPER IN-LINE (101 - 2000).	125 - 22	ELECTRICAL CONNECTOR, HYDRO HANDLE AND GAUGE CLUSTER	40 - 42
DOFFER, ADJUSTING HOUSING, UPPER PRO-12 - 18S (2001 -)	120 - 20	ELECTRICAL CONNECTOR, KEY SWITCH, CONSOLE LIGHT, ETHER SWITCH, HORN	40 - 48
DOFFER, IN-LINE (101 - 2000)	125 - 24	ELECTRICAL CONNECTOR, MOMENTARY FLOOR SWITCH	40 - 45
DOFFER, HOSE, PRO-12 - 18S (2001 -)	120 - 22	ELECTRICAL CONNECTOR, MONITOR LIGHT MODULE AND TACHOMETER	40 - 46
DOME LIGHT (ROCKER TYPE)	40 - 26	ELECTRICAL CONNECTORS, CAB FLOOR.	40 - 41
DOOR ASSEMBLY, COTTON	150 - 10	ELECTRICAL CONNECTORS, MICROSWITCH AND AUXILIARY PLUG.	40 - 47
DOOR, BASKET EXTENSION LEFT-HAND	160 - 20	ELEMENT, AIR FILTER	30 - 2
DOOR, CAB.	90 - 10	ELEMENT,FUEL FILTER	30 - 22
DOORS, UNIT, IN-LINE (101 - 2000)	115 - 16	ELEMENT,FUEL FILTER	30 - 24
DOORS, UNIT, PRO-12 - 18S (2001 -)	110 - 16	ENCLOSURE, FAN, BASKET FLOOR.	160 - 10
DRAIN HOSE, FUEL FILTER	30 - 22	END CAP, HYDROSTATIC PUMP.	50 - 34
DRAIN HOSE, FUEL FILTER	30 - 24	ENGINE BLOCK, REMANUFACTURED COMPLETE	20 - 20
DRIVE GEARS, UPPER HOUSING DRUM IN-LINE (101 - 2000).	125 - 12	ENGINE COOLANT ADAPTER.	20 - 42
DRIVE GEARS, UPPER HOUSING DRUM PRO-12 - 18S (2001 -)	120 - 10	ENGINE COOLANT HEATER	40 - 35
DRIVE SHAFT, UNIT, IN-LINE (101 - 2000)	125 - 1	ENGINE FAN AND FAN BELT	20 - 4
DRIVE SHAFT, UNIT, PRO-12 - 18S (2001-)	120 - 2	ENGINE FLYWHEEL	20 - 52
DRIVE, FAN	20 - 48	ENGINE FRONT PLATE.	20 - 15
DRIVE, FAN	20 - 50	ENGINE HOOD AND SCREENS	80 - 2
DRIVE, HYDROSTATIC PUMP.	50 - 1	ENGINE LIFT STRAPS	20 - 45
DRIVE, LH UNIT, GEAR CASE IN-LINE (101 - 2000).	125 - 4	ENGINE MAJOR OVERHAUL GASKET SET.	20 - 54
DRIVE, RH UNIT, GEAR CASE IN-LINE (101 - 2000).	125 - 6	ENGINE OIL BY-PASS VALVE	20 - 18
DRUM DRIVE GEARS, UPPER HOUSING IN-LINE (101 - 2000).	125 - 12	ENGINE OIL COOLER	20 - 42
DRUM DRIVE GEARS, UPPER HOUSING PRO-12 - 18S (2001 -)	120 - 10	ENGINE OIL DIPSTICK AND TUBE	20 - 23
DRUM HEAD AND CAM, IN-LINE (101 - 2000)	125 - 14	ENGINE OIL FILL CAP	20 - 22
DRUM HEAD AND CAM, PRO-12 - 18S (2001 -)	120 - 12	ENGINE OIL FILL PLUG	20 - 8
DRUM SLIP CLUTCH AND IDLER GEARS IN-LINE (101 - 2000).	125 - 10	ENGINE OIL PAN	20 - 26
DRUM SLIP CLUTCH AND IDLER GEARS PRO-12 - 18S (2001 -16000)	120 - 8	ENGINE OIL PAN	20 - 28
DRUM SPEED SENSOR, PRO-12 - 18S (2001 -)	120 - 10	ENGINE OIL PRESSURE REGULATING VALVE (ENG. SER. NO. -889024)	20 - 10
DRUM, BRAKE	60 - 16	ENGINE OIL PRESSURE REGULATING VALVE (ENG. SER. NO. 889025-)	20 - 18
DRUM, PICKER BAR, IN-LINE (101 - 2000)	125 - 16	ENGINE OIL PRESSURE SENSOR	20 - 25
DRUM, PICKER BAR, PRO-12 - 18S (2001 -)	120 - 18	ENGINE OIL PUMP.	20 - 24
DRYER, AIR CONDITIONING	90 - 48	ENGINE OIL PUMP GEAR	20 - 24
DUCT LADDER	90 - 4	ENGINE OIL PUMP HOUSING.	20 - 24
DUCT SUPPORT (-2036)	150 - 14	ENGINE OIL PUMP INTAKE	20 - 24
DUCT SUPPORT (2037-)	150 - 16	ENGINE OVERHAUL KIT	20 - 64
DUCT, AIR	150 - 9	ENGINE PISTON.	20 - 14
DUCT, UNIT TO BASKET	150 - 12	ENGINE SHORT BLOCK	20 - 20
DUST COVER, COMPRESSOR	90 - 53	ENGINE SUPPORTS AND BELT SHIELD	20 - 6
		ENGINE VENTILATING SYSTEM	20 - 32
E		ENGINE WIRING HARNESS	40 - 12
ELBOW, ENGINE VENTILATING.	20 - 32	EQUALIZER, PARK BRAKE	60 - 14
ELECTRIC STARTING AID	40 - 6	ETHER SWITCH CONNECTOR	40 - 48
		EVAPORATOR AND HOSES, CAB A/C	90 - 46
		EXHAUST MANIFOLD	30 - 10
		EXHAUST MANIFOLD GASKET	30 - 10
		EXHAUST PIPE, ASPIRATOR, PRE-CLEANER	30 - 4
		EXHAUST VALVE	20 - 34
		EXPANSION VALVE, A/C	90 - 46
		EXTENSION AND GRATE, STALKLIFTERS IN-LINE (101 - 2000)	115 - 18
		EXTENSION AND GRATE, STALKLIFTERS PRO-12 - 18S (2001 -)	110 - 18
		EXTENSION DOOR, BASKET, LEFT-HAND	160 - 20
		EXTENSION, BASKET, 14-INCH	160 - 21
		EXTINGUISHER, FIRE	80 - 26

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
F			
FAN AND FAN BELT, ENGINE	20 - 4	FRONT DRUM PRESSURE PLATE, PRO-12 - 18S (2001 -)	110 - 12
FAN BELTS	20 - 46	FRONT PLATE, ENGINE	20 - 15
FAN CONTROLLER ADAPTER	40 - 37	FRONT WHEEL SHIELD, LH.	80 - 24
FAN CONTROLLER CONNECTOR.	40 - 40	FRONT WHEEL SHIELD, RH	80 - 22
FAN DRIVE	20 - 48	FUEL FILTER	30 - 22
FAN DRIVE	20 - 50	FUEL FILTER	30 - 24
FAN DRIVE HOUSING	20 - 50	FUEL FILTER ELEMENT	30 - 22
FAN DRIVE HUB.	20 - 48	FUEL FILTER ELEMENT	30 - 24
FAN DRIVE HUB.	20 - 50	FUEL FILTER FUEL LINES	30 - 22
FAN DRIVE PULLEY	20 - 48	FUEL FILTER FUEL LINES	30 - 24
FAN DRIVE PULLEY	20 - 50	FUEL FILTER HEATER	30 - 22
FAN ENCLOSURE, BASKET FLOOR.	160 - 10	FUEL FILTER, WATER SEPARATOR	30 - 27
FAN ENGAGE ACTUATOR	150 - 8	FUEL GAUGE	40 - 24
FAN HOUSING	150 - 2	FUEL INJECTION LINES (LUCAS)	30 - 12
FAN IDLER AND LINKAGE (COTTON)	150 - 6	FUEL INJECTION LINES (STANADYNE)	30 - 14
FAN SHAFT, SHEAVE AND ROTOR	150 - 4	FUEL INJECTION NOZZLE	30 - 11
FEEDBACK LINK, HYDROSTATIC PUMP	50 - 26	FUEL INJECTION PUMP (LUCAS)	30 - 12
FIELD LAMPS	90 - 57	FUEL INJECTION PUMP (STANADYNE)	30 - 14
FILLER NECK, HYDRAULIC RESERVOIR	70 - 1	FUEL INJECTION PUMP COLD ADVANCE SWITCH	30 - 16
FILTER, AIR.	30 - 2	FUEL INJECTION PUMP DRIVE GEAR (LUCAS)	30 - 12
FILTER, CAB AIR	90 - 43	FUEL INJECTION PUMP GEAR (STANADYNE)	30 - 14
FILTER, CAB VENT	90 - 17	FUEL INJECTION PUMP SOLENOID WIRE HARNESS	30 - 16
FILTER, FUEL	30 - 22	FUEL INJECTION SYSTEM (LUCAS).	30 - 12
FILTER, FUEL	30 - 24	FUEL INJECTION SYSTEM (STANADYNE)	30 - 14
FILTER, GREASE	130 - 8	FUEL LINES,FUEL FILTER	30 - 22
FILTER, HYDRAULIC OIL.	70 - 4	FUEL LINES,FUEL FILTER	30 - 24
FILTER, WATER	140 - 8	FUEL TANK AND SENDER	30 - 6
FILTER, WATER SEPARATOR	30 - 27	FUEL TRANSFER PUMP	30 - 26
FINAL DRIVE GEAR AND AXLE	50 - 21	FUEL TRANSFER PUMP PUSH ROD.	30 - 26
FINAL DRIVE HOUSING, SHAFTS AND BEARINGS	50 - 22	FUSE AND RELAY BLOCK	40 - 44
FINGER GRATES, BASKET LID	160 - 14	FUSE BLOCK, CHASSIS WIRING	40 - 38
FIRE EXTINGUISHER	80 - 26	FUSES AND RELAYS, CONSOLE	40 - 10
FLANGE, PICKER BAR DRUM, IN-LINE (101 - 2000)	125 - 16	FUSES, RELAYS AND CIRCUIT BREAKERS	40 - 38
FLANGE, PICKER BAR DRUM, PRO-12 - 18S (2001 -)	120 - 18		
FLAP, DOFFER, IN-LINE (101 - 2000)	115 - 4	G	
FLAP, DOFFER, PRO-12 - 18S (2001 -)	110 - 4	GASKET SET, CYLINDER HEAD REMOVAL.	20 - 56
FLOOR CONNECTORS, CAB ELECTRICAL	40 - 41	GASKET SET, ENGINE MAJOR OVERHAUL	20 - 54
FLOOR MAT.	90 - 18	GASKET SET,IN CHASSIS OVERHAUL.	20 - 56
FLOOR SWITCH CONNECTOR, MOMENTARY	40 - 45	GASKET, CYLINDER HEAD	20 - 34
FLOOR, COTTON BASKET	160 - 10	GASKET, OIL PAN (ENGINE)	20 - 26
FLOOR, PLATFORM	90 - 1	GASKET, TIMING GEAR COVER (ENG. SER. NO. 900552-)	20 - 12
FLUID, TRANSMISSION	50 - 9	GASKET, TIMING GEAR COVER (ENG.SER.NO.-900551)	20 - 10
FLUSH WATER LINES AND FITTINGS	140 - 12	GASKET,EXHAUST MANIFOLD	30 - 10
FLYWHEEL HOUSING	20 - 53	GASKET,OIL PAN	20 - 28
FLYWHEEL RING GEAR	20 - 52	GASKET,PLASTIC	20 - 18
FLYWHEEL SHIELD (EUROPE)	20 - 6	GASKET,ROCKER ARM COVER.	20 - 8
FLYWHEEL, ENGINE.	20 - 52	GAUGE CLUSTER CONNECTOR	40 - 42
FOOT CONTROL SWITCH, COMPACTOR	40 - 7	GAUGE, WATER	140 - 1
FORK, SHIFT, TRANSMISSION UNIT DRIVE SHAFT.	50 - 17	GAUGES, DOFFER, IN-LINE (101-2000)	125 - 27
FRAME WEIGHTS	80 - 8	GAUGES, DOFFER, PRO-12 - 18S (2001 -)	120 - 25
FRAME, BASKET LID	160 - 12	GAUGES, MONITOR	40 - 24
FRAME, MAIN	80 - 1	GEAR AND AXLE, FINAL DRIVE.	50 - 21
FRAME, PICKING UNIT BOTTOM, IN-LINE (101 - 2000)	115 - 8	GEAR CASE HUB, LOWER, IN-LINE (101 - 2000).	125 - 8
FRAME, PICKING UNIT BOTTOM, PRO-12 - 18S (2001 -)	110 - 8	GEAR CASE HUB, LOWER, PRO-12 - 18S (2001 -)	120 - 6
FRAME, PLATFORM	90 - 2	GEAR CASE, LH UNIT DRIVE IN-LINE (101 - 2000)	125 - 4
FRAME, UNIT LIFT ARM	100 - 2	GEAR CASE, PICKING UNIT, PRO-12 - 18S (2001 -)	120 - 4
FRONT DRUM PRESSURE PLATE, IN-LINE (101 - 2000)	115 - 12		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
GEAR CASE, RH UNIT DRIVE		HANDRAIL, PLATFORM	90 - 4
IN-LINE (101 - 2000)	125 - 6	HANGER, PICKING UNIT, IN-LINE	
GEAR DOFFER IDLER, IN-LINE		(101 - 2000)	115 - 6
(101 - 2000)	125 - 12	HANGER, PICKING UNIT, PRO-12 - 18S	
GEAR, CAMSHAFT	20 - 16	(2001 -)	110 - 6
GEAR, CRANKSHAFT	20 - 7	HARDWARE KIT, COMPRESSOR	90 - 51
GEAR, DOFFER DRIVE IDLER, IN-LINE		HARDWARE, PREFERRED METRIC	180 - 2
(101 - 2000)	125 - 26	HARDWARE, PREFERRED METRIC	180 - 3
GEAR, DOFFER DRIVE IDLER, PRO-12 - 18S		HARNESS, CAB WIRING	40 - 8
(2001 -)	120 - 24	HARNESS, CHASSIS WIRING	40 - 14
GEAR, DOFFER IDLER, PRO-12 - 18S		HARNESS, CONSOLE WIRING (PIN -2000)	40 - 18
(2001 -)	120 - 10	HARNESS, CONSOLE WIRING (PIN 2001-)	40 - 20
GEAR, DOFFER IN-LINE (101 - 2000)	125 - 22	HARNESS, ENGINE WIRING AND STARTING AID	40 - 12
GEAR, DOFFER, PRO-12 - 18S (2001 -)	120 - 20	HARNESS, PLATFORM WIRING	40 - 16
GEAR, DRUM IDLER, IN-LINE		HARNESS, ROW UNIT MONITOR WIRING	40 - 22
(101 - 2000)	125 - 10	HARNESS, TETHER SWITCH	90 - 58
GEAR, DRUM IDLER, PRO-12 - 18S		HARNESS, WIRING, FAN CONTROLLER ADAPTER	40 - 37
(2001 - 16000)	120 - 8	HARNESS, WIRING, PICKING UNIT	40 - 23
GEAR, ENGINE OIL PUMP	20 - 24	HEAD, CYLINDER	20 - 34
GEAR, FUEL INJECTION PUMP (STANADYNE)	30 - 14	HEAD, PICKER DRUM, IN-LINE	
GEAR, FUEL INJECTION PUMP DRIVE (LUCAS)	30 - 12	(101 - 2000)	125 - 14
GEAR, PICKER BAR, IN-LINE		HEAD, PICKER DRUM, PRO-12 - 18S	
(101 - 2000)	125 - 18	(2001 -)	120 - 12
GEAR, UPPER HOUSING DRUM DRIVE		HEADER, OIL FILTER	20 - 30
IN-LINE (101 - 2000)	125 - 12	HEADER, OIL FILTER	20 - 31
GEAR, UPPER HOUSING DRUM DRIVE		HEADLINER, CAB ROOF	90 - 17
PRO-12 - 18S (2001 -)	120 - 10	HEATER BLOWER (CAB)	90 - 40
GEARS, DIFFERENTIAL	50 - 14	HEATER CONTROL VALVE AND HOSES	90 - 44
GEARS, PICKER BAR, PRO-12 - 18S		HEATER CORE	90 - 46
(2001 -)	120 - 14	HEATER, AIR INTAKE	40 - 32
GEARS, SPIRAL BEVEL	50 - 16	HEATER, ENGINE COOLANT	40 - 35
GEARS, TRANSMISSION INPUT	50 - 10	HEIGHT SENSING HYDRAULIC LINES AND	
GEARS, TRANSMISSION INTERMEDIATE	50 - 12	HOSES	70 - 6
GLOW PLUG, AIR INTAKE HEATER	40 - 32	HEIGHT SENSING LINKAGE AND VALVE	
GLOW PLUG, ELECTRIC STARTING AID	40 - 6	IN-LINE (101 - 2000)	115 - 20
GRATE, BASKET LID	160 - 14	HEIGHT SENSING LINKAGE AND VALVE	
GRATE, STALKLIFTER, IN-LINE		PRO-12 - 18S (2001 -)	110 - 20
(101 - 2000)	115 - 18	HEIGHT SENSING VALVE	70 - 22
GRATE, STALKLIFTER, PRO-12 - 18S		HIGH PRESSURE SWITCH, A/C	90 - 48
(2001 -)	110 - 18	HOLDER, MOISTENER PAD,	
GREASE CHIME CONNECTOR	40 - 48	IN-LINE (-2000)	140 - 16
GREASE MANIFOLD	130 - 8	HOLDER, MOISTENER PAD,	
GREASE PUMP	130 - 4	PRO-12 - 18S (2001-)	140 - 14
GREASE TANK	130 - 2	HOOD BRACE	20 - 45
GREEN FLUSH WATER LINES	140 - 12	HOOD SCREENS, REAR	80 - 4
GRID BARS AND SUPPORTS, PICKING UNIT		HOOD, BASKET LID OPENING	160 - 12
IN-LINE (101 - 2000)	115 - 10	HOOD, ENGINE	80 - 2
GRID BARS AND SUPPORTS, PICKING UNIT		HORN	40 - 27
PRO-12 - 18S (2001 -)	110 - 10	HORN CONNECTOR, 3-SECOND AND PULSING	40 - 48
GROMMETS, UNIT CABINET, PRO-12 - 18S		HORN SWITCH	40 - 2
(2001 -)	110 - 24	HOSE, AIR	150 - 7
GUIDE, PLANT, IN-LINE		HOSE, AIR CLEANER	30 - 2
(101 - 2000)	115 - 18	HOSE, AIR CONDITIONING CONDENSER AND	
GUIDE, PLANT, PRO-12 - 18S		DRYER	90 - 48
(2001 -)	110 - 18	HOSE, AIR CONDITIONING EVAPORATOR	90 - 46
		HOSE, AUGER COMPACTOR HYDRAULIC	70 - 12
H		HOSE, BASKET LIFT HYDRAULIC	70 - 10
HANDBRAKE LEVER	60 - 13	HOSE, FLUSH WATER, GREEN	140 - 12
HANDLE, CAB DOOR	90 - 10	HOSE, HEATER	90 - 44
HANDLE, HYDROSTATIC CONTROL	90 - 26	HOSE, HEIGHT SENSING HYDRAULIC	70 - 6
HANDLE, UNIT DOOR, IN-LINE		HOSE, HYDRAULIC PUMP AND FILTER	70 - 4
(101 - 2000)	115 - 16	HOSE, HYDROSTATIC CIRCUIT	50 - 24
HANDLE, UNIT DOOR, PRO-12 - 18S		HOSE, HYDROSTATIC PUMP	50 - 2
(2001 -)	110 - 16	HOSE, LUBRICATION MANIFOLD	130 - 8
HANDRAIL, BASKET LID	160 - 16	HOSE, LUBRICATION SYSTEM	130 - 4
		HOSE, RADIATOR	
		(SERIAL NO. 101-3000)	20 - 1

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HOSE, RADIATOR	20 - 2	HYDROSTATIC PUMP AUXILIARY PUMP MOUNTING . . .	50 - 36
(SERIAL NO. 4001 -)	20 - 5	HYDROSTATIC PUMP DISPLACEMENT CONTROL . . .	50 - 32
HOSE, RADIATOR COOLANT RESERVOIR.	60 - 6	HYDROSTATIC PUMP DRIVE	50 - 1
HOSE, STEERING HYDRAULIC.	130 - 6	HYDROSTATIC PUMP END CAP.	50 - 34
HOSE, UNIT LUBRICATION.	70 - 14	HYDROSTATIC PUMP HOUSING, SWASHPLATE	
HOSE, VANE COMPACTOR HYDRAULIC.	20 - 32	AND CYLINDER BLOCK	50 - 26
HOSE, VENTILATION SYSTEM	140 - 10	HYDROSTATIC PUMP SHAFT AND SERVO ASSY.	50 - 28
HOSE, WATER, MOISTENER COLUMN (CLEAR)	150 - 2	HYDROSTATIC PUMP VALVES, PLUGS AND SEALS.	50 - 30
HOUSING, FAN	20 - 50		
HOUSING, FAN DRIVE	50 - 22	I	
HOUSING, FINAL DRIVE	20 - 53	IDLER GEAR, DOFFER DRIVE, IN-LINE	
HOUSING, FLYWHEEL	50 - 26	(101 - 2000).	125 - 26
HOUSING, HYDROSTATIC PUMP	90 - 20	IDLER GEAR, DOFFER DRIVE, PRO-12 - 18S	
HOUSING, MONITOR	115 - 2	(2001 -)	120 - 24
HOUSING, PICKING UNIT UPPER		IDLER GEAR, DRUM IN-LINE	
IN-LINE (101 - 2000).	110 - 2	(101 - 2000).	125 - 10
HOUSING, PICKING UNIT UPPER		IDLER GEAR, DRUM, PRO-12 - 18S	
PRO-12 - 18S (2001 -)	115 - 1	(2001 - 16000)	120 - 8
HOUSING, PICKING UNIT, IN-LINE		IDLER, COTTON FAN.	150 - 6
(101 - 2000)	50 - 18	IGNITION SWITCH AND KEY	40 - 10
HOUSING, TRANSMISSION	120 - 20	IMPELLER, WATER PUMP	140 - 7
HOUSING, UPPER DOFFER ADJUSTING		IMPELLER, WATER PUMP	
PRO-12 - 18S (2001 -)	125 - 22	(ENG.SER.NO.900552-)	20 - 38
HOUSING, UPPER DOFFER, ADJUSTING		IMPELLER, WATER PUMP	
IN-LINE (101 - 2000).	20 - 24	(ENG.SER.NO.-900551)	20 - 37
HOUSING, ENGINE OIL PUMP	20 - 4	IN CHASSIS OVERHAUL GASKET SET.	20 - 56
HUB, ENGINE FAN.	20 - 48	INDICATOR LIGHTS	40 - 24
HUB, FAN DRIVE	20 - 50	INLET OIL FILL	20 - 22
HUB, FAN DRIVE	125 - 8	INLET, FAN	150 - 2
HUB, LOWER GEAR CASE, IN-LINE		INLET, WATER PUMP.	20 - 36
(101 - 2000)	120 - 6	INNER ROOF AND COVERS	90 - 16
HUB, LOWER GEAR CASE, PRO-12 - 18S		INNER TUBE (EXPORT)	80 - 20
(2001 -)	80 - 20	INPUT SHAFT, TRANSMISSION	50 - 10
HUB, REAR WHEEL	70 - 1	INSIDE CAB MIRROR	90 - 55
HY-GARD HYDRAULIC OIL	70 - 20	INTAKE VALVE.	20 - 34
HYDRAULIC CONTROL VALVE	70 - 23	INTAKE, AIR	30 - 17
HYDRAULIC CYLINDER (2" X 8")		INTAKE, ENGINE OIL PUMP	20 - 24
VANE COMPACTOR.	70 - 14	INTERMEDIATE SHAFT, TRANSMISSION	50 - 12
HYDRAULIC CYLINDER AND LINES, VANE			
COMPACTOR.	70 - 3	J	
HYDRAULIC CYLINDER, CROSS AUGER LIFT	70 - 10	JACKSHAFT, UNIT DRIVE, IN-LINE	
HYDRAULIC CYLINDERS AND LINES, BASKET		(101 - 2000).	125 - 3
LIFT	70 - 6	JACKSHAFT, UNIT DRIVE, PRO-12 18S	
HYDRAULIC LINES AND HOSES, HEIGHT		(2001-)	120 - 1
SENSING	50 - 38		
HYDRAULIC MOTOR ASSY., 75 CC		K	
SAUER-SUNDSTRAND	70 - 12	KEY SWITCH CONNECTOR.	40 - 48
HYDRAULIC MOTOR, COMPACTOR	160 - 18	KEY, IGNITION.	40 - 10
HYDRAULIC MOTOR, COMPACTOR	70 - 30	KIT, COMPRESSOR HARDWARE	90 - 51
HYDRAULIC MOTOR, COMPACTOR AUGER	170 - 18	KIT, CYLINDER LINER O-RING	20 - 14
HYDRAULIC MOTOR, COMPACTOR AUGER	50 - 9	KIT, ENGINE OVERHAUL	20 - 64
HYDRAULIC MOTOR, TRANSMISSION	70 - 1	KIT, HYDRAULIC PUMP SEAL	70 - 18
HYDRAULIC OIL.	70 - 2	KIT, WATER PUMP REPAIR	
HYDRAULIC OIL COOLER AND HOSES	70 - 16	(ENG.SER.NO.900552-)	20 - 38
HYDRAULIC PUMP (45 CM3 (2.75 CU. IN.))	70 - 18	KIT, TURBOCHARGER HARDWARE	30 - 18
HYDRAULIC PUMP SEAL KIT.	70 - 4	KIT, WATER PUMP REPAIR	
HYDRAULIC PUMP, OIL FILTER, SUCTION AND		(ENG.SER.NO.-900551)	20 - 37
PRESSURE LINES	60 - 6	KNEE SPINDLE KNUCKLE, REAR AXLE	80 - 14
HYDRAULIC STEERING LINES, HOSES AND		KNUCKLE, REAR AXLE KNEE SPINDLE	80 - 14
CYLINDER	70 - 8		
HYDRAULIC SYSTEM, LUBRICATION PUMP	70 - 1		
HYDRAULIC/HYDROSTATIC RESERVOIR	40 - 42		
HYDRO HANDLE CONNECTOR.	50 - 24		
HYDROSTATIC CIRCUIT	50 - 6		
HYDROSTATIC CONTROL CABLE.	90 - 26		
HYDROSTATIC CONTROL HANDLE	50 - 2		
HYDROSTATIC PUMP			

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
L		LUG COVER, WHEEL	80 - 18
LABELS, CHASSIS.	170 - 2		
LABELS, CHASSIS.	170 - 4	M	
LABELS, CHASSIS.	170 - 6	MAIN BEARING CAP	20 - 18
LABELS, SAFETY	170 - 12	MAIN BEARINGS	20 - 7
LABELS, SAFETY	170 - 14	MAIN FRAME	80 - 1
LABELS, WARNING	170 - 14	MAIN WHEEL	80 - 17
LADDER AND HANDRAILS, PLATFORM AND BASKET	90 - 4	MANIFOLD, AIR CONDITIONING COMPRESSOR (6081HN003)	90 - 50
LADDER SUPPORT (-2036)	150 - 14	MANIFOLD, EXHAUST	30 - 10
LADDER SUPPORT (2037-)	150 - 16	MANIFOLD, LUBRICATION	130 - 8
LAMP, FIELD	90 - 57	MANIFOLD, UNIT LUBRICATION.	130 - 6
LAMP, WARNING (-XXXXXX)	40 - 3	MASTER CYLINDER, BRAKE	60 - 8
LAMP, WARNING (XXXXXX-)	40 - 4	MAT	90 - 18
LATCH, CAB DOOR	90 - 10	MDC KIT, HYDROSTATIC PUMP	50 - 32
LATCH, MOISTENER COLUMN, IN-LINE (-2000)	140 - 16	MICROSWITCH CONNECTOR	40 - 47
LATCH, MOISTENER COLUMN, PRO-12 - 18S (2001-)	140 - 14	MIRROR BRACKETS, REAR VIEW.	90 - 56
LEVELER ASSY., HYDROSTATIC PUMP	50 - 28	MIRROR, REAR VIEW (INSIDE AND OUTSIDE)	90 - 55
LEVER, CONSOLE CONTROL	90 - 24	MODULE, DIODE	40 - 43
LEVER, HANDBRAKE	60 - 13	MODULE, MONITOR LIGHT.	40 - 46
LEVER, HEIGHT SENSING LINKAGE IN-LINE (101 - 2000)	115 - 20	MOISTENER COLUMN WATER LINES (CLEAR)	140 - 10
LEVER, HEIGHT SENSING LINKAGE PRO-12 - 18S (2001-)	110 - 20	MOISTENER COLUMN WATER LINES, FLUSH (GREEN)	140 - 12
LID FRAME, BASKET	160 - 12	MOISTENER COLUMN, IN-LINE (-2000)	140 - 16
LID GRATES, SCREENS AND FINGERS	160 - 14	MOISTENER COLUMN, PRO-12 - 18S (2001-)	140 - 14
LID LINKAGE, BASKET.	160 - 1	MOMENTARY FLOOR SWITCH CONNECTOR	40 - 45
LIFT ARM AND FRAME, UNIT.	100 - 2	MONITOR ASSEMBLY	90 - 20
LIFT BRACKET, HYDROSTATIC PUMP.	50 - 34	MONITOR GAUGES	40 - 24
LIFT HYDRAULICS, BASKET	70 - 10	MONITOR LIGHT MODULES AND TACHOMETER CONNECTORS	40 - 46
LIFT STRAPS, ENGINE.	20 - 45	MONITOR, ROW UNIT	40 - 22
LIGHT BAR	90 - 57	MOTOR ASSY., HYDRAULIC, SAUER-SUNDSTRAND 75 CC	50 - 38
LIGHT, DOME (ROCKER TYPE)	40 - 26	MOTOR, COMPACTOR	160 - 18
LIGHT, FIELD	90 - 57	MOTOR, COMPACTOR AUGER	70 - 12
LIGHTS, INDICATOR	40 - 24	MOTOR, COMPACTOR AUGER HYDRAULIC	70 - 30
LINE, BRAKE	60 - 10	MOTOR, COMPACTOR AUGER HYDRAULIC	170 - 18
LINE, TURBOCHARGER OIL	30 - 20	MOTOR, HYDROSTATIC	50 - 24
LINE, UNIT LUBRICATION	130 - 6	MOTOR, STARTER.	40 - 28
LINE, WATER, MOISTENER COLUMN (CLEAR).	140 - 10	MOTOR, TRANSMISSION HYDRAULIC.	50 - 9
LINER, CYLINDER.	20 - 14	MOTOR, WINDSHIELD WIPER	90 - 54
LINES, FUEL INJECTION (LUCAS)	30 - 12	MOUNTING FLANGE, AUXILIARY, HYDROSTATIC PUMP	50 - 36
LINES, FUEL INJECTION (STANADYNE)	30 - 14	MOUNTING STRAPS, HYDROSTATIC PUMP	50 - 2
LINKAGE, BASKET LID.	160 - 1	MUD SCRAPERS	80 - 21
LINKAGE, COTTON FAN IDLER	150 - 6		
LINKAGE, HEIGHT SENSING, IN-LINE (101 - 2000)	115 - 20	N	
LINKAGE, HEIGHT SENSING, PRO-12 - 18S (2001 -)	110 - 20	NEUTRAL START SAFETY SWITCH	50 - 32
LOW PRESSURE SWITCH, A/C	90 - 46	NOZZLE, AIR TUBES AND DUCTS.	150 - 9
LOWER GEAR CASE HUB IN-LINE (101 - 2000)	125 - 8	NOZZLE, FUEL INJECTION	30 - 11
LOWER GEAR CASE HUB, PRO-12 - 18S (2001 -).	120 - 6	NOZZLE, TRANSITION JET POST	150 - 7
LUBE PUMP, TRANSMISSION	50 - 10	NOZZLE, UNIT TO BASKET DUCT.	150 - 12
LUBRICANT, TRANSMISSION.	50 - 9		
LUBRICATION MANIFOLD	130 - 8	O	
LUBRICATION PUMP	130 - 14	OIL COOLER, ENGINE	20 - 42
LUBRICATION PUMP AND SYSTEM.	130 - 4	OIL COOLER, HYDRAULIC	70 - 2
LUBRICATION PUMP HYDRAULIC SYSTEM	70 - 8	OIL DIPSTICK (ENGINE)	20 - 23
LUBRICATION TANK AND WRAPPER	130 - 2	OIL FILL INLET	20 - 22
LUBRICATION TRANSFER PUMP	130 - 10	OIL FILLER OPENING COVER	20 - 22
LUBRICATION TRANSFER PUMP	130 - 12		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
OIL FILTER	20 - 30	PICKING UNIT GRID BARS AND SUPPORTS	
OIL FILTER	20 - 31	PRO-12 - 18S (2001 -)	110 - 10
OIL FILTER ADAPTER	20 - 30	PICKING UNIT HANGER, IN-LINE	
OIL FILTER ADAPTER	20 - 31	(101 - 2000).	115 - 6
OIL FILTER AND LINES, HYDRAULIC	70 - 4	PICKING UNIT HANGER, PRO-12 - 18S	
OIL FILTER HEADER.	20 - 30	(2001 -)	110 - 6
OIL FILTER HEADER.	20 - 31	PICKING UNIT POSTS, IN-LINE	
OIL LINES, TURBOCHARGER	30 - 20	(101 - 2000).	115 - 4
OIL PAN AND GASKET, ENGINE	20 - 26	PICKING UNIT POSTS, PRO-12 - 18S	
OIL PAN GASKET	20 - 28	(2001 -)	110 - 4
OIL PRESSURE SWITCH.	20 - 25	PICKING UNIT UPPER HOUSING, IN-LINE	
OIL RESERVOIR, HYDRAULIC/HYDROSTATIC	70 - 1	(101 - 2000).	115 - 2
OIL STRAINER, TRANSMISSION	50 - 10	PICKING UNIT UPPER HOUSING, PRO-12 - 18S	
OIL, HYDRAULIC	70 - 1	(2001 -)	110 - 2
OIL, TRANSMISSION	50 - 9	PICKING UNIT WIRING HARNESS.	40 - 23
OPERATOR'S SEAT AND BACKREST	90 - 30	PICKING UNIT, COMPLETE, IN-LINE	
ORIFICE, UNIT LUBRICATION	130 - 6	(101 - 2000).	115 - 1
OUTSIDE MIRRORS	90 - 55	PIN, REAR AXLE PIVOT	80 - 9
OVERFLOW COOLANT RESERVOIR	20 - 5	PINION, PICKING UNIT GEAR CASE	
OVERHAUL KIT, ENGINE.	20 - 64	PRO-12 - 18S (2001 -)	120 - 4
		PIPE, EXHAUST	30 - 4
P		PISTON KIT, HYDROSTATIC PUMP SERVO	50 - 28
PAD, MOISTENER,		PISTON RINGS	20 - 14
IN-LINE (-2000).	140 - 16	PISTON, ENGINE	20 - 14
PAD, MOISTENER,		PISTON, HYDROSTATIC PUMP	50 - 26
PRO-12 - 18S (2001-)	140 - 14	PIVOT SUPPORT, REAR AXLE (FRONT)	80 - 10
PAN, ENGINE OIL	20 - 26	PIVOT SUPPORT, REAR AXLE (REAR).	80 - 12
PAN, ENGINE OIL	20 - 28	PIVOT, BASKET LID	160 - 12
PANEL, AIR CONDITIONER.	90 - 42	PLANT GUIDE, IN-LINE	
PANEL, BASKET FRONT AND REAR	160 - 4	(101 - 2000).	115 - 18
PANEL, TUNNEL BOTTOM	80 - 6	PLANT GUIDE, PRO-12 - 18S	
PANELS, R.H. CAB.	90 - 8	(2001 -)	110 - 18
PARK BRAKE CABLE	60 - 14	PLASTIC GASKET	20 - 18
PARK BRAKE PEDAL	60 - 13	PLATE, ENGINE FRONT	20 - 15
PEDAL ASSEMBLY, PARK BRAKE	60 - 13	PLATE, FRONT DRUM PRESSURE, IN-LINE	
PEDAL, BRAKE	60 - 12	(101 - 2000).	115 - 12
PICKER BAR DRIVE SHAFT, IN-LINE		PLATE, FRONT DRUM PRESSURE, PRO-12 - 18S	
(101 - 2000)	125 - 18	(2001 -)	110 - 12
PICKER BAR DRUM, STUD AND BEARING		PLATE, PICKING UNIT BOTTOM FRAME	
IN-LINE (101 - 2000).	125 - 16	IN-LINE (101 - 2000)	115 - 8
PICKER BAR DRUM, STUD AND BEARING		PLATE, PICKING UNIT BOTTOM FRAME	
PRO-12 - 18S (2001 -)	120 - 18	PRO-12 - 18S (2001 -)	110 - 8
PICKER BAR JOURNAL, IN-LINE		PLATE, REAR DRUM PRESSURE, IN-LINE	
(101 - 2000)	125 - 14	(101 - 2000).	115 - 14
PICKER BAR JOURNAL, PRO-12 - 18S		PLATE, REAR DRUM PRESSURE, PRO-12 - 18S	
(2001 -)	120 - 12	(2001 -)	110 - 14
PICKER BAR SPINDLE DRIVE SHAFT,		PLATFORM AND SKIRTS	90 - 1
PRO-12 - 18S (2001-)	120 - 14	PLATFORM FRAME	90 - 2
PICKER BAR, SPINDLE AND WRENCH		PLATFORM HANDRAILS AND LADDERS.	90 - 4
IN-LINE (101 - 2000).	125 - 20	PLATFORM WIRING HARNESS	40 - 16
PICKER BAR, SPINDLE AND WRENCH		PLUG,ENGINE OIL FILL	20 - 8
PRO-12 - 18S (2001 -)	120 - 16	PLUGS AND SEALS, HYDROSTATIC PUMP.	50 - 30
PICKER DRUM HEAD AND CAM, IN-LINE		PLUGS, UNIT CABINET, PRO-12 - 18S	
(101 - 2000)	125 - 14	(2001 -)	110 - 24
PICKER DRUM HEAD AND CAM, PRO-12 - 18S		POINT, STALKLIFTER, IN-LINE	
(2001 -)	120 - 12	(101 - 2000).	115 - 18
PICKING UNIT BOTTOM FRAME, IN-LINE		POINT, STALKLIFTER, PRO-12 - 18S	
(101 - 2000)	115 - 8	(2001 -)	110 - 18
PICKING UNIT BOTTOM FRAME, PRO-12 - 18S		POPPET, HYDROSTATIC PUMP	50 - 30
(2001 -)	110 - 8	POST, STEERING	60 - 2
PICKING UNIT GEAR CASE, PRO-12 - 18S		POSTS, PICKING UNIT, IN-LINE	
(2001 -)	120 - 4	(101 - 2000).	115 - 4
PICKING UNIT GRID BARS AND SUPPORTS		POSTS, PICKING UNIT, PRO-12 - 18S	
IN-LINE (101 - 2000).	115 - 10	(2001 -)	110 - 4
		POWER STEERING VALVE	60 - 4
		PRE-CLEANER	30 - 4
		PREFERRED METRIC HARDWARE	180 - 2

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
PREFERRED METRIC HARDWARE	180 - 3	RADIO, ANTENNA AND SPEAKERS	40 - 36
PRESSURE PLATE, FRONT DRUM, IN-LINE (101 - 2000)	115 - 12	RADIUS GAUGES, DOFFER, IN-LINE (101-2000)	125 - 27
PRESSURE PLATE, FRONT DRUM, PRO-12 - 18S (2001 -)	110 - 12	RADIUS GAUGES, DOFFER, PRO-12 - 18S (2001 -)	120 - 25
PRESSURE PLATE, REAR DRUM IN-LINE (101 - 2000)	115 - 14	RAIL AND SHIFTER, TRANSMISSION HOUSING	50 - 18
PRESSURE PLATE, REAR DRUM PRO-12 -18S (2001 -)	110 - 14	REAR AXLE CENTER	80 - 9
PRESSURIZER BLOWER (CAB)	90 - 40	REAR AXLE FRONT PIVOT SUPPORT	80 - 10
PULLEY, A/C COMPRESSOR	90 - 53	REAR AXLE KNEE SPINDLE KNUCKLE	80 - 14
PULLEY, FAN DRIVE	20 - 48	REAR AXLE REAR PIVOT SUPPORT	80 - 12
PULLEY, FAN DRIVE	20 - 50	REAR AXLE TIE RODS	80 - 16
PULLEY, IDLER	20 - 46	REAR DRUM PRESSURE PLATE, IN-LINE (101 - 2000)	115 - 14
PULLEY, TENSIONER	20 - 48	REAR DRUM PRESSURE PLATE, PRO-12 - 18S (2001 -)	110 - 14
PULLEY, TENSIONER	20 - 50	REAR HOOD SCREENS AND RADIATOR SUPPORTS	80 - 4
PULLEY, UNIT DRIVE, IN-LINE (101 - 2000)	125 - 3	REAR OIL SEAL, CRANKSHAFT	20 - 53
PULLEY, UNIT DRIVE, PRO-12 18S (2001-)	120 - 1	REAR VIEW MIRROR BRACKETS	90 - 56
PULLEY, WATER PUMP	20 - 36	REAR VIEW MIRRORS	90 - 55
PULLEY, WATER PUMP	140 - 6	REAR WHEEL	80 - 20
PULLEY, ALTERNATOR	40 - 34	RECEIVER-DRYER, AIR CONDITIONING	90 - 48
PULLEY, CRANKSHAFT	20 - 44	REFLECTORS	170 - 6
PUMP DISPLACEMENT CONTROL, HYDROSTATIC	50 - 32	RELAY AND FUSE BLOCK	40 - 44
PUMP DRIVE, HYDROSTATIC	50 - 1	RELAY, ELECTRIC STARTING AID	40 - 6
PUMP END CAP, HYDROSTATIC	50 - 34	RELAYS AND CIRCUIT BREAKERS	40 - 38
PUMP FITTINGS AND SUPPORT, WATER	140 - 6	RELAYS AND FUSES, CONSOLE	40 - 10
PUMP HOUSING, SWASHPLATE AND CYLINDER BLOCK, HYDROSTATIC	50 - 26	RESERVOIR, BRAKE	60 - 10
PUMP LINES AND HOSES, HYDRAULIC	70 - 4	RESERVOIR, COOLANT OVERFLOW	20 - 5
PUMP MOUNTING, AUX. PUMP TO HYDROSTATIC PUMP	50 - 36	RESERVOIR, HYDRAULIC/HYDROSTATIC	70 - 1
PUMP SHAFT AND LEVELER ASSY., HYDROSTATIC	50 - 28	RESISTOR, BLOWER (CAB)	40 - 8
PUMP VALVES, HYDROSTATIC	50 - 30	RING GEAR, FLYWHEEL	20 - 52
PUMP, ENGINE OIL	20 - 24	RING, REAR WHEEL BOLT	80 - 20
PUMP, FUEL INJECTION (LUCAS)	30 - 12	RINGS, PISTON	20 - 14
PUMP, FUEL INJECTION (STANADYNE)	30 - 14	ROCKER ARM COVER	20 - 8
PUMP, FUEL TRANSFER	30 - 26	ROCKER ARM COVER GASKET	20 - 8
PUMP, HYDRAULIC (45 CM3 (2.75 CU. IN.))	70 - 16	ROCKER ARMS AND SHAFT	20 - 9
PUMP, HYDROSTATIC	50 - 2	ROCKSHAFT PIVOT LUBRICATION LINES	160 - 22
PUMP, HYDROSTATIC	50 - 24	ROD, CONNECTING	20 - 14
PUMP, LUBRICATION	70 - 8	ROD, HEIGHT SENSING LINKAGE IN-LINE (101 - 2000)	115 - 20
PUMP, LUBRICATION	130 - 4	ROD, HEIGHT SENSING LINKAGE PRO-12 - 18S (2001 -)	110 - 20
PUMP, LUBRICATION	130 - 14	ROD, PUSH	20 - 9
PUMP, LUBRICATION TRANSFER	130 - 10	RODS, STALKLIFTER, IN-LINE (101 - 2000)	115 - 22
PUMP, LUBRICATION TRANSFER	130 - 12	RODS, STALKLIFTER, PRO-12 - 18S (2001 -)	110 - 22
PUMP, TRANSMISSION LUBE	50 - 10	ROLLER, PICKING UNIT HANGER IN-LINE (101 - 2000)	115 - 6
PUMP, WATER	140 - 7	ROLLER, PICKING UNIT HANGER PRO-12 - 18S (2001 -)	110 - 6
PUMP, WATER (ENG. SER. NO. 900552-)	20 - 38	ROOF, CAB	90 - 14
PUMP, WATER (ENG. SER. NO. -900551)	20 - 37	ROOF, INNER	90 - 16
PUSH ROD, FUEL TRANSFER PUMP	30 - 26	ROTOR, FAN (COTTON)	150 - 4
PUSH RODS	20 - 9	ROW UNIT MONITOR	40 - 22
 R 		 S 	
R.H. CAB PANELS AND WINDOW HINGE	90 - 8	SADDLE, WATER TANK.	140 - 2
RADIATOR AND HOSES (SERIAL NO. 101-3000)	20 - 1	SAFETY LABELS	170 - 12
RADIATOR AND HOSES (SERIAL NO. 4001-)	20 - 2	SAFETY LABELS	170 - 14
RADIATOR COOLANT RESERVOIR	20 - 5	SAFETY SWITCH, NEUTRAL START	50 - 32
RADIATOR SUPPORTS	80 - 4	SCRAPER, FRONT DRUM PRESSURE PLATE IN-LINE (101 - 2000)	115 - 12
		SCRAPER, FRONT DRUM PRESSURE PLATE PRO-12 - 18S (2001 -)	110 - 12

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
SCRAPER, MUD	80 - 21	SHAFT, UNIT DRIVE, IN-LINE	
SCREEN AND TUBE, TRANSMISSION OIL	50 - 10	(101 - 2000)	125 - 1
SCREEN, BASKET FRONT AND REAR	160 - 4	SHAFT, UNIT DRIVE, PRO-12 - 18S	
SCREEN, BASKET LID	160 - 14	(2001-)	120 - 2
SCREEN, BASKET RIGHT SIDE	160 - 8	SHAFT, UPPER DOFFER ADJUSTING	
SCREEN, CONTROL FILTER, HYDROSTATIC		IN-LINE (101 - 2000)	125 - 22
PUMP	50 - 30	SHAFT, UPPER DOFFER ADJUSTING	
SCREEN, ENGINE	80 - 2	PRO-12 - 18S (2001 -)	120 - 20
SCREEN, REAR HOOD	80 - 4	SHAFT, UPPER HOUSING DRUM DRIVE GEAR	
SEAL KIT, COMPRESSOR	90 - 52	DRIVE, IN-LINE (101 - 2000)	125 - 12
SEAL KIT, HYDRAULIC PUMP	70 - 18	SHAFT, UPPER HOUSING DRUM DRIVE GEAR	
SEALANT, GREEN	80 - 4	PRO-12 - 18S (2001 -)	120 - 10
SEAT	90 - 30	SHEAVE, FAN (COTTON)	150 - 4
SEAT ADJUSTMENT AND COVER	90 - 34	SHEAVE, TRANSMISSION UNIT DRIVE SHAFT	50 - 17
SEAT ARMREST LINKS		SHEAVE, UNIT DRIVE, IN-LINE	
(PERSONAL-POSTURE™ SEAT)	90 - 32	(101 - 2000)	125 - 3
SEAT ASSEMBLY	90 - 28	SHEAVE, UNIT DRIVE, PRO-12 18S	
SEAT BELT	90 - 30	(2001-)	120 - 1
SEAT SUSPENSION	90 - 36	SHEAVE, WATER PUMP	140 - 6
SEAT SUSPENSION SUPPORT	90 - 38	SHELL, PICKING UNIT, IN-LINE	
SENDER, FUEL	30 - 6	(101 - 2000)	115 - 1
SENDER, LUBRICATION PRESSURE	130 - 8	SHIELD, ENGINE FAN BELT	20 - 6
SENDING UNIT, OIL PRESSURE	20 - 25	SHIELD, FLYWHEEL (EUROPE)	20 - 6
SENSOR, DIFFERENTIAL	50 - 14	SHIELD, FRONT WHEEL, LH	80 - 24
SENSOR, DRUM SPEED, PRO-12 - 18S		SHIELD, FRONT WHEEL, RH	80 - 22
(2001 -)	120 - 10	SHIELD, PICKING UNIT GEAR CASE	
SENSOR, FAN	150 - 4	PRO-12 - 18S (2001 -)	120 - 4
SENSOR, TACHOMETER	40 - 33	SHIELD, STALKLIFTER, IN-LINE	
SENSOR, WATER PRESSURE	140 - 4	(101 - 2000)	115 - 18
SEPARATOR, WATER	30 - 27	SHIELD, STALKLIFTER, PRO-12 - 18S	
SERVO ASSY., HYDROSTATIC PUMP	50 - 28	(2001 -)	110 - 18
SHAFT, DOFFER, IN-LINE (101 -2000)	125 - 24	SHIELD, TUNNEL BOTTOM	80 - 6
SHAFT, DOFFER, PRO-12 - 18S (2001 -)	120 - 22	SHIFT CABLE, TRANSMISSION	50 - 4
SHAFT, DRUM SLIP CLUTCH AND IDLER GEARS		SHIFT LEVERS, CONSOLE	90 - 24
IN-LINE (101 - 2000)	125 - 10	SHIFTER AND RAIL, TRANSMISSION HOUSING	50 - 18
SHAFT, DRUM SLIP CLUTCH AND IDLER GEARS		SHIFTER FORK, TRANSMISSION UNIT DRIVE	
PRO-12 - 18S (2001 -16000)	120 - 8	SHAFT	50 - 17
SHAFT, FAN (COTTON)	150 - 4	SHOE, BRAKE	60 - 16
SHAFT, FINAL DRIVE	50 - 22	SHOE, HEIGHT SENSING, IN-LINE	
SHAFT, HEIGHT SENSING LINKAGE		(101 - 2000)	115 - 20
IN-LINE (101 - 2000)	115 - 20	SHOE, HEIGHT SENSING, PRO-12 - 18S	
SHAFT, HEIGHT SENSING LINKAGE		(2001 -)	110 - 20
PRO-12 - 18S (2001 -)	110 - 20	SHOE, STALKLIFTER POINT, IN-LINE	
SHAFT, HYDROSTATIC CHARGE PUMP	50 - 36	(101 - 2000)	115 - 18
SHAFT, HYDROSTATIC PUMP	50 - 28	SHOE, STALKLIFTER POINT, PRO-12 - 18S	
SHAFT, LH UNIT DRIVE GEAR CASE		(2001 -)	110 - 18
IN-LINE (101 - 2000)	125 - 4	SHORT BLOCK, ENGINE	20 - 20
SHAFT, LOWER GEAR CASE HUB		SIGNS, CHASSIS	170 - 2
IN-LINE (101 - 2000)	125 - 8	SIGNS, CHASSIS	170 - 4
SHAFT, LOWER GEAR CASE HUB		SIGNS, SAFETY	170 - 12
PRO-12 - 18S (2001 -)	120 - 6	SKIRT, PLATFORM	90 - 1
SHAFT, PICKER BAR, IN-LINE		SLAVE CYLINDER, BRAKE	60 - 18
(101 - 2000)	125 - 18	SLIP CLUTCH AND IDLER GEARS, DRUM	
SHAFT, PICKER BAR, PRO-12 - 18S		IN-LINE (101 - 2000)	125 - 10
(2001-)	120 - 14	SLIP CLUTCH AND IDLER GEARS, DRUM	
SHAFT, PICKING UNIT GEAR CASE		PRO-12 - 18S (2001 -16000)	120 - 8
PRO-12 - 18S (2001 -)	120 - 4	SLIP CLUTCH, LOWER GEAR CASE HUB	
SHAFT, RH UNIT DRIVE GEAR CASE		IN-LINE (101 - 2000)	125 - 8
IN-LINE (101 - 2000)	125 - 6	SLIP CLUTCH, LOWER GEAR CASE HUB	
SHAFT, ROCKER ARM	20 - 9	PRO-12 - 18S (2001 -)	120 - 6
SHAFT, TRANSMISSION INPUT	50 - 10	SMV EMBLEM	170 - 6
SHAFT, TRANSMISSION INTERMEDIATE	50 - 12	SOCKET, GAUGE CLUSTER WIRING	40 - 42
SHAFT, TRANSMISSION UNIT DRIVE	50 - 17	SOCKET, HYDRO HANDLE WIRING	40 - 42
SHAFT, UNIT DRIVE JACKSHAFT		SOLENOID VALVE	
IN-LINE (101 - 2000)	125 - 3	(-16001)	70 - 26
SHAFT, UNIT DRIVE JACKSHAFT		SOLENOID VALVE	
PRO-12 18S (2001-)	120 - 1	(16001-)	70 - 27

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
SOLENOID, HYDRAULIC CONTROL VALVE	70 - 20	SUN GEAR, PICKING UNIT UPPER HOUSING	
SOLENOID, STARTER	40 - 28	IN-LINE (101 -2000)	125 - 12
SOUND-GARD® CAB.	90 - 6	SUN GEAR, PICKING UNIT UPPER HOUSING	
SPEAKERS, ANTENNA AND RADIO	40 - 36	PRO-12 - 18S (2001 -)	120 - 10
SPINDLE CLEANER SOLUTION.	140 - 2	SUPPORT, BASKET	160 - 2
SPINDLE MOISTENER COLUMN,		SUPPORT, CAB ROOF	90 - 14
IN-LINE (-2000)	140 - 16	SUPPORT, DUCT AND LADDER (-2036)	150 - 14
SPINDLE MOISTENER COLUMN,		SUPPORT, DUCT AND LADDER (2037-)	150 - 16
PRO-12 - 18S (2001-)	140 - 14	SUPPORT, ENGINE	20 - 6
SPINDLE WETTING AGENT	140 - 2	SUPPORT, FAN	150 - 2
SPINDLE, PICKER BAR, IN-LINE		SUPPORT, HYDROSTATIC PUMP	50 - 2
(101 - 2000)	125 - 20	SUPPORT, MOISTENER COLUMN,	
SPINDLE, PICKER BAR, PRO-12 - 18S		IN-LINE (-2000)	140 - 16
(2001 -)	120 - 16	SUPPORT, MOISTENER COLUMN,	
SPINDLE, REAR AXLE	80 - 14	PRO-12 - 18S (2001-)	140 - 14
SPIRAL BEVEL GEARS AND BEARINGS.	50 - 16	SUPPORT, REAR AXLE PIVOT (FRONT)	80 - 10
SPRING, BRAKE SHOE	60 - 16	SUPPORT, REAR AXLE PIVOT (REAR)	80 - 12
SPRING, DRUM SLIP CLUTCH, IN-LINE		SUPPORT, SEAT SUSPENSION	90 - 38
(101 - 2000)	125 - 10	SUPPORT, STEERING POST	60 - 2
SPRING, DRUM SLIP CLUTCH, PRO-12 - 18S		SUPPORT, WATER PUMP.	140 - 6
(2001 -16000)	120 - 8	SUSPENSION, SEAT	90 - 36
SPRING, LOWER GEAR CASE HUB		SWASHPLATE, HYDROSTATIC PUMP	50 - 26
IN-LINE (101 - 2000)	125 - 8	SWITCH AND HARNESS, TETHER	90 - 58
SPRING, LOWER GEAR CASE HUB		SWITCH CONNECTOR, CONSOLE	40 - 49
PRO-12 - 18S (2001 -)	120 - 6	SWITCH CONNECTOR, MOMENTARY FLOOR	40 - 45
SPUR GEAR, DRUM IDLER, IN-LINE		SWITCH, A/C HIGH PRESSURE	90 - 48
(101 - 2000)	125 - 10	SWITCH, A/C LOW PRESSURE	90 - 46
SPUR GEAR, DRUM IDLER, PRO-12 - 18S		SWITCH, CAB WIPER	40 - 8
(2001 -16000)	120 - 8	SWITCH, COMPACTOR FOOT CONTROL	40 - 7
SPUR GEAR, LOWER GEAR CASE HUB		SWITCH, DIMMER	40 - 5
IN-LINE (101 - 2000)	125 - 8	SWITCH, HORN	40 - 2
SPUR GEAR, LOWER GEAR CASE HUB		SWITCH, IGNITION	40 - 10
PRO-12 - 18S (2001 -)	120 - 6	SWITCH, LUBRICATION PRESSURE.	130 - 4
STABILIZER, TOP LINK.	100 - 1	SWITCH, LUBRICATION PRESSURE.	130 - 8
STALKLIFTER RODS, IN-LINE		SWITCH, NEUTRAL START SAFETY	50 - 32
(101 - 2000)	115 - 22	SWITCH, OIL PRESSURE.	20 - 25
STALKLIFTER RODS, PRO-12 - 18S		SWITCH, PARK BRAKE.	60 - 13
(2001 -)	110 - 22	SWITCH, TRANSMISSION SAFETY	50 - 18
STALKLIFTERS, EXTENSION AND GRATE		SWITCH,FUEL INJECTION PUMP COLD	
IN-LINE (101 - 2000)	115 - 18	ADVANCE	30 - 16
STALKLIFTERS, EXTENSION AND GRATE		SWITCHES, AIR CONDITIONER.	90 - 42
PRO-12 - 18S (2001 -)	110 - 18	SWITCHES, CONSOLE CONTROL PANEL	40 - 10
STARTER	40 - 28	SYSTEM, FUEL INJECTION (LUCAS)	30 - 12
STARTER SWITCH AND KEY	40 - 10	SYSTEM, FUEL INJECTION (STANADYNE)	30 - 14
STARTING AID WIRING HARNESS	40 - 12		
STEERING ARM, REAR AXLE	80 - 16	T	
STEERING COLUMN AND STEERING WHEEL	60 - 1	TACHOMETER.	40 - 24
STEERING CYLINDER	70 - 24	TACHOMETER CONNECTOR	40 - 46
STEERING LINES AND CYLINDERS.	60 - 6	TACHOMETER SENSOR	40 - 33
STEERING POST AND SUPPORT.	60 - 2	TANK, FUEL	30 - 6
STEERING VALVE	60 - 4	TANK, HYDRAULIC OIL	70 - 1
STEP, BASKET LID	160 - 16	TANK, LUBRICATION	130 - 2
STOP LIGHT, MONITOR	40 - 24	TANK, WATER	140 - 2
STRAINER, GREASE	130 - 8	TEE FITTING, INJECTION NOZZLE	30 - 11
STRAINER, MOISTENER COLUMN,		TEMPERATURE GAUGE, ENGINE	40 - 24
IN-LINE (-2000)	140 - 16	TENSIONER, BELT IDLER	20 - 48
STRAINER, MOISTENER COLUMN,		TENSIONER, BELT IDLER	20 - 50
PRO-12 - 18S (2001-)	140 - 14	TERMINAL, CAB FLOOR CONNECTORS.	40 - 41
STRAP, ALTERNATOR	40 - 30	TERMINAL, CONSOLE SWITCH CONNECTOR	40 - 49
STRAP, FUEL TANK	30 - 6	TERMINAL, FAN CONTROLLER CONNECTOR	40 - 40
STRAP, HYDRO CONTROL	50 - 2	TERMINAL, FLOOR SWITCH CONNECTOR	40 - 45
STRAP, REAR VIEW MIRROR.	90 - 56	TERMINAL, FUSE AND RELAY BLOCK.	40 - 44
STUD, PICKER BAR DRUM, IN-LINE		TERMINAL, HYDRO HANDLE AND GAUGE CLUSTER	
(101 - 2000)	125 - 16	CONNECTORS	40 - 42
STUD, PICKER BAR DRUM, PRO-12 - 18S			
(2001 -)	120 - 18		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
TERMINAL, KEY SWITCH, CONSOLE LIGHT, ETHER SWITCH & WARNING HORN CONNECTORS	40 - 48	UNIT DRIVE, IN-LINE (101 - 2000)	125 - 1
TERMINAL, MICROSWITCH AND AUXILIARY PLUG CONNECTORS	40 - 47	UNIT DRIVE, PRO-12 - 18S (2001 -)	120 - 2
TERMINAL, MONITOR LIGHT MODULE AND TACHOMETER CONNECTORS	40 - 46	UNIT GRID BARS AND SUPPORTS IN-LINE (101 - 2000)	115 - 10
TETHER SWITCH AND HARNESS	90 - 58	UNIT GRID BARS AND SUPPORTS PRO-12 - 18S (2001 -)	110 - 10
THERMOSTAT	20 - 40	UNIT HANGER, IN-LINE (101 - 2000)	115 - 6
THERMOSTAT COVER	20 - 40	UNIT HANGER, PRO-12 - 18S (2001 -)	110 - 6
THERMOSTAT COVER TUBE	20 - 40	UNIT LIFT ARM AND FRAME	100 - 2
THERMOSTAT, AIR CONDITIONING	90 - 46	UNIT LUBRICATION MANIFOLD AND FITTINGS.	130 - 6
THROTTLE CONTROL CABLE	30 - 8	UNIT SHIFT CABLE	50 - 5
THROTTLE LEVER	90 - 24	UNIT SHIFT LEVER	90 - 24
TIE RODS, REAR AXLE	80 - 16	UNIT TO BASKET DUCTS.	150 - 12
TIMING GEAR COVER (ENG. SER. NO. 900552-)	20 - 12	UNIT UPPER HOUSING, IN-LINE (101 - 2000)	115 - 2
TIMING GEAR COVER (ENG.SER.NO.-900551)	20 - 10	UNIT UPPER HOUSING, PRO-12 - 18S (2001 -)	110 - 2
TIMING GEAR COVER GASKET (ENG.SER.NO.-900551)	20 - 10	UNIT, COMPLETE REPAIR, IN-LINE (101 - 2000)	115 - 1
TONE WHEEL, FAN	150 - 4	UNIVERSAL JOINT, CROSS SHAFT IN-LINE (101 - 2000)	125 - 2
TOP LINK STABILIZER	100 - 1	UNIVERSAL JOINT, CROSS SHAFT PRO-12 - 18S (2001 -)	120 - 3
TRANSFER PUMP, LUBRICATION	130 - 10	UNIVERSAL JOINT, HYDROSTATIC PUMP DRIVE.	50 - 1
TRANSFER PUMP, LUBRICATION	130 - 12	UNIVERSAL JOINT, UNIT DRIVE SHAFT IN-LINE (101 - 2000)	125 - 1
TRANSMISSION AND MOTOR	50 - 9	UNIVERSAL JOINT, UNIT DRIVE SHAFT PRO-12 - 18S (2001-)	120 - 2
TRANSMISSION BRACKETS	50 - 8	UPHOLSTERY, CAB REAR	90 - 12
TRANSMISSION CASE	50 - 18	UPPER DOFFER ADJUSTING HOUSING IN-LINE (101 - 2000)	125 - 22
TRANSMISSION DIFFERENTIAL	50 - 14	UPPER DOFFER ADJUSTING HOUSING PRO-12 - 18S (2001 -)	120 - 20
TRANSMISSION INPUT SHAFT, GEARS, LUBE PUMP AND BEARINGS	50 - 10	UPPER HOUSING DRUM DRIVE GEARS IN-LINE (101 - 2000)	125 - 12
TRANSMISSION INTERMEDIATE SHAFT	50 - 12	UPPER HOUSING DRUM DRIVE GEARS PRO-12 - 18S (2001 -)	120 - 10
TRANSMISSION SHIFT CABLE	50 - 4	UPPER HOUSING, PICKING UNIT IN-LINE (101 - 2000)	115 - 2
TRANSMISSION SPIRAL BEVEL GEARS.	50 - 16	UPPER HOUSING, PICKING UNIT PRO-12 - 18S (2001 -)	110 - 2
TRANSMISSION UNIT DRIVE SHAFT AND BEARINGS	50 - 17	V	
TUBE AND DUCTS, AIR	150 - 9	VALVE, BASKET INTERLOCK	70 - 29
TUBE, AIR CLEANER	30 - 2	VALVE, BASKET LIFT HYDRAULIC.	70 - 10
TUBE, ENGINE OIL DIPSTICK	20 - 23	VALVE, ENGINE OIL PRESSURE REGULATING (ENG. SER. NO. -889024)	20 - 10
TUBE, ENGINE VENTILATING	20 - 32	VALVE, ENGINE OIL PRESSURE REGULATING (ENG. SER. NO. 889025-)	20 - 18
TUBE, TIRE (EXPORT)	80 - 20	VALVE, EXHAUST	20 - 34
TUBE, UNIT LUBRICATION	130 - 6	VALVE, HEIGHT SENSING	70 - 22
TUBE, THERMOSTAT COVER	20 - 40	VALVE, HEIGHT SENSING, IN-LINE (101 - 2000)	115 - 20
TUNNEL BOTTOM PANELS.	80 - 6	VALVE, HEIGHT SENSING, PRO-12 - 18S (2001 -)	110 - 20
TURBOCHARGER	30 - 18	VALVE, HYDRAULIC CONTROL	70 - 20
TURBOCHARGER HARDWARE KIT	30 - 18	VALVE, INTAKE	20 - 34
TURBOCHARGER OIL LINES.	30 - 20	VALVE, POWER STEERING.	60 - 4
TURN SIGNAL CONTROL AND WIRING HARNESS	40 - 2	VALVE, SOLENOID (-16001)	70 - 26
U			
UNIT BOTTOM FRAME, IN-LINE (101 - 2000)	115 - 8		
UNIT BOTTOM FRAME, PRO-12 - 18S (2001 -)	110 - 8		
UNIT CABINET PLUGS AND GROMMETS PRO-12 - 18S (2001 -)	110 - 24		
UNIT DOORS, IN-LINE (101 - 2000)	115 - 16		
UNIT DOORS, PRO-12 - 18S (2001 -)	110 - 16		
UNIT DRIVE GEAR CASE, LH IN-LINE (101 - 2000)	125 - 4		
UNIT DRIVE GEAR CASE, RH IN-LINE (101 - 2000)	125 - 6		
UNIT DRIVE JACKSHAFT, IN-LINE (101 - 2000)	125 - 3		
UNIT DRIVE JACKSHAFT, PRO-12 18S (2001-)	120 - 1		