

9965 COTTON PICKER



JOHN DEERE

PARTS CATALOG

9965 COTTON PICKER

PC2366 (AUG-05) English

John Deere Des Moines Works

North American Edition

Litho in U.S.A. (Revised)

COPYRIGHT © 2005

DEERE & COMPANY

Moline, Illinois

All rights reserved

NP5360 -UN-01JAN94



*JOHN DEERE 9965 COTTON PICKER
(MANUFACTURED 1993 - 1997)*

(SPECIFICATIONS AND DESIGN ARE SUBJECT TO CHANGE WITHOUT NOTICE.)

SERIAL NUMBER LISTING INFORMATION

THE COTTON PICKER SERIAL NUMBER PLATE IS LOCATED ON LEFT-HAND SIDE OF MAIN FRAME, AT CENTER. SERIAL NUMBER INFORMATION IS LISTED TO SHOW ON WHICH MACHINES EACH PART CAN BE USED; FOR EXAMPLE:

- THE PART CAN BE USED ON ALL MACHINES.
- 000000- THE PART CAN BE USED ON ALL MACHINES BEGINNING WITH THE SERIAL NUMBER OR YEAR.
- 000000 THE PART CAN BE USED ON ALL MACHINES UP TO AND INCLUDING THE SERIAL NUMBER OR YEAR LISTED.
- 000000-000000 THE PART CAN BE USED ON ALL MACHINES BETWEEN AND INCLUDING THE SERIAL NUMBERS OR YEARS LISTED.

WHEN XXXXXX'S ARE LISTED IN PLACE OF A SERIAL NUMBER, A SERIAL NUMBER CHANGE WAS MADE BUT THE EXACT SERIAL NUMBER WAS NOT AVAILABLE WHEN THE CATALOG WAS PRODUCED.

DIRECTION ARROW

ARROWS ARE USED WITH ILLUSTRATIONS TO INDICATE THE FRONT OF THE UNIT. "RIGHT-HAND" AND "LEFT-HAND" SIDES ARE DETERMINED BY FACING IN THE DIRECTION OF MACHINE FORWARD TRAVEL.

BOX-ENCLOSED ILLUSTRATIONS

A KEY NUMBER, SHOWN IN THE PARTS LIST, IS ASSIGNED TO A BOX ENCLOSING ALL PARTS SOLD AS A SERVICE ASSEMBLY.

BOLT AND CAP SCREW STRENGTH IDENTIFICATION

BOLTS AND CAP SCREWS REQUIRED TO HAVE HIGH-STRENGTH QUALITIES EQUIVALENT TO SAE GRADE 8 ARE IDENTIFIED THROUGHOUT THIS CATALOG BY THE DESCRIPTION HS SAE 8. ALL STANDARD BOLTS AND CAP SCREWS ARE SAE GRADE 5 OR LOWER.

COMPLETE GOODS LISTINGS

COMPLETE GOODS ARE LISTED IN BOLD FACE TYPE. ORDER SEPARATELY. DO NOT INCLUDE ON REPLACEMENT PARTS ORDER.

SI UNITS OF MEASURE

METRIC DIMENSIONS ARE GIVEN, WHERE APPLICABLE, THROUGHOUT THIS PARTS CATALOG.

HOSE DIMENSIONS LISTED ARE EITHER FITTING SIZE X LENGTH X FITTING SIZE OR I.D. X LENGTH.

CKSO SERVICE PARTS

SERVICE PARTS DESIGNATED CKSO ARE USED IN CERTAIN AREAS OF THE WORLD. IF YOUR SOURCE OF SERVICE PARTS IS IN EUROPE OR AFRICA, ORDER THESE PARTS DESIGNATED CKSO.

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

SHORT BLOCK SERIAL NUMBER PLATE (-RGSB076882500)

RGP3513 -UN-01JAN94




RGP3513

THE REPLACEMENT SHORT BLOCK ASSEMBLY HAS A SERIAL NUMBER PLATE ATTACHED. THE ORIGINAL ENGINE SERIAL NUMBER MUST BE STAMPED ONTO THE NEW PLATE IN THE BLANK SPACE PROVIDED, AS A REFERENCE FOR YOUR DEALER. THE PLATE CAN BE ATTACHED WITH (2) 37H44 DRIVE SCREWS.

- | | |
|---------------------------------------|----------------------------|
| 1. DESIGNATES ENGINE MANUFACTURER | RG - WATERLOO ENGINE WORKS |
| 2. DESIGNATES REPLACEMENT SHORT BLOCK | SB |
| 3. DESIGNATES LITERS | XXX- 076 (7.6) |
| 4. DESIGNATES THE PRODUCTION DATE | 8825 |
| 5. DESIGNATES COMPONENT SEQUENCE | 00 |

SHORT BLOCK SERIAL NUMBER IDENTIFICATION (RE603860295-)

RGP4460 -UN-05MAR04



SERIAL NUMBER STAMPED INTO CASTING OF BLOCK NEAR PREVIOUS SERIAL NUMBER PLATE.

EXAMPLE: RE603860295

- | | |
|-----------------------------------|---------|
| 1. DESIGNATES SERVICE PART NUMBER | RE60386 |
| 2. DESIGNATES MONTH ASSEMBLED | 02 |
| 3. DESIGNATES YEAR ASSEMBLED | 95 |

TWO LINE BAR CODED ENGINE SERIAL NUMBER PLATE (LOCATED ON FUEL INJECTION PUMP SIDE OF ENGINE)

RGP3513 -UN-01JAN94



RGP3513

FIRST LINE

RG - WATERLOO ENGINE WORKS

DESIGNATES ENGINE MANUFACTURER.

6

DESIGNATES NUMBER OF CYLINDERS.

076 (7.6 LITERS)

DESIGNATES LITER DISPLACEMENT.

A - TURBOCHARGED AND AFTERCOOLED

DESIGNATES TYPE OF AIR INTAKE SYSTEM.

N

DESIGNATES DES MOINES WORKS.

XXXXXX

DESIGNATES ENGINE SERIAL NUMBER.

SECOND LINE

6076AN031

DESIGNATES ENGINE APPLICATION
9965

SECTION INDEX

GENERAL INFORMATION	10
ENGINE	20
FUEL AND AIR	30
ELECTRICAL	40
POWER TRAIN	50
STEERING AND BRAKES	60
HYDRAULICS	70
WHEELS, REAR AXLES AND SHEET METAL	80
OPERATOR STATION	90
PICKING UNIT LIFT100
PICKING UNIT CABINET.110
PICKING UNIT SYSTEM120
PICKING UNIT LUBRICATION SYSTEM130
WATER SYSTEM.140
AIR SYSTEM.150
BASKET160
DECALS170
PREFERRED METRIC HARDWARE180
NUMERICAL INDEX190

ALPHABETICAL INDEX

	PAGE		PAGE
A			
ACTUATOR, FAN ENGAGE	150 - 20	BASKET ENDS	160 - 8
ADJUSTABLE TREAD REAR AXLE	80 - 19	BASKET EXTENDER	160 - 30
ADJUSTMENT, SEAT (SN -6000)	90 - 18	BASKET EXTENDER LINKAGE	160 - 32
ADJUSTMENT, SEAT (SN 6001-)	90 - 20	BASKET EXTENSION	160 - 24
AFTERCOOLER	30 - 4	BASKET FLAP	160 - 34
AID, COLD WEATHER STARTING	30 - 9	BASKET INTERLOCK SWITCH	40 - 29
AIR CLEANER	30 - 1	BASKET INTERLOCK VALVE	70 - 39
AIR CONDITIONING COMPRESSOR (S.N. 2001-)	90 - 66	BASKET LAMPS AND FIELD LAMPS	40 - 22
AIR CONDITIONING COMPRESSOR PARTS	90 - 60	BASKET LID AND TOP	160 - 16
AIR CONDITIONING COMPRESSOR PARTS (S.N. -2000)	90 - 64	BASKET LIFT HYDRAULIC LINES AND HOSES (CYLINDER TO CYLINDER)	70 - 20
AIR CONDITIONING COMPRESSOR(NIPPONDENSO) AIR DUCT, TRANSITION (IN-LINE)	90 - 62	BASKET LOCK-UP	160 - 10
AIR DUCTS (CONVENTIONAL UNITS)	150 - 8	BASKET SUPPORT	160 - 2
AIR FILTER, CAB	90 - 51	BASKET TELESCOPING HYDRAULIC CYLINDERS, LINES & HOSES	70 - 22
AIR HOSES (IN-LINE)	150 - 13	BASKET WITH COMPACTOR, COMPLETE	160 - 4
AIR INTAKE TUBES AND PRE SCREENER	30 - 2	BASKET, L.H. SIDE	160 - 6
AIR LOUVER, PANEL AND SWITCHES	90 - 50	BASKET, R.H. SIDE AND FLOOR	160 - 4
AIR SWITCH INSTRUMENT PANEL (CONVENTIONAL)	40 - 46	BATTERY, BATTERY BOX AND CABLES	40 - 1
AIR TUBES (CONVENTIONAL UNITS)	150 - 11	BEARING CAP, FINAL DRIVE	50 - 17
AIR TUBES (IN-LINE)	150 - 12	BEARING, THRUST (6076)	20 - 28
ALARM, CONSOLE	40 - 12	BEARING, WATER PUMP	20 - 46
ALTERNATOR AND MOUNTING BRACKETS	40 - 6	BEARINGS, FINAL DRIVE	50 - 19
ANCHOR, TOW	80 - 4	BEARINGS, MAIN (6076)	20 - 28
ANEROID ACTIVATOR, HYDRAULIC (NIPPONDENSO)	30 - 41	BELT, COMPRESSOR (SERIAL NO. -2000)	90 - 70
ANEROID ACTIVATOR, HYDRAULIC (6076) (ROBERT BOSCH)	30 - 40	BELT, COMPRESSOR (SERIAL NO. 2001-)	90 - 71
ANTENNA, RADIO AND SPEAKERS	40 - 26	BELT, ENGINE FAN	20 - 43
ARMATURE (NIPPONDENSO) (12V F4)	40 - 4	BENDIX DRIVE (12V F4)	40 - 4
ARMREST, SEAT (PERSONAL-POSTURE™ SEAT)	90 - 16	BLADE, WINDSHIELD WIPER	90 - 55
ARMS, ROCKER	20 - 8	BLOCK ASSEMBLY, COMPLETE	20 - 2
ASHTRAY	90 - 38	BLOCK, SHORT (WITH HEAD BOLTS)	20 - 14
ASSEMBLY, COMPLETE BLOCK	20 - 2	BLOCK, SHORT (WITHOUT HEAD BOLTS)	20 - 12
AUGER, COMPACTOR, LH	160 - 22	BLOCK, VALVE	50 - 25
AUGER, COMPACTOR, RH	160 - 21	BLOWER, PRESSURIZER	90 - 48
AXLE BRACKET, REAR	80 - 5	BOLTS, CYLINDER HEAD (6076)	20 - 4
AXLE EXTENSIONS, REAR	80 - 24	BOTTOM FRAME (IN-LINE UNITS)	110 - 8
AXLE KNEE AND KNUCKLE, REAR	80 - 20	BOTTOMS, FRAME (CONVENTIONAL UNITS)	110 - 26
AXLE SPACERS	80 - 25	BOX, BATTERY	40 - 1
AXLE SPACERS (CONV. UNIT, SKIP-ROW) (64" SKIP ROW)	80 - 26	BOX, GEAR, SKIP ROW	120 - 8
AXLE STABILIZER CYLINDER, 3 1/2 X 10"	70 - 49	BRACKET, FIRE EXTINGUISHER	80 - 34
AXLE, FINAL DRIVE	50 - 19	BRACKET, FUEL FILTER (6076) (JUNE 1994-XXXX)	30 - 15
AXLE, FRONT	80 - 2	BRACKET, FUEL FILTER (6076) (XXXX-)	30 - 16
AXLE, REAR, ADJUSTABLE TREAD	80 - 19	BRACKET, FUEL SHUT-OFF (ESN -512892)	30 - 33
B			
BACKREST, OPERATOR'S SEAT	90 - 14	BRACKET, FUEL SHUT-OFF (ESN 512893-)	30 - 35
BAFFLES, PICKING UNIT (CONVENTIONAL UNITS)	110 - 28	BRACKET, HYDRAULIC VALVE	70 - 24
BAR, MIRROR	90 - 57	BRACKET, MOUNTING, HEIGHT SENSING VALVE (CONVENTIONAL UNITS)	110 - 46
BAR, PICKER	120 - 32	BRACKET, REAR AXLE	80 - 5
BARS, GRID (CONVENTIONAL UNITS)	110 - 30	BRACKET, UNIT LIFT (CONVENTIONAL UNITS)	100 - 6
BARS, GRID (IN-LINE UNITS)	110 - 10	BRACKETS, ALTERNATOR MOUNTING	40 - 6
BASKET COMPACTOR DRIVES	160 - 23	BRACKETS, HYDROSTATIC PUMP	50 - 27
BASKET COMPACTOR HYDRAULIC LINES	70 - 34	BRACKETS, MOUNTING, COMPRESSOR (SERIAL NO. -2000)	90 - 70
BASKET CYLINDER END LUBRICATION LINES	160 - 1	BRACKETS, MOUNTING, COMPRESSOR (SERIAL NO. 2001-)	90 - 71
BASKET DUMP HYDRAULIC CYLINDER	70 - 47	BRACKETS, TRANSMISSION	50 - 3
BASKET DUMP HYDRAULIC CYLINDER (SN -XXXX)	70 - 46	BRAKE CABLE, PARK	60 - 21
		BRAKE CYLINDER, MASTER	60 - 12
		BRAKE LINES AND RESERVOIR	60 - 16
		BRAKE PEDAL, PARK	60 - 20

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
BRAKE PEDALS	60 - 19	COMPACTOR AUGER & SUPPORTS, RH.	160 - 21
BRAKE SHOES AND DRUM	60 - 14	COMPACTOR DRIVES, BASKET	160 - 23
BRAKE SLAVE CYLINDER	60 - 18	COMPACTOR SWITCH, FOOT CONTROL	
BREAKERS, CIRCUIT	40 - 8	(SERIAL NO. -2000)	40 - 19
BRUSH, CONVEYOR.	160 - 17	COMPACTOR SWITCH, FOOT CONTROL	
BUSHING, CAMSHAFT.	20 - 9	(SERIAL NO. 2001-)	40 - 20
BUSHING, CAMSHAFT.	20 - 10	COMPLETE BLOCK ASSEMBLY	20 - 2
BYPASS VALVE, OIL FILTER	20 - 34	COMPLETE REPAIR UNIT, IN-LINE	
		(101 - 2000).	110 - 1
C		COMPRESSOR BELT AND MOUNTING BRACKETS	
		(SERIAL NO. -2000)	90 - 70
CAB AIR FILTER AND HOUSING	90 - 51	COMPRESSOR BELT AND MOUNTING BRACKETS	
CAB DOOR (SOUND-GARD CAB)	90 - 28	(SERIAL NO. 2001-)	90 - 71
CAB REAR UPHOLSTERY	90 - 30	COMPRESSOR CLUTCH PULLEY (NIPPONDENSO)	90 - 62
CAB ROOF AND SUPPORTS	90 - 32	COMPRESSOR HARDWARE KIT (NIPPONDENSO)	90 - 63
CAB ROOF HEADLINER	90 - 35	COMPRESSOR HARDWARE KIT (SN 2001-)	90 - 68
CAB WINDOWS (SOUND-GARD)	90 - 26	COMPRESSOR PARTS	
CAB WIRING DIAGRAM	40 - 24	(S.N. -2000).	90 - 64
CAB, SOUND-GARD (COMPLETE)	90 - 25	COMPRESSOR PARTS (S.N. 2001-)	90 - 69
CABLE, HYDROSTATIC CONTROL	90 - 46	COMPRESSOR SEAL KIT.	90 - 60
CABLE, PARK BRAKE	60 - 21	COMPRESSOR, AIR CONDITIONING	
CABLE, THROTTLE	30 - 44	(NIPPONDENSO)	90 - 62
CABLE, TRANSMISSION SHIFT.	50 - 4	COMPRESSOR, AIR CONDITIONING	
CABLE, UNIT SHIFT	50 - 5	(S.N. 2001-)	90 - 66
CABLES, BATTERY	40 - 1	COMPRESSOR, CLUTCH (S.N. 2001-)	90 - 67
CAM, PICKER BAR HEAD	120 - 28	CONDENSER, A/C	50 - 40
CAMSHAFT	20 - 9	CONNECTING RODS (6076)	20 - 24
CAMSHAFT BUSHING	20 - 9	CONNECTOR, ELECTRICAL, SERVICE KIT.	40 - 40
CAMSHAFT BUSHING	20 - 10	CONNECTORS, ELECTRICAL, WEATHERPACK.	40 - 44
CAMSHAFT FOLLOWER	20 - 8	CONNECTORS, FUEL INJECTION PUMP HOUSING	
CAMSHAFT FOLLOWER	20 - 9	(NIPPONDENSO) (ESN 568538-)	30 - 37
CAMSHAFT GEAR.	20 - 9	CONNECTORS, FUEL INJECTION PUMP HOUSING	
CAP PLUG KIT, UNIT SHELL	110 - 22	(ROBERT BOSCH) (ESN -568537)	30 - 36
CAP, RADIATOR	20 - 40	CONSOLE ASSEMBLY	90 - 38
CAPS, MAIN BEARING	20 - 10	CONSOLE CONTROLS, FUSES AND RELAYS	40 - 12
CASE, GEAR UNIT DRIVE, INNER		CONSOLE WIRING HARNESS	40 - 10
(CONVENTIONAL UNITS)	120 - 16	CONTROL CABLE, HYDROSTATIC.	90 - 46
CASE, GEAR UNIT DRIVE, INNER		CONTROL CABLE, THROTTLE	30 - 44
(IN-LINE UNITS)	120 - 12	CONTROL HANDLE, HYDROSTATIC	
CASE, GEAR UNIT DRIVE, MIDDLE		(XXXX-)	90 - 44
(NO. 4 UNIT OF 5 ROW IN-LINE PICKER)	120 - 10	CONTROL HANDLE, HYDROSTATIC (-XXXX)	90 - 42
CASE, GEAR UNIT DRIVE, OUTER		CONTROL LEVERS, CONSOLE	90 - 40
(CONVENTIONAL UNITS)	120 - 19	CONTROL LINES, FUEL (NIPPONDENSO)	
CASE, GEAR UNIT DRIVE, OUTER		(ESN 568538-)	30 - 30
(IN-LINE UNITS)	120 - 11	CONTROL VALVE, HYDRAULIC	70 - 10
CASE, TRANSMISSION	50 - 6	CONTROL VALVE, HYDROSTATIC DRIVE	
CENTER HOUSING, TURBOCHARGER (6076)		DISPLACEMENT	50 - 36
(SCHWITZER)	30 - 8	CONTROL, TURN SIGNAL	40 - 14
CHAIN, PICKING UNIT UPPER HOUSING DRUM		CONTROLS, FUSES AND RELAYS, CONSOLE	40 - 12
DRIVE	120 - 26	CONVEYOR BRUSHES	160 - 17
CHAINS, DUCT LIFT	160 - 15	CONVEYOR DRIVE	160 - 28
CHARGE PUMP, HYDROSTATIC DRIVE	50 - 35	CONVEYOR FRAME	160 - 26
CHASSIS DECAL SET	170 - 6	CONVEYOR HYDRAULIC LINES.	70 - 34
CHASSIS WIRING HARNESS	40 - 30	CONVEYOR HYDRAULIC MOTOR	70 - 53
CIRCUIT BREAKERS AND RELAYS	40 - 8	COOLANT AND ENGINE TEMPERATURE SENDERS	20 - 6
CLEANER, AIR	30 - 1	COOLER AND OIL FILTER HOUSING	20 - 34
CLEANER, SPINDLE.	140 - 2	COOLER, ENGINE OIL	20 - 34
CLUTCH, COMPRESSOR (NIPPONDENSO)	90 - 62	COTTON DOOR, LARGE OUTSIDE (IN-LINE)	150 - 4
CLUTCH, COMPRESSOR (S.N. 2001-)	90 - 67	COTTON DOOR, SMALL INSIDE (IN-LINE)	150 - 5
CLUTCH, LUBRICATION PUMP	130 - 5	COTTON DOORS (CONVENTIONAL UNITS)	150 - 2
COIL, COMPRESSOR (NIPPONDENSO)	90 - 62	COTTON FAN ASSEMBLY, COMPLETE.	150 - 1
COIL, FIELD WINDING (12V F4)	40 - 4	COTTON FAN COVER	80 - 13
COLD WEATHER STARTING AID	30 - 9	COUNTERSHAFT, UNIT DRIVE	
COLUMN, STEERING (SN -XXXX).	60 - 1	(IN-LINE UNITS).	120 - 2
COLUMN, STEERING (SN XXXX-)	60 - 2	COUPLER, REMOTE FILL.	140 - 4
COMPACTOR AUGER & SUPPORTS, LH.	160 - 22	COVER STARTER SOLENOID (NIPPONDENSO)	40 - 3
		COVER, COTTON FAN	80 - 13

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
COVER, DOOR TRACK	90 - 28	DOORS, UNIT (IN-LINE UNITS)	110 - 16
COVER, HOUSING, TRANSMISSION AND DIFFERENTIAL	50 - 7	DRIVE GEAR, OIL PUMP (ESN 500000-)	20 - 26
COVER, HYDROSTATIC DRIVE PUMP	50 - 32	DRIVE HOUSING, INNER (CONVENTIONAL UNITS)	120 - 16
COVER, INJECTION PUMP ACCESS	20 - 30	DRIVE HOUSING, INNER (IN-LINE UNITS)	120 - 12
COVER, INSPECTION (CONVENTIONAL UNITS)	110 - 32	DRIVE HOUSING, MIDDLE (NO. 4 UNIT OF 5 ROW IN-LINE PICKER)	120 - 10
COVER, ROCKER ARM (6076)	20 - 7	DRIVE HOUSING, OUTER (CONVENTIONAL UNITS)	120 - 19
COVER, STABILIZER CYLINDER	80 - 16	DRIVE HOUSING, OUTER (IN-LINE UNITS)	120 - 11
COVER, TIMING GEAR	20 - 30	DRIVE SHAFT, FINAL DRIVE	50 - 20
COVER, VALVE (6076)	20 - 7	DRIVE SHAFT, UNIT (CONVENTIONAL)	120 - 4
COVERS AND INNER ROOF	90 - 34	DRIVE SHAFT, UNIT (IN-LINE)	120 - 5
CRANKSHAFT (ESN 500000-)	20 - 26	DRIVE WHEELS	80 - 18
CRANKSHAFT DAMPER	20 - 27	DRIVE, BENDIX (12V F4)	40 - 4
CRANKSHAFT FRONT OIL SEAL	20 - 30	DRIVE, CONVEYOR	160 - 28
CRANKSHAFT POSITION SENSOR	20 - 31	DRIVE, HYDROSTATIC MOTOR	50 - 22
CRANKSHAFT PULLEY	20 - 27	DRIVE, INNER UNIT, GEAR CASE (CONVENTIONAL UNITS)	120 - 16
CROSS SHAFT AND UNIVERSAL JOINT	120 - 6	DRIVE, INNER UNIT, GEAR CASE (IN-LINE UNITS)	120 - 12
CUTTER, VINE	120 - 43	DRIVE, MIDDLE UNIT, GEAR CASE (NO. 4 UNIT OF 5 ROW IN-LINE PICKER)	120 - 10
CYLINDER BLOCK FITTINGS	20 - 10	DRIVE, OUTER UNIT, GEAR CASE (CONVENTIONAL UNITS)	120 - 19
CYLINDER COVER, STABILIZER	80 - 16	DRIVE, OUTER UNIT, GEAR CASE (IN-LINE UNITS)	120 - 11
CYLINDER HEAD (6076)	20 - 4	DRIVE, PUMP, HYDROSTATIC	50 - 34
CYLINDER HEAD BOLTS (6076)	20 - 4	DRUM SLIP CLUTCH AND IDLER GEARS	120 - 24
CYLINDER HEAD GASKET (6076)	20 - 4	DRUM, BRAKE	60 - 14
CYLINDER HEAD GASKET KIT (6076)	20 - 22	DRUM, PICKER BAR	120 - 34
CYLINDER HEAD GASKET (6076)	20 - 22	DRY AIR CLEANER ELEMENT CLEANING GUN	30 - 46
CYLINDER LINERS (6076)	20 - 24	DRYER-RECEIVER, A/C	90 - 58
CYLINDER LUBRICATION LINES	160 - 1	DUCT LIFT CHAINS	160 - 15
CYLINDER, BASKET DUMP	70 - 47	DUCT SUPPORT	160 - 12
CYLINDER, BASKET DUMP (SN -XXXX)	70 - 46	DUCT, UNIT TO BASKET (CONVENTIONAL UNIT)	150 - 6
CYLINDER, BRAKE SLAVE	60 - 18	DUCT, UNIT TO BASKET (IN-LINE)	150 - 8
CYLINDER, BRAKE, MASTER	60 - 12		
CYLINDER, STEERING	70 - 50	D	
CYLINDER, UNIT LIFT (CONVENTIONAL UNITS)	70 - 42		
CYLINDER, UNIT LIFT (IN-LINE) (SN -6385)	70 - 44		
CYLINDER, UNIT LIFT (IN-LINE) (SN 6386-)	70 - 45		
		E	
DAMPER KEY	20 - 26	ELECTRIC SHUT-OFF SOLENOID (ESN -512892)	30 - 33
DAMPER, CRANKSHAFT	20 - 27	ELECTRIC SHUT-OFF SOLENOID (ESN 512893-) (RB OR ND)	30 - 35
DECAL SET, CHASSIS	170 - 6	ELECTRIC SHUT-OFF SOLENOID KIT (6076) (EARLY DESIGN)	30 - 32
DECALS	170 - 1	ELECTRIC SHUT-OFF SOLENOID REPAIR KIT (LATE DESIGN) (6076)	30 - 34
DECALS, SAFETY	170 - 2	ELECTRICAL CONNECTOR SERVICE KIT	40 - 40
DIAGRAM, WIRING, CAB	40 - 24	ELECTRICAL TERMINALS AND CONNECTORS, WEATHERPACK	40 - 44
DIFFERENTIAL GEARS AND SHAFTS	50 - 12	ELECTRICALLY OPERATED STARTING AID	30 - 9
DIMMER SWITCH	40 - 18	ELECTROMAGNETIC LUBRICATION PUMP CLUTCH	130 - 5
DIPSTICK, ENGINE OIL (6076)	20 - 36	ENDS, BASKET	160 - 8
DOFFER	120 - 38	ENGINE COOLANT HEATER	40 - 36
DOFFER DRIVE IDLER GEAR (UPPER HOUSING DRIVE)(IN-LINE UNITS)	120 - 42	ENGINE FAN AND BELT	20 - 43
DOFFER DRIVE TIGHTENER SPROCKET	120 - 41	ENGINE HOOD	80 - 6
DOFFER FLAP	110 - 4	ENGINE HOOD SIDE SCREENS AND SUPPORTS	80 - 8
DOFFER GAGES	120 - 40	ENGINE OIL (TORQ-GARD)	20 - 1
DOME LIGHT (ROCKER TYPE)	40 - 23	ENGINE OIL COOLER	20 - 34
DOOR CAB (SOUND-GARD CAB)	90 - 28	ENGINE OIL DIPSTICK (6076)	20 - 36
DOOR, COTTON, LARGE OUTSIDE (IN-LINE)	150 - 4	ENGINE OIL DIPSTICK TUBE (6076)	20 - 36
DOOR, COTTON, SMALL INSIDE (IN-LINE)	150 - 5	ENGINE OIL FILTER	20 - 34
DOOR, COTTON, TRANSITION AND SUCTION (CONVENTIONAL UNITS)	150 - 2	ENGINE OIL PUMP	20 - 32
DOOR, FRONT AND OUTER SIDE SWING (CONVENTIONAL UNITS)	110 - 38		
DOOR, INNER PICKING UNIT, SKIP-ROW (CONVENTIONAL UNITS)	110 - 39		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
ENGINE OIL PUMP INTAKE (6076)	20 - 38	FLOOR MAT	90 - 31
ENGINE OVERHAUL KIT(S) (ESN 500000-)	20 - 18	FLOOR, BASKET	160 - 4
ENGINE OVERHAUL KIT(S)(ESN -499999)	20 - 16	FLOOR, LEFT-HAND PLATFORM (IN-LINE UNITS)	90 - 6
ENGINE RAILS	80 - 2	FLOOR, PLATFORM	90 - 4
ENGINE REBUILD GASKET KIT (6076)	20 - 22	FLOORS, LEFT-HAND PLATFORM (CONVENTIONAL UNITS)	90 - 7
ENGINE SPEED SENSOR (6076)	20 - 31	FLUSH SYSTEM SWITCH, FOOT CONTROL (SERIAL NO. -2000)	40 - 19
ENGINE TEMPERATURE SENDER	20 - 6	FLUSH SYSTEM SWITCH, FOOT CONTROL (SERIAL NO. 2001-)	40 - 20
ENGINE UNDERHAUL KIT (STD BRGS) (6076)	20 - 20	FLYWHEEL	20 - 25
ENGINE VENTILATOR OUTLET HOSE (6076)	20 - 7	FOLLOWER, CAMSHAFT	20 - 8
ETHER STARTING FLUID	30 - 9	FOLLOWER, CAMSHAFT	20 - 9
EVAPORATOR AND HOSES	90 - 54	FRAME BOTTOMS AND STIFFENERS (CONVENTIONAL UNITS)	110 - 26
EXHAUST MANIFOLD GASKETS (6076)	30 - 10	FRAME, BOTTOM (IN-LINE UNITS)	110 - 8
EXHAUST MANIFOLDS (6076)	30 - 10	FRAME, CONVEYOR	160 - 26
EXHAUST PIPE AND MUFFLER	30 - 11	FRAME, LID LINKAGE	160 - 19
EXHAUST VALVE SHIELD (6076)	20 - 4	FRAME, MAIN	80 - 2
EXHAUST VALVES (6076)	20 - 4	FRAME, PLATFORM	90 - 2
EXPANDED ENGINE OVERHAUL KIT(S) (ESN -499999)	20 - 16	FRAME, UNIT LIFT(IN-LINE UNITS)	100 - 2
EXPANDED ENGINE OVERHAUL KIT(S) (ESN 500000-)	20 - 18	FRONT DRUM PRESSURE PLATES (CONVENTIONAL UNITS)	110 - 36
EXTENDER, BASKET	160 - 30	FRONT DRUM PRESSURE PLATES (IN-LINE UNITS)	110 - 12
EXTENSION, BASKET	160 - 24	FRONT DRUM SIDE SHEETS AND PANELS (CONVENTIONAL UNITS)	110 - 34
EXTENSION, PLATFORM (IN-LINE UNITS)	90 - 12	FRONT OIL SEAL	20 - 30
EXTENSIONS, REAR AXLE	80 - 24	FRONT PICKING UNIT GRID BARS (CONVENTIONAL UNITS)	110 - 31
EXTENSIONS, UNIT LIFT (IN-LINE UNITS)	100 - 2	FRONT PLANT SHIELDS	80 - 28
EXTINGUISHER, FIRE	80 - 34	FRONT SWING DOOR (CONVENTIONAL UNITS)	110 - 38
F			
F.I.P. GEAR (NIPPONDENSO) (ESN 568538-)	30 - 30	FRONT WATER MANIFOLD	20 - 44
F.I.P. LUBE LINES (NIPPONDENSO) (ESN 568538-)	30 - 30	FUEL CHECK VALVE	30 - 18
FAN ASSEMBLY, COMPLETE FAN	150 - 1	FUEL CONTROL LINES (E.S.N. -568537)	30 - 28
FAN DRIVE, FIXED	20 - 42	FUEL CONTROL LINES (NIPPONDENSO) (ESN 568538-)	30 - 30
FAN ENGAGE ACTUATOR	150 - 20	FUEL FILTER	30 - 18
FAN HOUSING	150 - 14	FUEL FILTER (6076) (JUNE 1994-XXXX)	30 - 15
FAN IDLER AND LINKAGE	150 - 18	FUEL FILTER (6076) (XXXX-)	30 - 16
FAN PULLEY	20 - 42	FUEL FILTER BRACKET (6076) (JUNE 1994-XXXX)	30 - 15
FAN SHAFT, SHEAVE AND ROTOR	150 - 16	FUEL FILTER BRACKET (6076) (XXXX-)	30 - 16
FAN, COVER, COTTON	80 - 13	FUEL FILTER LINES	30 - 18
FAN, ENGINE	20 - 43	FUEL INJ LINES (ESN 568538-)	30 - 26
FIELD LAMPS AND BASKET LAMPS	40 - 22	FUEL INJ NOZZLES (ESN 568538-)	30 - 26
FIELD WINDING COIL (12V F4)	40 - 4	FUEL INJECTION LINES (W/ROBERT BOSCH PUMP)	30 - 24
FILTER, AIR, CAB	90 - 51	FUEL INJECTION NOZZLE (NIPPONDENSO) (ESN -568537)	30 - 20
FILTER, ENGINE OIL	20 - 34	FUEL INJECTION NOZZLE (NIPPONDENSO) (ESN 568538-)	30 - 22
FILTER, FUEL	30 - 18	FUEL INJECTION NOZZLES (W/ROBERT BOSCH PUMP)	30 - 24
FILTER, WATER	140 - 9	FUEL INJECTION PUMP (NIPPONDENSO) (ESN 568538-)	30 - 30
FILTER, WEEP HOLE (WATER PUMP)	20 - 46	FUEL INJECTION PUMP (ROBERT BOSCH) (E.S.N. -568537)	30 - 28
FINAL DRIVE	50 - 16	FUEL INJECTION PUMP GEAR (E.S.N. -568537)	30 - 28
FINAL DRIVE AXLE, GEAR AND BEARINGS	50 - 19	FUEL INJECTION PUMP GOVERNOR LEVERS (NIPPONDENSO)	30 - 39
FINAL DRIVE HOUSING AND BEARING CAP	50 - 17		
FINAL DRIVE PINION, DRIVE SHAFTS AND BEARINGS	50 - 20		
FIRE EXTINGUISHER	80 - 34		
FITTINGS, CYLINDER BLOCK	20 - 10		
FITTINGS, LUBRICATION FILL	130 - 8		
FITTINGS, WATER PUMP	140 - 6		
FIXED FAN DRIVE	20 - 42		
FLAP	40 - 50		
FLAP MONITOR	40 - 50		
FLAP, BASKET	160 - 34		
FLAP, DOFFER	110 - 4		
FLAT O-RING KIT, HYDRAULIC	70 - 54		

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
FUEL INJECTION PUMP HOUSING CONNECTOR (ROBERT BOSCH) (ESN -568537)	30 - 36	GEAR, OIL PUMP DRIVE	20 - 32
FUEL INJECTION PUMP HOUSING CONNECTORS (NIPPONDENSO) (ESN 568538-)	30 - 37	GEAR, OIL PUMP DRIVE (ESN 500000-)	20 - 26
FUEL INJECTION PUMP LUBE LINES (E.S.N. -568537)	30 - 28	GEAR, PICKING UNIT UPPER HOUSING.	120 - 26
FUEL INJECTION PUMP THROTTLE LEVER (ROBERT BOSCH) (ESN -568537)	30 - 38	GEAR, STARTER.	20 - 25
FUEL LEAK-OFF LINE (NIPPONDENSO) (ESN 568538-)	30 - 30	GEARBOX, OFFSET	120 - 22
FUEL LEAK-OFF LINES (W/ROBERT BOSCH PUMP)	30 - 24	GEARS AND SHAFT (DRIVE HOUSING) MIDDLE (NO. 4 UNIT OF 5 ROW IN-LINE PICKER)	120 - 10
FUEL LEAK-OFF LINES (ESN 568538-)	30 - 26	GEARS AND SHAFT (DRIVE HOUSING), INNER (CONVENTIONAL UNITS)	120 - 16
FUEL SHUT-OFF BRACKET (ESN -512892)	30 - 33	GEARS AND SHAFT (DRIVE HOUSING), INNER (IN-LINE UNITS).	120 - 12
FUEL SHUT-OFF BRACKET (ESN 512893-)	30 - 35	GEARS AND SHAFT (DRIVE HOUSING), OUTER (CONVENTIONAL UNITS)	120 - 19
FUEL TANK	30 - 12	GEARS AND SHAFT (DRIVE HOUSING), OUTER (IN-LINE UNITS).	120 - 11
FUEL TRANSFER PUMP (NIPPONDENSO) (ESN 568538-)	30 - 43	GEARS, DIFFERENTIAL	50 - 12
FUEL TRANSFER PUMP (NIPPONDENSO) (ESN 568538-)	30 - 30	GEARS, PICKER BAR	120 - 30
FUEL TRANSFER PUMP (ROBERT BOSCH) (ESN -568537)	30 - 42	GEARS, PICKER BAR	120 - 31
FUSES AND RELAYS, CONSOLE	40 - 12	GEARS, SPIRAL BEVEL	50 - 14
FUSES, RELAYS AND CIRCUIT BREAKERS	40 - 8	GOVERNOR LEVERS, FUEL INJECTION PUMP (NIPPONDENSO)	30 - 39
G		GRATES, STALK LIFTER (CONVENTIONAL UNIT).	110 - 40
GAGES, DOFFER	120 - 40	GRATES, STALK LIFTER (IN-LINE UNITS)	110 - 18
GASKET KIT, CYLINDER HEAD (6076)	20 - 22	GRID BARS AND SUPPORTS (CONVENTIONAL UNITS)	110 - 30
GASKET KIT, ENGINE REBUILD (6076)	20 - 22	GRID BARS, FRONT (CONVENTIONAL UNITS)	110 - 31
GASKET KIT, SHORT BLOCK (6076)	20 - 22	GROUND WIRE, A/C ELECTRIC CLUTCH (S.N. 2001-)	90 - 67
GASKET, CYLINDER HEAD (6076)	20 - 4	GROUND WIRE, AIR CONDITIONING COMPRESSOR (SERIAL NO. 2001-)	90 - 71
GASKET, OIL COOLER.	20 - 34	GUN, DRY AIR CLEANER ELEMENT CLEANING	30 - 46
GASKET, OIL FILTER HOUSING.	20 - 34	H	
GASKET, OIL PAN	20 - 37	HANDBRAKE LEVER.	60 - 20
GASKET, OIL PUMP INTAKE (6076)	20 - 38	HANDLE, HYDROSTATIC CONTROL (XXXX-)	90 - 44
GASKET, REAR OIL SEAL	20 - 29	HANDLE, HYDROSTATIC CONTROL (-XXXX)	90 - 42
GASKET, ROCKER ARM COVER (6076)	20 - 7	HANDRAIL, FRONT & REAR	160 - 19
GASKET, TIMING GEAR COVER	20 - 30	HANDRAILS AND LADDER (IN-LINE UNITS)	90 - 8
GASKET, TURBOCHARGER	30 - 6	HANDRAILS AND STEP (CONVENTIONAL UNITS)	90 - 10
GASKET, WATER MANIFOLD	20 - 44	HANDRAILS, SIDE	160 - 20
GASKET, WATER PUMP	20 - 46	HANGER, PICKING UNIT (IN-LINE UNITS)	110 - 6
GASKETS, EXHAUST MANIFOLD (6076)	30 - 10	HARDWARE KIT, COMPRESSOR (NIPPONDENSO)	90 - 63
GASKETS, INTAKE MANIFOLD	30 - 4	HARDWARE KIT, COMPRESSOR (SN 2001-)	90 - 68
GAUGES, MONITOR	40 - 48	HARNESS, CHASSIS WIRING	40 - 30
GEAR BOX, SKIP ROW.	120 - 8	HARNESS, CONSOLE WIRING	40 - 10
GEAR CASE, INNER UNIT DRIVE (CONVENTIONAL UNITS)	120 - 16	HARNESS, WIRING, MONITOR (CONVENTIONAL UNITS)	40 - 33
GEAR CASE, INNER UNIT DRIVE (IN-LINE UNITS)	120 - 12	HARNESS, WIRING, PICKING UNIT/WARNING LAMP (IN-LINE UNITS).	40 - 32
GEAR CASE, MIDDLE UNIT DRIVE (NO. 4 UNIT OF 5 ROW IN-LINE PICKER)	120 - 10	HARNESS, WIRING, PLATFORM	40 - 28
GEAR CASE, OUTER UNIT DRIVE (CONVENTIONAL UNITS)	120 - 19	HEAD BOLT KIT (6076)	20 - 4
GEAR CASE, OUTER UNIT DRIVE (IN-LINE UNITS)	120 - 11	HEAD, CYLINDER (6076)	20 - 4
GEAR, CAMSHAFT	20 - 9	HEAD, PICKER BAR	120 - 28
GEAR, F.I.P. (NIPPONDENSO) (ESN 568538-)	30 - 30	HEADLINER, CAB ROOF	90 - 35
GEAR, FINAL DRIVE	50 - 19	HEATER CONTROL VALVE AND HOSES	90 - 52
GEAR, FUEL INJECTION PUMP (E.S.N. -568537)	30 - 28	HEATER, ENGINE COOLANT	40 - 36
GEAR, IDLER, DOFFER DRIVE (UPPER HOUSING DRIVE)(IN-LINE UNITS)	120 - 42	HEIGHT SENSING HYDRAULIC LINES AND HOSES (IN-LINE UNITS)	70 - 16
		HEIGHT SENSING HYDRAULIC LINES, SUPPLEMENTAL	70 - 18
		HEIGHT SENSING HYDRAULICS (IN-LINE UNITS).	70 - 14
		HEIGHT SENSING LINKAGE (IN-LINE UNITS).	110 - 20

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
HEIGHT SENSING LINKAGE, INNER (CONVENTIONAL UNITS)	110 - 42	HYDRAULIC LINES AND HOSES, UNIT LIFT & HEIGHT SENSING (CONV. UNITS)	70 - 12
HEIGHT SENSING OUTER LINKAGE AND SHOE (CONVENTIONAL UNITS)	110 - 44	HYDRAULIC LINES AND HOSES, UNIT LIFT & HEIGHT SENSING (IN-LINE UNITS)	70 - 14
HEIGHT SENSING VALVE (CONVENTIONAL UNIT)	70 - 37	HYDRAULIC LINES, BASKET TELESCOPING	70 - 22
HEIGHT SENSING VALVE (IN-LINE UNIT)	70 - 36	HYDRAULIC LINES, MAIN PRESSURE	70 - 32
HEIGHT SENSING VALVE MOUNTING BRACKETS (CONVENTIONAL UNITS)	110 - 46	HYDRAULIC MOTOR, COMPACTOR	70 - 52
HOOD, ENGINE	80 - 6	HYDRAULIC MOTOR, CONVEYOR	70 - 53
HOOD, REAR	80 - 12	HYDRAULIC OIL COOLER	50 - 40
HOOD, UNIT, R.H. AND L.H. WITH DECALS (CONVENTIONAL UNITS)	110 - 32	HYDRAULIC PUMP	70 - 4
HORN (SN XXXX-)	40 - 16	HYDRAULIC PUMP DRIVE AND SUPPORTS	70 - 2
HORN (SN 2001-XXXX)	40 - 15	HYDRAULIC PUMP OVERHAUL KIT (2.4 IN3)	70 - 8
HORN SWITCH	40 - 14	HYDRAULIC PUMP STROKE CONTROL VALVE	70 - 6
HOSE, A/C RECEIVER-DRYER	90 - 58	HYDRAULIC PUMP SUCTION & BLEED-OFF HOSES	70 - 28
HOSE, AIR (IN-LINE)	150 - 13	HYDRAULIC PUMP, REPLACEMENT	70 - 3
HOSE, ENGINE VENTILATOR OUTLET (6076)	20 - 7	HYDRAULIC RETURN LINES AND HOSES	70 - 26
HOSE, FIRE EXTINGUISHER	80 - 34	HYDRAULIC TUBES & HOSES, STEERING TO CYLINDERS	60 - 10
HOSES AND FITTINGS, OIL COOLER BYPASS	50 - 38	HYDRAULIC TUBES AND HOSES, STEERING	60 - 8
HOSES AND LINES, HYDRAULIC RETURN	70 - 26	HYDRAULIC VALVE BRACKET	70 - 24
HOSES, HEATER	90 - 52	HYDRAULIC/HYDROSTATIC RESERVOIR	70 - 25
HOSES, RADIATOR	20 - 40	HYDROSTATIC CONTROL CABLE	90 - 46
HOUSING CONNECTORS, FUEL INJECTION PUMP (ROBERT BOSCH) (ESN -568537)	30 - 36	HYDROSTATIC CONTROL HANDLE (XXXX-)	90 - 44
HOUSING, DRUM SLIP CLUTCH	120 - 24	HYDROSTATIC CONTROL HANDLE (-XXXX)	90 - 42
HOUSING, FAN	150 - 14	HYDROSTATIC DRIVE CHARGE PUMP	50 - 35
HOUSING, FINAL DRIVE	50 - 17	HYDROSTATIC DRIVE DISPLACEMENT CONTROL VALVE	50 - 36
HOUSING, HYDROSTATIC PUMP	50 - 30	HYDROSTATIC DRIVE MOTOR	50 - 22
HOUSING, OIL COOLER AND FILTER	20 - 34	HYDROSTATIC DRIVE MOTOR, KIT	50 - 24
HOUSING, PICKING UNIT, IN-LINE (101 - 2000)	110 - 1	HYDROSTATIC DRIVE OIL LINES	50 - 39
HOUSING, PICKING UNITS (CONVENTIONAL UNITS)	110 - 23	HYDROSTATIC DRIVE PISTON	50 - 33
HOUSING, REAR OIL SEAL	20 - 29	HYDROSTATIC DRIVE PUMP AND SHAFT	50 - 28
HOUSING, THERMOSTAT, FRONT	20 - 44	HYDROSTATIC DRIVE PUMP COVER	50 - 32
HOUSING, TRANSMISSION AND DIFFERENTIAL	50 - 6	HYDROSTATIC DRIVE PUMP KIT	50 - 26
HOUSING, TURBOCHARGER CENTER (6076) (SCHWITZER)	30 - 8	HYDROSTATIC OIL COOLER AND SUPPORTS	50 - 40
HOUSING, UPPER DOFFER	120 - 36	HYDROSTATIC PUMP DRIVE	50 - 34
HOUSING, UPPER DRIVE GEARS, PICKING UNIT	120 - 26	HYDROSTATIC PUMP, SHEAVE, BRACKETS AND FITTINGS.	50 - 27
HOUSING, UPPER PICKING UNIT (IN-LINE UNITS)	110 - 2		
HUB, LOWER GEAR CASE (CONVENTIONAL UNITS)	120 - 20	I	
HUB, LOWER GEAR CASE (IN-LINE UNITS)	120 - 14	IDLER AND LINKAGE, FAN	150 - 18
HYDRAULIC ANEROID ACTIVATOR (NIPPONDENSO)	30 - 41	IDLER GEAR, DOFFER DRIVE (UPPER HOUSING DRIVE)(IN-LINE UNITS)	120 - 42
HYDRAULIC ANEROID ACTIVATOR (6076) (ROBERT BOSCH)	30 - 40	IDLER GEARS, DRUM SLIP CLUTCH	120 - 24
HYDRAULIC CONTROL VALVE	70 - 10	IGNITION SWITCH AND KEY	40 - 12
HYDRAULIC CYLINDER, UNIT LIFT (IN-LINE) (SN -6385)	70 - 44	IMPELLER, WATER PUMP	20 - 46
HYDRAULIC CYLINDER, UNIT LIFT (IN-LINE) (SN 6386-)	70 - 45	INJECTION NOZZLE, FUEL (NIPPONDENSO) (ESN -568537)	30 - 20
HYDRAULIC CYLINDER, 3-1/2" X 10"	70 - 49	INJECTION NOZZLE, FUEL (NIPPONDENSO) (ESN 568538-)	30 - 22
HYDRAULIC CYLINDERS, BASKET TELESCOPING	70 - 22	INJECTION PUMP (NIPPONDENSO) (ESN 568538-)	30 - 30
HYDRAULIC HOSE, HYDRAULIC PUMP SUCTION AND BLEED-OFF	70 - 28	INJECTION PUMP ACCESS COVER	20 - 30
HYDRAULIC HOSES, STABILIZER CYLINDER	70 - 30	INNER DOOR, PICKING UNIT, SKIP-ROW (CONVENTIONAL UNITS)	110 - 39
HYDRAULIC LINES & HOSES, BASKET LIFT (CYLINDER TO CYLINDER)	70 - 20	INNER HEIGHT SENSING LINKAGE (CONVENTIONAL UNITS)	110 - 42
HYDRAULIC LINES AND HOSES, BASKET COMPACTOR AND CONVEYOR	70 - 34	INNER ROOF AND COVERS	90 - 34
HYDRAULIC LINES AND HOSES, HEIGHT SENSING (IN-LINE UNITS)	70 - 16	INPUT SHAFT, TRANSMISSION	50 - 8
		INSERTS, VALVE SEAT (6076)	20 - 4
		INSIDE CAB MIRROR	90 - 56
		INSTRUMENT PANEL, AIR SWITCH (CONVENTIONAL)	40 - 46
		INTAKE MANIFOLD	30 - 4

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
INTAKE MANIFOLD GASKETS	30 - 4	LAMP, REAR WARNING/TAIL	40 - 21
INTAKE VALVES (6076)	20 - 4	LAMPS, FIELD AND BASKET	40 - 22
INTAKE, ENGINE OIL PUMP (6076)	20 - 38	LARGE OUTSIDE COTTON DOOR (IN-LINE)	150 - 4
 J			
JACKSHAFT, UNIT DRIVE (IN-LINE UNITS)	120 - 2	LATCH, DOOR	90 - 28
JETS, PISTON COOLING	20 - 10	LEAD ASSEMBLY, OIL TEMPERATURE SWITCH	70 - 25
 K			
KEY, DAMPER	20 - 26	LEFT-HAND PLATFORM FLOORS (CONVENTIONAL UNITS)	90 - 7
KEY, IGNITION	40 - 12	LEFT-HAND PLATFORM FLOORS (IN-LINE UNITS)	90 - 6
KIT(S), ENGINE OVERHAUL (ESN 500000-)	20 - 18	LEVER THROTTLE, FUEL INJECTION PUMP (ROBERT BOSCH) (ESN -568537)	30 - 38
KIT(S), ENGINE OVERHAUL (ESN -499999)	20 - 16	LEVER, FUEL INJECTION PUMP THROTTLE (ROBERT BOSCH) (ESN -568537)	30 - 38
KIT(S), EXPANDED ENGINE OVERHAUL (ESN -499999)	20 - 16	LEVER, HANDBRAKE	60 - 20
KIT(S), EXPANDED ENGINE OVERHAUL (ESN 500000-)	20 - 18	LEVERS, CONSOLE CONTROL	90 - 40
KIT, COMPRESSOR HARDWARE (NIPPONDENSO)	90 - 63	LID LINKAGE FRAMES FRONT & REAR	160 - 19
KIT, COMPRESSOR HARDWARE (SN 2001-)	90 - 68	LID, BASKET	160 - 16
KIT, COMPRESSOR SEAL	90 - 60	LID, LINKAGE LINKS	160 - 18
KIT, COMPRESSOR SEAL (S.N. -2000)	90 - 64	LIFT ARMS, UNIT (IN-LINE UNITS)	100 - 4
KIT, ELECTRIC SHUT-OFF SOLENOID (6076) (EARLY DESIGN)	30 - 32	LIFT BRACKET, UNIT (CONVENTIONAL UNITS)	100 - 6
KIT, ELECTRIC SHUT-OFF SOLENOID REPAIR (LATE DESIGN) (6076)	30 - 34	LIFT STRAPS, ENGINE (6076) (ENGINE S/N 500000-)	20 - 21
KIT, ELECTRICAL CONNECTOR SERVICE	40 - 40	LIFTERS, STALK (CONVENTIONAL UNITS)	110 - 40
KIT, HEAD BOLT (6076)	20 - 4	LIFTERS, STALK (IN-LINE UNITS)	110 - 18
KIT, HYDRAULIC PUMP OVERHAUL (2.4 IN3)	70 - 8	LIGHT, DOME (ROCKER TYPE)	40 - 23
KIT, HYDROSTATIC DRIVE MOTOR	50 - 24	LINE, BRAKE	60 - 16
KIT, HYDROSTATIC DRIVE PUMP	50 - 26	LINE, FUEL LEAK-OFF (NIPPONDENSO) (ESN 568538-)	30 - 30
KIT, LUBRICATOR POWER DRIVE	130 - 15	LINER O-RINGS (6076)	20 - 24
KIT, PISTON/LINER (6076) (ESN 500000-)	20 - 24	LINER SHIM (6076)	20 - 24
KIT, REPAIR, UNIT LIFT CYLINDER (CONVENTIONAL UNITS)	70 - 42	LINERS, CYLINDER (6076)	20 - 24
KIT, REPAIR, UNIT LIFT CYLINDER (IN-LINE) (SN -6385)	70 - 44	LINES, AIR CONDITIONING (CAB ROOF)	90 - 54
KIT, REPAIR, UNIT LIFT CYLINDER (IN-LINE) (SN 6386-)	70 - 45	LINES, F.I.P. LUBE (NIPPONDENSO) (ESN 568538-)	30 - 30
KIT, SEAL, 1.50 DIA. MASTER HYDRAULIC CYLINDER	70 - 40	LINES, FUEL CONTROL (E.S.N. -568537)	30 - 28
KIT, SEAL, 1.50 DIA. SLAVE HYDRAULIC CYLINDER	70 - 41	LINES, FUEL CONTROL (NIPPONDENSO) (ESN 568538-)	30 - 30
KIT, SPRAY VALVE	140 - 20	LINES, FUEL FILTER	30 - 18
KIT, STEERING CYLINDER	70 - 51	LINES, FUEL INJ (ESN 568538-)	30 - 26
KIT, STROKE CONTROL VALVE SHUT-OFF	70 - 6	LINES, FUEL INJECTION (W/ROBERT BOSCH PUMP)	30 - 24
KIT, TERMINAL AND WIRING	40 - 38	LINES, FUEL LEAK-OFF (W/ROBERT BOSCH PUMP)	30 - 24
KIT, UNDERHAUL ENGINE (STD BRGS) (6076)	20 - 20	LINES, FUEL LEAK-OFF (ESN 568538-)	30 - 26
KIT, UNIT SHELL CAP PLUG	110 - 22	LINES, OIL, HYDROSTATIC DRIVE	50 - 39
KIT, WATER PUMP REPAIR (6076)	20 - 48	LINES, PRESS WATER (IN-LINE UNITS TO SPINDLE MOISTENER)	140 - 14
KNEE AND KNUCKLE, REAR AXLE	80 - 20	LINES, PRESSURE WATER (CONVENTIONAL UNITS)	140 - 16
 L			
LABELS	170 - 1	LINES, TURBOCHARGER OIL	30 - 6
LABELS, CHASSIS	170 - 6	LINES, WATER, MOISTENER COLUMN	140 - 12
LABELS, SAFETY	170 - 2	LINKAGE AND SPROCKET, DOFFER DRIVE TIGHT	120 - 41
LADDER AND HANDRAILS (IN-LINE UNITS)	90 - 8	LINKAGE, BASKET EXTENDER	160 - 32
		LINKAGE, FAN IDLER	150 - 18
		LINKAGE, HEIGHT SENSING (IN-LINE UNITS)	110 - 20
		LINKAGE, INNER HEIGHT SENSING (CONVENTIONAL UNITS)	110 - 42
		LINKAGE, OUTER HEIGHT SENSING (CONVENTIONAL UNITS)	110 - 44
		LINKAGE, THROTTLE	30 - 44
		LINKS, LID LINKAGE	160 - 18
		LONGBLOCK, "COMPLETE BLOCK ASSEMBLY"	20 - 2
		LOWER GEAR CASE HUB (CONVENTIONAL UNITS)	120 - 20
		LOWER GEAR CASE HUB (IN-LINE UNITS)	120 - 14
		LUBE LINES, F.I.P. (NIPPONDENSO) (ESN 568538-)	30 - 30

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
LUBE LINES, FUEL INJECTION PUMP (E.S.N. -568537)	30 - 28	NOZZLE, FUEL INJECTION (NIPPONDENSO) (ESN 568538-)	30 - 22
LUBE PUMP, TRANSMISSION	50 - 8	NOZZLE, SUCTION DOOR (CONVENTIONAL UNITS)	150 - 2
LUBRICANT, SPINDLE	130 - 2	NOZZLE, TRANSITION JET POST (IN-LINE)	150 - 13
LUBRICATION FILL AND PRESSURE FITTINGS	130 - 8	NOZZLES, FUEL INJ (ESN 568538-)	30 - 26
LUBRICATION MANIFOLD AND FITTINGS (CONVENTIONAL)	130 - 6	NOZZLES, FUEL INJECTION (W/ROBERT BOSCH PUMP)	30 - 24
LUBRICATION MANIFOLD AND FITTINGS (IN-LINE)	130 - 7	O	
LUBRICATION PUMP	130 - 18	O-RINGS, HYDRAULIC, FLAT	70 - 54
LUBRICATION PUMP AND CLUTCH	130 - 4	O-RINGS, LINER (6076)	20 - 24
LUBRICATION PUMP CLUTCH	130 - 5	OFFSET GEARBOX	120 - 22
LUBRICATION PUMP REPAIR KIT	130 - 19	OIL COOLER BYPASS HOSES AND FITTING	50 - 38
LUBRICATION RESERVE PANEL (IN-LINE UNITS)	130 - 13	OIL COOLER GASKET	20 - 34
LUBRICATION TANK	130 - 2	OIL COOLER, HYDROSTATIC	50 - 40
LUBRICATION TRANSFER PUMP	130 - 16	OIL FILTER BYPASS VALVE	20 - 34
LUBRICATION, RESERVE PANEL (CONVENTIONAL UNITS)	130 - 14	OIL FILTER HOUSING GASKET	20 - 34
LUBRICATOR DRIVE POWER KIT	130 - 15	OIL FILTER, ENGINE	20 - 34
M		OIL LINES, HYDROSTATIC DRIVE	50 - 39
MAGNETIC PICK-UP (6076)	20 - 31	OIL LINES, TURBOCHARGER	30 - 6
MAIN BEARING CAPS	20 - 10	OIL PAN	20 - 37
MAIN BEARINGS (6076)	20 - 28	OIL PAN GASKET	20 - 37
MAIN FRAME, FRONT AXLE, ENGINE RAILS	80 - 2	OIL PRESSURE REGULATING VALVE	20 - 34
MAIN HYDRAULIC PRESSURE LINES	70 - 32	OIL PRESSURE SENDER	20 - 10
MANIFOLD, INTAKE	30 - 4	OIL PUMP DRIVE GEAR	20 - 32
MANIFOLD, LUBRICATION (CONVENTIONAL)	130 - 6	OIL PUMP DRIVE GEAR (ESN 500000-)	20 - 26
MANIFOLD, LUBRICATION (IN-LINE)	130 - 7	OIL PUMP INTAKE GASKET (6076)	20 - 38
MANIFOLD, UNIT LUBRICATION (CONVENTIONAL UNITS)	130 - 12	OIL SEAL, CRANKSHAFT FRONT	20 - 30
MANIFOLD, UNIT LUBRICATION (IN-LINE UNITS)	130 - 10	OIL SEAL, REAR	20 - 29
MANIFOLD, WATER, FRONT	20 - 44	OIL, ENGINE	20 - 1
MANIFOLDS, EXHAUST (6076)	30 - 10	OPERATOR PRESENCE INSPECTION BYPASS	90 - 72
MASTER BRAKE CYLINDER	60 - 12	OPERATOR'S SEAT AND BACKREST	90 - 14
MAT	90 - 31	OUTER HEIGHT SENSING LINKAGE (CONVENTIONAL UNITS)	110 - 44
MIRROR	90 - 57	OUTER SIDE SWING DOOR (CONVENTIONAL UNITS)	110 - 38
MIRROR, REAR VIEW (INSIDE AND OUTSIDE)	90 - 56	OUTLET TUBE, ENGINE VENTILATOR (6076)	20 - 7
MOISTENER COLUMN WATER LINES	140 - 12	OUTSIDE MIRRORS	90 - 56
MOISTENER, SPINDLE	140 - 18	OVERFLOW TANK, RADIATOR	20 - 40
MONITOR ASSEMBLY	90 - 36	OVERHAUL KIT(S), ENGINE (ESN 500000-)	20 - 18
MONITOR GAUGES	40 - 48	OVERHAUL KIT(S), ENGINE (ESN -499999)	20 - 16
MONITOR WIRING HARNESS (CONVENTIONAL UNITS)	40 - 33	OVERHAUL KIT, HYDRAULIC PUMP (2.4 IN3)	70 - 8
MONITOR, FLAP	40 - 50	P	
MONITOR, ROW UNIT (CONVENTIONAL UNITS)	40 - 35	PAD, MOISTENER	140 - 18
MONITOR, ROW UNIT (IN-LINE UNITS)	40 - 34	PAN, OIL	20 - 37
MOTOR, HYDRAULIC, COMPACTOR	70 - 52	PANEL, AIR CONDITIONER	90 - 50
MOTOR, HYDRAULIC, CONVEYOR	70 - 53	PANEL, INSTRUMENT, AIR SWITCH (CONVENTIONAL)	40 - 46
MOTOR, HYDROSTATIC DRIVE	50 - 22	PANELS AND SIDE SHEETS (CONVENTIONAL UNITS)	110 - 32
MOTOR, STARTING (NIPPONDENSO) (12V F4)	40 - 3	PANELS AND SIDE SHEETS (CONVENTIONAL UNITS)	110 - 34
MOTOR, WINDSHIELD WIPER	90 - 55	PANELS, R.H. CAB	90 - 27
MUFFLER AND EXHAUST PIPE	30 - 11	PARK BRAKE CABLE	60 - 21
N		PEDAL ASSEMBLY, PARK BRAKE	60 - 20
NOZZLE, DUCTS (CONVENTIONAL UNITS)	150 - 6	PEDALS, BRAKE	60 - 19
NOZZLE, FUEL INJECTION (NIPPONDENSO) (ESN -568537)	30 - 20	PICK-UP, MAGNETIC (6076)	20 - 31
		PICKER BAR DRIVE SHAFT	120 - 31
		PICKER BAR DRUM, STUD AND BEARING	120 - 34
		PICKER BAR HEAD, CAM AND CAP	120 - 28

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
PICKER BAR SPINDLE DRIVE SHAFT	120 - 30	PUMP DRIVE, HYDROSTATIC	50 - 34
PICKER BAR, SPINDLE AND WRENCH	120 - 32	PUMP, CHARGE, HYDROSTATIC DRIVE	50 - 35
PICKING UNIT GRID BARS (IN-LINE UNITS)	110 - 10	PUMP, ENGINE OIL	20 - 32
PICKING UNIT HANGER (IN-LINE UNITS)	110 - 6	PUMP, FUEL INJECTION (ROBERT BOSCH) (E.S.N. -568537)	30 - 28
PICKING UNIT HOUSING (CONVENTIONAL UNITS)	110 - 23	PUMP, FUEL TRANSFER (NIPPONDENSO) (ESN 568538-)	30 - 30
PICKING UNIT POSTS (IN-LINE UNITS)	110 - 4	PUMP, FUEL TRANSFER (NIPPONDENSO) (ESN 568538-)	30 - 43
PICKING UNIT REAR POSTS AND BAFFLES (CONVENTIONAL UNITS)	110 - 28	PUMP, FUEL TRANSFER (ROBERT BOSCH) (ESN -568537)	30 - 42
PICKING UNIT UPPER HOUSING (CONVENTIONAL UNITS)	110 - 24	PUMP, HYDRAULIC	70 - 4
PICKING UNIT UPPER HOUSING (IN-LINE UNITS)	110 - 2	PUMP, HYDRAULIC, REPLACEMENT	70 - 3
PICKING UNIT WIRING HARNESS (IN-LINE UNITS)	40 - 32	PUMP, HYDROSTATIC	50 - 27
PICKING UNIT, COMPLETE, IN-LINE (101 - 2000)	110 - 1	PUMP, LUBRICATION	130 - 18
PINION SHAFT, TRANSMISSION	50 - 10	PUMP, LUBRICATION TRANSFER	130 - 16
PINION, FINAL DRIVE	50 - 20	PUMP, SOLUTION	140 - 8
PIPE, EXHAUST	30 - 11	PUMP, TRANSFER (ROBERT BOSCH) (E.S.N. -568537)	30 - 28
PISTON COOLING JETS	20 - 10	PUMP, WATER	20 - 46
PISTON RINGS (6076) (ESN 500000-)	20 - 24	PUMP, FUEL INJECTION (NIPPONDENSO) (ESN 568538-)	30 - 30
PISTON/LINER KIT(6076) (ESN 500000-)	20 - 24	PUSH RODS	20 - 8
PISTON, ENGINE (6076)(ESN 500000-)	20 - 24		
PISTON, HYDROSTATIC DRIVE	50 - 33	R	
PLANT SHIELDS	80 - 30	R.H. CAB PANELS AND WINDOW HINGE	90 - 27
PLANT SHIELDS (CONV. UNITS, SKIP-ROW)	80 - 32	RADIATOR AND HOSES	20 - 40
PLANT SHIELDS, FRONT	80 - 28	RADIATOR SUPPORTS AND SIDE SCREENS	80 - 10
PLATE, TOP, PICKING UNIT (CONVENTIONAL UNITS)	110 - 24	RADIO, ANTENNA AND SPEAKERS	40 - 26
PLATES, PRESSURE, FRONT DRUM (CONVENTIONAL UNITS)	110 - 36	RAILS, ENGINE	80 - 2
PLATES, PRESSURE, FRONT DRUM (IN-LINE UNITS)	110 - 12	REAR AXLE	80 - 19
PLATES, PRESSURE, REAR DRUM (CONVENTIONAL UNITS)	110 - 37	REAR AXLE BRACKET	80 - 5
PLATES, PRESSURE, REAR DRUM (IN-LINE UNITS)	110 - 14	REAR AXLE EXTENSIONS	80 - 24
PLATFORM EXTENSION (IN-LINE UNITS)	90 - 12	REAR AXLE KNEE AND KNUCKLE	80 - 20
PLATFORM FLOOR AND SKIRTS	90 - 4	REAR AXLE TIE RODS	80 - 22
PLATFORM FRAME	90 - 2	REAR DRUM PRESSURE PLATES (CONVENTIONAL UNITS)	110 - 37
PLATFORM WIRING HARNESS	40 - 28	REAR DRUM PRESSURE PLATES (IN-LINE UNITS)	110 - 14
POST, "JET AIR" (CONVENTIONAL UNITS)	110 - 34	REAR HOOD	80 - 12
POST, STEERING	60 - 4	REAR OIL SEAL	20 - 29
POSTS, PICKING UNIT (IN-LINE UNITS)	110 - 4	REAR OIL SEAL GASKET	20 - 29
POSTS, REAR, PICKING UNIT (CONVENTIONAL UNITS)	110 - 28	REAR OIL SEAL HOUSING	20 - 29
POWER KIT, LUBRICATOR DRIVE	130 - 15	REAR SCRAPERS	80 - 15
POWER STEERING VALVE	60 - 6	REAR UNIT SIDE SHEETS AND FRONT HOOD (CONVENTIONAL UNITS)	110 - 32
PRESSURE PLATE, REAR DRUM (CONVENTIONAL UNITS)	110 - 37	REAR VIEW MIRRORS	90 - 56
PRESSURE PLATE, REAR DRUM (IN-LINE UNITS)	110 - 14	REAR WARNING LAMP AND TAIL LAMP	40 - 21
PRESSURE PLATES, FRONT DRUM (CONVENTIONAL UNITS)	110 - 36	REAR WHEEL	80 - 27
PRESSURE PLATES, FRONT DRUM (IN-LINE UNITS)	110 - 12	RECEIVER-DRYER, A/S	90 - 58
PRESSURE WATER LINES AND FITTINGS (CONVENTIONAL UNITS)	140 - 16	REFLECTORS, CHASSIS	170 - 6
PRESSURE WATER LINES AND FITTINGS (IN-LINE UNITS TO SPINDLE MOISTENER)	140 - 14	REFRIGERANT, AIR CONDITIONER (S.N. 2001-)	90 - 66
PRESSURIZER BLOWER	90 - 48	RELAYS AND CIRCUIT BREAKERS	40 - 8
PULLEY, COMPRESSOR (NIPPONDENSO)	90 - 62	RELAYS AND FUSES, CONSOLE	40 - 12
PULLEY, CRANKSHAFT	20 - 27	REMOTE FILL	140 - 4
PULLEY, FAN	20 - 42	REPAIR KIT, ELECTRONIC SPRAY VALVE	140 - 20
PUMP AND CLUTCH, LUBRICATION	130 - 4	REPAIR KIT, LUBRICATION PUMP	130 - 19
		REPAIR KIT, UNIT LIFT CYLINDER (CONVENTIONAL UNITS)	70 - 42
		REPAIR KIT, UNIT LIFT CYLINDER (IN-LINE) (SN -6385)	70 - 44
		REPAIR KIT, UNIT LIFT CYLINDER (IN-LINE) (SN 6386-)	70 - 45
		REPAIR KIT, WATER PUMP (6076)	20 - 48

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
REPLACEMENT HYDRAULIC PUMP	70 - 3	SHAFT, BASKET COMPACTOR DRIVE	160 - 23
RESERVE LUBRICATION PANEL (CONVENTIONAL UNITS)	130 - 14	SHAFT, FAN	150 - 16
RESERVE LUBRICATION PANEL (IN-LINE UNITS)	130 - 13	SHAFT, HYDROSTATIC PUMP	50 - 28
RESERVOIR, BRAKE	60 - 16	SHAFT, PICKER BAR	120 - 30
RESERVOIR, HYDRAULIC/HYDROSTATIC	70 - 25	SHAFT, PICKER BAR	120 - 31
RINGS, PISTON (6076) (ESN 500000-)	20 - 24	SHAFT, PINION, TRANSMISSION	50 - 10
ROCKER ARM COVER (6076)	20 - 7	SHAFT, ROCKER ARM	20 - 8
ROCKER ARM COVER GASKET (6076)	20 - 7	SHAFT, TRANSMISSION INPUT	50 - 8
ROCKER ARM SHAFT	20 - 8	SHAFT, TRANSMISSION UNIT DRIVE	50 - 15
ROCKER ARMS	20 - 8	SHAFTS, DIFFERENTIAL	50 - 12
ROCKSHAFT AND TUBES, STABILIZER (CONVENTIONAL UNITS)	100 - 8	SHEAVE, ALTERNATOR	40 - 6
ROCKSHAFT PIVOT LUBRICATION LINES	160 - 1	SHEAVE, FAN	150 - 16
ROCKSHAFT, SAFETY STOP AND UNIT LIFT BRACKET (CONVENTIONAL UNITS)	100 - 6	SHEAVE, HYDROSTATIC PUMP	50 - 27
RODS, CONNECTING (6076)	20 - 24	SHELL, PICKING UNIT (CONVENTIONAL UNITS)	110 - 23
RODS, PUSH	20 - 8	SHELL, PICKING UNIT, IN-LINE (101 - 2000)	110 - 1
RODS, STALKLIFTER (CONVENTIONAL UNITS)	110 - 47	SHIELD, EXHAUST VALVE (6076)	20 - 4
RODS, STALKLIFTER (IN-LINE UNITS)	110 - 48	SHIELD, WHEEL, RIGHT-HAND (IN-LINE UNITS, 4-ROW 30-INCH)	80 - 33
ROOF, CAB	90 - 32	SHIELDS, PLANT	80 - 30
ROOF, INNER	90 - 34	SHIELDS, PLANT (CONV. UNITS, SKIP-ROW)	80 - 32
ROTOR, FAN	150 - 16	SHIELDS, PLANT, FRONT	80 - 28
ROW ADJUSTMENT SCREW (CONVENTIONAL UNITS)	110 - 34	SHIFTER CAM, TRANSMISSION	50 - 7
ROW UNIT MONITOR (CONVENTIONAL UNITS)	40 - 35	SHIFTER FORKS	50 - 6
ROW UNIT MONITOR (IN-LINE UNITS)	40 - 34	SHIM, LINER (6076)	20 - 24
S			
SAFETY DECALS	170 - 2	SHOE, HEIGHT SENSING (IN-LINE UNITS)	110 - 20
SAFETY STOPS, UNIT LIFT (CONVENTIONAL UNITS)	100 - 6	SHOE, INNER HEIGHT SENSING (CONVENTIONAL UNITS)	110 - 42
SCRAPERS, REAR	80 - 15	SHOE, OUTER HEIGHT SENSING (CONVENTIONAL UNITS)	110 - 44
SCREENS, ENGINE SIDE	80 - 8	SHOES, BRAKE	60 - 14
SCREENS, SIDE	80 - 10	SHORT BLOCK (WITH HEAD BOLTS)	20 - 14
SEAL KIT FOR 1.50 DIA. MASTER HYDRAULIC CYLINDER	70 - 40	SHORT BLOCK (WITHOUT HEAD BOLTS)	20 - 12
SEAL KIT FOR 1.50 DIA. SLAVE HYDRAULIC CYLINDER	70 - 41	SHORT BLOCK GASKET KIT (6076)	20 - 22
SEAL KIT, COMPRESSOR	90 - 60	SIDE HANDRAILS	160 - 20
SEAL KIT, COMPRESSOR (S.N. -2000)	90 - 64	SIDE SHEETS AND PANELS (CONVENTIONAL UNITS)	110 - 34
SEAL, FRONT OIL	20 - 30	SIGNS	170 - 1
SEAL, REAR OIL	20 - 29	SIGNS, CHASSIS	170 - 6
SEAL, WATER PUMP	20 - 46	SIGNS, SAFETY	170 - 2
SEALANT	110 - 22	SKIP ROW GEAR BOX	120 - 8
SEAT ADJUSTMENT AND COVER (SN -6000)	90 - 18	SKIRTS, PLATFORM	90 - 4
SEAT ADJUSTMENT AND COVER (SN 6001-)	90 - 20	SLAVE CYLINDER, BRAKE	60 - 18
SEAT ARMREST LINKS (PERSONAL- POSTURE™ SEAT)	90 - 16	SLIP CLUTCH, DRUM	120 - 24
SEAT ASSEMBLY	90 - 13	SMALL INSIDE COTTON DOOR (IN-LINE)	150 - 5
SEAT SUSPENSION	90 - 22	SOLENOID SWITCH, STARTER	40 - 2
SEAT SUSPENSION SUPPORT	90 - 24	SOLENOID, ELECTRIC SHUT-OFF (ESN -512892)	30 - 33
SEAT, OPERATOR'S	90 - 14	SOLENOID, ELECTRIC SHUT-OFF (ESN 512893-) (RB OR ND)	30 - 35
SENDER, COOLANT AND ENGINE	20 - 6	SOLENOID, STARTER (12V F4)	40 - 4
SENDER, OIL PRESSURE	20 - 10	SOUND-GARD CAB	90 - 25
SENSOR, CRANKSHAFT POSITION	20 - 31	SPACER, AXLE	80 - 25
SENSOR, CRANKSHAFT SPEED	20 - 31	SPACER, ENGINE FAN	20 - 43
SENSOR, ENGINE SPEED (6076)	20 - 31	SPACERS, AXLE (CONV. UNIT, SKIP-ROW) (64" SKIP ROW)	80 - 26
SEPARATOR, WATER (-JUNE 1994)	30 - 14	SPEAKERS, ANTENNA AND RADIO	40 - 26
SERVICE KIT, ELECTRICAL CONNECTOR	40 - 40	SPINDLE CLEANER	140 - 2
SERVO, HYDROSTATIC PUMP	50 - 30	SPINDLE LUBRICANT	130 - 2
SET, COMPRESSOR HARDWARE (NIPPONDENSO)	90 - 63	SPINDLE MOISTENER	140 - 18
		SPINDLE, PICKER BAR	120 - 32
		SPIRAL BEVEL GEARS AND BEARINGS	50 - 14
		SPRAY VALVE REPAIR KIT	140 - 20
		SPROCKET AND LINKAGE, DOFFER DRIVE TIGHT	120 - 41
		SPROCKETS, PICKING UPPER HOUSING	120 - 26

ALPHABETICAL INDEX - CONTINUED

	PAGE		PAGE
SPROCKETS, UPPER DOFFER	120 - 36	SWITCHES, AIR CONDITIONER	90 - 50
STABILIZER CYLINDER COVER	80 - 16	SWITCHES, CONSOLE CONTROL PANEL	40 - 12
STABILIZER CYLINDER HYDRAULIC HOSES & FITTINGS	70 - 30		
STABILIZER ROCKSHAFT AND TUBES (CONVENTIONAL UNITS)	100 - 8	T	
STABILIZER VALVE	70 - 38	TACHOMETER	40 - 48
STABILIZER, TOP LINK (IN-LINE UNITS)	100 - 1	TAIL LAMP	40 - 21
STALK LIFTERS (CONVENTIONAL UNITS)	110 - 40	TANK, FUEL	30 - 12
STALK LIFTERS (IN-LINE UNITS)	110 - 18	TANK, LUBRICATION	130 - 2
STALKLIFTER RODS (CONVENTIONAL UNITS)	110 - 47	TANK, OVERFLOW, RADIATOR	20 - 40
STALKLIFTER RODS (IN-LINE UNITS)	110 - 48	TANK, WATER	140 - 2
STARTER GEAR	20 - 25	TERMINAL AND WIRING KIT	40 - 38
STARTER SOLENOID (12V F4)	40 - 4	TERMINALS AND CONNECTORS	40 - 37
STARTER SOLENOID COVER (NIPPONDENSO)	40 - 3	TERMINALS, ELECTRICAL, WEATHERPACK	40 - 44
STARTER SOLENOID SWITCH	40 - 2	TETHER, OPERATOR PRESENCE BYPASS	90 - 72
STARTER SWITCH AND KEY	40 - 12	THERMOSTAT HOUSING, FRONT	20 - 44
STARTING MOTOR (NIPPONDENSO) (12V F4)	40 - 3	THERMOSTATS	20 - 44
STEERING COLUMN (SN -XXXX)	60 - 1	THROTTLE CONTROL CABLE	30 - 44
STEERING COLUMN (SN XXXX-)	60 - 2	THROTTLE LEVER, FUEL INJECTION PUMP (ROBERT BOSCH) (ESN -568537)	30 - 38
STEERING CYLINDER	70 - 50	THRUST BEARING (6076)	20 - 28
STEERING CYLINDER KIT	70 - 51	TIE RODS, REAR AXLE	80 - 22
STEERING POST AND SUPPORT	60 - 4	TIGHTENER, DOFFER DRIVE	120 - 41
STEERING TUBES & HOSES TO CYLINDERS	60 - 10	TIMING GEAR COVER	20 - 30
STEERING TUBES AND HOSES, PLATFORM	60 - 8	TIMING GEAR COVER GASKET	20 - 30
STEERING VALVE, POWER	60 - 6	TOP LINK STABILIZER (IN-LINE UNITS)	100 - 1
STEP (CONVENTIONAL UNITS)	90 - 10	TOP PLATE, UPPER HOUSING (CONVENTIONAL UNITS)	110 - 24
STIFFENERS, BOTTOM FRAME (CONVENTIONAL UNITS)	110 - 26	TOP, BASKET	160 - 16
STRAPS, ENGINE LIFT (6076) (ENGINE S/N 500000-)	20 - 21	TORQ-GARD ENGINE OIL	20 - 1
STROKE CONTROL VALVE SHUT-OFF KIT	70 - 6	TOW ANCHOR	80 - 4
STROKE CONTROL VALVE, HYDRAULIC PUMP	70 - 6	TRANSFER PUMP (ROBERT BOSCH) (E.S.N. -568537)	30 - 28
STUD, PICKER BAR DRUM	120 - 34	TRANSFER PUMP, FUEL (NIPPONDENSO) (ESN 568538-)	30 - 43
SUN GEAR, PICKING UNIT UPPER HOUSING	120 - 26	TRANSFER PUMP, FUEL (NIPPONDENSO) (ESN 568538-)	30 - 30
SUPPLEMENTAL HEIGHT SENSING HYDRAULIC LINES	70 - 18	TRANSFER PUMP, FUEL (ROBERT BOSCH) (ESN -568537)	30 - 42
SUPPLEMENTARY TERMINALS AND CONNECTORS	40 - 37	TRANSFER PUMP, LUBRICATION	130 - 16
SUPPORT, BASKET	160 - 2	TRANSMISSION AND DIFFERENTIAL HOUSING AND SHIFTER FORKS	50 - 6
SUPPORT, DUCT	160 - 12	TRANSMISSION AND DIFFERENTIAL HOUSING COVER AND SHIFTER CAM	50 - 7
SUPPORT, HYDRAULIC PUMP	70 - 2	TRANSMISSION BRACKETS	50 - 3
SUPPORT, SEAT SUSPENSION	90 - 24	TRANSMISSION INPUT SHAFT, GEARS, LUBE PUMP AND BEARINGS	50 - 8
SUPPORT, WATER PUMP	140 - 6	TRANSMISSION PINION SHAFT, GEARS AND BEARINGS	50 - 10
SUPPORTS, ENGINE HOOD	80 - 8	TRANSMISSION SHIFT CABLE	50 - 4
SUPPORTS, LUBRICATION TANK	130 - 2	TRANSMISSION UNIT DRIVE SHAFT AND BEARINGS	50 - 15
SUPPORTS, RADIATOR	80 - 10	TRANSMISSION, COMPLETE	50 - 2
SUPPORTS, WATER TANK	140 - 2	TUBE, AIR (CONVENTIONAL UNITS)	150 - 11
SWASHPLATE, HYDROSTATIC PUMP	50 - 30	TUBE, AIR (IN-LINE)	150 - 12
SWITCH (NIPPONDENSO) (12V F4)	40 - 4	TUBE, ENGINE OIL DIPSTICK (6076)	20 - 36
SWITCH (STARTER) (12V F4)	40 - 4	TUBE, WATER MANIFOLD BYPASS	20 - 44
SWITCH, BASKET INTERLOCK	40 - 29	TUBES, ENGINE AIR INTAKE	30 - 2
SWITCH, COMPACTOR FOOT CONTROL (SERIAL NO. -2000)	40 - 19	TUBES, STABILIZER ROCKSHAFT (CONVENTIONAL UNITS)	100 - 8
SWITCH, COMPACTOR FOOT CONTROL (SERIAL NO. 2001-)	40 - 20	TURBOCHARGER	30 - 6
SWITCH, DIMMER	40 - 18	TURBOCHARGER CENTER HOUSING (6076) (SCHWITZER)	30 - 8
SWITCH, FLUSH SYSTEM FOOT CONTROL (SERIAL NO. -2000)	40 - 19	TURBOCHARGER GASKET	30 - 6
SWITCH, FLUSH SYSTEM FOOT CONTROL (SERIAL NO. 2001-)	40 - 20	TURBOCHARGER OIL LINES	30 - 6
SWITCH, HORN	40 - 14	TURN SIGNAL CONTROL AND WIRING HARNESS	40 - 14
SWITCH, HYDROSTATIC CONTROL HANDLE (XXXX-)	90 - 44		
SWITCH, IGNITION	40 - 12		
SWITCH, OIL PRESSURE	20 - 10		
SWITCH, STARTER SOLENOID	40 - 2		