

670, 770, 790, 870, 970, 1070 Compact Utility Tractors

TECHNICAL MANUAL

**John Deere
Worldwide Commercial and
Consumer Equipment Division**

**TM1470 (15MAR99)
Replaces TM1470 (15MAR94)**

Litho in U.S.A

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

N This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

FOS MANUALS—REFERENCE

TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

Contents

SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Repair Specifications
- Group 20—Fuel and Lubricants
- Group 25—Serial Number Locations

SECTION 20—ENGINE REPAIR

- Group 05—670/770
- Group 06—870/970/1070
- Group 07—790
- Group 10—Cooling System
- Group 15—Throttle and Governor Control Linkage
- Group 20—Fuel System

SECTION 40—ELECTRICAL SYSTEM

- Group 05—Alternator
- Group 10—Starter
- Group 15—Sender, Switches and Gauges

SECTION 50—POWER TRAIN REPAIR—670/770/790

- Group 05—Clutch Housing
- Group 06—Single Stage Clutch
- Group 07—Dual Stage Clutch
- Group 10—Transmission
- Group 15—Rear PTO Drive Shaft
- Group 20—Differential
- Group 25—Final Drive
- Group 30—Mechanical Front Wheel Drive
- Group 35—Throttle and Governor Control Linkage

Section 55—POWER TRAIN REPAIR —870/970/1070

- Group 05—Clutch Housing
- Group 06—Dual Stage Clutch
- Group 10—Transmission
- Group 15—Rear PTO Drive Shaft
- Group 20—Differential
- Group 25—Final Drive
- Group 30—Mechanical Front Wheel Drive—870
- Group 35—Mechanical Front Wheel Drive
—970/1070
- Group 40—Mid Mount PTO

SECTION 60—STEERING AND BRAKE REPAIR

- Group 05—Manual Steering
- Group 10—Power Steering
- Group 15—Brake Repair—670/770/790
- Group 20—Brake Repair—870/970/1070

SECTION 70—HYDRAULIC REPAIR

- Group 05—Hydraulic Pump and Filter
- Group 10—Rockshaft—670/770/790
- Group 11—Rockshaft—870/970/1070
- Group 15—Selective Control Valve
- Group 20—Rear Auxiliary Hydraulic Lines

SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Wheels
- Group 10—Front Axle
- Group 15—Hood
- Group 20—3-Point Hitch
- Group 25—Seat and Support
- Group 30—Roll-Gard
- Group 35—Mower Spindles
- Group 40—Mower Gearbox

SECTION 210—OPERATIONAL CHECKOUT PROCEDURE AND SPECIFICATIONS

- Group 05—Test and Adjustment Specifications
- Group 10—Operational Checkout Procedures

SECTION 220—ENGINE OPERATION, TESTS, AND ADJUSTMENTS

- Group 05—Component Locations
- Group 10—Theory of Operation
- Group 15—Engine System Diagnosis

SECTION 240—ELECTRICAL SYSTEM OPERATION AND TESTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis and Test
- Group 20—Schematic

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1470-19-15JAN99

COPYRIGHT©1999
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**

SECTION 250—POWER TRAIN—670/770/790

Group 05—Component Location

Group 10—Theory of Operation

Group 15—Diagnosis and Test

SECTION 255—POWER TRAIN—870/970/1070

Group 05—Component Location

Group 10—Theory of Operation

Group 15—Diagnosis and Test

SECTION 260—STEERING AND BRAKES

Group 05—Component Location

Group 10—Theory of Operation

Group 15—Diagnosis and Test

SECTION 270—HYDRAULIC SYSTEM

Group 05—Component Location

Group 10—Theory of Operation

Group 15—Diagnosis and Test

Group 20—Schematic

240

250

255

260

270

INDX

Contents

240

250

255

260

270

INDX

Section 10

GENERAL INFORMATION

Contents

	Page	
Group 05—Safety	10-05-1	
Group 10—General Specifications		
Machine Specifications		
670/770/790.	10-10-1	
870/970/1070.	10-10-4	
Group 15—Repair Specifications		
Repair Specifications	10-15-1	
Metric Series Torque Chart	10-15-10	
Inch Series Torque Chart	10-15-11	
Group 20—Fuel and Lubricants		
Fuel Specifications	10-20-1	
Fuel Storage.	10-20-1	
Filling the Fuel Tank	10-20-2	
Diesel Engine Oil	10-20-3	
Engine Coolant.	10-20-4	
Anti-Chatter Transmission/Hydraulic Oil.	10-20-4	
Gear Oil	10-20-5	
Extreme Pressure Grease	10-20-5	
Alternative Lubricants	10-20-6	
Lubricant Storage.	10-20-6	
Group 25—Serial Number Locations		10-25-1

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



O53,ALERT -19-16JUN87

10
05
1
-UN-07DEC88
T81389

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



O53,SIGNAL -19-07OCT85


-19-30SEP88
TS187

FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



O53,READ -19-23APR87

-UN-23AUG88
TS201

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



O53,FLAME -19-05JAN88


-UN-23AUG88
TS227

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



O53,SPARKS -19-05JAN88


-UN-23AUG88
TS204

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



O53,FIRE2 -19-03MAR88

-UN-23AUG88
TS291

PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10—15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.



O53, POISON -19-21DEC87

SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



O53, RCAP -19-29NOV88


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.




X9811
-UN-23AUG88

O53,FLUID -19-01DEC88

PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.




TS230
-UN-24MAY89

O53,PARK -19-05JAN88

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.




O53,LOWER -19-21DEC87

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.




O53,WEAR -19-23APR87

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




O53,LOOSE -19-21DEC87

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



O53,AIR

-19-05JAN88

TS220
-UN-23AUG88

UNDERSTAND CORRECT SERVICE

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.

Catch draining fuel, oil, or other fluids in suitable containers. Do not use food or beverage containers that may mislead someone into drinking from them. Wipe up spills at once.



O53,LIGHT


-19-23FEB88

TS223
-UN-23AUG88

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



O53,LIFT


-19-05JAN88

TS226
-UN-23AUG88

KEEP ROPS INSTALLED PROPERLY

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



O53,ROPS3 -19-23APR87

SERVICE TIRES SAFELY


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



O53,RIM -19-21DEC87