
TM120, TM130, TM140, TM155, TM175, TM190 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	11
SECTION 21 - TRANSMISSION SYSTEMS	12
SECTION 23 - DRIVE LINES	21
SECTION 25 - FRONT AXLE	23
SECTION 27 - MECHANICAL REAR WHEEL DRIVE	26
SECTION 31 - POWER TAKE-OFF	29
SECTION 33 - BRAKES	33
SECTION 35 - HYDRAULIC SYSTEM	36
SECTION 41 - STEERING	55
SECTION 44 - FRONT AXLE AND WHEELS	57
SECTION 50 - AUXILIARY UNITS	58
SECTION 55 - ELECTRICAL SYSTEM	60
SECTION 90 - CAB	109

The following pages are the collation of the contents pages from each section and chapter of the TM Series Repair manual. Complete Repair part # 87611238.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TM Series Tractors.

SECTION 00 - GENERAL

BOOK 1 - 87611239

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	3
	Important Notice	3
	Shimming	3
	Rotating Shaft Seals	3
	O Rings	3
	Sealers	3
	Bearings	3
	Spring Pins	3
	Precautionary Notice	4
	Equipment Notice	4
	Spare Parts Notice	4
	General Notices	4
	Health and Safety	5
	Health and Safety Precautions	5
	Precautionary Statements	14
	Safety	15
	The Tractor	15
	Driving the Tractor	15
	Operating the Tractor	15
	Operating the PTO	16
	Servicing the Tractor	16
	Diesel Fuel	17
	ROPS	17
	Ecology and the Environment	18
	Precautions	18
	Minimum Hardware Tightening Torques	19
	Federal Emissions Warranty	21
	California Emission Control Warranty Statement	22
	Lubricants and Fluids	24
	Sulphur in Fuel	24
	Biodegradable Transmission, Drive Axle, Hub, and Hydraulic System Oil	24

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 1 - Separating and Removing The Engine

CONTENTS

Section	Description	Page
	Tightening Torques	2
	Special Tools	3
	Separating and Removing the Engine	4
	Front Axle and Support	4
	Separating Front Axle and Support from Engine	4
	Installation	12
	Engine and Front Support	14
	Separating Engine and Front Support from Transmission	14
	Installation	20
	Engine	21
	Removal	21
	Installation	24

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 2 - 7.5L CNH Engine

CONTENTS

Section	Description	Page
	Specifications	6
	Cylinder Block	6
	Cylinder Head	6
	Exhaust Valves	7
	Intake Valves	7
	Valve Springs	7
	Camshaft Lobe Lift	7
	Installed Valve Recession	7
	Valve Inserts	7
	Valve Seats	8
	Valve Timing	8
	Camshaft Idler Gear	8
	Camshaft Gear	8
	Rocker Arm Shaft	8
	Rocker Arm	8
	Tappets	8
	Camshaft	8
	Connecting Rods	9
	Piston Pin	9
	Pistons	9
	Piston Rings	9
	Crankshaft	10
	Crankshaft Drive Gear	10
	Main Bearing	10
	Crankpin Bearings	10
	Crankshaft Re-grinding	11
	Flywheel	11
	Oil Pump	11
	Oil Pressure	11
	Oil Filter Support	12
	Engine Oils and Change Periods	12

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 2 - 7.5L CNH Engine (Continued)

CONTENTS

Section	Description	Page
	Engine Oil Capacities	12
	Grease and Sealants	12
	Thermostat	12
	Radiator Cap	12
	Water Pump	12
	Fan Belt	12
	Cooling System Capacities	12
	Cooling Fluid	12
	Tightening Torques	13
	Description	13
	Special Tools	15
	Troubleshooting	16
	Description of Operation	20
	General	20
	Cylinder Block Assembly	20
	Cylinder Head Assembly	21
	Camshaft Assembly	21
	Crankshaft Assembly	21
	Connecting Rods	22
	Pistons	22
	Manifolds	22
	Timing Gears	22
	Lubrication System	23
	Crankcase Breather	26
	Overhaul - Cylinder Head	27
	Introduction	27
	Operations or Repairs That Can Be Performed With the Engine Still in the Vehicle	27
	Timing Check	28
	Cylinder Head, Valves, and Related Parts	31
	Cylinder Head Removal	31
	Cylinder Head Disassembly	34

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 2 - 7.5L CNH Engine (Continued)

CONTENTS

Section	Description	Page
	Cylinder Head Inspection and Repair	35
	Cylinder Head Assembly	39
	Engine Front Cover and Timing Gears	42
	Timing Gears Check and Removal	42
	Installation	44
	Oil Pan	47
	Removal	47
	Inspection and Repair	47
	Installation	47
	Flywheel	48
	Removal	48
	Inspection and Repair	48
	Installation	48
	Rear Cover Plate	49
	Removal	49
	Installation	49
	Oil Pump	50
	Removal	50
	Disassembly	51
	Inspection and Repair	51
	Installation	51
	Oil Pressure Relief Valve	52
	Removal	52
	Installation	52
	Camshaft	53
	Removal	53
	Inspection and Repair	53
	Camshaft Bearings	54
	Removal	54
	Installation	54
	Camshaft and Tappet Installation	54

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 2 - 7.5L CNH Engine (Continued)

CONTENTS

Section	Description	Page
	Pistons	55
	Removal	55
	Inspection and Repair	56
	Connecting Rod Bush Replacement	58
	Cylinder Block Overhaul	59
	Cylinder Bore	60
	Sleeving - Boring and Honing	61
	Piston and Piston Ring Replacement and Installation	62
	Crankshaft	65
	Removal	65
	Inspection and Repair	65
	Assembly	66
	Front Crankshaft OSL Seat Installation	69
	Engine Compression Test	71
	Test Procedure	71
	Test Readings	71
	Test Conclusion	71
	Cooling System - (CNH 7.5 Liter Engine)	72
	Description of Operation	72
	Troubleshooting	74
	Tightening Torques	75
	Specifications	75
	Thermostat	75
	Water Pump	75
	Drive Belt	75
	Cooling Capacities	75
	Coolant Flow	75
	Cooling Fluid	75
	Overhaul - Cooling System	76
	Radiator	76
	Removal	76

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 2 - 7.5L CNH Engine (Continued)

CONTENTS

Section	Description	Page
	Inspection and Repair	77
	Installation	77
Thermostat		78
	Removal	78
	Inspection and Repair	78
	Installation	78
Temperature Warning Sender		79
	Installation	79
Vistronic Fan Assembly		79
	Clutch Testing	79
	Removal	79
	Installation	79
	Fan Blade Removal	80
	Assembly	80
Fan Belt Tensioner		80
	Removal	80
	Inspection and Repair	80
	Assembly	80
Idler Pulley (with air conditioning only)		81
Water Pump		81
	Removal	81
	Disassembly	82
	Inspection and Repair	83
	Assembly	83
	Installation	84

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 3 - Fuel System

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	3
	Special Tools	4
	Description of Operations	5
	Single Filter Fuel System	5
	Duel Filter Fuel System	6
	Fuel Shut Off (Injection Pump)	7
	Fuel Injection Pumps	7
	Fuel Sedimenter/Primary Filter	8
	Electric Lift Pump	8
	Secondary Fuel Filter	9
	Power Boost	9
	Constant Engine Speed Control	10
	175 and 190 Tractors	10
	High RPM Switch Priority	10
	Fuel System Overhaul	11
	Bosch VE Type Fuel Injection Pump (Mechanically Governed)	11
	Removal	11
	Inspection	12
	Fuel Injection Pump Timing and Installation	12
	Bosch VP Fuel Injection Pump (Electronically Controlled)	15
	System Diagram	15
	Removal	16
	Inspection	17
	Injection Pump Timing Check	17
	Injection System Bleeding	21
	Fuel Injectors	21
	Removal	21
	Testing	22
	Disassembly	23
	Inspection and Repair	24
	Assembly	26
	Installation	26

SECTION 10 - ENGINE

BOOK 1 - 87611239

Chapter 3 - Fuel System (Continued)

CONTENTS

Section	Description	Page
	Electric Lift Pump	26
	Removal	26
	Testing	27
	Turbocharger	27
	Removal	27
	Disassembly	28
	Cleaning	28
	Inspection	29
	Assembly	29
	Installation	29
	Air Intake Components	31
	Description of Operation	31
	Air Cleaner	31
	Removal	31
	Disassembly (Mechanically Governed Engines)	31
	Disassembly (Electronically Governed Engines)	31
	Inspection and Repair	32
	Assembly	34
	Main Fuel Tank	34
	Removal and Installation	34
	Auxiliary Fuel Tank	36
	Removal and Installation	36
	Crankcase Ventilation	36
	Foot Throttle Cable (Mechanically Governed Engines)	36
	Replacement	36
	Adjustment	37
	Hand Throttle Cable	37
	Replacement	37
	Adjustment	37

SECTION 18 - CLUTCH

BOOK 1 - 87611239

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
	Specifications	2
	13" LUK Clutch	2
	14" Valeo Clutch	2
	Tightening Torques	3
	Sectional Views	4
	13" LUK Clutch - Longitudinal Sectional View	4
	Hydraulic Clutch Control Assembly	4
	Special Tools	5
	Description and Operation	5
	General	5
	Operation	5
	Troubleshooting	6
	Overhaul	7
	Clutch	7
	Disassembly and Assembly	7
	Clutch Hydraulic Control	9
	Removal-Installation	9
	Clutch Pedal Adjustment	10
	Disassembly-Assembly	11
	Clutch Control Hydraulic Circuit Bleeding	13

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 1 - Semi-Powershift Transmission

CONTENT

Section	Description	Page
	Specifications	3
	Semi-Powershift Transmission and Range Gears	3
	Creeper Gears	5
	Tightening Torques	6
	Special Tools	7
	Sectional Views	11
	Semi-Powershift	11
	Range Control Valve	12
	Description and Operation	14
	Introduction	14
	Clutches	14
	Direction, Speed and Range Changes	15
	Gear Selection Sequence	16
	Selecting a Gear - No Clutch Pedal	16
	Selecting a Gear With Clutch Pedal	16
	Range Shifting	16
	Shuttling	16
	Failed Synchronizer Engagement	16
	Semi-Powershift Transmission Oil Flow Illustrations	17
	Semi-Powershift Transmission Oil Flow with 1st Gear Forward Engaged	17
	Semi-Powershift Transmission Oil Flow with 6th Gear Forward Engaged	18
	Power Flow 1st Gear Medium Range-Forward	19
	Power Flow 2nd Gear Medium Range-Forward	20
	Power Flow 2nd Gear Medium Range-Reverse	21
	Limp Home Feature	22
	Description	22
	Instructions	22
	Testing and Calibration	23
	Transmission Clutches, A, B, C, D and E	23
	Pressure Test	23

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 1 - Semi-Powershift Transmission (Continued)

CONTENT

Section	Description	Page
	Low, Medium, High and Reverse Synchronizer	25
	Pressure Test	25
	Clutch and Synchronizer Calibration	27
	Calibration Procedure	27
	Tractor Preparation	27
Overhaul		30
	Semi-Powershift Transmission Housing	30
	Removal	30
	Installation	33
	Transmission Overhaul	34
	Disassembly	34
	Assembly	45
	Adjustments - Internal Components	50
	Semi-Powershift Range Control Valve Assembly	54
	Removal	54
	Installation	55
	Disassembly	56
	Assembly	59
	Semi-Powershift Range Control Solenoid Valve	60
	Replacement	60
	Semi-Powershift Transmission Control Valve	62
	Removal	62
	Installation	63
	Semi-Powershift Transmission Solenoid Valve	64
	Replacement	64

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 2 - Full Powershift Transmission - 30 and 40 kph Transmission

CONTENT

Section	Description	Page
	Specifications	3
	Creeper Gears	5
	Tightening Torques	6
	Special Tools	11
	Description and Operation	14
	Full Powershift Transmission Components	14
	Operation	16
	Full Powershift Transmission Power Flows	18
	1st Gear Selected	20
	10th Gear Selected	20
	16th Gear Selected	21
	Reverse 5th Gear Selected	21
	Input Sensors	22
	Output Devices	24
	Control Device	24
	Driving the Tractor	25
	Auto Shift Function	27
	Auto Shifting in Road Range	27
	Auto Shifting in Field Range	28
	Changing the Gear Span	28
	Go To Mode	29
	Speed Matching	30
	Programming Reverse Gear Ratios	31
	Testing and Calibration	33
	Clutch Calibration	33
	Description	33
	Calibration Procedure	33
	Automatic Calibration Sequence Mode	35
	Calibration Fault Codes	36

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 2 - Full Powershift Transmission - 30 and 40 kph Transmission (Continued)

CONTENT

Section	Description	Page
	Pressure Testing	37
	Transmission Clutches, A, B, C, D, E, F1, F2, F3 and R	37
Troubleshooting		40
	Fault Codes and Fault Finding	40
	Full Powershift Fault Code Display Logic	41
	Limp Home Feature	44
	Description	44
	Instructions	44
Overhaul		45
	Full Powershift Transmission Housing	45
	Removal	45
	Installation	49
	Disassembly	51
	Transmission Components Disassembly	62
	Oil Manifold Bush	62
	Transmission Upper Speed Shaft End Play Adjustment	63
Clutch Overhaul		64
	Clutch 'A'	64
	Clutch 'B'	66
	Clutch 'C'	67
	Clutch 'D'	69
	Clutch 'E'	70
	Clutch 'F3'	71
	Clutch 'F1'	72
	Clutch 'F2'	73
	Reverse Clutch	75
Transmission Reassembly		76
	A, B, C, D and E Clutch Testing	83
	Output Shaft (Fast/Slow) End Play Adjustment	84
	Medium Range Shaft End Play Adjustment	85

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 3 - Full Powershift Transmission, 175 - 190 Models

CONTENT

Section	Description	Page
	Specifications	3
	Full Powershift Transmission	3
	Creeper Gears	5
	Tightening Torques	6
	Special Tools	8
	Description and Operation	11
	Introduction	11
	Operation	14
	Top Cover - 175 and 190 Models	16
	Clutches	17
	Creeper Gears	18
	Power Flows	19
	Input Sensors	24
	Output Devices	26
	Control Device	26
	Full Powershift Transmission Controls	27
	Powershift Control	27
	Shuttle Lever	28
	Clutch Pedal	28
	Driving the Tractor	29
	Auto Shift Function	31
	Changing Gear Shift Threshold	34
	Standby Mode	34
	To Exit the Program	34
	Go To Mode	35
	Speed Matching	36
	Programming Reverse Gear Ratios	36
	Creeper Gears (where fitted)	39
	Creeper Gear Selection	39
	Testing and Calibration	40
	Clutch Calibration	40

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 3 - Full Powershift Transmission, 175 - 190 Models (Continued)

CONTENT

Section	Description	Page
	Description	40
	Calibration Procedure	40
	Automatic Calibration Sequence Mode	43
	Calibration Fault Codes	44
	Pressure Testing	45
	Transmission Clutches, A, B, C, D, E, F1, F2, F3, F4 and R	45
Troubleshooting		48
	Fault Codes and Fault Finding	48
	Full Powershift Fault Code Display Logic	49
	Limp Home Feature	52
	Description	52
	Operation	52
Overhaul		53
	Full Powershift Transmission Housing	53
	Removal	53
	Installation	58
	Disassembly	60
	Transmission Component Disassembly	73
	Oil Manifold Bush	73
	Transmission Upper Speed Shaft End Play Adjustment	74
	Clutch Overhaul	75
	Clutch 'A', 'B', 'C', 'D', 'E'	75
	Clutch 'A'	76
	Clutch 'B'	77
	Clutch 'C'	78
	Clutch 'D'	80
	Clutch 'E'	81
	Clutch 'F3'	82
	Clutch 'F1'	83
	Clutch 'F2'	84
	Reverse Clutch	86

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 3 - Full Powershift Transmission, 175 - 190 Models (Continued)

CONTENT

Section	Description	Page
	Transmission Rear Housing	87
	Disassembly	87
	Pump Drive Gear Installation	88
	Assembly	89
	Clutch Testing	96
	Output Shaft (Fast/Slow) End Play Adjustment	97
	Medium Range Shaft End Play Adjustment	98

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 4 - Dual Command Transmission (Hi-Lo)

CONTENT

Section	Description	Page
	Specifications	2
	Hi-Lo Transmission and Range Gears	2
	Creeper Gears	4
	Shuttle Gears	4
	Tightening Torques	5
	Special Tools	7
	Sectional Views	11
	Dual Command Transmission - Hi-Lo	11
	Range and Speed Control Assembly	12
	Hi-Lo Control Valve	12
	Description and Operation	13
	General	13

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 4 - Dual Command Transmission (Hi-Lo) (Continued)

CONTENT

Section	Description	Page
	Hi-Lo Transmission Oil Flow	14
	Oil Flow with Direct Drive Engaged	14
	Oil Flow with Under Drive Engaged	15
	Testing and Calibration	16
	Clutch and Synchronizer Calibration	16
	Calibration Procedure	16
	Transmission Clutches A and B	19
	Pressure Test	19
	Shuttle Synchronizer Operating Piston	21
	Pressure Test	21
	Troubleshooting	22
	Fault Codes and Fault Finding	22
	Dual Command Fault Code Display	23
	Fault Codes	26
	Clutch Spring Pressure Calibration Fault Codes	27
	Limp Home Feature	28
	Overhaul	29
	Dual Command Hi-Lo Transmission Housing	29
	Removal	29
	Installation	31
	Disassembly	32
	Assembly	42
	Adjustments - Internal Components	46
	Shuttle Gear Bearing Adjustment	46
	Range Input and Output Shaft Taper Bearing Adjustment	48
	Hi-Lo Control Valve	51
	Removal-Installation	51
	Speed and Range Control Assembly	54
	Removal	54
	Installation	55
	Disassembly	56
	Assembly	58

SECTION 21 - TRANSMISSION SYSTEMS

BOOK 2 - 87611240

Chapter 5 - Synchronized Mechanical Shuttle Transmission

CONTENT

Section	Description	Page
	Specifications	2
	Synchronized Mechanical Shuttle Transmission	2
	Creeper Gears	3
	Shuttle Gears	3
	Tightening Torques	4
	Special Tools	6
	Sectional Views	10
	Synchronized Mechanical Shuttle Transmission	10
	Description and Operation	14
	Troubleshooting	14
	Overhaul	15
	Synchronized Mechanical Shuttle Transmission Housing	15
	Removal	15
	Installation	17
	Disassembly of Speed and Range Gears	18
	Assembly of Speed and Range Gears	28
	Adjustments	31
	Disassembly of 5th Speed Gears	35
	Assembly of 5th Speed Gears	39
	Speed and Range Control Rail Assembly	40
	Removal	40
	Installation	41
	Creeper Gears	42
	Removal	42
	Installation	43
	Creeper External Control Lever	43
	Travel Adjustment	43

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**