
CX SERIES REPAIR MANUAL

COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	3
SECTION 14 - LIVE PTO	7
SECTION 21 - TRANSMISSION	9
SECTION 25 - FRONT MECHANICAL DRIVE	10
SECTION 29 - HYDROSTATIC SYSTEM	11
SECTION 33 - BRAKES AND CONTROL	14
SECTION 35 - HYDRAULIC SYSTEMS	14
SECTION 41 - STEERING AXLE	16
SECTION 50 - CLIMATE CONTROL	18
SECTION 55 - ELECTRICAL SYSTEMS	23
SECTION 60 - PRODUCT FEEDING	56
SECTION 66 - THRESHING	57
SECTION 72 - SEPARATION	58
SECTION 74 - CLEANING SYSTEMS	60
SECTION 80 - GRAIN STORAGE	62
SECTION 88 - ACCESSORIES	63
SECTION 90 - PLATFORM AND CAB	64

The following pages are the collation of the contents pages from each section and chapter of the CX Series Repair manual. Complete Repair part # 86630597.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the CX Series Combines.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 86978874

CONTENTS

Section	Description	Page
	Introduction	2
	Important information	2
	General instructions	3
	Shimming	3
	Rotating shaft seals	3
	O-ring seals	3
	Sealing compounds	3
	Cotter pins	3
	Spare parts	4
	Tools	4
	Safety regulations	5
	Accident prevention	5
	Safety rules	5
	General guidelines	5
	Start-up	7
	Hydraulic systems	7
	Wheels and Tyres	7
	Removal and Re-fitting	7
	Explanation of machine serial numbers	8
	Units of measure - Conversion chart	9
	Minimum hardware tightening torques	10
	Drives	12
	Main output shaft	14
	Unloading output shaft	16

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 1 - 7.5L New Holland Engine

CONTENTS

Section	Description	Page
10 000	Specifications	2
	Tightening Torques	10
	Special Tools	11
	Greases and Sealants	12
	Fault Finding	13
	Description and Operation	17
10 001	Engine Overhaul-Introduction	23
	Injection Pump Timing Check	24
10 100	Engine Disassembly and Overhaul:-	
10 101	Cylinder Head, Valves and Related parts	27
10 106	Front Cover and Timing Gears	38
10 102	Oil Pan	42
10 103	Flywheel	43
10 102	Rear cover plate	44
10 102	Oil pump	45
10 102	Oil Pressure Relief Valve	47
10 106	Camshaft, tappets and camshaft bearings	48
10 105	Pistons and Cylinder Block	51
10 103	Crankshaft	60
10 001	Engine compression test	69

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 2 - Cooling System

CONTENTS

Section	Description	Page
	Description and Operation	2
	Troubleshooting	4
	Specifications	5
	Disassembly and Repair	6

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 3 - Remove and Replace, 7.5L NH Engine

CONTENTS

Section	Description	Page
10 000	Engine	2
	Engine Removal	2
	Engine Installation	17

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 4 - Fuel System

CONTENTS

Section	Description	Page
10 000	Specifications	2
	Torques	2
	Special Tools	3
	Description and Operation	4
	Bosch P7100 Mechanically Controlled Fuel Injection System	6
	Bosch P7100 Electronically Controlled Fuel Injection System	12
	Fuel Injector Assemblies	17
10 200	Injection Pump Timing Check	19
	Adjustments and Diagnosis	22
	Low Idle and Antisurge	22
	Fuel Shutoff Diagnosis	22
	Maintenance	24
10 206	Fuel Prefilter and Water Separator	24
10 206	Fuel Filter and Water Separator	25
10 210	Fuel Lift Pump Sedimenter	25
	Bleeding the Fuel System	26
	Component Overhaul	27
10 242	Injection Pump	27
10 210	Fuel Lift Pump	31
	Fuel Shutoff Solenoid	32
10 218	Low Pressure Fuel Lines	33
10 218	High Pressure Fuel Lines	34
10 218	Fuel Injectors	36
	Injector Testing	39
	Injector Overhaul	39

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 5 - Iveco, Description of Operation

CONTENTS

Section	Description	Page
10 000	Walk Around	2
	The Iveco Engine	7
	Engine Block and Cylinder Liners	9
	Crankshaft	9
	Crankshaft Sealing Rings	10
	Connecting Rods	10
	Pistons	10
	Camshaft	11
	Timing System	11
	Flywheel	12
	Auxiliary Drivebelt	13
	Lubrication	14
	Oil Filter	15
	Oil Sump	16
	Cooling	16
	Electronically Controlled Injection System	17
	Pump Injector	18

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 6 - Remove and Replace, Iveco Engine

CONTENTS

Section	Description	Page
10 000	Engine	2

SECTION 10 - ENGINE

BOOK 1 - 86978874

Chapter 7 - IVECO Engine

Model	IVECO Engine
CX 860	F2BE0684A*B001
CX 880	F3AE0684D*B001

CONTENTS

Section	Description	Page
10 000	General specifications	2
	Fuel system data	6
	Torque settings	17
	Tools	29
	Lubrication diagram	32
	Fuel supply system diagram	33
	Mechanical troubleshooting	35
10 101 54	Engine. Disassembly-Assembly	38
10 101 53	Replacing Valve guides	114
10 101 60	Injector case. Replacement	115
10 102 70	Replacing the crankshaft front cover seal. Removal-Refitting	118
10 106 12	Adjusting clearance valve of intake exhaust rocker arms and pre-load of pump injector rocker arms	119
10 218 30	Pump injector. Removal-Refitting	120
10 246 14	Bleeding the fuel supply system	124
10 402 11	Water pump. Removal-Refitting	125
10 402 30	Thermostat. Removal-Refitting	125

SECTION 14 - LIVE PTO

BOOK 2 - 86978875

Chapter 1 - Engine Gearbox, Clutch Pack Removal/Installation

CONTENTS

Section	Description	Page
	Special Torque	2
	Labor Guide	2

SECTION 14 - LIVE PTO

BOOK 2 - 86978875

Chapter 2 - Engine Gearbox, Clutch Pack Rebuild

CONTENTS

Section	Description	Page
	Main Clutch Disassembly	2
	Main Clutch Assembly	6
	Unload Clutch Disassembly	12
	Unload Clutch Assembly	15

SECTION 14 - LIVE PTO

BOOK 2 - 86978875

Chapter 3 - Engine Gearbox Removal/Installation

CONTENTS

Section	Description	Page
	Gearbox	2
	Flexplate	21

SECTION 14 - LIVE PTO

BOOK 2 - 86978875

Chapter 4 - Engine Gearbox Rebuild

CONTENTS

Section	Description	Page
	Special Tool	2
	Gearbox Disassembly	3
	Inspection	9
	Bearing and Race Removal/Installation	11
	Clutch Cylinder Bushing Removal	11
	Clutch Cylinder Bushing Installation	12
	Gearbox Assembly	14

SECTION 21 - TRANSMISSION

BOOK 2 - 86978875

Chapter 1 - Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Gearbox shafts	3
	Shifting diagram	4
21 120	Traction gearbox - removal	5
21 145	Traction gearbox - disassembly	8
	Cover - Removal, Disassembly and assembly	9
	Differential shafts and differential - Removal	11
	Differential shaft - D/A	15
	Selector shaft - Removal	16
	Drive shaft - Removal	17
	Input shaft - Removal.	19
	Shifting disc and shifting drive gear - Removal	23
21 184	Differential - D./A.	28
21 145	Drive shaft - D./A.	33
21 145	Input shaft - D./A.	38
21 145	Traction gearbox - Assembly	43
	Shifting disc and shifting drive gear - Installation	43
	Input shaft - Installation	46
	Drive shaft - Installation	49
	Selector shaft - Installation	51
	Differential half shafts and differential - Installation	51
	Cover - Installation	53

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 86978875

Chapter 1 - Planetary Final Drives

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Gearbox shafts	3
25.000	Wheel bolt - Replacement	4
25.000	Planetary final drive - R./ I.	5
25.000	Planetary final drive - D./A.	7
	Planetary final drive - Disassembly	7
	Planet gear carrier - D./A.	10
	Sun gears - D./A.	13
	Output shaft - Assembly	15
	Input shaft - Assembly	17
	Planetary final drive - Assembly	18
	Input shaft - Installation	24

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 2 - 86978875

Chapter 2 - Standard Final Drives

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Gearbox shafts	3
	Wheel bolt - Replacement	4
	Final drive - R./ I.	5
	Final drive D./A.	7
	Disassembly	7
	Assembly	7

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 2 - 86978875

Chapter 1 - Hydrostatic Drive System Introduction

CONTENTS

Section	Description	Page
29 000	Specifications	2
	Special Tools	5
	Introduction	6
	Hydrostatic Drive Schematic For C720, 740 and 760 Machines	9
	Hydrostatic Drive Schematic For C780, 820, 840, 860 and 880 Machines	10
	Explanation of Hydraulic Symbols	12

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 2 - 86978875

Chapter 2 - Hydrostatic System Operation

CONTENTS

Section	Description	Page
29 000	Hydrostatic System Operation	2
	Multi Function Valves	8
	Servo Valve	12
	Hydrostatic Drive Motor Valves	14
	Oil Cooler Bypass Valve	16
	Hydrostatic Pump and Drive Motor Identification Numbers	17
	Hydrostatic Pump	19
	Hydrostatic Drive Motor	22

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 2 - 86978875

Chapter 3 - Filling the Hydrostatic System and Start-up Procedure

CONTENTS

Section	Description	Page
29 000	Filling the Hydrostatic System and Start-up Procedure	2

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 2 - 86978875

Chapter 4 - Powered Rear Axle

CONTENTS

Section	Description	Page
29 000	Powered Rear Axle (RWD) Introduction	2
	Equa-Trac II Control Valve	4
	Drain Valve	6
	Equa-Trac Valve - Off Position	10
	Equa-Trac Valve - Intermediate Position	12
	Equa-Trac Valve - On Position	14
	Powered Rear Axle Motors	19
	Powered Rear Axle Hydraulic Schematic	23

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 2 - 86978875

Chapter 5 - Pressure Testing and Troubleshooting

CONTENTS

Section	Description	Page
29 000	Specifications	2
	Main Hydrostatic System	3
	Pressure Testing	3
	Troubleshooting	7

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 2 - 86978875

Chapter 6 - Hydrostatic Pump and Motor Repair

CONTENTS

Section	Description	Page
29 212	Main Hydrostatic Pump Removal	2
29 212	Main Hydrostatic Pump Installation	3
29 212	Drive Motor Removal	4
29 212	Drive Motor Installation	6
	Series 90 Hydrostatic System - Minor Repairs	8
29 218	Multi-Function Valve Adjustment	8
29 218	Removing the Multi-Function Valve Cartridge	10
29 218	Installing the Multi-Function Valve	11
	Adjusting the Charge Pressure Relief Valve - Pump	11
29 218	Checking the Charge Pressure Relief Valve - Motor	12
	Removing the Charge Pressure Relief Valve - Pump	12
29 218	Installing the Charge Pressure Relief Valve - Pump	13
29 218	Replacing the Charge Pressure Relief Valve - Motor	14
	Removing the Control Valve	14
29 218	Inspecting the Control Valve	15
29 218	Installing the Control Valve	16
29 212	Removing the Charge Pump	17
29 212	Installing the Charge Pump	19
29 218	Removing the Loop Flushing Valve	21
29 218	Installing the Loop Flushing Valve	22
29 218	Removing the Shaft Seal	23
29 218	Installing the Shaft Seal	24
29 218	Removing the Shaft (Pump and Motor)	25
29 218	Installing the Shaft (Pump and Motor)	26
	Series 90 Hydrostatic System - Major Repairs	28

SECTION 33 - BRAKES AND CONTROL

BOOK 2 - 86978875

Chapter 1 - Brakes and Control

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Brake linings - Replacement	3
	Brake cylinders	5
	Bleeding the brakes	6
	Bleeding the left-hand side circuit	6
	Bleeding the connection pipe between the two main cylinders	7
	Bleeding the right-hand side circuit	7
	Brake shoe and brake disc - R./L.	8
	Parking brake shoe and parking brake disc - R./L.	11
	Parking brake - Manual release	13
	Parking brake piston travel and adjustment	14
	Parking brake linings - Replacement	17
	Bleeding the hydraulic parking brake cylinder	18
	Parking brake cylinder - D./A.	19

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 86978876

Chapter 1 - Introduction

CONTENTS

Section	Description	Page
35 000	Specifications	1
	Introduction	2
	High Pressure Circuit Diagram	4
	High Pressure System Component Locations	7
	High Pressure System Component Descriptions	8
	Low Pressure Circuit Diagram	19
	Low Pressure System Component Locations	21
	Low Pressure System Component Descriptions	22

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 86978876

Chapter 2

Closed Centre Load Sensing (CCLS) Variable Displacement Pump

CONTENTS

Section	Description	Page
35 000	Specifications	1
	Description and Operation	2

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 86978876

Chapter 3

Pressure Testing and Fault Finding The High and Low Pressure Hydraulic Systems

CONTENTS

Section	Description	Page
35 000	Introduction	1
	Special Tools	2
	Specifications	3
	CCLS Hydraulic Pump (High Pressure) Installation	3
	Fixed Displacement Hydraulic Pump (Low Pressure) Installation	3
	Fault Finding	4
Pressure and Flow Testing:		
	Low Pressure Standby	10
	High Pressure Standby	11
	Load Sensing Circuit Test	12
	Variable Flow Piston Pump Flow Test	13
	Steering Test	14
	Steering Circuit Pressure Test	14
	Steering Relief Valve Pressure Test	15
	Chaff Blower Motor Valve Pressure Test	15
	Low Pressure Test	15
	Low Pressure Pump Flow Test	16

SECTION 35 - HYDRAULICS

BOOK 3 - 86978876

Chapter 4 - Hydraulic Pump

CONTENTS

Section	Description	Page
	Special Torque	2
	Hydraulic Pump Overhaul	3

SECTION 35 - HYDRAULIC SYSTEMS

BOOK 3 - 86978876

Chapter 5 - Stack Valves Overhaul

CONTENTS

Section	Description	Page
	Main Stack Valve	2
	Feeder Stack Valve	10
	Low Pressure Valve Block	18

SECTION 41 - STEERING AXLE

BOOK 3 - 86978876

Chapter 1 - Axle, General

CONTENTS

Section	Description	Page
41 101	Heavy Duty Adjustable Steering Axle (HDASA)	2
41 101	Powered Rear Axle (PRA)	2
41 101	Steering Axle Adjustment	2
41 101	Powered Rear Axle Adjustment	2
	Height Position	8
	Track Width Position	9

SECTION 41 - STEERING AXLE

BOOK 3 - 86978876

Chapter 2 - Wheel Bearings (HDASA)

CONTENTS

Section	Description	Page
41 204	Wheel Bearing Disassembly	2
41 204	Wheel Bearing Repacking	3
41 204	Wheel Bearing Assembly	3

SECTION 41 - STEERING AXLE

BOOK 3 - 86978876

Chapter 3 - Steering Pivot (HDASA)

CONTENTS

Section	Description	Page
41 204	Hub Casting Disassembly	2
41 204	Steering Bushing Replacement	3
41 204	Hub Casting Assembly	5

SECTION 41 - STEERING AXLE

BOOK 3 - 86978876

Chapter 4 - Center Section

CONTENTS

Section	Description	Page
41 101	Center Section Adjustment / Repair	2

SECTION 41 - STEERING AXLE

BOOK 3 - 86978876

Chapter 5 - Powered Rear Steering Axle

CONTENTS

Section	Description	Page
41 000	Specifications	2
	Bolt Torque Specifications	2
	Special Tools	2
	Introduction and General Information	6
	Troubleshooting - Powered Rear Axle	8
	Powered Rear Axle Hydraulic Pressure Test	10
	Test Pressures vs. Machine Operation Mode	13
	Powered Rear Axle Leak Test	15
	Powered Rear Axle Solenoid Valve Testing	18
	Start-up Procedure for Powered Rear Axle	20
	Wheel Motor Maintenance Schedule	21
	Equa-Trac II Valve	23
	Wheel Motor	26
	Wheel Motor Overhaul	34

SECTION 50 - CLIMATE CONTROL

BOOK 3 - 86978876

Chapter 1 - A/C System

CONTENTS

Section	Description	Page
	Special Tools	2
	Special Torque	2
	A/C Cycle	4
	Refrigerant	8
	Testing and Troubleshooting, General	12
	Pressure / Temperature Relationships	14, 24
	Preliminary Troubleshooting and Testing	17
	Preliminary Diagnosis Chart	18
	Test Procedure - Stabilizing the System	19
	A/C System Performance Test and Diagnosis Chart	20
	Gauge Readings and Interpretations	25

SECTION 50 - CLIMATE CONTROL

BOOK 3 - 86978876

Chapter 2 - Air Filters

CONTENTS

Section	Description	Page
	Air Filter Description	2
	Fresh Air Intake Grill Cleaning	3
	Recirculation Air Filter Removal	3
	Recirculation Air Filter Installation	4
	Separator Filter Removal	4
	Separator Filter Installation	5

SECTION 50 - CLIMATE CONTROL

BOOK 3 - 86978876

Chapter 3 - Blower Fans

CONTENTS

Section	Description	Page
	Blower Fans Description	2
	Circulation Fan Removal	3
	Circulation Fan Installation	6
	Separator Fan Removal	9
	Separator Fan Installation	10
	Labor Guide	10

SECTION 50 - CLIMATE CONTROL

BOOK 3 - 86978876

Chapter 4 - Compressor

CONTENTS

Section	Description	Page
	Compressor Description	2
	Compressor Removal	2
	Compressor Installation	3
	Clutch Removal	3
	Clutch Installation	7
	Labor Guide	8

SECTION 50 - CLIMATE CONTROL

BOOK 3 - 86978876

Chapter 5 - Condenser

CONTENTS

Section	Description	Page
	Condenser Description	2
	Condenser Removal	2
	Condenser Installation	3
	Labor Guide	4

SECTION 50 - CLIMATE CONTROL

BOOK 3 - 86978876

Chapter 6 - Cool Box

CONTENTS

Section	Description	Page
	Cool Box Description	2
	Cool Box Damper Actuator Removal	2
	Cool Box Damper Actuator Installation	3
	Labor Guide	3

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**