
CR920, CR940, CR960, CR970 REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	4
SECTION 14 - LIVE PTO	13
SECTION 21 - TRANSMISSION	15
SECTION 25 - FRONT MECHANICAL DRIVE	16
SECTION 29 - HYDROSTATIC SYSTEM	19
SECTION 33 - BRAKES AND CONTROLS	25
SECTION 35 - HYDRAULIC SYSTEMS	26
SECTION 41 - STEERING AXLE	31
SECTION 50 - CLIMATE CONTROL	34
SECTION 55 - ELECTRICAL SYSTEMS	41
SECTION 60 - PRODUCT FEEDING	79
SECTION 66 - THRESHING	84
SECTION 72 - DISCHARGE BEATER	87
SECTION 74 - CLEANING SYSTEMS	87
SECTION 80 - GRAIN STORAGE	93
SECTION 88 - ACCESSORIES	95
SECTION 90 - PLATFORM, CAB, BODYWORK, DECALS	98

The following pages are the collation of the contents pages from each section and chapter of the CR920, CR940, CR960, and CR970 Repair manual. Complete Repair part # 87600552.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the CR920, CR940, CR960, and CR970 Combines.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87600553

Chapter 1 - General Information

CONTENTS

Section	Description	Page
	Foreword	3
	About Improvements	3
	Part and Accessories	3
	Precautionary Statements	4
	Personal Safety	4
	Machine Safety	4
	Information	4
	Safety Precautions	4
	Personal Considerations	4
	Equipment Considerations	5
	General Considerations	6
	Operational Considerations	6
	Health and Safety Precautions	7
	Acids and Alkalis	7
	Adhesives and Sealers	7
	Antifreeze	8
	Battery Acids	8
	Brake and Clutch Linings and Pads	8
	Brazing	8
	Chemical Materials - General	8
	Clutch Linings and Pads	9
	Corrosion Protection Materials	9
	Cutting	9
	Dewaxing	9
	Do's	9
	Don'ts	9
	Dusts	9
	Electric Shock	9
	Exhaust Fumes	10
	Fiber Insulation	10
	Fire	10
	First Aid	10
	Foams- Polyurethane	10
	Fuels	10

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87600553

Chapter 1 - General Information (Continued)

CONTENTS

Section	Description	Page
	Gas Cylinders	11
	Gases	11
	Gas Shielding Welding	11
	Gas Welding	11
	General Workshop Tools and Equipment	11
	Glues	12
	High-pressure Air, Lubrication and Oil Test Equipment	12
	Legal Aspects	12
	Lubricants and Greases	12
	Noise Insulation Material	12
	Paints	12
	Paint Thinners	12
	Pressurized Equipment	12
	Resistance Welding	12
	Sealers	12
	Solder	12
	Welding	12
	Service Techniques	13
	General	13
	Hoses and Tubes	13
	Product Identification	14
	Base Unit	14
	Engine	14
	Straw Chopper (If Equipped)	16
	Powered Rear Axle Wheel Motors (If Equipped)	16
	Minimum Hardware Tightening Torques	17
	Recommended Lubricants And Coolants (North America Only)	21

SECTION 10 - ENGINE

BOOK 1 - 87600553

Chapter 1 - 7.5L Engine Block

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	9
	Special Tools	10
	Troubleshooting	12
	Description and Operation	16
	Overhaul	23
	Introduction	23
	Injection Pump	24
	Timing	24
	Cylinder Head	28
	Removal	28
	Disassembly	32
	Inspection and Repair	33
	Assembly	37
	Engine Front Cover and Timing Gears	41
	Timing Gears Checking and Removal	41
	Gears - Inspection and Repair	44
	Installation	44
	Oil Pan	46
	Removal	46
	Inspection and Repair	46
	Installation	46
	Flywheel	47
	Removal	47
	Inspection and Repair	48
	Installation	48
	Rear Cover Plate	49
	Removal	49
	Installation	49
	Oil Pump	51
	Removal	51
	Disassembly	51
	Inspection and Repair	52
	Installation	52

SECTION 10 - ENGINE

BOOK 1 - 87600553

Chapter 1 - 7.5L Engine Block (Continued)

CONTENTS

Section	Description	Page
	Oil Pressure Relief Valve	53
	Removal	53
	Installation	53
	Camshaft	54
	Removal	54
	Inspection and Repair	54
	Camshaft Bearings	55
	Installation	55
	Pistons	57
	Removal	57
	Inspection and Repair	58
	Connecting Rod Bush Replacement	59
	Cylinder Block Overhaul	61
	Cylinder Bore	62
	Specifications	62
	Sleeving - Boring and Honing	63
	Reassembly	64
	Installing Piston Assembly Into Block	66
	Crankshaft	67
	Removal	67
	Inspection and Repair	68
	Reassembly	69
	Front Crankshaft Cassette Oil Seal Replacement	72
	Removal	72
	Installation	74
	Engine Compression Test	78
	Test Procedure	78
	Test Readings	78
	Test Conclusion	78

SECTION 10 - ENGINE

BOOK 1 - 87600553

Chapter 2 - 7.5L Cooling

CONTENTS

Section	Description	Page
	Description and Operation	2
	Troubleshooting	4
	Specifications	5
	Overhaul	6
	Thermostat	6
	Removal	6
	Inspection and Repair	6
	Installation	6
	Fan Belt Tensioner	7
	Removal	7
	Inspection and Repair	7
	Reassembly	7
	Idler Pulley	8
	Water Pump	8
	Removal	8
	Disassembly and Repair	9
	Inspection and Repair	10
	Assembly	10
	Installation	12

SECTION 10 - ENGINE

BOOK 1 - 87600553

Chapter 3 - 7.5L Complete Engine, Remove and Replace

CONTENTS

Section	Description	Page
	Overhaul	2
	Engine	2
	Removal	2
	Installation	17

SECTION 10 - ENGINE

BOOK 1 - 87600553

Chapter 4 - 7.5L Fuel System

CONTENTS

Section	Description	Page
	Specifications	3
	Tightening Torques	3
	Special Tools	4
	Description and Operation	5
	General	5
	Bosch P7100 Mechanically Controlled Fuel Injection System	7
	Bosch P7100 Electronically Controlled Fuel Injection System	13
	Fuel Injector Assemblies	18
	Overhaul	20
	Injection Pump	20
	Timing Check	20
	Set Low Idle and Anti-Surge	24
	Fuel Shutoff Diagnosis	24
	Fuel Prefilter/Water Separator	26
	Replace	26
	Fuel Filter/Water Separator	27
	Replace	27

SECTION 10 - ENGINE

BOOK 1 - 87600553

Chapter 4 - 7.5L Fuel System (Continued)

CONTENTS

Section	Description	Page
	Supply Pump Sedimenter	27
	Inspect	27
	Fuel System	28
	Bleeding	28
	Injection Pump	29
	Removal	29
	Installation	31
	Fuel Lift Pump	34
	Removal	34
	Installation	34
	Fuel Shutoff Solenoid	35
	Removal	35
	Installation	35
	Low Pressure Fuel Injection Lines	36
	Removal	36
	Installation	36
	High Pressure Fuel Injection Lines	37
	Removal	37
	Installation	37
	Fuel Injectors	39
	Removal	39
	Testing	40
	Disassembly	42
	Inspection and Repair	42
	Assembly	44
	Installation	45

SECTION 10 - ENGINE

BOOK 2 - 87600554

Chapter 5 - 7.8L, 10.3L Description of Operation

CONTENTS

Section	Description	Page
	Walk Around	2
	Engine Block and Cylinder Liners	9
	Crankshaft	9
	Crankshaft Sealing Rings	10
	Connecting Rods	10
	Pistons	10
	Camshaft	11
	Timing System	11
	Flywheel	12
	Auxiliary Drive Belt	13
	Lubrication	14
	Oil Filter	15
	Oil Sump	16
	Cooling	16
	Electronically Controlled Injection System	17
	Pump Injector	18

SECTION 10 - ENGINE

BOOK 2 - 87600554

Chapter 6 - 7.8L, 10.3L Complete Engine, Remove and Replace

CONTENTS

Section	Description	Page
	Overhaul	2
	Engine	2
	Removal	2
	Installation	15

SECTION 10 - ENGINE

BOOK 2 - 87600554

Chapter 7 - 7.8L, 10.3L Engine Block

<i>Model</i>	<i>Engine</i>	<i>Size</i>
CR 960	F2BE0684A*B001	7.8L
CR 970	F3AE0684D*B001	10.3L

CONTENTS

Section	Description	Page
	Specifications	3
	General	3
	Lubrication	5
	Cooling System	5
	Rev Counter	5
	Timing System	6
	Fuel System	7
	Crank Gear and Cylinder Data	8
	Cylinder Head - Timing System	13
	Torque Settings	17
	Engine F2B	17
	Engine F3A	22
	Plan of Tightening Sequence of Screws Securing Sub-Crankcase	27
	Special Tools	30
	System Diagrams	33
	Mechanical Troubleshooting	36
	Overhaul	39
	Engine	39
	Assembly and Disassembly	39
	Assembling Crankshaft With Main Bearing Caps, Thrust Bearings and Rings, Crankshaft End Float	50
	Assembling Pistons With Piston Rings, Pins, Connecting Rods, Connecting Rod Caps and Bearings - Checking Protrusion Over the Top Face of the Crankcase	53
	Fitting and Tightening the Cylinder Head	55
	Fitting Oil Pump, Timing System Intermediate Gears and Gear Box	56
	Engine Flywheel Assembly	58
	Fitting Camshaft	59
	Fitting Injectors - Pump	60

SECTION 10 - ENGINE

BOOK 2 - 87600554

Chapter 7 - 7.8L, 10.3L Engine Block (Continued)

CONTENTS

Section	Description	Page
	Fitting Rocker Arm Shaft	60
	Completing the Engine	64
	Assembly Diagram For Fan Drive Belt - Water Pump - Alternator For F2B Engine ..	67
	Assembly Diagram For Fan Drive Belt - Water Pump - Alternator For F3A Engine ..	68
	Checks, Measurements and Repairs on the Crankcase, Cylinder Liners	69
	Checks, Measurements and Repairs on the Crankshaft, Bearings	72
	Selecting Main and Big End Bearing Shells	76
	Preliminary Appraisal of Data to Make the Selection	77
	Checks, Measurements and Repairs on the Pistons	86
	Checks, Measurements and Repairs on the Connecting Rods	89
	Piston Connecting Rod Assembly	92
	Checks, Measurements and Repairs on the Cylinder Head	95
	Valve Seats On The Head	98
	Checks, Measurements and Repairs on the Tappets And Camshaft	99
	Checks, Measurements and Repairs on the Valve Springs, Rocker Arm Shaft and Rocker Arms	103
	Rocker Arms	106
	Checks, Measurements and Repairs on the Lubrication System	106
	Cooling	111
	Checks, Measurements and Repairs on the Cooling Circuit	111
	Fuel Supply	113
	Valve Guides	115
	Injector Case	116
	Replacing the Crankshaft Front Cover Seal	119
	Adjusting Clearance Valve of Intake Exhaust Rocker Arms and Pre-Load of Pump Injector Rocker Arms	120
	Pump Injector - Removal and Refitting	121
	Bleeding the Fuel Supply System	125
	Water Pump	126
	Thermostat	126

SECTION 10 - ENGINE

BOOK 2 - 87600554

Chapter 8 - Common Engine Compartment Components

CONTENTS

Section	Description	Page
	Overhaul	2
	Cooling Fan Drive	2
	Removal	2
	Disassembly	4
	Inspection	5
	Assembly	5
	Installation	7
	Radiator Unit	9
	Removal	9
	Disassembly	15
	Inspection	16
	Assembly	17
	Installation	18
	Rotary Screen	23
	Removal	23
	Disassembly	24
	Inspection	25
	Assembly	26
	Installation	28
	Rotary Screen Drive Shaft	29
	Removal	29
	Installation	31
	Rotary Screen Seal	33
	Replacement	33
	Rotary Screen Brush	34
	Removal	34
	Installation	35
	Rotary Screen Brush Actuator	37
	Removal	37
	Installation	38

SECTION 14 - LIVE PTO

BOOK 3 - 87600555

Chapter 1 - Engine Gearbox, Clutch Pack Removal/Installation

CONTENTS

Section	Description	Page
	Special Torque	2
	Special Tool	2
	General	3
	Labor Guide	3
	Overhaul	4
	Clutch Pack	4
	Removal	4
	Installation	11

SECTION 14 - LIVE PTO

BOOK 3 - 87600555

Chapter 2 - Engine Gearbox, Clutch Pack Rebuild

CONTENTS

Section	Description	Page
	Overhaul	2
	Main Clutch	2
	Disassembly	2
	Assembly	6
	Unload Clutch	12
	Disassembly	12
	Assembly	15

SECTION 14 - LIVE PTO

BOOK 3 - 87600555

Chapter 3 - Engine Gearbox Removal/Installation

CONTENTS

Section	Description	Page
	Gearbox	2
	Removal	2
	Installation	12
	Flexplate	21
	Removal	21
	Installation	23

SECTION 14 - LIVE PTO

BOOK 3 - 87600555

Chapter 4 - Engine Gearbox Rebuild

CONTENTS

Section	Description	Page
	Overhaul	2
	Gearbox	2
	Disassembly	2
	Inspection	8
	Component Repair - Bearing and Race Removal/Installation	10
	Component Repair - Clutch Cylinder Bushing Removal/Installation	10
	Assembly	13

SECTION 21 - TRANSMISSION

BOOK 3 - 87600555

Chapter 1 - Transmission

CONTENTS

Section	Description	Page
	Specifications	2
	Tightening Torques	2
	Special Tools	3
	Sectional/Exploded Views	4
	Transmission Cover (Exploded View)	4
	Gearbox Shafts (Sectional View)	5
	Shifting Diagram (Sectional View)	6
	Shifting Disc/Drive Gear (Sectional View)	7
	Shifting Disc/Drive Gear (Exploded View)	8
	Differential (Sectional View)	9
	Differential (Exploded View)	10
	Differential Shafts (Exploded View)	11
	Drive Shaft/Cover (Exploded View)	12
	Drive Shaft (Sectional View)	13
	Drive Shaft (Exploded View)	14
	Input Shaft and Bearing Caps (Exploded View)	15
	Input Shaft (Sectional View)	16
	Input Shaft (Exploded View)	17
	Overhaul	18
	Transmission	18
	Removal	18
	Disassembly	22
	Assembly	38
	Installation	52
	Differential	57
	Disassembly	57
	Assembly	59
	Drive Shaft	60
	Disassembly	60
	Assembly	63
	Input Shaft	65
	Disassembly	65
	Assembly	66

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 3 - 87600555

Chapter 1 - Planetary Final Drive

CONTENTS

Section	Description	Page
	General Specification – Final Drive	3
	Specifications	3
	Type I and Type II Final Drive Identification	3
	Final Drive – Torque	4
	Final Drive – Special tools	5
	Overview	6
	Final Drive – Sectional View	6
	Final Drive – Exploded View	8
	Final Drive Reducer, Spur Gear – Sectional View	10
	Final Drive Reducer, Spur Gear – Exploded View	10
	Final Drive Input Shaft – Exploded View	11
	Final Drive Input Shaft – Overview	12
	Final Drive Reducer, Satellite and Planetary – Exploded View	13
	Overhaul – Type I Final Drive	14
	Removal	14
	Disassembly	15
	Assembly	19
	Installation	28
	Final Drive Reducer, Spur Gear	29
	Disassembly	29
	Assembly	29
	Final Drive Input Shaft	32
	Disassembly	32
	Assembly	33
	Final Drive Output Shaft	34
	Disassembly	34
	Assembly	35
	Final Drive Reducer, Satellite and Planetary	37
	Disassembly	37
	Assembly	38

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 3 - 87600555

Chapter 1 - Planetary Final Drive (Continued)

CONTENTS

Section	Description	Page
	Final Drive Wheel Stud	41
	Replacement	41
	Overhaul - Type II Final Drive	42
	Removal	42
	Disassembly	43
	Assembly	49
	Distance Ring Combinations Table	50
	Installation	59
	Final Drive Input Shaft	60
	Disassembly	60
	Assembly	61
	Final Drive Output Shaft	62
	Disassembly	62
	Assembly	63
	Final Drive Reducer, Satellite and Planetary	65
	Disassembly	65
	Assembly	66
	Final Drive Wheel Stud	69
	Replacement	69
	Half-shaft	70
	Removal	70
	Installation	71

SECTION 25 - FRONT MECHANICAL DRIVE

BOOK 3 - 87600555

Chapter 2 - 11/111 Final Drives

CONTENTS

Section	Description	Page
25 000	Specifications	2
	Tightening Torques	2
	Special Tools	2
	Overview	3
	Final Drive (Standard Seal) - Sectional View	3
	Final Drive (Mud Seal) - Sectional View	4
	Overhaul	5
	Wheel Bolt	5
	Replacement	5
	Final Drive	6
	Removal	6
	Disassembly	7
	Inspection	9
	Assembly	10
	Installation	16

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 4 - 87600556

Chapter 1 - Hydrostatic Drive System Introduction

CONTENTS

Section	Description	Page
	Specifications	2
	Hydrostatic Oil	2
	Hydrostatic Pump (CR920, 940 and 960 Machines W/Hd 11/111 Final Drives)	2
	Hydrostatic Pump (CR940 and 960 Machines W/Planetary Final Drives)	3
	Hydrostatic Pump (CR970 and 980 Machines)	3
	Hydrostatic Drive Motor (CR920, 940 and 960 Machines W/Hd 11/111 Final Drives)	3
	Hydrostatic Drive Motor (CR940 And 960 Machines W/Planetary Final Drives; CR970 and 980 Machines)	4
	Oil Cooler Bypass Valve	4
	Introduction	5
	Oil Reservoir	5
	Hydrostatic Pump	5
	Hydrostatic Brake (External Block)	5
	Hydrostatic Brake (Integrated)	6
	Hydrostatic Drive Motor	6
	Powered Rear Axle (PRA) (Optional)	7
	Hydrostatic Drive Schematic	8
	Explanation of Hydraulic Symbols	11

SECTION 29 - HYDROSTATIC SYSTEM

BOOK 4 - 87600556

Chapter 2 - Hydrostatic System Operation

CONTENTS

Section	Description	Page
	Description of Operation	2
	Hydrostatic System	2
	Neutral	2
	Forward	2
	Schematic Circuit for CR920, 940, 960, 970 and 980 Machines	3
	Hydrostatic Block Operation (External Block)	4
	Hydrostatic Block Operation (Integrated Brake)	5
	Reverse	5
	Schematic Circuit for CR920, 940, 960, 970 and 980 Machines	6
	Gear Changing	10
	Temperature Control	10
	Schematic Circuit for CR920, 940, 960, 970 and 980 Machines	11
	Multi Function Valves	12
	Charge Check Valve 8a - 9a	14
	Pressure Limiter 8b - 9b	14
	High Pressure Relief Valve 8c - 9c	14
	Bypass Valve 8d - 9d	15
	Servo Valve	16
	System in Neutral	16
	Servo Solenoid Valve 10a Energized	16
	Hydrostatic Drive Motor Valves	18
	Shuttle Spool Valve	18
	Flushing Relief Valve	18
	Pressure Release Valve Circuit	18
	Oil Cooler bypass Valve	20
	Hydrostatic Pump and Drive motor Identification Numbers	21
	Hydrostatic Pump	23
	Variable Displacement Pump	23
	Pump Characteristics	24
	Hydrostatic Drive Motor	26
	Fixed Displacement Motors	26
	Drive Motor Characteristics	28

**Thanks very much for your reading,
Want to get more information,
Please click here, Then get the complete
manual**

JustClickHere 

NOTE:

**If there is no response to click on the link above,
please download the PDF document first, and then
click on it.**

**Have any questions please write to me:
admin@servicemanualperfect.com**